

# Workshop Service Manual

**ECHO**

**TRACTORS**

**350 AND 460 MODELS**



# DAVID MCNEILL

## SECTION 1:

## GENERAL INFORMATION

### CONTENTS

	PAGE
Description	1
Specification	2
Pre-delivery Inspection	3
Maintenance	4



**IDENTIFICATION**

The identification of the 2200 350 and 400 tractors is provided by the unit serial number and the engine serial number.



Fig. 1 -- Unit serial number

**Unit Serial number (Fig. 1)**

In tractoress it is stamped on the edge of the left side of the rear axle cover, adjacent to the hub.

**8TXL97498**

**Engine Serial number (Fig. 2)**

The 3.080 engine of Model 350 has the engine serial number stamped usually in the upper middle part of the left side of the block.

**152ME  
2125ODL**



Fig. 2 -- Engine serial number of Model 350

**Engine Serial number (Fig. 3)**

The 4.080 engine of the Model 400 has the engine serial number stamped in the upper-left part of the left cylinder head.



Fig. 3 -- Engine serial number of Model 400

**NOTE:** -- When making any inquiry, state or request for information with respect to other tractoress

models, always state the model, serial numbers and engine numbers.

**Main locations of the instruments and controls**

In Figure 4 the different instruments and controls used on both models are shown.




Fig. 4 - Instruments and controls

1 - Temperature gauge	6 - Indicator light/taillight passenger door open
2 - Tachometer	7 - License plate
3 - Fuel gauge	8 - Auxiliary fuel tank control lever
4 - Throttle control lever	9 - Gear shift lever
5 - Battery charge control light	10 - Dashboard light
6 - Headlight switch	11 - Steering column lever
7 - Horn button	12 - Engine oil OUT warning
8 - Front wheel anti lock	13 - Oil pressure warning light
9 - Right turn signal	
10 - Left turn signal	

**SPECIFICATIONS**

The specifications of the different sections, which have not been included in their corresponding group, are set out below:

**Gear box**

## — Gear ratios:

$$1st \quad \frac{18}{33} \times \frac{18}{30} \times \frac{12}{20} = 8.26:1$$

$$2nd \quad \frac{18}{33} \times \frac{18}{30} \times \frac{17}{20} = 8.93:1$$

$$3rd \quad \frac{18}{33} \times \frac{18}{30} \times \frac{22}{21} = 9.83:1$$

$$4th \quad \frac{18}{33} \times \frac{18}{30} \times \frac{25}{19} = 10.64:1$$

$$5th \quad \frac{18}{33} = 2.38:1$$

$$6th \quad \frac{17}{33} = 1.02:1$$

$$7th \quad \frac{12}{33} = 0.36:1$$

$$8th \quad \frac{20}{33} = 0.60:1$$

$$\text{Low reverse } \frac{18}{33} \times \frac{18}{30} \times \frac{25}{20} = 8.98:1$$

$$\text{High reverse } \frac{18}{33} = 2.13:1$$




Fig. 9 - Transmission diagram.

**Gear sets**

- Differential reduction 4.6:1 (13 pinion teeth - 46 sunwheel teeth)
- Pinion/sunwheel reduction 7.088:1 (17 pinion teeth - 101 sunwheel teeth)
- Total rear gear reduction 33.31:1

**Power take-off**

— Position	Front
— Dimensions	94.5 mm in diameter
— Number of splines	8 (conforming to ISO recommendation)
— Height above the ground	
Model 380	850 mm
Model 480	740 mm
— Distance to the tractor's center axis from plane	8 mm
— Direction of rotation	To the right
— Reduction	$\frac{14}{41} \times \frac{20}{28} = 4.1 : 1$
— Speed	9440 rpm. at 2000 rpm. of the engine



**Weights of the tractor in operating conditions  
(without the cab and with tool bar, full)**

— Without toolbar	
Model 380:	
Over the front axle	700 kg
Over the rear axle	1,200 kg
Total weight	1,900 kg
Model 480:	
Over the front axle	700 kg
Over the rear axle	1,300 kg
Total weight	2,100 kg

— With tool bar (empty and loaded)	
Weights	
Model 380:	
Over the front axle	1,000 kg
Over the rear axle	1,400 kg
Total weight	2,500 kg
Model 480:	
Over the front axle	1,000 kg
Over the rear axle	1,300 kg
Total weight	2,300 kg

— Model 480	
Weights	
Over the front axle	1,000 kg
Over the rear axle	1,300 kg
Total weight	2,300 kg

Wirtschaftsmathematik	Wirtschaftsmathematik	Wirtschaftsmathematik	Wirtschaftsmathematik
Wirtschaftsmathematik	Wirtschaftsmathematik	Wirtschaftsmathematik	Wirtschaftsmathematik
Wirtschaftsmathematik	Wirtschaftsmathematik	Wirtschaftsmathematik	Wirtschaftsmathematik
Wirtschaftsmathematik	Wirtschaftsmathematik	Wirtschaftsmathematik	Wirtschaftsmathematik
Wirtschaftsmathematik	Wirtschaftsmathematik	Wirtschaftsmathematik	Wirtschaftsmathematik



Wirtschaftsmathematik	Wirtschaftsmathematik	Wirtschaftsmathematik	Wirtschaftsmathematik
Wirtschaftsmathematik	Wirtschaftsmathematik	Wirtschaftsmathematik	Wirtschaftsmathematik
Wirtschaftsmathematik	Wirtschaftsmathematik	Wirtschaftsmathematik	Wirtschaftsmathematik
Wirtschaftsmathematik	Wirtschaftsmathematik	Wirtschaftsmathematik	Wirtschaftsmathematik
Wirtschaftsmathematik	Wirtschaftsmathematik	Wirtschaftsmathematik	Wirtschaftsmathematik

**Capacities**

Fuel tank	300 liters
Cooler	
Model 380	6.0 liters
Model 480	6.25 liters
Oil filter	0.8 liter
Engine cooling system	
Model 380	10.5 liters
Model 480	12.5 liters
Air cleaner	1.0 liter
Steering box	1.0 liter
Gear box, main axle and hydraulic oil	30.0 liters

**LUBRICATION**

The quality of the lubricant to be used for each part is indicated in the lubrication schedule. By using only good-quality lubricants, the tractor will be maintained in perfect working order.

**APPROVED LUBRICANTS - ALL TERRITORIES**

ITEM	GRADE TYPE - - -	GENERAL	S-1	10W-30	S-10W	MONO	S-10W	MONO	MONO
LUBRICANT	SAE 10W-30	S-10W-30	-10000*	-10700	-10700*	-10700	-10700*	-10700	-10700
	SAE 10W-40		-10700*	-10700	-10700*	-10700	-10700*	-10700	-10700
	SAE 10W-50		-10700*	-10700	-10700*	-10700	-10700*	-10700	-10700
TRANS.	SAE 80W-90		MONO -10W-30	-10700	-10700	-10700	-10700	-10700	-10700
GEAR OIL	SAE 80W-90		-10700*	-10700	-10700*	-10700	-10700*	-10700	-10700
	SAE 10W-30		-10700*	-10700	-10700*	-10700	-10700*	-10700	-10700
HYDRAULIC	SAE 10W-30		MONO -10W-30	-10700	-10700	-10700	-10700	-10700	-10700
STEERING	SAE 10W-30		-10700*	-10700	-10700*	-10700	-10700*	-10700	-10700
	SAE 10W-40		-10700*	-10700	-10700*	-10700	-10700*	-10700	-10700

\*Breakthrough and change.

**PRE-DELIVERY INSPECTION**

Before delivering the tractor to the customer, the pre-delivery inspection described as follows shall be carried out:

- Check engine oil level.
- Check oil level of the gear box, rear axle and hydrostatics.
- Check steering fluid oil level.
- Check radiator water level (add antifreeze if necessary).
- Check oil reservoir oil level and hydraulic assembly.
- Check tension of the fan/balanced belt.
- Check electrolyte level of the battery.
- Check operation of the engine control switch and cold-starting.
- Check operation of the controls and transmission panel.
- Check tire and full visibility signs, without engine heat.
- Check operation of the clutch, free travel and maximum engagement thrust.
- Check operation of the power take-off.
- Check free travel of the brake and parking brake pedals.
- Please check basic and three point linkage in working position.
- Check electrical connection and condition of wiring.
- Tighten up nuts and bolts in general.
- Check operation of the hydrostatic lift.
- Check tightness of wheel hub and air pressure of the tires.
- Start up tractor and observe its behavior, checking the following:
  - (i) Operation of the gears
  - (ii) Operation of the drives
  - (iii) Operation of the brakes and uniformity of braking
  - (iv) Operation of differential locking
  - (v) Operation of the steering

**Maintenance**

The good running of the tractor depends on its maintenance. In this chapter all the necessary information is given for performing the maintenance

operations on the different components at the proper time.

**Maintenance schedule****General checks & fly**

- Check the sensitivity position of the air cleaner.

**Every 10 hours or daily**

- Check engine transmission oil level.
- Check radiator water level.
- Check transmission oil at the fuel filter.

- Clean the air cleaner (in normal conditions).
- Check the tank soon after changing a wheel.

**Every 50 hours or weekly**

- Clean the air cleaner (in normal conditions).
- Check oil level of the gear box, rear axle and hydraulic oil.
- Check electrolyte level of the battery.
- Remove impurities from the fuel sediment cap.
- Cleaned lubrication in the following units:
  - a) Front axle gear pin.

- b) Brake and clutch pedal shaft.
- c) Kingpin bolts.
- d) Drag link.
- e) Both joints of the steering track rod to the steering arm.
- f) Leveling legs.

**Every 100 hours or monthly**

- Test torque efficiency and free travel of the pedals.
- Test clutch pedal free travel.
- Check or adjust alternator belt tension.
- Check tightness of wheel nuts.

- Check or clean and grease front wheel axle spindle bearings.
- Check and oil accelerator and cut-out lamp connection.

**Every 250 hours**

- Change correctness of air engine filter.
- Check steering box oil level.
- Clean the outside of the radiator honeycombs.

- Clean the box (in place).
- Tighten up nuts and bolts in general.

**Every 500 hours**

- Change fuel filter.
- Open and test injectors.
- Tighten up cylinder head and manifolds.
- Test and adjust the model data and clean the engine air breathing tube.

- Clean the cooling radiator material.
- Clean the rear brake master.
- Test the adjustment of the steering linkage.

**Service 1000 hours:**

- Change the oil/coolant mix, gearbox and rear axle oil.
- Clean the hydraulic system filters.

The maintenance operations listed here involve regular:

**STEEL, SHEET METAL, AND BODY (Section 2)**

- Always keep body parts clean and repaint them as soon as they become damaged or sensitized to salt.

**FRONT AXLE AND STEERING MECH (Section 3)**

- Grease the axle pin (Fig. 7).
- Grease king pin bolt (Fig. 8).
- Grease the drag links.
- Grease ball joints of steering knick and tie steering arms (Fig. 9).



Fig. 7



Fig. 8

which are grouped together in each section), after 30 hours.

- Inspect and clean the fuel tank.
- Check the alternator and starter motor.

should test and reapply the paint appearance of the body.

- Check or replace and grease the wheel spindle bearings (Fig. 10).
- Test the adjustment of steering linkage.
- Check steering box oil level (Fig. 11).



Fig. 8



Fig. 9

**ENGINE Function II**

- Check carburetor air level (Fig. 11).
- Change air濶ous of 150, 10° diagonal (Fig. 12) filter and the angle filter.
- Relighten cylinder head and manifold.
- Check and clean the intake air tank (Fig. 13).



Fig. 11



Fig. 12

The adjustment of the rocker arm lash when done with a feeler gauge, is 0.30 mm for both valves. While the angle valve is 0.25 mm for both intake and exhaust.

- Clean the engine air breathing holes.



Fig. 13



Fig. 14

**FUEL FEED SYSTEM (Section II)**

- Clean the oil cleaner filter (Fig. 15).
- Check the fuel filter and fuel oil (Fig. 16).
- Clean the air cleaner.
- Remove deposits from the fuel line sections (Fig. 17).

- Clean and oil the accelerator and carburetor lever (Fig. 18).
- Change the fuel filter cleaner.
- Clean and test the pump.
- Clean and pour the fuel tank.



Fig. 10



Fig. 11

**COOLING SYSTEM (checklist 6)**

- Check coolant water level.
- Clean the outside of the radiator grille (Fig. 16).



Fig. 12



Fig. 13



Fig. 14

- Flush out the cooling system (Fig. 15) (note: drain plug for the Model 460 has plug is located behind the master cylinder (Fig. 25) (drain plug).



Fig. 15

**CLUTCH (Section 1)**

- Grease clutch bell clutch pedal shaft (Fig. 26).
- Lubricate clutch pedal free travel.

**GEARBOX (Section 2)**

- Check the oil level of the gearbox, rear side and R9 (Fig. 27). This oil should come up to the level of the check hole situated on the right side face of the gearbox, between the two ribs.
- Change the gearbox, rear side and R1 oil (Fig. 23) through bolt (Fig. 23) filling hole.



Fig. 26



Fig. 23



Fig. 27



Fig. 28

**HYDRAULIC SYSTEM (Section 3)**

- Check the oil level of the R9, rear side and gearbox (Fig. 29).
- Change R9, rear side and gearbox oil (Figs. 22 and 23).
- Grease the levelling lever (Fig. 26).
- Grease oil lines (Figs. 28 and 30).
- Clean the two R9 lines (Figs. 26 and 30). These lines filters can be back-flushed with clean gear oil and cleaned with air.



Fig. 26



Fig. 27



Fig. 28



Fig. 29

**REAR AXLE (Section 10)**

- Check at least one of the rear axle gearboxes and fit (Fig. 21).
- Clean rear axle bearing housing above the oil seal (Fig. 22).

— Change the rear axle gearbox and fit of Figs. 21 and 22.

**BRACKETS (Section 11)**

- Trace the broken or cracked propell-shaft (Fig. 23).
- Test brake efficiency and pedal travel.

**WHEELS AND TIRES (Section 12)**

- After a wheel change, test the wheel bolts.
- Check the tightness of the wheel nuts.
- Test the tire pressure.

**ELECTRICAL EQUIPMENT AND INSTRUMENTS**

(Section 1B)

- Check battery electrolyte level.
- Check or adjust alternator drive belt tension (Fig. 1B).
- Inspect alternator and motor brush.



Fig. 1B

## SECTION 2:

# SEAT SHEET METAL AND BODY

000419999

PAGE

Seat	1
Specifications	1
Description	1
Removing and installing the seat	1
Dismantling and assembly of the operator's seat	2
Bucket-mounted seat	4
Sheet metal and bodywork	5
Specifications	5
Description	5
Removing and installing the front grille	7
Removing and installing the hood	7
Removing and installing saddle saddle	7
Removing and installing the frontview panel	10
Removing and installing the fenders	10
Removing and installing the step plates	11



Production SP-1929-0XP-1  
1st Edition 1-79

## SEAT

## SPECIFICATIONS

Type of seat  
Suspension  
Type of shock absorber

SWING 3800/38  
Hydraulic springs.  
Concentric shock absorber

## DESCRIPTION (figs. 1 and 2)

The seat is designed to permit comfort and reduce fatigue of the operator, thereby increasing his work performance. The seat combining is of plastic resin. The height of the seat back can be adjusted by the wing nuts (A). Control 203 enables the position of the springs to be regulated (C), in accordance with the driver's weight and the irregularities of the ground. The shock absorber (B) softens the return of the springs (C), eliminating any jolts and harshness of the suspension. It is for the operator to have the pedals and other controls at a distance most in keeping with his own personal status; the seat is also adjustable laterally. For this purpose, the bolts (D) of the side plates attached to the left frame are strengthened. Loosen and tighten the set screws once the seat has been set in the most comfortable position.



FIG. 1 - SEAT



FIG. 2 - Lowering of the seat

## TO REMOVE AND INSTALL THE SEAT

To remove the front seat, proceed as follows:

- Loosen the two jolts and the lock nut (F, fig. 2) and pull the rear frame (in this way the head of the bolt can come loose).
- Withdraw the two screws and the nut and lift the seat (fig. 2).

To install the seat, carry out the above operation in reverse.



Fig. 4 - Removed off the road.

## DISASSEMBLY AND ASSEMBLY OF THE SEAT

(Fig. 4)

The road load must remain maximum. If however, for any reason, it is necessary to disassemble it, proceed as follows:

Disassemble like the following:

- The rear back (A) by taking off the safety lock (B).
- Rear seat back (C) by loosening its set screws.
- The stay lock (D) of the seating (E) and place aside (F).
- The rear headrest (G).
- The back support (H) of the springs (I).
- The inner adjustment rod (J) and the guide clip (L) of the upper frame of the shock absorber at (K).

- The rear arms (O) of the seat (K).
- The link bolt (M) and its safety pin (P).
- The rear bolt (N).

Once the seat has been taken apart, check the condition of the plastic bearings, rubber stops and other parts, replacing any component found to be defective or which does not offer complete security.

To assemble the seat, carry out the above disassembly procedures in reverse.

Note. -- Lubricate the wing nuts (H) with a graphite grease.




FIG. 4 - Exploded view of the seat

**FRONTR MOUNTED SEAT (Fig. 8)**

The front-mounted seat consists of a safety designed front rail attached to the left frame. To remove or install the seat, it is only necessary to loosen or tighten the nuts which secure it to the upper surface of the front frame.




FIG. 8 - FRONT-MOUNTED SEAT

## SHEET METAL AND BODYWORK

### SPECIFICATIONS

Type of bodywork

Hood with flat bonnets and facia panels.

### DESCRIPTION (Fig. 8)

The plate shows the assembly of the hood (A), front grille (B), front valence (C), instrument panel (D) and the two facia panels (E) which are equipped with a front light.

These parts, which can be very easily interlocked and assembled in a short time, afford protection to both

the engine and the interior. Under no circumstances should the facia be used without these 2479911 pieces. Always keep them clean and replace them as soon as they are soiled or damaged to prevent dust and insects the good appearance of the vehicle.




Fig. 8 - Front bodywork




Fig. 7 - Detailed view of the front seat, showing:

### TO REMOVE AND INSTALL THE FRONT GRILLE (Fig. 8)

To remove the front grille, proceed as follows:

- Remove the two screws (A).
- Pull the front grille (B) forwards and upwards to disengage the two guides (C) from their housing in the cross members.

To install the front grille, reverse the above operations.



Fig. 8 - Removing the front grille.

### TO REMOVE AND INSTALL THE HOOD

To remove the hood, proceed as follows:

- Raise the right-hand side of the hood.
- Remove the four screws from both guides.

- Remove the hood assembly. To install hood, reverse the above procedure.



Fig. 9 - Front view with hood removed.



Fig. 10 - Removal of front hood.

#### TO REMOVE AND INSTALL THE FRONT COWLING

To remove the front cowling, proceed as follows:

- Remove the front pole.
- Remove the hood.
- Disconnect the air cleaner-to-indator hose (A, Fig. 15).
- Disconnect electrical connections of the following:
  - a) the regulator
  - b) the horn, as well as its earth wire
  - c) the front right headlight
- Remove the air pipe (Fig. 10).
- Remove the clearer intake filter (Fig. 15).
- Remove the two side mud-flap-lifter set screws (Fig. 12) (be careful with the two rubber washers which fit at these abutments).

— Remove the four used-to-chassis set screws (Fig. 12).

— Partially lower the two indicator set screws.

— Pull the used towards, disengaging it from the indicator (Fig. 14).

Once the cowling has been removed from the two tor, remove the following:

- a) the regulator
- b) the air cleaner
- c) the horn
- d) the right and left headlights and their brackets.

To install the front cowling, carry out the above procedure in reverse order. Do not forget to tighten the indicator set screws and to place the two rubber washers in the side lock points (between mud and ceiling).



Fig. 17 — Removal of front bumper assembly.



Fig. 18 — Removal of front headlight assembly (left side).



Fig. 19 — Removal of front headlight assembly (right side).



Fig. 20 — Taking off the front end.

### TO REMOVE AND REINSTALL THE INSTRUMENT PANEL

To remove the instrument panel, proceed as follows:

- Remove the headrest.
- Loosen the handle control lever.



Fig. 15 — Removal of the headrest

- Remove the instrument panel and handle bar assembly (Fig. 16).

- Pull the panel towards cabin using it as a tie rod.

To install the panel, carry out the above procedure in reverse order.



Fig. 16 — Removal of panel

### TO REMOVE AND INSTALL THE FENDERS

To remove the fenders, proceed as follows:

- Disconnect the wiring at the lights in the connection box (Fig. 17), located on the left side of the rear wheel arch.
- Remove the fender brackets see section Fig. 36.
- Remove the two set screws of each fender, hold each side of the rear frame (Fig. 18).
- Take off the fenders (Fig. 19).

To install the fenders, carry out the above procedure in reverse.



Fig. 17 — Connection box




Fig. 19 — Front fender panel - plate and screws.



Fig. 20 — Front fender panel.



Fig. 21 — Tearing off the fenders.

**To REMOVE AND REINSTALL THE STEP PLATES**

To remove the step plates, carry out the following procedures:

- Remove the step plate-to-fender set screws (Fig. 22).
- Remove the step plate-to-trunk set screws.
- Remove the step plates.

To install the step plates, carry out the above operations in reverse order.




Fig. 21 - Panel and stop plane

## SECTION 3:

# FRONT AXLE AND STEERING

### CONTENTS

	PAGE
Front axle	1
Specifications	5
Description	5
Front wheel adjustment	6
Tire fit	7
Removing and installing the front wheel hub assembly	8
Assembly	8
Removing the front wheel hub assembly	9
Installing the front wheel hub assembly	9
Removing and installing a 1000-interpreter	9
Removing and installing the center bearing of the front axle	10
Bushing	10
Specifications	10
Description	11
Removing and installing the tractor steering box	12
Disassembling the steering box	12
Assembling the steering box	14



Publication SP-1029-AFP  
See Bulletin 7-38

**FROST AXLE****SPECIFICATIONS**

Front angle	0°
Center angle	30°/30°
Oxygen introduction angle	111°
Toe-in	0 to 8.00 mm
Kingpin diameter	27.00 to 28.00 mm
Kingpin swiveling limits diameter	28.00 to 28.08 mm
Bumper adjustment limit	47.50 to 47.60 mm
Center pivot pin limiting valve diameter	41.00 to 41.40 mm

**DESCRIPTION**

The front axle is of the floating type and is mounted into the cross member with a pivot pin.

The cross member is joined to the rear side plates and is coupled to the engine with four bolts in each side and six bolts in the cross member itself.

The front axle is made up of a strong series base of quadrangular cross-section and individual side extensions, joined to the housing of the kingpins. The side extensions can be fitted to the center beam in different solutions, thus making it possible to obtain different track widths.

**ADJUSTMENT OF THE FRONT TREAD**

(Figs. 1 and 2)

The side side extensions can be moved in increments of 10 mm per side, which provides the following series track widths: 1.25 m, 1.35 m, 1.46 m, 1.56 m, 1.67 m, 1.77 m and 1.87 m.

To adjust the front track proceed as follows:

- Place the front end of the trailer.
- Loosen the two slings (G) which secure the ends of the track rods (E) to the track fork (D) of

the truck body (B). These slings have a lock, a threaded rod and a safety nut (A).

— Take out the lock nut, loosen one of the captive nuts (M), move each extension (B) to the center beam (C).

— Place the side extensions at the desired track spacing at the same time as the necessary adjustments are made on the track rods. For this purpose, the four track shims have machined grooves

for the different track dimensions. These grooves fit into the sleeve holes and provide for side assembly of the track rods.



Fig. 1 - Front road adjustment

— Since the track adjustment has been carried out, tighten all nuts and bolts and check the track to the ground.




Fig. 2 - Rear road adjustment

## 5028.5

The sum of the track widths of the 1390Z 200 and 4WD models, comprising item 5, parameter 294-established (production standard), pertaining to the design characteristics of both sets, no specific value is

fixed. It is 0.20 mm. As can be gathered from the following, the top-in is compensated by the different track adjustments since there is a different track width for each model setting.

## 5028.6 TO REMOVE AND INSTALL THE FRONT AXLE-CHASSIS MOUNTING ASSEMBLY

(Figs. 3 and 4)

The operations involved in removing and installing the front side-cross member assembly should be carried out in the following order:

- Place a shock under the master cylinder.
- Place a wedge between the front side-cross beam and the oil pan both sides.
- Remove the front.
- Disconnect the passing chain at its connection with the timing belt.
- Drain water from engine and radiator.
- Remove upper and lower radiator-to-engine hoses.

- Remove all character-angle links mounted here.
- Take the front grille off the tractor.
- Disconnect the battery terminals.
- Take out the eight bolts that secure the two side-to-the engine.
- Take out the six bolts that secure the cross member to the engine.
- Pull the front side-cross member assembly forward to disengage it from the engine.
- Check up the assembly adequately and remove.

- (1) The radiator.
- (2) The battery, periodically moving the front head lamp brackets backwards.
- (3) The radiator cap, air cleaner and bonnet assembly.

To install the front axle cover member assembly, follow the above procedure in reverse order.



Fig. 3 -- To remove the front axle cover member assembly.




Fig. 4 -- FRONT AXLE-STEERING ASSEMBLY.

### DISMANTLING OF THE FRONT WHEEL HUB ASSEMBLY (Fig. 8)

To carry out this operation, proceed as follows:

- Raise the front of the tractor and remove the wheel from the hub.
- Remove the hub cap (A).
- Pull out the center pin (B).

- Remove the centralized nut (C) and the washer (D).
- Disassemble the following from steering knuckle: The hub (E), together with the bearings (F) and (G) and the retainer (H).
- Remove the following from the hub: the half-nut (I) and (J) of both bearings.



Fig. 8 - Front hub assembly

### ASSEMBLY OF THE FRONT WHEEL HUB ASSEMBLY

- Press the hub sleeve in the hub.
- Set the inner bearing in place (F).
- Enclose the retainer (H) with the hub sleeve towards the inside of the hub, driving it into the step located inside of it.
- Push (E) the hub with grease and mount it on the steering knuckle.

- Assemble the outer bearing (G), the washer (D) and the centralized nut (C). Tighten the centralized nut to 8.3 kgf and then loosen it approximately half a turn so that the hub has an axial play of 0 to 0.20 mm.

- Insert a lock center pin (B).
- Fit the hub cap with grease, set it in place and mount the wheel.

### TO REMOVE AND INSTALL A SIDE EXTENSION OF THE FRONT AXLE (Figs. 8, 9 and 10)

The same procedure must be followed when removing a side extension even when the part is not being changed to another model.

The procedure is as follows:

- Raise the front of the tractor and remove the wheel.
- The following applies when changing a steering knuckle (Fig. 8):
  - Remove the hub assembly as described on page 4.
  - Put shims under the steering knuckle or steering knuckle hub assembly to prevent them from falling to the ground while carrying out the following operations.
  - Remove the rear end bolts which secure the drag link hub to the kingpin and discharge both parts.
  - Take out the king pin nuts (2).

- Remove the shims from under the steering knuckle or steering knuckle hub assembly and their own weight will cause them to slide out of their housing in the side extension. Take out the bearing (3).

At this point the steering knuckle is left free. To install it, carry out the above procedure in reverse order. When removing the side extension, the trouble of separating the hub from the steering knuckle can be avoided by disengaging them together and pressing as follows:

- Remove the three nuts (1) which secure the beam side extension.
- Take out the side extension.

**NOTE:** — Before reassembling a side extension, make sure the inside bearings of the king pin housing and the grease cup are in good condition, replacing them if necessary. To install the side extension, reverse the procedure described above.




Fig. 8 — Removing a steering knuckle



Fig. 9 — Installing a steering knuckle assembly




Fig. 9 - Suspension cable position.

#### **TO REMOVE AND INSTALL THE FRONT AXLE CENTER BEAM (Fig. 10)**

To remove and install the center beam of the front axle, proceed as follows:

— Raise the front end of the tractor and place up the center beam under front wheel wells.




Fig. 10 — Removing and installing the front axle center beam.

- Disconnect the steering servo at the U-jig hub.
- Disconnect the track rod at both ends.
- Remove ball's sleeve.
- Take out the six side extensions and central.
- Remove both of the side extensions together with ball steering module and hub.
- Loosen the nut and set screw of the center lower pivot pin.
- Detach the pivot pin. Having previously removed the center bearing and disengage it.

**NOTE.** — Before reassembling the center beam, check the pivot pin housing bearing and the grease cap, replacing them if necessary.

To install the center beam, follow the above procedure in reverse order.

**NOTE.** — When installing the pivot pin (fig. 2-14), leave a clearance of 1.61 or 0.039 to 0.054 mm. Tighten the nut ID to a torque of 2.7 to 3.6 kg. The threads of the center ID must be completely free of grease and be given a coating of shockbreaker before assembly; applying a torque of 3 to 4 kg.




Fig. 2-14 — Removal of pivot pin.

## STEERING

## SPECIFICATIONS

Type	Steer and cast self-locking ball system
Gear ratio	20.1:1
Steering	14.
Lubricant	SAE 80 S.P.
Wheel bearing	Right-hand thread
Worm bearings	Two solid ball bearings
Number of upper worm bearing balls	10 (0.32 mm (1.18")
Number of lower worm bearing balls	10 (0.32 mm (1.18")
Number of male worms and balls	347.03 mm (13.6")
Worm adjusting washers	Size of 0.1 0.18 and 0.25 mm
Steering nut travel	30°
Steering maximum force	347
Steering column gear ratio	Paper of 6.1 mm
Steering wheel turns from lock to lock	5.5

## DESCRIPTION FIG. 10




Fig. 10 - Steering assembly.

The steering mechanism is of the high performance self-aligning ball type and requires very little attention aside from normal maintenance.

Two ball bearings (14) receive the thrust. These are located at the upper and lower ends of the wheel shaft (3). The adjustment of these bearings is by means of a plunger (15) located between the steering column flange (16) and the cover (17). At the upper end of the steering column a bearing (18) is fitted, and acts as bearing neck for the wheel shaft.

The wheel shaft drives the steering nut (19), which consists of the nut itself and the transfer tube, held together by the transfer tube lock. The nut rotates in the steering nut and moves some distance to form a guide. The ends of the guide are connected by means of the transfer tube, providing a smooth road surface when driving fast speeds.

When the wheel shaft turns the balls in the guide are attracted by movement, passing through the track hole and entering the outer end of the guide. Only the balls can be forced into the groove.

The link (16) of the sleeve (18) is coupled to the central end of the steering nut. The central end, which stands out from the steering nut, activates the roller (6) which moves longitudinally along the groove in the lower face of the sleeve sleeve (18).

The function of the roller is to ensure that the steering nut, mounted independently, follows in a straight line, parallel to the wheel shaft, and has the effect of increasing the steering ratio when the steering nut moves away from the position in which the wheel is pointed to the front.

The coupling of the sleeve with the steering nut is effected by means of the retaining nut (11) to prevent the outside of the steering nut and cover.

## TO REMOVE AND REINSTALL THE TRACTOR STEERING BOX.

To remove the steering box, proceed as follows:

### Remove:

- The hood.
- The driver's seat.
- The steering-wheel, after first marking its position.
- The radiator cowl and instrument panel, after

removing the manual transmission and the transmission cable.

- The fuel tank.
- The throttle linkage.
- The steering arm (see tool KTP 910/1).
- The steering box.

To install the steering box in the tractor, carry out the same procedure in reverse order.

## DISMANTLING THE STEERING BOX

Once the steering box has been placed on the bench and its accessories removed, dismantle it as follows:

### Remove:

- The side cases and lip seal (Fig. 11).

- The mounting factor and after through the side cover housing (Fig. 12).
- The steering columns and tie plates (Fig. 13) so that extra adjustment is obtainable. They will be needed when installing the steering box again.
- The main shaft, raising it high enough to be slide-




Fig. 11 ... Removing the side cases



Fig. 12 ... Removing the main shaft

- expose the thrust washer, the upper bearing race and the two balls. Withdraw the worm shaft through the idle control housing (Fig. 14) together with the bearing nut and the two balls of the lower bearing.
- The worm shaft's steering nut (Fig. 15), loosening it immediately. Be careful with the 6x10 bolts located in the guidage and handle tube.

Once the steering box has been disassembled, check the plastic bearing in the upper part of the steering column, the bearing in the lower wheel housing, the rubber on the same side and the other components of the assembly. Replace all parts which are either old or have worn out parts.



Fig. 14 — Removing the worm shaft




Fig. 15 — Removing the steering nut



Fig. 16 — Removing the steering column

**ASSEMBLY OF THE STEERING BOX**

Once all parts of the assembly have been inspected and cleaned, the steering box should be assembled as follows:

- Fit the steering nut on the stem, including the lock nuts (the park auxiliary lock) (Fig. 36).



Fig. 36 — Fitting the steering nut on the shaft.

- Place the bolts in the housing case. A thin coating of clean grease will help to maintain the bolts in the correct position.
- Insert the upper shaft with the steering nut through the left lower housing, keeping it in such a way that the lower end of the upper shaft is placed beneath the base of the lower bearing.

Take care not to move the upper shaft so that the tail of the lower bearing will not displace, prevent by locking.

- Run the upper bolt race onto the upper shaft, pulling the ball guide downwards, until it is near its limit in the box. After first applying a thin coating of clean grease, place the balls in the race and insert it into the housing.

- Set the thrust washer at the upper shaft and fit nuts on the upper ball race.

- Fit the upper gear on the upper shaft and assemble the adjustment sleeve and steering column, securing it to the box cover with two washers.

While tightening the steering column set screws, turn the main shaft by hand. If it is too stiff, and it has collapsed plates, it, on the other hand, the main shaft is too fine, remove some adjustment plates.

When the steering column is fully tightened, the main shaft should turn quite freely.

- Mount the meter at a 90° angle with regards to the arm, so that the latter has the entire the central part of the steering gear.
- Fit the outer on the central edge of the steering gear, which extends out from the sector fork.
- Assemble the gear cover, ensuring that the roller follows the longitudinal groove on the inside face of the cover.

Once the cover has been assembled, run the main shaft so that the sector is in a straight position, that is, in the middle of its travel. Check to see if there is any play in the sector shaft and, if there is any play, or gaps if it is too tight, adjustment is necessary. The adjusting screws will be counter nuts are located on the outside face of the side covers.

- Fit the steering box with the correct amount of oil of the recommended viscosity.

## SECTION 3:

# FRONT AXLE AND STEERING

### CONTENTS

### PAGE

Front axle	1
Spool Bearings	1
Description	1
Front wheel adjustment	1
Tools	2
Removing and installing the front axle-ribs-motor assembly	2
Replacing the front wheel hub assembly	4
Installing the front wheel hub assembly	4
Removing and installing a side connector	5
Removing and installing the center bolts of the front axle	6
Mechanical Steering	9
Specifications	9
Description	11
Removing and installing the master steering box	12
Disassembling the steering box	12
Assembling the steering box	13
Hydraulic steering system	15



**HYDRAULIC STEERING SYSTEM****CONTENTS**

Item	Page
Specifications	17
General description	21
Operation	23
Maintenance 2300 hours	25
Maintenance 1400 hours	28
Inspection of the system	32
Renewing and refilling the hydraulic pump 1300 hours	33
Disassembling the hydraulic pump 1300 hours	38
Assembling the hydraulic pump 1300 hours	39
Renewing and refilling the hydraulic pump 1400 hours	39
Checking the safety valve setting pressures	41
Disassembling, checking and reassembling the hydraulic pump 1400 hours	42
Disassembling the hydraulic oil reservoir 1300 hours	43
Disassembling and assembling the safety valve 1300 hours	44
Renewing and refilling the transmission unit 1300 and 1400 hours	45
Disassembling the hydraulic unit 1300 and 1400 hours	46
Disassembling the steering gear	47
Assembling the steering gear	48
Fault finding chart	49

## HYDROSTATIC STEERING SYSTEM

**SPECIFICATIONS**

<b>Hydraulic sizes</b>	
Outer cylinder length	476.5 mm
Outer	67 mm
Outer Diameter	10 mm
Inner cylinder length	276.8 mm
Outer	55 mm
Outer Diameter	10 mm
Shaft overall length	541.5 mm
Spigot	32.9 mm
Diameter	25 mm
Front and tail pivot: total shaft length	55 mm
Piston diameter	48.125 mm
Cylinder base flange mounting bolt pitch	107.65 mm
Weld base to cross shaft	100 kg/mm <sup>2</sup>
Steel base, working pressure	
<b>Steering column</b>	
Dynal length	470 mm
Diameter	34 mm
Hydrostatic unit	
Hydrostatic unit output flowrate	300 cm <sup>3</sup> /rev. (different sizes for 200 and 1 rev/s)
Bore diameter	30.716 mm
Louvre cover surface 20 rev/s	0.667 (20 rev/s) 0.333 (1 rev/s)
Hydrostatic unit to steering column fastening	
surface 10.	100.716 mm <sup>2</sup>
Thread size	M5.7 mm (1 rev/s)
Steering column	
Diameter	80 mm
N° of turns from stop to stop (Road with 30-mm-thick road)	6 towards the left 8 towards the right
N° of turns from stop to stop (Road with 15-mm-thick road)	6 towards the left 3.5 towards the right
<b>Hydraulics oil reservoir capacity</b>	
200 Tractor	1.0 liters
300 Tractor	1.0 liters
Steering pump flow output	
200 Tractor	300 per minute
400 Tractor	533 per minute at 1,000 r.p.m.
<b>Surface valve setting pressures</b>	
200 Tractor	0.6 kg/cm <sup>2</sup>
400 Tractor	0.8 kg/cm <sup>2</sup>
<b>Recommended hydraulic oils</b>	
<b>Brake</b>	
Hydraulic HLP-45	
Titan 27	
Titan 30	
OT 26	
OT 30	
<b>Tightening torques</b>	
Hydraulic coupling nuts	Right side 17.5 N·m
Steering arm rear support bracket mounting bolts	11.2 to 15.2
Hydrostatic unit to steering column screws	4.0 to 5.0
Hydrostatic unit to mirror frame mounting screws	0.8 to 1
Hydrostatic oil reservoir support bracket mounting screws	0.8 to 1




Fig. 7 - Front wheel steering assembly




Fig. 11 - Front wheel assembly (not to scale)

### GENERAL DESCRIPTION

#### 300-Truck

The Hydrostatic steering system fitted to 300 model tractors comprises the following components:

1. Gear type hydraulic pump MA, located at the engine right hand side towards the front and it is driven by a gear in the timing case.
2. Oil reservoir HB, comprising the hydraulic oil tank including cap in the steering circuit, incorporating a safety valve HS.  
This reservoir is fitted at the engine right hand side, towards the rear and top part, to front of the fuel tank.  
The oil filter is also located in this reservoir. The oil level dipstick is located in the oil filter cap (C).
3. Hydrosteering unit (D) attached to the bottom end of the steering column and secured to the tractor body by means of a support bracket.  
The hydrosteering unit, the hydraulic pump and the steering gear are connected with hydraulic pipes.



Fig. 91 - Hydrosteering unit assembly - 300 Tractor

4. Dual action steering ram (P) with a single stem, fitted on the tractor L.H. side. The ram rear ball joint is attached to the gearbox housing by means of a bracket (Q). The front end ball joint is secured to the steering arm. The ram houses two oil inlet hydraulic pipe unions coming from the hydrostatic unit which will determine the steering towards either side.

#### 460-Tractors:

The hydrostatic steering system fitted to 460 tractors comprises the following components:

1. Gear type hydraulic pump (A), incorporating the hydraulic oil reservoir (B), located at the engine L.H. side front end. It is driven by a gear in the timing case.
2. The oil reservoir (B) incorporates an oil filter and a safety valve. The oil filler plug (C) is also used to check the oil level in the reservoir.
3. Hydrostatic unit (F), attached to the steering column bottom end and secured to the tractor frame by means of a bracket. Hydraulic pipes connect the hydraulic oil pump to the steering ram.
4. Dual action steering ram (D) with a single stem. Its rear end ball joint is attached to a bracket (E) and the front end ball joint is secured to the steering arm.




Fig. 20 — Location of the steering ram fitted to 350 Tractors




Fig. 21 — Hydrostatic unit arrangement - 460 Tractors

The basic hydraulic steering unit is a set of gears, the function of which is provide a steady current oil flow to the steering rack and, in the case of an emergency, it acts as a back pump. This unit consists of:

- A pump motor containing a fixed cover ring (1) with two lobes, and an inner rotor (2) with outer lobes.
- A two-element, four way valve distributor valve, the two elements are primary valves (3) and an inner valve (4). The outer sleeve is connected directly to the steering wheel.
- A rotation shaft (5) that mechanically connects the rear ABS to the outer sleeve (3), thus providing instant synchronization.
- A check valve (6) located between the return and pressure connections.





Fig. 22 - Exploded view of basic hydraulic steering unit

- 1 - Housing
- 2 - Pump motor with body
- 3 - Primary valve
- 4 - Primary valve sleeve
- 5 - Rotation shaft
- 6 - Check valve
- 7 - Outer sleeve ring
- 8 - Rotor

Fig. 23 - Hydraulic steering unit components

- 1 - Return hoses
- 2 - Return pressure
- 3 - Inner sleeve
- 4 - Outer sleeve
- 5 - Check valve
- 6 - Outer sleeve ring
- 7 - Rotor
- 8 - Distributor valve assembly
- 9 - Distributor valve feed hole
- 10 - Back plate
- 11 - Return pressure
- 12 - External feed hoses
- 13 - Distributor valve lock tool



**OPERATION**

1. The 2000-300 and 3000 tractors equipped with the Hydrostatic Steering Unit have an independent hydraulic circuit fitted with an oil reservoir.
  2. All 2000 Tractors incorporate the hydraulics of steering in the hydraulic pump.
- On 2000 MARCO Tractors, the hydraulic oil reservoir is located on the engine right hand side bracket. On new Impala, connection from the reservoir to the pump is achieved through hydraulic pipe.
3. Safety valve setting pressure must be of 50 kg/cm<sup>2</sup> for both tractors models.
  4. The pressurized oil supplied by the pump through the safety valve body goes to the hydrostatic unit by means of two steel pipes, i.e. a return pipe and a pressure pipe.
  5. When the steering wheel is non-rotative and the steering wheel is in central position, the small recessed holes on the lower sleeve coincide with the outlet holes on the outer sleeve, thus allowing a free circulation of oil through said holes, returning to the reservoir once again.




Fig. 24 - Hydrostatic system

A - Oil tank supply line  
 B - Return line  
 C - Pump output line  
 D - Return return line

- b. When turning the steering wheel the valve ports and valve sleeves turn 36° and 45° respect of the axis. The passages leading to the cylinder ports progressively open by an approximate rotation of 13°. These passages are fully opened by an approximate rotation of 20°.  
After a rotation of approximately 45° the control ports are closed.

Oil circulation through gear with losses:

- a. Motor gear losses.
- b. A flow volume servo directly proportional to the steering-wheel angular movement on the servoflat cylinder, to turn the front axles to the desired direction.
- c. The loss resistance feed from the inner gear to the valve outer sleeve is such that the return servo-servo ports or reverse speed are closed when the angular movement of the outer gear reaches until that of the steering wheel.




Fig. 20 - Hydrostatic powered steering oil circulation  
Right-hand turn

- A - Oil to increase flow to motor
- B - Oil to prevent flow to cylinder
- C - Return flow
- D - Return flow




Fig. 21 - Hydrostatic powered steering oil circulation  
Left-hand turn

- A - Oil to increase flow to motor
- B - Oil to increase flow to cylinder
- C - Return flow
- D - Return flow

**Maintenance****500 Hours**

1. Every 10 hours of operation or 500, lubricate the rear ball joint with an aluminum multi-purpose grease, through nipple 15.

**Fig. 27 - Hydraulic cylinder rear end housing 500 hours**

- ① - Cylinder body
- ② - Rear ball joint grease nipple



2. Every 200 hours of operation, check oil level in rear steering oil reservoir. Replace reservoir, filter with good quality oil. See Specifications on Page 15.

**Fig. 28 - Checking oil level - 500 hours**

- ① - Reservoir
- ② - Cone end of rear steering cover
- ③ - Oil reservoir



3. Every 1,000 hours of operation or weekly (whichever first occurs), flush the entire steering circuit and refill with new oil.

Also change the steering fluid 500 hours inside the reservoir. Use oil rated 10W or any aluminum quality from SPECIFICATIONS on page 15.

**NOTE:** When adding oil to the reservoir or changing steering fluid, check oil and reservoir needs. Stop short to the circuit would cause unnecessary damage.

**Fig. 29 - Flushing circuit - 500 hours**

- ④ - Reservoir 14
- ⑤ - Filter housing
- ⑥ - Reservoir 16
- ⑦ - Oil reservoir



**Maintenance****800 Torsions:**

- Every 10 hours of duty, lubricate the steering rear pivot and ball joint through nipple 122. Use multi-purpose grease.

- Every 200 hours of operation, check the hydraulic pump oil reservoir (12) level, by following the procedure outlined below:

— Shut the engine and turn the steering wheel one full rotation the L-R side.

**Ply 10 — Hydraulic oil level and serviceage**

- A —Hydraulic pump  
B —Axle assembly pressure relief

- Keep the engine running for 30 seconds.
- Remove the filter plug (10). The oil level must reach up to the filter media lower slot. Replace it and re-tighten.
- Re-fit the filter plug. Start the engine and keep it running for another three seconds.
- Re-choose the filter plug again and check that oil bypassing occurs as required to reach the correct level.
- Tighten the filter plug screw more and tighten to 1.6 kgf/cm torque.

**Ply 10 — Cleaning/replacing reservoir oil level****800 Torsions**

- — 10 minutes  
■ — Oil filter and bypass

- Every 1,000 hours of operation, change the oil separator oil filter element as per the following instructions (Ply. 20).

- Place suitable dust container under the rear "WV".
- Remove the bolt (B).
- Remove the reservoir (A).
- Separate the diaphragm (D).
- Remove the outer side (H).
- Remove the nut (J).
- Remove the retaining (K).
- Remove the nut (L).
- Remove the seal (M).
- Remove the filtering element (N) and discard. Clean all components in paraffin and dry them.
- Replace the "O" ring (G).

Replace the elements by reversing the above procedures except for:

- Ply 10 item "O" ring is new filtering element.
- Reservoir must now be tightened to 2 kgf/cm.
- Ply 10 the reservoir and check that level is correct.




Fig. 20 — Exploded view of reservoir and filter

## **REFILLING THE STEERING SYSTEM**

### **404-Tractors:**

1. Remove the filter plug.
2. Fill the pump reservoir with fresh oil up to the max. hole lower level.
3. Buff the filter plug and tighten to 1.0 kgf m.
4. Start the engine and hold it at 800 r.p.m. for 30 sec. (402444).
5. Turn the steering wheel. Drive wheel to stop (left), turn left to right and from right to left.
6. Stop the engine and refill the reservoir.
7. Start the engine and hold it at 1,200 r.p.m. (402444).
8. Repeat operations 6 above.
9. Turn the steering wheel to the L.H. stop and keep it there for about 10 sec. Repeat the operation with the steering wheel turned to the R.H. side stop (When the steering wheel is held against either stop, the safety valve will be held until it operates).
10. Repeat the operation under 9, above, three times.
11. Stop the engine, check for leaks at all joints and repeat the suspension items 1 to 10.
12. Loosen the unions on the steering arm slightly to remove all air that might have built inside the tank. Turn the steering wheel from stop to stop while the engine is running and tighten the unions adequately.

### **404-Tractors:**

1. To bleed the steering system on 404 tractors follow the procedure outlined in item 12, above.

## **REFILLING AND PURGING THE STEERING PUMP, ON 200-TRACTORS**

1. Loosen the pressure relief pipe union (B).
2. Loosen-out the suction pipe union (C) letting the air drain into an adequate container.
3. Unscrew the housing screws (A) and pull out the pump assembly (B) from its housing by the steering case.
4. Refill the pump by repeating the above stated procedures and branch the oil suction pipe and outlet pipe (casing not to change their original fitting positions).



Fig. 23 — Inspecting the steering system




Fig. 24 — Removing the steering pump (Item B) - Tractor

### DISASSEMBLING THE STEERING PUMP (2) TO EXAMINATIONS

1. Detach the locking washer (14) and remove the nut (13) and bearing cap (12) retaining the helical gear (11) to the center housing (10) using snap ring (10).
2. Detach the helical gear from the gear shaft. Tap the gear loose with a plastic hammer or use a suitable puller if required.
3. Remove the woodruff key (6) from the shaft.
4. Remove the right, socket-head set-screws (1) and nutscrews retaining the pump cover (5) to the pump body (4).
5. Separate the cover from the body. Unless necessary the oil seal can be removed from the cover by carefully sliding it out with a suitable steel bearing drift.
6. Extract the bi-shaped 'O' ring (3) from its housing groove in the pump body, and withdraw the outer 'O' rings (2) and outer bearing (1) from the KOFI bronze bearing (12). Separate the inner from the gears, taking care not to force the split separator (13).
7. Withdraw the pump pins (8) and (9) and the two bronze bearings (11).
8. Examine the bearings for signs of seizure or scoring on the face or journals. Light scoring can be removed by careful tipping on a surface plate, using 'O' grade emery paper with 1000 grit immersed.
9. Examine the body for wear in the gear running pads. If the wear is more than 1.1 mm at the thinnest side, the body must be replaced.
10. Examine the gears for excessive wear or damage on journals. Holes in teeth, burrs and across the gear face or the tooth edge should not exceed 0.020 mm. The gear pinions can, if required, be lightly polished with 'O' grade emery paper to remove some wear. The gear teeth may be polished by sandwiching the entire gears between the gear shell and a steel bearing and rotating them.
11. Oil seals, piston washers and 'O' rings should be replaced when reassembling the pump.




Fig.8 - Exploded view of steering pump drive assembly mounting points

- 1 - Pump body
- 2 - Outer driving gear
- 3 - Outer bearing
- 4 - Outer bearing
- 5 - Pump cover
- 6 - Woodruff key
- 7 - Counterweight
- 8 - Pump pins
- 9 - Pump pins
- 10 - Helical gear

- 11 - Inner bearing
- 12 - Helical drive gear
- 13 - Drive sleeve assembly
- 14 - Thrust washer 'O' ring
- 15 - Piston rod
- 16 - Piston washer
- 17 - Gasket

## ASSEMBLING THE STEERING PUMP 300 TRACTORS

The bearing housing must be assembled in correct relationship to the gears and to the housing in the pump body or bodies. To this end, when dismantling the pump the components should be arranged on the work bench in accordance with their original mounting position (see Fig. 30).

Carry out a thorough cleaning with benzene or petrol (gasoline) when reassembling the components.

1. If the oil seal has been retained previously, insert a new suitable oil seal in the pump housing. The oil seal used here differs in its seating in the pump housing from the front cones, which are identified by the small recesses in the front edge of their flanges. Inserted in these the rubber expander sleeve (10).
2. Fit the rear bearing (21) into the pump body (19). Care should be taken to distinguish these bearings from the front cones, which are identified by the small recesses in the front edge of their flanges. Inserted in these the rubber expander sleeve (10).
3. Assemble the pressure driving gear (20) and driven gear (18) with their respective bearing flanges with each other. Be careful not to invert the opposite mounting position of the driven gear, so as to avoid interference of tooth drive slots.
4. Fit the front bearing (10) onto the gear journals and insert the rubber expander sleeve (10) between them.
5. Fit two carbon thrust washers (13) and rubber rings (12) on the front bearing, ensuring that the rubber rings seal correctly around the shafts.
6. Fit a new flat-packed O-ring (11) onto the groove in the pump body (19).
7. Assemble the pump housing (16) to the pump body (19) taking care not to damage the oil seal when passing the driving shaft (18) through. Fit the right assembly and washer (17) and tighten firmly to 2.8 kgf/cm² (28 Nm). An adjustable torque wrench must be used for this operation. Be careful that this torque figure is not exceeded.
8. Reassemble the assembly (Fig. 30) in the following driving gear shaft and assemble the latter gear (19) to the shaft.

9. Place a locking washer (26) onto the shaft and insert the single nut into the borehole in the gear. Turn on the locking nut (25), tighten fully and lock the nut onto the plain face of the locking washer.

### REMOVING AND REFITTING THE STEERING PUMP - 4WD TRACTORS

1. Place a suitable steel container beneath the tractor to collect the oil from the steering chassis.
2. Loosen out the return and outlet pipe unions (B and C, respectively).
3. Loosen out the 4 screws (A) securing the pump body to the timing case.



Fig. 30 - Removing the steering pump - 4WD Tractor

- A - Securing screws
- B - Return pipe union
- C - Outlet pipe union

4. Lift off the pump (D) and oil reservoir (E) assembly from the tractor.
5. Refit by reversing the removal procedure except that:
  - Fit a new sealing gasket between pump, timing and timing case cases.
  - Fill the reservoir 80-90% oil.
  - Bleed the system (see page 27).
  - Check the wheel spacers for bent and misaligned.



Fig. 31 - Reversing the pump and oil reservoir assembly - 4WD Tractor

**CHECKING THE SAFETY VALVE SETTING PRESSURE - TWO STAGES**

1. Start the engine and leave it running at 1,000 rpm, with the steering wheel turned square to 10 o'clock, until the oil temperature reaches 50°C. Stop the engine.
2. Disconnect the pressure relief valve from the pump and connect a pressure gauge like that to its housing.
3. Start the engine.
4. If the pressure reading is lower than the specified check the system as follows:
  - Drain the system.
  - Remove the reservoir.
  - With a screwdriver adjust the regulating screw in or out to increase or decrease the pressure, respectively.

**Remarks:** — Naturally the regulating screw is secured by a welding spot to prevent pressure setting alteration.

- Turn the reservoir.
- Fill with oil branch in the pressure gauge reservoir.
- Start the engine and check that the pressure reading is 4-6 kg/cm<sup>2</sup>.



Fig. 38 -- Checking safety valve  
PRESSURE-TESTING




Fig. 39 -- Safety valve pressure limiting regulating screw

a -- Oil-flow housing guide  
b -- Valve body




Fig. 40 -- Cross-section view of oil separator, safety valve and spring

1	initial valve part	2	30000 mPa
2	valve seat	3	3000 mPa
3	O-ring	4	oil reservoir

## DISASSEMBLY, INSPECTION AND REASSEMBLY OF STEERING PUMP, 400 TRACTORS

### Disassembly

- Remove the screws and fibre washers from the pump body cap (item 3 on page 30) and place the pump body in a suitable vice.
- Loosen and the safety valve plug (E) along with its sealing washer.
- Loosen and the clear housing plate (D) along with its sealing washer.
- Remove the 10 mm (E) sealing clip part of the reservoir mounting from the body (F).
- Release the pump retaining position on the workload (G).
- Sight out the washer tab (H) locking the nut (I).
- Loosen and the nut (I) and remove along with washer (H).
- Note: - Lock the gear in order to loosen the nut.
- Remove the drive gear (K) with a standard gear puller.
- Remove the gear (K) and the locknut key (M).
- Draw a fitting mark on the pump body (L) and the workload (G) to take the setting operation easier.
- Loosen and remove the (N) "Wavy" sleeve (O) and washers, retaining the end plate (P) to the pump body (F).
- Remove the bearing ring (R).

Fig. 44 - Steering pump components - old version

- 1 - 10 mm
- 2 - End plate
- 3 - Reservoir cap
- 4 - Reservoir supporting "10" ring
- 5 - Oil bearing end
- 6 - Clear housing
- 7 - Pump body
- 8 - "10" sealed "10" ring
- 9 - Bearing "10" cap
- 10 - Safety valve
- 11 - Reservoir plate
- 12 - Drive gear housing
- 13 - Counterweight
- 14 - Drive gear
- 15 - Washers
- 16 - "Wavy" sleeve gear
- 17 - Other gear retaining bolt
- 18 - End plate retaining screw
- 19 - Threaded screw supporting bearing

- Remove the "10" rings (H) and the (J) bushings (L).
- Remove the (K) bearing (L) from the drive gear shaft.
- Remove the bearing (M) from the drive gear.
- Remove bolts, the drive (K) and the drive (M) gear.
- Remove the oil lip seal from the end plate (N) and fit a new one.

### Check

Check the bearing for wear. Carefully inspect the insulation sleeves and the joints between the hub and the hub holder. Any scoring or damage to this area may cause permanent blocks.

Usually on servicing, the bearings must be pulled out and replaced by new ones. However, if new bearings are not available, the existing ones may be reconditioned (only if major bearings are concerned). Check them as per the following instructions: Press a piece of heavy paper against to possible on a flat surface. Polish the surface by sliding the bearing in a circular pattern. Check that the bearing can move freely inside the pump housing. If not measured, polish the bearing properly again.

After polishing, thoroughly heat the bearing to facilitate its removal.



Visually check the wear, smoothness or cracks in the pump body and end plates. Due to oil pressure, the gears normally cut a groove in the pump body, total width. This groove should never exceed 0.1 mm, otherwise the pump body must be changed.

The only repair that can be performed on the pump body is to carefully grind off any burrs at the groove edge with a very fine grit emery paper. Thoroughly clean the damage on the gear teeth or gear shaft. If gear shafts are so badly worn that they are of minor importance, they can be replaced with pinions without grinding the emery paper.

Gears having small bearings on the surfaces can be reconditioned with pacific coated graphite 'O' rings (see Fig. 42).

Check gear backlash, which cannot be greater than 0.25 mm. If gears cannot be polished since damage is of greatest importance, it may yet have to be used. Gears are only supplied in sets of two, i.e. drive and driven gears.

Inspect the reservoir, especially the bottom concrete base area to keep oil scraped if the seal is compromised.

Also check the 'O' ring sealing surfaces for condition.

Finally, examine the safety valve and seat for corrosion. If so required, slightly smear the parts and seat with adequate grease. Then, clean carefully.

**NOTICE. —** The piston is cut out for the oil under pressure feeding the gearbox on to the pump body itself. If the bearings are worn, the groove will be cut deeper.



Fig. 42 — Fitting the bearings with the encoder shield removed first.

#### Assembly

- Fit the drive (3) and driven (6) gear shafts into the pump housing.
- Fit the bearing (5) and (4) so to the counter-shaft housing that they have the corresponding fitting positions.
- Fit the encoder shield (1) between the inner side sleeve and drive like bearing (4) or to their seats.
- Place the 'O' ring (2) round the bearing bushes with the corresponding thrust washer (12), as shown in Fig. 43.
- Place the 'W' shaped 'O' ring (3).
- Fit the end plate on to the pump body, careful not to damage the oil feed slot when fitting it to the drive shaft.
- Cross the end plate by means of 8 screws. Tighten them diagonally.
- Fit the safety valve (4).
- Place the wooden key (5) in to the drive shaft (6) housing and pass the pump housing over.
- Insert the tool washer (7) and tighten the nut. Then bend the link on the washer on to the nut tips.
- Assure the mounting position of the pump and fit the filter bracket/pump screen (8) suitable wrench.
- Screw the safety valve (4) into its housing.
- Mount the reservoir, 'O' ring and flange.



Fig. 43 — Fitting the half-shaft washer and 'O' ring.

### REMOVING THE BRAKE master CYLINDER FROM DRIVE TRACTOR AND DISASSEMBLING AND ASSEMBLING THE SAFETY VALVE

1. Park the tractor.
2. Remove the nuts from the four pipes (A, B, C and D).
3. Unscrew the bracket to engine support bracket fastening screws.
4. Remove the master and safety valve assembly from tractor.



Fig. 14 - Removing master cylinder - DR Tractor

- A - Pressure pipe to hydraulics unit
- B - Return pipe to reservoir
- C - Reservoir to engine support bracket
- D - Pressure pipe from engine to hydraulics unit via the valve body

### Disassembling and assembling the safety valve

1. Place the reservoir valve assembly on a work bench vice.
- NOTE:** This valve can also be disassembled with retaining flange in position.
2. Loosen the screw (3) and remove along with the spring (2).
3. Loosen and remove the screw (3). Remove the spring (2).
4. Clean all components carefully. Check the spring (2) and piston (4) for perfect condition.
5. Insert the piston (4) in its housing. The flange part of the piston (4) must be on the side of the longer neck (1).
6. Siphon the piston (4) assembly with a sealing washer (5). On the other side, siphon the piston (4) assembly with the spring (2) and the sealing washer (5).
7. Place the assembly to the bracket by means of the screw. Apply torque of 8 to 10 kgf.
8. Connect the pipes (A), (B), (C) and (D).
9. Oil the reservoir with good quality gear oil, as indicated under SPECIFICATIONS.



Fig. 15 - Disassembling the safety valve

- 1 - Safety valve assembly
- 2 - Sealing washer
- 3 - Safety valve base
- 4 - Valve body housing
- 5 - Valve piston/sealing washer
- 6 - Valve housing
- 7 - Valve handle

## REMOVING AND REFITTING THE HYDRAULIC BRAKE UNIT.

**300 and 400 Tractors:**

**Remark:**

1. Remove the steering wheel (1) by means of a puller (2).
- Remark:** — This costs 1000 marks.

Fig. K6 — Removing the steering wheel

2. Remove the hand throttle lever (3).

**Remark:** — Care not to lose the locknut key securing the hand throttle lever (3) to the main linkage.

3. Pull out the dust cover (5).

4. Loosen and then remove (6) securing the instrument panel onto the shield.

Fig. K7 — Removing the instrument panel and front mudflap shield


5. Unscrew the instrument shield (7) out of the engine assembly.

Fig. K8 — Instrument shield



6. Release the lock and turn the front wheel lock (2).

**Fig. 49 - Removing the lock and turn the front wheel lock.**




7. Loosen and the four nuts (2) from the hydraulic master cylinder (1).

**Fig. 50 - Removing the hydraulic master cylinder.**



8. Place the instrument panel (M) on the front foot.
9. Through the hollow space in the front foot, loosen and the four screws securing the mounting column (2) to the hydraulic master cylinder. Use a fine sanding tool (3).

**Fig. 51 - Removing the steering balance and hydraulics unit from body.**



10. Slide the steering column (P) away from its housing.

Fig. 54 - Removing the steering column through the hollow space in the fender.



11. Slightly push apart the fuel pipe from circuit 18 and remove the hydraulic unit from the housing on the frame.

Fig. 55 - Removing the hydraulic unit from the fender.




**Rebuilding:** Reverse the removal operations to re-fit the hydraulic system back to the master, leaving the following in mind:

- Bleeding pressure in hydraulic unit support arm according to master cylinder pressure to 4.5 to 5.5 kg/cm<sup>2</sup>.
- Tighten the steering wheel to column flange nut to 150 kgf cm.

**DISMANTLING THE HYDRAULIC STEERING****USM1-358 and M2/Turbo**

To dismantle the hydraulic steering unit, please note as a note: Check valve with the T union base assembly, then proceed as follows:

1. Unscrew and remove the T union (K1) with the seal ring (K2).
- NOTE:** —One of the valves is equipped with the check valve stop (A).
2. Remove the cover (B) along with the O-ring (B1).
3. Remove the lower valve ring (K3) along with the valve (K4) and the O-ring (K5).
4. Remove the spacer washer (E).
5. Remove the valve plate (L1) and O-ring (K6).
6. Remove the center shaft (J).
7. With the aid of an appropriate extraction tool, extract the check valve assembly (K7) in the hydraulics unit.
8. Turn the hub assembly unit and remove the bolt (P), which will come out easily.
9. With a plastic hammer, tap the valve sleeve (P1) until it comes, out through the valve (K7).
10. Remove the pin (K8) from the valve sleeve (P1).
11. Separate the outer sleeve (P1) from the support (K3).
12. Remove the following parts from the hydraulic unit:
  - a) Seal ring (K9)
  - b) Differential washer (T)
  - c) Outer bearing (K11)
  - d) Bush washer (P2)
  - e) O-ring (K12)
  - f) Gently remove the rubber seal with the steel ring (K13).
13. With the aid of a screwdriver, apply pressure to the 6 pressure springs (K14) until retaining some from spring (K15).

**Fig. 30 — Exploded view of hydraulic unit**

1	Check valve stop
2	Outer sleeve
3	Hub assembly
4	Spacer washer
5	Valve plate
6	Outer bearing
7	Pin
8	Outer sleeve
9	Seal ring
10	Outer bearing
11	Check valve stop
12	Seal ring
13	Center shaft
14	Check valve sleeve

15	Check valve sleeve
16	O-ring
17	Outer sleeve
18	Outer bearing
19	Pressure spring
20	O-ring
21	Check valve stop
22	Outer bearing
23	O-ring
24	Outer bearing
25	Outer bearing
26	Outer bearing
27	Outer bearing
28	Outer bearing
29	Outer bearing
30	Outer bearing
31	Outer bearing
32	Outer bearing
33	Outer bearing
34	Outer bearing
35	Outer bearing
36	Outer bearing
37	Outer bearing
38	Outer bearing
39	Outer bearing
40	Outer bearing
41	Outer bearing
42	Outer bearing
43	Outer bearing
44	Outer bearing
45	Outer bearing
46	Outer bearing
47	Outer bearing
48	Outer bearing
49	Outer bearing
50	Outer bearing
51	Outer bearing
52	Outer bearing
53	Outer bearing
54	Outer bearing
55	Outer bearing
56	Outer bearing
57	Outer bearing
58	Outer bearing
59	Outer bearing
60	Outer bearing
61	Outer bearing
62	Outer bearing
63	Outer bearing
64	Outer bearing
65	Outer bearing
66	Outer bearing
67	Outer bearing
68	Outer bearing
69	Outer bearing
70	Outer bearing
71	Outer bearing
72	Outer bearing
73	Outer bearing
74	Outer bearing
75	Outer bearing
76	Outer bearing
77	Outer bearing
78	Outer bearing
79	Outer bearing
80	Outer bearing
81	Outer bearing
82	Outer bearing
83	Outer bearing
84	Outer bearing
85	Outer bearing
86	Outer bearing
87	Outer bearing
88	Outer bearing
89	Outer bearing
90	Outer bearing
91	Outer bearing
92	Outer bearing
93	Outer bearing
94	Outer bearing
95	Outer bearing
96	Outer bearing
97	Outer bearing
98	Outer bearing
99	Outer bearing
100	Outer bearing
101	Outer bearing
102	Outer bearing
103	Outer bearing
104	Outer bearing
105	Outer bearing
106	Outer bearing
107	Outer bearing
108	Outer bearing
109	Outer bearing
110	Outer bearing
111	Outer bearing
112	Outer bearing
113	Outer bearing
114	Outer bearing
115	Outer bearing
116	Outer bearing
117	Outer bearing
118	Outer bearing
119	Outer bearing
120	Outer bearing
121	Outer bearing
122	Outer bearing
123	Outer bearing
124	Outer bearing
125	Outer bearing
126	Outer bearing
127	Outer bearing
128	Outer bearing
129	Outer bearing
130	Outer bearing
131	Outer bearing
132	Outer bearing
133	Outer bearing
134	Outer bearing
135	Outer bearing
136	Outer bearing
137	Outer bearing
138	Outer bearing
139	Outer bearing
140	Outer bearing
141	Outer bearing
142	Outer bearing
143	Outer bearing
144	Outer bearing
145	Outer bearing
146	Outer bearing
147	Outer bearing
148	Outer bearing
149	Outer bearing
150	Outer bearing
151	Outer bearing
152	Outer bearing
153	Outer bearing
154	Outer bearing
155	Outer bearing
156	Outer bearing
157	Outer bearing
158	Outer bearing
159	Outer bearing
160	Outer bearing
161	Outer bearing
162	Outer bearing
163	Outer bearing
164	Outer bearing
165	Outer bearing
166	Outer bearing
167	Outer bearing
168	Outer bearing
169	Outer bearing
170	Outer bearing
171	Outer bearing
172	Outer bearing
173	Outer bearing
174	Outer bearing
175	Outer bearing
176	Outer bearing
177	Outer bearing
178	Outer bearing
179	Outer bearing
180	Outer bearing
181	Outer bearing
182	Outer bearing
183	Outer bearing
184	Outer bearing
185	Outer bearing
186	Outer bearing
187	Outer bearing
188	Outer bearing
189	Outer bearing
190	Outer bearing
191	Outer bearing
192	Outer bearing
193	Outer bearing
194	Outer bearing
195	Outer bearing
196	Outer bearing
197	Outer bearing
198	Outer bearing
199	Outer bearing
200	Outer bearing
201	Outer bearing
202	Outer bearing
203	Outer bearing
204	Outer bearing
205	Outer bearing
206	Outer bearing
207	Outer bearing
208	Outer bearing
209	Outer bearing
210	Outer bearing
211	Outer bearing
212	Outer bearing
213	Outer bearing
214	Outer bearing
215	Outer bearing
216	Outer bearing
217	Outer bearing
218	Outer bearing
219	Outer bearing
220	Outer bearing
221	Outer bearing
222	Outer bearing
223	Outer bearing
224	Outer bearing
225	Outer bearing
226	Outer bearing
227	Outer bearing
228	Outer bearing
229	Outer bearing
230	Outer bearing
231	Outer bearing
232	Outer bearing
233	Outer bearing
234	Outer bearing
235	Outer bearing
236	Outer bearing
237	Outer bearing
238	Outer bearing
239	Outer bearing
240	Outer bearing
241	Outer bearing
242	Outer bearing
243	Outer bearing
244	Outer bearing
245	Outer bearing
246	Outer bearing
247	Outer bearing
248	Outer bearing
249	Outer bearing
250	Outer bearing
251	Outer bearing
252	Outer bearing
253	Outer bearing
254	Outer bearing
255	Outer bearing
256	Outer bearing
257	Outer bearing
258	Outer bearing
259	Outer bearing
260	Outer bearing
261	Outer bearing
262	Outer bearing
263	Outer bearing
264	Outer bearing
265	Outer bearing
266	Outer bearing
267	Outer bearing
268	Outer bearing
269	Outer bearing
270	Outer bearing
271	Outer bearing
272	Outer bearing
273	Outer bearing
274	Outer bearing
275	Outer bearing
276	Outer bearing
277	Outer bearing
278	Outer bearing
279	Outer bearing
280	Outer bearing
281	Outer bearing
282	Outer bearing
283	Outer bearing
284	Outer bearing
285	Outer bearing
286	Outer bearing
287	Outer bearing
288	Outer bearing
289	Outer bearing
290	Outer bearing
291	Outer bearing
292	Outer bearing
293	Outer bearing
294	Outer bearing
295	Outer bearing
296	Outer bearing
297	Outer bearing
298	Outer bearing
299	Outer bearing
300	Outer bearing
301	Outer bearing
302	Outer bearing
303	Outer bearing
304	Outer bearing
305	Outer bearing
306	Outer bearing
307	Outer bearing
308	Outer bearing
309	Outer bearing
310	Outer bearing
311	Outer bearing
312	Outer bearing
313	Outer bearing
314	Outer bearing
315	Outer bearing
316	Outer bearing
317	Outer bearing
318	Outer bearing
319	Outer bearing
320	Outer bearing
321	Outer bearing
322	Outer bearing
323	Outer bearing
324	Outer bearing
325	Outer bearing
326	Outer bearing
327	Outer bearing
328	Outer bearing
329	Outer bearing
330	Outer bearing
331	Outer bearing
332	Outer bearing
333	Outer bearing
334	Outer bearing
335	Outer bearing
336	Outer bearing
337	Outer bearing
338	Outer bearing
339	Outer bearing
340	Outer bearing
341	Outer bearing
342	Outer bearing
343	Outer bearing
344	Outer bearing
345	Outer bearing
346	Outer bearing
347	Outer bearing
348	Outer bearing
349	Outer bearing
350	Outer bearing
351	Outer bearing
352	Outer bearing
353	Outer bearing
354	Outer bearing
355	Outer bearing
356	Outer bearing
357	Outer bearing
358	Outer bearing
359	Outer bearing
360	Outer bearing
361	Outer bearing
362	Outer bearing
363	Outer bearing
364	Outer bearing
365	Outer bearing
366	Outer bearing
367	Outer bearing
368	Outer bearing
369	Outer bearing
370	Outer bearing
371	Outer bearing
372	Outer bearing
373	Outer bearing
374	Outer bearing
375	Outer bearing
376	Outer bearing
377	Outer bearing
378	Outer bearing
379	Outer bearing
380	Outer bearing
381	Outer bearing
382	Outer bearing
383	Outer bearing
384	Outer bearing
385	Outer bearing
386	Outer bearing
387	Outer bearing
388	Outer bearing
389	Outer bearing
390	Outer bearing
391	Outer bearing
392	Outer bearing
393	Outer bearing
394	Outer bearing
395	Outer bearing
396	Outer bearing
397	Outer bearing
398	Outer bearing
399	Outer bearing
400	Outer bearing
401	Outer bearing
402	Outer bearing
403	Outer bearing
404	Outer bearing
405	Outer bearing
406	Outer bearing
407	Outer bearing
408	Outer bearing
409	Outer bearing
410	Outer bearing
411	Outer bearing
412	Outer bearing
413	Outer bearing
414	Outer bearing
415	Outer bearing
416	Outer bearing
417	Outer bearing
418	Outer bearing
419	Outer bearing
420	Outer bearing
421	Outer bearing
422	Outer bearing
423	Outer bearing
424	Outer bearing
425	Outer bearing
426	Outer bearing
427	Outer bearing
428	Outer bearing
429	Outer bearing
430	Outer bearing
431	Outer bearing
432	Outer bearing
433	Outer bearing
434	Outer bearing
435	Outer bearing
436	Outer bearing
437	Outer bearing
438	Outer bearing
439	Outer bearing
440	Outer bearing
441	Outer bearing
442	Outer bearing
443	Outer bearing
444	Outer bearing
445	Outer bearing
446	Outer bearing
447	Outer bearing
448	Outer bearing
449	Outer bearing
450	Outer bearing
451	Outer bearing
452	Outer bearing
453	Outer bearing
454	Outer bearing
455	Outer bearing
456	Outer bearing
457	Outer bearing
458	Outer bearing
459	Outer bearing
460	Outer bearing
461	Outer bearing
462	Outer bearing
463	Outer bearing
464	Outer bearing
465	Outer bearing
466	Outer bearing
467	Outer bearing
468	Outer bearing
469	Outer bearing
470	Outer bearing
471	Outer bearing
472	Outer bearing
473	Outer bearing
474	Outer bearing
475	Outer bearing
476	Outer bearing
477	Outer bearing
478	Outer bearing
479	Outer bearing
480	Outer bearing
481	Outer bearing
482	Outer bearing
483	Outer bearing
484	Outer bearing
485	Outer bearing
486	Outer bearing
487	Outer bearing
488	Outer bearing
489	Outer bearing
490	Outer bearing
491	Outer bearing
492	Outer bearing
493	Outer bearing
494	Outer bearing
495	Outer bearing
496	Outer bearing
497	Outer bearing
498	Outer bearing
499	Outer bearing
500	Outer bearing
501	Outer bearing
502	Outer bearing
503	Outer bearing
504	Outer bearing
505	Outer bearing
506	Outer bearing
507	Outer bearing
508	Outer bearing
509	Outer bearing
510	Outer bearing
511	Outer bearing
512	Outer bearing
513	Outer bearing
514	Outer bearing
515	Outer bearing
516	Outer bearing
517	Outer bearing
518	Outer bearing
519	Outer bearing
520	Outer bearing
521	Outer bearing
522	Outer bearing
523	Outer bearing
524	Outer bearing
525	Outer bearing
526	Outer bearing
527	Outer bearing
528	Outer bearing
529	Outer bearing
530	Outer bearing
531	Outer bearing
532	Outer bearing
533	Outer bearing
534	Outer bearing
535	Outer bearing
536	Outer bearing
537	Outer bearing
538	Outer bearing
539	Outer bearing
540	Outer bearing
541	Outer bearing
542	Outer bearing
543	Outer bearing
544	Outer bearing
545	Outer bearing
546	Outer bearing
547	Outer bearing
548	Outer bearing
549	Outer bearing
550	Outer bearing
551	Outer bearing
552	Outer bearing
553	Outer bearing
554	Outer bearing
555	Outer bearing
556	Outer bearing
557	Outer bearing
558	Outer bearing
559	Outer bearing
560	Outer bearing
561	Outer bearing
562	Outer bearing
563	Outer bearing
564	Outer bearing
565	Outer bearing
566	Outer bearing
567	Outer bearing
568	Outer bearing
569	Outer bearing
570	Outer bearing
571	Outer bearing
572	Outer bearing
573	Outer bearing
574	Outer bearing
575	Outer bearing
576	Outer bearing
577	Outer bearing

### ASSEMBLING HYDRAULIC STEERING UNIT- 300 and 500 Transaxle

Before assembling the steering unit, proceed as follows:

- a) Clean all components carefully with petroleum.
- b) Examine all parts for signs of wear or damage.
- c) Inspect either the outer sleeve (F), the inner spool (E) or the body (D) appear to be worn, gear, change the outer hydraulic oil and assembly, inspect for the O-rings.
1. Fasten the body (D) to a work bench and tighten all nuts with clean oil. Carry out the subsequent assembly with absolute cleanliness.
2. Insert the inner sleeve (E) in the outer sleeve (F).
3. Insert the pin (G) through the holes in both sleeves.
4. Place the 8 screws (H) opposite each other on either side. The two bottom screws are fixed internally, and opposite the others.
5. If previously removed, set the outer sleeve and steel sleeve (F).
6. Insert the O-ring (G), making sure it is well centred.
7. Place the washer (I) over the ring (G).
8. Insert the outer bearing (J).
9. Place the pin (L) against (K) with the lower chain-link rivets opposite the bearing.
10. Insert the mounting (M).
11. Insert the outer seal into sleeve assembly. Into the hydrostatic steering unit and make sure that all previously assembled parts are in their respective locations.
12. Insert the bolt (N) in the larger threaded hole and tighten the nut (O).
13. Place the O-ring (P) in the hydrostatic unit body groove.
14. Fit the plate (Q) making sure the holes are correctly aligned.
15. Place the O-ring (R) over the plate (Q).
16. Place the outer ring (S) with the inner (T) over the O-ring (R). The outer ring (S) should be cleaned, then the bolts.



Fig. 38.—Assembling the hydrostatic steering unit.

(F) - Outer sleeve assembly  
(G) - Outer sleeve  
(H) - Hydraulic oil nuts



Fig. 39.—Marking the outer sleeve.

(F) - Outer sleeve  
(G) - Outer bearing  
(H) - Nylon pins  
(L) - Mounting

## 11. Hold the center-shaft as follows:

- a) The hole and SAWI of the center shaft (1.) must be aligned between the holes (2.) on the sleeve (3.).

b) Once well aligned, insert cone to the assembly until it goes no further than one of the slots, and the fork-end (4.) engages the pin (5).

**NOTE:** — It is important that the line (SAW) is perfectly aligned with (SAW). Should this not be the case, the hydrodrive-unit will not operate correctly.

## 12. Place the O-ring (6-Fig. 84)

## 13. Place the spider washer (7-Fig. 84) over the center-shaft

## 14. Place the seal plate (8-Fig. 84) over the entire assembly, holding such that the hole housing the check valve (9) stays lower (10) &amp; vertically (11).

## 15. Tighten the 1 screw with lock-washer (12) securely and tightly. Tighten torque 3.8 kgf.m.




Fig. 84 — Alignment of center-shaft with sleeve

- 1 — Center-shaft
- 2 — Center-shaft
- 3 — Sleeve (see Fig. 84)
- 4 — Fork-end of the center-shaft and fork

Fig. 85 — Assembling the hydrodrive-unit

- A — Check valve ring.
- B — Seal plate.
- C — Hydrodrive-unit base case.



**DEMANTLING THE REAR BEAR/BELL JOINT:**

ADM/T 200 and 300 Two-tone

Removing the rear from the trailer

Please see [Section 1](#)

1. Place the cylinder on a workbench vice.
2. Remove hub (A), washer (B), cover cap (C) and seal pin (D).
3. With an adequate hard punch (E/F), remove the shaft lock pin (F) securing the bell joint (G) to the collector rod.
4. Unscrew the nut (H) and bolt (I) from the rod.
5. Remove the inner cap (J) with the wrench (K) and unscrew the nutlock sleeve (L).

To assemble the rear bell joint, invert the dismantling procedure.

After assembling the bell joint, apply multi-purpose grease through the grease nipple (M).

Fig. M - Exploded view of rear bell joint components

- A - Hub/crank arm
- B - Seal pin or bearing retaining sleeve
- C - Cover cap
- D - Seal pin
- E - Hard pin
- F - Shaft lock pin
- G - Bell joint
- H - Nut
- I - Bolt
- J - Inner cap
- K - Wrench
- L - Nutlock sleeve
- M - Grease nipple

**Front end bell joint:****Removal:**

1. Loosen the nut (N).
2. Unscrew the bolt/cap body (O).

**Assembly:**

1. Screw the bell joint (P) on the axle (Q) to a maximum.
2. Tighten the nut (N) until the bell joint is solid with flared.

**Remark:** — This bell joint is not equipped with a grease nipple; assembly is self-lubricating.



Fig. M - Dismantling the rear bell joint

- (1) - Support bearing housing sleeve
- (2) - Seal pin (D)
- (3) - Hard pin (E)
- (4) - Shaft lock pin (H)




Fig. M - Assembling the front end bell joint onto axle

- (A) - Hub/crank arm
- (B) - Seal pin (D)
- (C) - Bearing housing sleeve
- (D) - Seal pin (D) or bearing retaining sleeve
- (E) - Hard pin (Q)

www.english-test.net

— 1 —

1. Place the cylinder on a work bench vice.
  2. Remove the cylinder base plug (not the split plug).
  3. Walk the tool (CC-Rig) into alignment with the base.
  4. Remove the base plug (R), pulling same outward.

**Tool CC-RIG 004**

  1. Remove from tool joint base (ACO-20).
  2. Remove the front (L) bush split plug (R).
  3. Remove the rear (R) bush split plug (L).

- Put out the rod (W) along with front plug (R2), piston (T) and base cylinder (S).
- Separate the lower cylinder (U) from the front plug (W) and piston (T).
- Disassemble the self-start assembly as follows:
  - Plunge the rod (W) on one side.
  - Unscrew the nut (V).
  - Remove the pins (U) and piston (T).
- Remove the front plug (W) from the rod (W) through the piston hole. Do not attempt to remove same from the opposite side, or this would damage the base cylinder tube and pins moved.




Fig. 21.—Measuring the thickness of the outer envelope.

**ASSEMBLING THE HYDRAULIC RAM**

(Figs. 94C-21-30 to 96)

Carefully clean all cylinder components and change the front and rear seal O-rings. Change the piston rings. Check the remaining components and change same whenever necessary.

1. Insert the front plug (M2) on the rod (P1) on the piston threaded side.
2. Place the piston (P2) on the rod (P1), with the bore measurement.
3. Place the flat washer (A1) on the piston (P2). Tie the piston into position, place the rod in a soft vice and hold the rod by placing a wrench in the flat groove provided for this purpose in the front section.
4. Insert the sleeve (P3) in the lower cylinder (B1), using a long compressor. This can also be done by hand, making sure that the ring gaps are opposite each other.
5. Engage the front plug (M1) in the lower cylinder (B1).
6. Wash the entire lower cylinder assembly (B1) in the outer cylinder (A1), as shown in Fig. 96. Be careful not to damage the front plug O-ring (M2).
7. Insert the rod (P1) as far in as possible in the cylinder.
8. Place the rod (P1) and, by means of the tool (2122), tighten until properly.
9. By means of the pin (E2), block the end (L1) in the outer cylinder (A1).

Fig. 96 - Tie the piston into position

A - Outer cylinder  
L - Front plug  
E2 - Tie-off tool



Fig. 96 - Assembly of the lower cylinder into the outer cylinder

E - Tie-off tool  
A1 - Outer cylinder  
B1 - Piston  
P1 - Rod  
M1 - Front plug



Fig. 94C-21-30 - Lowering the lower cylinder assembly into the outer cylinder

J - Outer cylinder  
M2 - Front O-ring  
P1 - Tie-off tool  
B1 - Lower cylinder  
M1 - Front plug



10. In the outer end of the cylinder bore wall(s), insert the rear plug (I), as shown in Fig. 66.

Fig. 66 - Assembling rear plug (I) in cylinder

I1 - Rear plug  
I - Bearing  
J - Rear cylinder



11. Place the rear plug (I) and rings (D) properly with the seal (C).
12. With the pin (G) hold the rod (H) in the outer cylinder (L).

Fig. 67 - Holding rear plug (I)

I - Rear cylinder  
J - Outer cylinder  
C - T1-891-001

13. Fill the cylinder rear bore (J).



## TROUBLESHOOTING TABLE

PROBLEM	CAUSE	REMEDY
STEERING SYSTEM HAVING HARD TURNING STEERING WHEEL	1. Faulty pump. 2. A leak at the hydraulic unit. Check valve or valve belt missing. 3. Pressure relief valve is safety tank block in open position. 4. Broken or pressed pressure relief valve seating.	1. Repair the pump. 2. Mount the ball with a leak, since the emergency unit assembly can be checked separately. 3. Repair the relief valve assembly. 4. Change steering column. If the bearing can be removed, change same.
STEERING WHEEL TURNED CONTINUOUSLY WITHOUT HOLDING NEUTRAL POSITION	1. The oil pressure settings do not match the creature or the motor.	1. Disassemble the hydraulic sys and change the oil pressure settings.
VIBRATION BY THE DRIVE WHEELS	1. Air in hydraulic cylinder. 2. Wear on steering linkage.	1. Bled the circuit and eliminate the cause of air intake. 2. Change steering columns.
STEERING WHEEL CAN BE TURNED INDEFINITELY	1. Lack of oil in reservoir. 2. Faulty hydraulic cylinder. 3. Faulty hydraulic unit. 4. Incorrect leak between hydraulic unit and outer supply hose.	1. Fill to 14-40. 2. Change or repair cylinder. 3. Replace, clean and reassemble or change O-Rings. 4. Change O-Ring assembly.
THE DRIVEN WHEELS ARE TURNED IN JERKS	1. Incorrect fitting of leader shaft and hydraulic unit.	1. Disassemble the unit and reassemble per part.

PROBLEM	CASE	REASON
WHEELS TURN FEE SlowLY	<ol style="list-style-type: none"> <li>1. Insufficient amount of oil in pump.</li> <li>2. Faulty Grease Gun.</li> </ol>	<ol style="list-style-type: none"> <li>1. Increase pump output speed.</li> <li>2. Change or repair hydrostatic unit.</li> </ol>
HYDRAULIC MOTOR DOES NOT RETURN TO NEUTRAL POSITION. HYDROSTATIC UNIT FAILS TO ACT AS AN ENGINE	<ol style="list-style-type: none"> <li>1. Air valve or inequality between the outer and inner hoses.</li> <li>2. Low-compression road between outer and inner hoses, due to excessive pressure.</li> </ol>	<ol style="list-style-type: none"> <li>1. Remove hydrostatic unit from tractor and clean or change them along with the hydrostatic unit. Clean circuit completely and add new oil.</li> <li>2. Place a pressure gauge on master circuit and check pressure. Change relief valve whenever necessary.</li> </ol>
WHEELS TURN DIFFERENTLY. WHEELS TURN ONLY IN ONE DIRECTION	<ol style="list-style-type: none"> <li>1. Equipment leak in hydrostatic unit.</li> <li>2. Uneven level of piston within the hydrostatic cylinder.</li> </ol>	<ol style="list-style-type: none"> <li>1. Repair or change hydrostatic unit.</li> <li>2. Repair or change cylinder.</li> </ol>
GEAR SEIZE IN UPPER OR LOWER SECTION OF HYDROSTATIC UNIT	<ol style="list-style-type: none"> <li>1. Damaged sealing ring at lower side of hydrostatic unit.</li> <li>2. Hydrostatic base transmission.</li> <li>3. Delpolymer spheres and O-rings.</li> </ol>	<ol style="list-style-type: none"> <li>1. Disassemble hydrostatic unit and change ring.</li> <li>2. Replace the bottom section of gear to 2 inches of 2.5 mm.</li> <li>3. Change sealants and O-rings.</li> </ol>

## SECTION 4:

# ENGINE D3.152

### INDEX

Specifications	1
Descriptions	2
Trouble-shooting chart	3
Flame arrestor	4
Valve lock adjustment	4
Reactor arm shaft	4
Servicing reactor arm shaft	5
Intake manifold	5
Exhaust manifold	5
Valve settings	6
Cylinder head	8
Servicing cylinder head	7
Replaceable valve seats	9
Timing case cover	10
Timing gear	10
Camshaft	12
Timing case	12
Pivthead	13
Pivthead ring gear	13
Pivthead housing	13
Overdriveshaft rear bearing	14
Engine maincase	15
Oil pump	15
Servicing oil pump	16
Connecting rod big end bearings	17
Pistons and connecting rods	18
Servicing pistons and connecting rods	19
Cylinder liners	20
Camdriveshaft thrust half bearings	21
Camdriveshaft	22



**SPECIFICATIONS****ENGINE**

<b>Model and type</b>	Penta four stroke, direct diesel injection.
<b>Model</b>	SK 102
<b>Number of cylinders</b>	11
<b>Diameter of cylinders</b>	81.60 mm
<b>Stroke</b>	121 mm
<b>Displacement</b>	3,800 cm <sup>3</sup>
<b>Compression ratio</b>	16.5 : 1
<b>Concentric valve</b>	874. P. at 2,200 r.p.m. of engine.
<b>Power</b>	17.5 kgf/m or 1,000 N.p.m. of engine.
<b>Maximum torque</b>	2,200 r.p.m. under load; 2,200 r.p.m. no load and 650 ± 50 r.p.m. 140 kgf
<b>Maximum speed</b>	By gears.
<b>Timing system</b>	Built in a single high strength polymer casting.
<b>Cylinder block</b>	This heat casting
<b>Type of liner</b>	Cast iron.
<b>Carburetor</b>	Cast iron with extensive water cooling channels.
<b>Cylinder head</b>	Cast iron with hardened seats. Located in the top right-hand part of the block.
<b>Camshaft</b>	Molybdenum chrome forged steel with high frequency induction treated bearings.
<b>Camshaft housing</b>	H-beam forged steel.
<b>Connecting rod</b>	Aluminum alloy with separate machined head. Provided with one oil control and three intermediate rings.
<b>Piston</b>	In cylinder head, secured by camshaft by means of push rods and saddle seats.
<b>Valves</b>	
<b>Lubrication system</b>	
<b>Type</b>	Low pressure through valve driven oil pump.
<b>Oil flow</b>	Full flow, restricted on block with integrated body and filter.
<b>Oil pump capacity</b>	8.1 liters/h.
<b>Minimum pressure in oil line</b>	2.01 kg/cm <sup>2</sup> or 2,200 r.p.m. of engine and 1.2 kg/cm <sup>2</sup> 140 kgf with oil temperature in filter of 20 to 30°C.
<b>Pump excess pressure valve</b>	Piston type.
<b>Valve operating pressure</b>	3.6 to 4.0 kg/cm <sup>2</sup> .
<b>Filter bypass valve</b>	EM type.
<b>Valve opening differential pressure</b>	0.01 to 1.2 kg/cm <sup>2</sup> .
<b>Lubricant</b>	See general information.

## DESCRIPTION

The Perkins 1107/120 engine is of the three cylinder, water-cooled, direct diesel injection type. The total bore diameter of the cylinders is 117.44 mm and the stroke is 123 mm.

The engine has overhead valves mounted centrally in the cylinder head. The camshaft, located in the right-hand part of the cylinder block, is driven by a timing gear. The camshaft, in turn, actuates the valves by way of the rockers and rocker arms.

The cylinder block is a single piece of grey-iron casting which strength,

the气缸平面 have slotted blocks and four rings. The plates are coupled to their connecting rods by plain pins covered with shields. The connecting rod big end bearings are babbit coated and are made up of a shell of cast copper held in an iron sleeve bearing shell.

The engine has force feed lubrication. The oil is pumped up from the sump through the sump line by means of a rotary pump driven by the camshaft. The oil passes through the filter before circulating under pressure through the engine.

The crankshaft has five bearing points with their corresponding bearings. It is supported by bearing caps and its axial location is controlled by three half bushes located on the rear bearing.

## TROUBLE-SHOOTING CHART

TROUBLE	Possible cause
No visible operating speed.	1, 3, 3, 4, 5, 6, 7, 8, 9, 10, 11, 13, 14, 16, 18, 19, 20, 23, 21, 32,
The engine does not start.	8, 7, 9, 11, 13, 14, 15, 16, 18, 19, 20, 21, 22, 24, 21, 32, 33,
Difficult starting.	10, 11, 12, 14, 16, 18, 20, 21, 23, 24, 26, 27, 28, 29, 31, 33,
Lack of power.	10, 15, 14, 18, 19, 22,
Excessive fuel consumption.	10, 16,
Black exhaust smoke.	11, 13, 14, 18, 19, 20, 24, 27, 32,
Blue/water exhaust smoke.	8, 23, 26, 28, 29,
Loss of pressure.	4, 26, 27, 28, 29, 40, 42, 43, 44,
Engine knocking.	8, 14, 15, 16, 18, 22, 23, 25, 26, 48, 49, 46, 47,
Unusual running.	7, 8, 9, 11, 12, 13, 14, 16, 21, 23, 28, 31, 33, 46, 48,
Vibration.	13, 14, 23, 26, 46, 47, 48,
Excessive pressure.	4, 51,
Engine overheating.	18, 20, 28, 46, 50, 51, 53, 50, 54, 53,
Excessive pressure in carburetor.	28, 31, 32, 34, 35, 36,
Low compression.	16, 30, 34, 33, 31, 38,
Engine runs up and stops.	10, 11, 12,

## Trouble-shooting list

1. Battery charge low.
2. Poor electrical connections.
3. Starter motor faulty.
4. Missing grade of oil.
5. Insufficient operating speed.
6. Fuel tank empty.
7. Control contact operating.
8. Fuel feed pipe blocked.
9. Fuel pump faulty operation.
10. Fuel filter blocked.
11. Air cleaner blocked.
12. Air to fuel system.
13. Faulty injection pump operation.
14. Injector faulty.
15. Incorrect use of molten metal system.
16. Failure in cold-start system.
17. Injectors pump control broken.
18. Injectors pump setting incorrect.
19. Valve adjustment incorrect.
20. Gear transmission.
21. Tandem breather blocked.
22. Wrong type or grade of fuel.
23. Accelerator linkage sticking.
24. Inlet air pipe return blocked.
25. Leaking in cylinder head gasket.
26. Overheating.
27. Operating temperature exceed 90°.
28. Oil/kerosene purity violated.
29. Stability violation.
30. High pressure pipe blocked.
31. Water cylinders.
32. Valve seat seats tilted.
33. Plenum-chamber basket, seats or stems.
34. Valve stems and guides worn.
35. Injector specified air entering grade of oil.
36. Bearings worn or damaged.
37. Distributor Main Block.
38. Oil pump worn.
39. Pressure relief valve stays open.
40. Pressure relief valve stays closed.
41. Relief valve spring broken.
42. Diaphragm flexible pipe defective.
43. Oil filter clogged.
44. Plenum rest too tight.
45. Incorrect piston height.
46. Pin damaged.
47. Valve spring broken.
48. Plenum body balanced or wrongly assembled.
49. Thermostat faults.
50. Blockage in the cylinder block outlet cylinder head water jacket.
51. Fan belt slack.
52. Radiator blocked.
53. Water pump faults.
54. Shoulder pipe blocked.
55. Valve stem retainer/cracks.
56. Control lever too low.

**ROCKER COVER****Dismantling**

1. Park hood.
2. Disconnect breather pipe.
3. Remove rocker cover bolts nuts and washers.
4. Take off rocker cover.
5. Remove gasket.


**Assembly**

6. Reverse operations 1 to 5, except:
  - a) Grease piston lightly with suitable grease.
  - b) Before assembling rocker cover:
  - c) Do not over-tighten rocker cover bolts nuts.

**LASH ADJUSTMENT VALVE**

The valve lash  $\Delta$  measured between the rocker arm and support and has to be adjusted to 0.254 mm hot or 0.308 mm cold. For this, carry out the following operations:


1. Disassemble rocker cover.
2. Turn camshaft's left end (number 1 piston level T.O.A.) and the valves of the cylinder numbered.
3. Adjust clearance of numbers 1, 2, 3 and 8 valves.
4. Turn camshaft 200° (one full turn).
5. Adjust clearance of numbers 6 and 7 valves.
6. Assemble rocker cover.

**ROCKER ARM SHAFT****Dismantling**

1. Disassemble rocker cover.
2. Cleanse any water drain oil leak line orifice.
3. Remove rocker shaft fixing nuts and washers.
4. Withdraw complete rocker shaft.

**Assembly**

5. Reverse operation 2 to 4.
6. Adjust valve clearance.
7. Assemble rocker cover.



**SERVICING ROCKER ARM SHAFT****Dismantling**

1. Disassemble rocker arm shaft.
2. Remove cylinder head and end of shaft.
3. Remove shaft support.
4. Remove rocker arm.
5. Remove long spring.
6. Remove rocker arm.
7. Remove sleeve.
8. Remove shaft capsule.
9. Bend caps off.
10. Remove rocker arm.
11. Remove short spring.
12. Repeat operations 2 to 11 to complete dismantling of rocker shaft.
13. Remove all feed pipe and valves are broken, if rocker arm bushes are noisy, replace rocker arms.

**Assembly**

14. Reverse operations 1 to 13, EXCEPT:
  - a) Check that all parts are clean and lubricated with engine oil before assembling.
  - b) Fit both ends of the rocker arm shaft housing as shown in diagram 140.

**INTAKE MANIFOLD****Dismantling**

1. Remove head.
2. Disconnect exhaust header pipe.
3. Disconnect cold-start header feed pipe.
4. Release intake pipe (2).
5. Remove cooling tube and weather.
6. Take off manifold, or the same that mounting is from intake header pipe.
7. Remove and discard gasket.

**Assembly**

8. Install a new gasket.
9. Reverse operations 1 to 6.

**EXHAUST MANIFOLD****Dismantling**

1. Raise hood.
2. Remove exhaust pipe flange nuts.
3. Remove flange nuts and washers.
4. Withdraw exhaust manifold.
5. Remove and clean gasket.

**Assembly**

6. Install new gaskets.
7. Reverse operations 1 to 4.

**VALVE SPRINGS****Dismantling and assembly**

1. Disassemble rocker arm shaft.
2. Turn camshaft until piston number 1 piston is at T.B.C.
3. Compress valve springs 1 and 2 in housing with tools K138.01 and K138.02.
4. Remove collets.

**NOTE:** - Do not turn the camshaft again until the valves have been re-assembled and secured with their collets.

5. Remove dogs from springs.
6. Remove springs.
7. Remove spring seats.
8. Check free length of springs. This must be between 19.58 and 20.04 mm.
9. Set seats 1 and 3 in place and reassemble or replace springs, as required.
10. Reverse operations 4 until:
11. Turn camshaft until piston number 2 is at T.B.C.
12. Repeat operations 3 to 9 for valves numbers 3 and 4.
13. Turn camshaft until piston number 2 piston is at T.B.C.
14. Repeat operations 3 to 8 for valves numbers 5 and 6.
15. Assemble rocker arm shaft.

**CYLINDER HEAD****Dismantling**

1. Drain cooling system.
2. Disassemble head.
3. Disassemble rocker arm shaft.
4. Disassemble exhaust and inlet manifolds.
5. Disassemble High-pressure injection pump.
6. Disassemble injectors and nozzles.
7. Disassemble radiator cap, base and connection from between the thermostat housing and water pump.
8. Disconnect external oil-feed pipe.
9. Remove cylinder head nuts and take bolts in reverse order to the tightening sequence.
10. Take off cylinder head.
11. If necessary, remove thermostat casting.

**Assembly**

12. Perform operations 1 to 11, reverse:
  - a. Insert a new gasket on the cylinder head with new coat of sealing paste.
  - b. Seal off a new gasket on the thermostat casting if it has lost disassembly.



- a. Tighten up the cylinder head fixing bolts and nuts in the correct order, in three uniform stages, to a torque of 10 Kg m. (4.1 lb ft).
12. Bleed fuel system.
13. Start up engine and run it at approximately 1,200 r/min. for two minutes until normal working temperature is reached. Stop engine.
14. Disassemble rocker shaft.
15. Tighten nuts under head fixing bolts and nuts to correct sequence to a torque of 10 Kg m.
16. Assemble rocker shaft.
17. Start up engine and check that there are no leaks.



### REASSEMBLING CYLINDER HEAD

#### Dismantling and assembly

1. Dismantle cylinder head.
2. Dismantle valve springs.
3. Place cylinder head on its side and remove valves.

**NOTE:** — Keep valves in order to which they were assembled.

4. Loosen mounting.
5. Remove bolt and camshaft.
6. Remove push rod.
7. Repeat operations 4 to 6 for the remaining push rods.
8. Dismantle rear plate and its guides from cylinder head.
9. Clean all cylinder head openings, leaving them free of paint or other debris.
10. If there are excessive deposits in the cylinder head water passages, the use of cleaner EBRD Ref. A-93 is recommended.
11. Check for wear on both surfaces of valve guides.
12. If necessary, dismantle valve guides with tool PD 1-C.
13. Install new guides with tools PD 1-C and PD 1-C. Make sure guides are assembled correctly. Both ends are bevelled one to 45° and the other to 20° (the 20° end is also recessed). The 20° end must be inserted into the cylinder head through the top until the opposite end (45° bevel) stands not 14.00 to 15.00 mm above the top surface.
14. Check for excessive pitting or wear on valve seats.
15. If necessary, grind valve seats with the following tools: milling tools, profile cutter for valve seat valve seats, another one for those of inlet valves and the centre head. Grind as little metal as possible, polish well and ensure perfect seating.



16. Carefully clean all valves and check that they are not puffed, bent or bent.
17. If necessary, polish the valve stems with a grinder to an angle of 30°, taking off as little metal as possible and providing a sufficiently smooth finish.
18. Carefully clean valves and lubricate stems with engine oil.
19. If necessary, bend ground valves and respective seats until oil piping is removed and a good seating is obtained.
20. Carefully wash cylinder head and valves with clean gasoline and dry.
21. Check depth of valve travel with respect to cylinder head surface. This depth must be between 1.340 and 1.500 mm for inlet valves and between 1.325 and 2.100 mm for exhaust valves.
22. If the valve exceeds these limits, it must be replaced. Check valve lead (depth) again and if it is still basic (not left within the specified limit), a replaceable seat must be installed (only for exhaust valves). If it is an inlet valve which does not comply with the limits, the cylinder head has to be replaced.
23. Check that cylinder head surface is clean and, if necessary, place it to a thickness of about 0.03 mm bearing in mind that the lifterbox is not to exceed not more than 8.827 mm. This measurement must not be attained by working additional elsewhere.
24. Carefully clean cylinder head.
25. Reverse operations 1 to 6, except:
  - a) aluminum valves in their correct positions.
  - b) Lightly coat new piston gaskets with suitable sealing paste, as well as threads of the piston ring bolts.



**REPLACEMENT VALVE SEATS****Assembly procedure:**

Replaceable valve seats may only be assembled to EXAMAGIT valves and only as a last resort to extend cylinder head service life.

The assembly of replaceable valve seats is a precision operation and should therefore only be carried out by specialist personnel.

This operation must never be performed with a valve/vane guide in still assembled.

1. Remove cylinder head.
2. Using a valve guide housing as center, machine cylinder head surface flat according to instructions given.

**NOTE.** — Work as close as possible to maximum machining dimensions to allow for a possible later re-machining.

3. Remove machining rings and clean replaceable seat housing.
4. Using valve guide housing, set valve seat in place by means of an insertion tool made to the given measurements.

**NOTE.** — Replaceable valve seats must not be force-fitted into place nor lubricated.



5. Check that the replaceable valve seat is fully inserted into its housing and is on a level with the lower part of the cylinder head valve.
6. Reassess machining wear and rings and, if necessary, machine cylinder head surface.
7. Clean valve seat at a vertical angle of 15° so that after grinding the depth of the valve head below the cylinder head surface (see between 1.025 and 1.033 mm (production limit), for exhaust valves).

**KEY TO FIGURE 2**

- A. 7.30 to 7.32 mm.
- B. 41.00 to 42.54 mm.
- C. 0.00 mm max. tolerance.

**KEY TO FIGURE 4**

- A. 66.00 mm.
- B. 68.00 mm.
- C. 10.00 mm.
- D. 7.00 to 7.07 mm.
- E. 1.5 mm at 45°.
- F. 1.0 mm at 45°.
- G. 0.8 mm.
- H. 30.00 to 30.00 mm.
- I. 5.00 to 5.40 mm.
- J. 40.77 to 41.02 mm.



**TIMING CASE COVER****Dismantling**

1. Disconnect the breather between front cylinder engine and disassembly nozzle pump.
2. Remove bolt and nuts.
3. Remove crankshaft pulley.
4. Disconnect alternator cables.
5. Disconnect air intake and its support brackets.
6. Remove flywheel flange.
7. Remove bolts securing timing case cover.
8. Remove lifting tools.
9. Remove end covers.
10. Remove seal.

**Assembly**

11. Assemble seal.
12. Insert seal with a new gasket coated with anti-sealing paste.
13. Place pulley on crankshaft (cautiously to avoid damaging bearing), so as to center bearing and pulley.
14. Put on and tighten bolt 30800-30-00 to remove cover and remove cylinder.
15. Install remaining bolts and washers in position.
16. Reverse operations 1 to 8, except:
  - a) Tighten pulley fixing bolt to a torque of 15 kg m.

**INTERMEDIATE GEAR AND HOUSING****Dismantling**

1. Disassemble timing case cover.
2. Turn mainshaft until the marks on the intake pulley, crankshaft and intermediate gear are lined up with those of the intermediate gear.
3. Remove lock plate.
4. Remove bolt.
5. Remove lock washer.
6. Remove intermediate gear.
7. If necessary, disassemble intermediate gear hub.

**Assembly**

8. Assemble gear hub, making sure the sleeve is fitted into the hub using slide.
9. Assemble gear, making sure that gear marks are lined up.
10. Reverse operations 4 to 6, except:
  - a) Tighten bolt to a torque of 15 kg m.
11. Check intermediate gear axial play, which should be between 0.18 and 0.38 mm.
12. Reset lock plates prior one of the locking flats.
13. Assemble timing case cover.

**Crankshaft gear****Dismantling**

1. Disassemble intermediate gear.
2. Remove fixing bolts and washers.
3. Remove gear.

**Assembly**

4. Reverse operations 2 and 3, except:
  - a) Make sure that bearing housing and end of cam-shaft are in line.
5. Assemble intermediate gear.

**Injection pump gear****Dismantling**

1. Disassemble intermediate gear.
2. Remove fixing bolts and washers.
3. Remove gear.

**Assembly**


4. Reverse operations 2 and 3, except:
  - a) Make sure that gear dowel is housed in pump body slot.
  - b) Tighten bolts to a torque of 2 N.m.
5. Assemble intermediate gear.

**Cam-shaft gear****Dismantling**

1. Disassemble intermediate gear.
2. Remove plug.
3. Remove cam-shaft gear.
4. Remove key, if necessary.
5. Take off spacer, if necessary.


**Assembly**

6. Reverse operations 2 to 5.
7. Assemble intermediate gear.



**CAMSHAFT****Dismantling**


1. Disconnects rocker arm shaft.
2. Disconnects cam-shaft gear.
3. Disconnects fuel thermo.
4. Raise engine.
5. Disassemble cam-shaft and gear through them of engine, taking care that the cams do not damage the bearings.
6. Remove bolts and washers.
7. Remove gear.

**Assembly**

1. Reverse operations 8 to 1, except:
- a) When assembling, make sure the teeth on the gear and shaft mesh up.
- b) Assemble intermediate gear.
- c) Assemble rocker arm shaft.

**TOURER CASE****Dismantling**

1. Disconnects carburetor.
2. Disconnects injection pump gear.
3. Disconnects injection pump.
4. Disconnects engine cover.
5. Remove the two bolts and washers.
6. Remove bottom cover of case.
7. Remove King bolts and nuts.
8. Remove body-gears.
9. Remove intake-filter gear hub.
10. Remove and place gear.

**Assembly**

11. Assemble intermediate-gear hub.
12. Install a new gasket; lightly install with outside sealing paste.
13. Reverse operations 7 and 8.
14. Install bottom cover, making sure that the four holes of the cover and base-gears are lined up.
15. Reverse operations 3 and 4.
16. Assemble injection pump gear.
17. Assemble carburetor.



**FLYWHEEL:****Dismantling:**


1. Dismantle flywheel.
2. Remove the oil bolts and lock plates.
3. Remove flywheel.

**Assembly:**

4. Reverse operations 2 and 3, except:
  - a. Locate flywheel on flywheel flange so that the unfastened hole of flange flange up with the flywheel hole with no bolt.
  - b. Tighten flywheel bolts to a torque of 10 kg m and secure them with new lock plates.
5. Reassemble flywheel.

**FLYWHEEL-RING GEAR:****Dismantling:**

1. Dismantle flywheel.
2. Drill a hole 5 mm in diameter and up to a depth of only 10 mm below-toe (the flywheel could be damaged) at midway point between inner diameter of ring gear and base of one of its teeth.
3. Place a cold chisel at base of tooth, above the hole.
4. Cover flywheel and cutting point with a brick, work on a hammer. Now fragments that might fly off.
5. Hold flywheel and remove cold chisel firmly to split ring gear.

**Reassembly:**

6. Hold ring gear to a temperature of about 40°C (104°F, 104°F) A (110°F/40°C).
7. Place ring gear on flywheel with teeth entry guide towards front of flywheel, quickly fit ring gear into its housing until it rest firmly.
8. Assemble flywheel.

**FLYWHEEL HOUSING:****Dismantling:**

1. Dismantle flywheel.
2. Remove bolts and washers.
3. Remove screws.
4. Remove bearing front cap.

**Assembly:**


5. Reverse operations 2 to 4, except:
  - a. Make sure that flywheel housing and engine block surfaces are mechanically clean.
  - b. Lightly coat both elements with an appropriate mounting paste.
6. Assemble flywheel.

**CRANKSHAFT BEARING RETAINER****Dismantling**

1. Dismantle flywheel housing.
2. Remove bolts and washers.
3. Remove retainer housing together with seal.
4. Remove and discard gasket.
5. Remove retaining ring from flywheel.

**Replacement**

6. In reassembly, the flywheel is assembled with its flat face-alignment line on surface of flywheel bearing, countersink flange end. If it is correct, the rear retainer must be inserted further into the housing than it should be inserted 2.3 mm and, if necessary, a former 3.2 mm, making 5.4 mm total. If these spacings should not be sufficient, the countersink flange contact surface has to be machined.
7. Lubricate retainer and flywheel housing with clean engine oil. Please immerse in flywheel housing to the required depth with tool FD 1481.
8. Insert a new gasket tightly connected with suitable sealing paste.
9. Lubricate retainer, countersink flange and tool FD 1482 with clean engine oil.
10. Using tool FD 1482, install retainer assembly and its housing. Make sure that it is correctly engaged on the block hole.
11. Remove tool FD 1482.
12. Reassemble tool 1480/2.



**ENGINE CRANKCASE****Disassembly**

1. Disconnect trunnions between front side and engine.
2. Remove plug from carburetor and drain oil. Cool it in a suitable container.
3. Remove bolts and nuts.
4. Remove side and topshields.
5. Support carburetor and various bolts and washers.
6. Separate trunnion from block.
7. Remove and discard gasket.

**Assembly**

8. Reverse operations 1 to 6, noting:
  - a) Check that contact surfaces are clean.
  - b) Fit new gaskets, lightly smeared with suitable sealing paste.
  - c) Fill crankcase on the correct level with specified engine oil.

**OH, PUMP****Disassembly**

1. Disassemble engine crankcase.
2. Disassemble timing case cover.
3. Remove timing-case lockbar cover.
4. Disconnect pump pressure pipe.
5. Remove stalks and intermediate gear.
6. Remove bolt and washer.
7. Withdraw cover.

**Assembly**

8. Reverse operations 1 to 7.



**BUSHING OIL PUMP****Disassembly**

1. Disassemble oil pump.
2. Take out piston.
3. Remove cover.
4. Remove O-ring seal.
5. Check clearance at all points between maximum diameter of tapered bore and minimum diameter of tapered rods. If clearance exceeds 0.100 mm., a new oil pump piston must be installed.
6. Check clearance between tapered neck and pump rods. If clearance exceeds 0.002 mm., a new pump must be installed.
7. Check clearance between top of piston and pump body. If clearance exceeds 0.200 mm., a new oil pump piston must be installed.
8. If necessary, take out center pin.
9. Remove plug.
10. Remove spring.
11. Remove safety valve.
12. If necessary, disassemble gear with tools FJ 100 and FD 150-4A.  
Check the mesh or damage in parts and replace if necessary.

**Assembly**

13. Reverse operations 8 to 12 and 1 to 6, except:  
at insert primary gear with flat face towards  
shaft so it does not hit end of shaft. Then  
press shaft key fits into gear housing.
14. Insert a bearing.



**CONNECTING ROD END BEARINGS****Disassembly**

1. Disassemble oil pump.
2. Turn crankshaft until bearing to be disassembled is at 6 o'clock.
3. Remove main base cap and bolts.
4. Remove big end cap together with half bearing.
5. Remove half bearing from cap.
6. Take out big end bolts.
7. Turn crankshaft until upper half bearing can be removed.
8. Repeat operations 2 to 7 to disassemble remaining bearing.


**Note:** If half bearing has been re-used, if one should be held, replace complete set.

**Check:** For wear or ovalization associated with a misalignment. The diameter of journal should be checked both on a horizontal and vertical plane and at both ends.

Wear and ovalization must not exceed 0.0001 in. If above this limit, the crankshaft must be ground or replaced.

**Assembly**

9. Reverse operations 7 to 8, noting:
  - a) Check that all components are machined clean and lubricated with clean engine oil specified.
  - b) Make sure half bearing base fit in connecting rod slot but that they are correctly assembled to their original positions.
  - c) The connecting rod caps and bolts are special and whenever they are replaced this must be with ones supplied by the engine manufacturer.
  - d) Make sure that base of bolt heads is seated correctly in connecting rod shoulder.
  - e) Check that connecting rod and big end base cap are assembled with matching identification marks and in left side of engine.
10. Tighten big end bolts to a torque of 7 kg m (60 ft-lb).



**PINTLES AND CONNECTING RODS****Dismantling**

1. Dismantle cylinder head.
2. Dismantle big end bearings.
3. Withdraw piston and connecting rods through top of cylinder.

**Assembly**

Check condition of piston, rings and liners and if it is not of inspection, replace them.

- A. Clean all parts carefully and lubricate them with clean engine oil specified.

**NOTE:** Please ring on piston in such a way that gap in each ring is at 180° in relation to the previous one.

- B. With tool 3883, insert each piston and connecting rod into the top part of its respective cylinder. Take note that the word «FRONT» is printed front of piston.
- C. Assemble big end bearings for without interference.
- D. Check height of each piston with tool P0418. At 601.32 mm the piston must be 0.000 to 0.010 mm below top surface of block.
- E. Assemble oil ports.
- F. Assemble cylinder head.



### REMOVING PISTONS AND CONNECTING RODS

#### Disassembly


1. Disassemble pistons and rods.
  2. Remove rings from each piston.
  3. Remove wrist pin from each piston.
  4. Heat piston in a clean liquid to a temperature of 95 to 100°.
  5. Carefully remove piston pins.
  6. Remove carbon deposits from piston pin bore and connecting ring grooves.
  7. Prepare piston for reaming.
  8. Check piston rods adjustment.
  9. If necessary, remove small rod bushes.
  10. Place rings in slots, assembly parts at top of cylinder and check gap.
- Note:** The gaps used for reassembly:  
 Rod piston rings:  
 1st ring: 0.00 to 0.06 mm.  
 2nd, 3rd and 4th rings: 0.26 to 0.46 mm.  
 Connecting piston rings:  
 1st, 2nd and 3rd rings: 0.26 to 0.46 mm.  
 4th ring: 0.05 to 0.40 mm.
11. After installing new rings, check vertical clearance of piston. This clearance must be between:  
 Rod piston rings:  
 1st and 2nd-degree: 0.17 to 0.30 mm.  
 2nd ring: 0.040 to 0.200 mm.  
 3rd ring: 0.050 to 0.080 mm.  
 Connecting piston rings:  
 1st and 2nd rings: 0.58 to 0.88 mm.  
 3rd ring: 0.080 to 0.200 mm.  
 4th ring: 0.020 to 0.030 mm.

#### Assembly

12. If necessary, install new small rod bushes, bring up bush lubrication hole with a screwing tool and end.
13. With rod 208, check that each rod is perpendicular and parallel. If there is any distortion, it MUST BE REPAVED.
14. Heat piston in a clean liquid, assemble connecting rods in their respective piston and insert piston pins.

**NOTE:** The piston head carries a rib supported transversely near of its sides. Clean air pressure to connecting rods with cavity towards connecting rod and big end cap film ribbed areas.

15. Install new oil seals on each piston pin.



## 16. Starting from the top, install rings in the following order:

- 1st: Engine ring.
- 2nd: Internally-ribbed compression ring.
- 3rd: Internally ribbed compression ring.
- 4th: Anti-explosive expander ring.


**NOTE:** The internally ribbed compression rings must be placed with step towards piston head. Place rings in such position so that the gap of one ring is at TDC in relation to the previous ring.

## 17. Assemble piston rod connecting rods.

## CYLINDER LINERS


## Disassembly

1. Disassemble piston and rod.
2. Remove liner from cylinder block.
3. With tool FD 100 withdraw expander and hollow hydraulic cylinder, extract liner from cylinder through bore of liner.



## Reassembly



1. Reverse operations 1 to 3, except:
- a) Cylinder liner should be handled and stored with care. The slightest defect or burr could cause considerable damage when assembled in bore.
- b) Care! Two faces with flange should not be ground but have to be replaced by new ones if damaged.
- c) Before inserting a new liner, soak this and the corresponding cylinder should be normally cleaned, especially the groove at top of cylinder where the flanges locate.
- d) All parts should be completely lubricated before assembly with clean engine oil.
- e) Check that flange of each liner does not pull the housing at top of cylinder out of shape.
- f) When it is necessary to move the top of each liner, move it between 0.000 and 0.008 mm below top face of block.
- g) Check condition of piston and if at all worn, replace liner.
- h) Install a set of new rings.
- i) Allow a settling in period before checking inside diameter of liners.
- j) Each liner must be checked in three positions: upper, middle and lower; the readings must be taken both transversely and radially to center line of block.



## CRANKSHAFT THRUST HALF WASHERS

### Disassembly and replacement:

1. Disconnect clutch.
  2. Push crankshaft backwards and check side clearance between thrust half-washer and mainshaft. The clearance should be between 0.000 and 0.080 mm.
  3. If side play does not lie within these limits, proceed as follows:
  4. Disassemble crankshaft rear bearing.
  5. Take out the two lock washers.
  6. Remove rear main bearing cap together with two lower thrust half-washers.
  7. Push the two upper half-washers with a wire until they can be withdrawn.
  8. Break off the lockwashers.
  9. Before re-assembling, lubricate all components with clean engine oil.
  10. Place the two new upper thrust half-washers in crank housing units (left hand crankshaft half bearing).
  11. Place the two new lower thrust half-washers in rear mainbearing cap and assemble it.
  12. Put the lock washers and tighten them to a torque of 18 kg cm.
  13. Check crankshaft axial play again.
  14. If axial play is still not correct, larger size lower half-washers may be required. Please consultors S to T.
- NOTE:** Both upper and lower thrust half-washers have to be of the same thickness.
15. Re-assemble rear bearing.
  16. Assemble crankcase.



**DISASSEMBLY****Disassembly**

1. Drain engine oil.
2. Disconnect engine from exhaust system.
3. Separate bearing between front side and engine and cylinder block and gearbox.
4. Disassemble timing case.
5. Disassemble big end bearings.
6. Disassemble thrust half bearings.
7. Disassemble crankshaft gear.
8. Take out the six fixing bolts from the outer three bearing caps.
9. Remove the lower bearing cap with their respective half bearings.
10. Withdraw crankshaft.
11. Remove upper half bearing from crankshaft assembly.
12. Clean all components carefully.

Check with a micrometer the wear of journal on crankshaft, bearing or crankcase. The diameter of journals and bearings should be checked both horizontally and vertically just at both ends. Wear and eccentricity must not exceed 0.001 mm.

Diameters of crankpins and front end see journal may correspond to the following measurements:

- a) Without 8.254 mm.
- b) Without 8.258 mm.
- c) Without 8.262 mm.


If crankshaft requires grinding below 0.001 mm, install a new crankshaft. The width of the crankpins might be increased when grinding, but is no more than 0.005 mm from 8 mm (0.001 in).

It is important to keep journals and crankpins well in accordance. After grinding, rough edges should be removed from crankpins holes.

Tapered crankshafts must be removed with the Tuffeting process after grinding. If this treatment can not be carried out, a new crankshaft must be required.

If the three assembly positions of the crankshaft rear support have been used, the crankshaft flange should be general.

Remove with the minimum amount of heat from the flange to eliminate warping. The flange should not be machined below a minimum diameter of 133.77 mm. It is not necessary to apply Tuffeting process to flange, repair crankshaft for cracks and regrinding.

**Assembly**

13. Reverse operations 7 to 12, except:
  - a) Check that cylinder block and crankshaft lubrication holes are not blocked.
  - b) Check that bearing cap fixing bolts are not stretched. Only bolts supplied by engine manufacturer should be used.
  - c) Make sure all components are mechanically clean and properly balanced with engine oil.
  - d) The bearing caps are numbered starting from front of engine. Each bearing cap is also marked with the same part number as is stamped on bottom face of block, and they must be matched up.
  - e) Tighten bolts to a torque of 50 kg m.
14. Assemble crankshaft thrust half bearings.
15. Assemble connecting rod big end bearings.
16. Assemble timing case.
17. Reverse operation 8.
18. Fit engine with specified oil.

## SECTION 4:

## **ENGINE D4.203**

### **INDEX**

	Page
Specifications	11
Description	12
Frontid-shafting sleeve	12
Rocker cover	12
Valve lead adjustment	12
Rocker arm shaft	12
Bearing rocker-arm shaft	12
Inlet manifold	12
Exhaust manifold	12
Brake springs	12
Cylinder head	12
Bearing cylinder head	12
Hydrodynamic valve lifter	12
Timing case cover	12
Timing gear	12
Crankshaft	12
Timing case	12
flywheel	12
Flywheel ring gear	12
Flywheel housing	12
Crankshaft rear retaining	12
Engine crossbar	12
Oil pump	12
Bearing oil pump	12
Connecting rod big and bearings	12
Pistons and connecting rods.	12
Bearing piston and connecting rods	12
Cylinder liners	12
Crankshaft thrust half washers	12
Crankshaft	12



**SPECIFICATIONS****Engine**

<b>Make and type</b>	Pentius four-stroke, direct diesel hydraulic.
<b>Model</b>	D4.210
<b>Number of cylinders</b>	Four
<b>Outer bore</b>	81.44 mm
<b>Stroke</b>	127 mm
<b>Displacement</b>	5,996 c.c.
<b>Compression ratio</b>	16.6 : 1
<b>Power</b>	50.014 F. at 2,000 r.p.m. of engine.
<b>Maximum torque</b>	21.8 kg.m. at 1,300 r.p.m. of engine.
<b>Maximum speed</b>	2,000 r.p.m. under load; 2,374 r.p.m. no load and 4,000 ± 100 r.p.m. idling.
<b>Timing system</b>	By gears.
<b>Cylinder block</b>	Built of a single, high strength grey-iron casting.
<b>Type of liner</b>	Thin wall casting.
<b>Combustion</b>	Cast iron with extensive water cooling channels.
<b>Cylinder head</b>	Cast iron with honed bore. Located in top flange part of cylinder block.
<b>Camshaft</b>	Molybdenum strengthened steel with high frequency induction treated camshafts.
<b>Connecting rods</b>	Brassiere forged steel.
<b>Pistons</b>	Aluminum alloy with concave machining in head. Provided with one oil control and three compression rings.
<b>Valves</b>	In cylinder head, driven by camshaft through push rods and rocker arms.

**Lubrication system**

<b>Type</b>	Low pressure through roller-chain oil pump.
<b>Oil filter</b>	Fluid filter, mounted on block with integral body and element.
<b>Oil-burner capacity</b>	7 litres.
<b>Minimum pressure in oil line</b>	2.01 kg/cm <sup>2</sup> at 2,000 r.p.m. of engine and 1.2 kg/cm <sup>2</sup> at idling speed with oil temperature in line of 30 to 80° C.
<b>Normal exhaust pressure range</b>	Pressure type.
<b>Valve operating pressure</b>	0.0 to 0.3 kg/cm <sup>2</sup> .
<b>Filter bypass valve</b>	Null type.
<b>Valve operating differential pressure</b>	0.08 to 1.2 kg/cm <sup>2</sup> .
<b>Lubricant</b>	See general information.

## DESCRIPTION

The Perkins 34.200 engine is of the four cylinder, water-cooled, direct diesel injection type. The rated cylinder bore is 164.8 mm and the stroke is 127 mm.

The engine has precision cast iron mounted vertically in the cylinder head. The camshaft, located in the right-hand part of the cylinder block, is driven by a driving gear. The camshaft, in turn, actuates the valves by way of the lifter and rocker arms.

The cylinder block is a single piece of high strength grey iron casting.

The piston pinches have slotted heads and flat stops. The pistons are coupled to their connecting rods by piston pins secured with lockpins. The connecting rod big end bearings are replaceable and are made up of a steel sheet covered with a tin and aluminum alloy.

The engine has force feed lubrication. The oil is sucked up from the sumpcase through the sump filter by means of a rotary pump driven by the camshaft. The oil passes through the gear before circulating under pressure through the engine.

The crankshaft has five bearing pairs with their corresponding bearings. It is supported by bearing caps and its axial location is controlled by sleeve half bushes located on the rear bearing.

## TROUBLE-SHOOTING CHART

Trouble	Possible cause
Indicates working speed.	1, 2, 3, 4.
Engine does not start.	5, 6, 7, 8, 9, 10, 11, 12, 14, 15, 16, 17, 18, 19, 20, 22, 23, 29,
Difficult starting.	8, 13, 9, 10, 11, 12, 13, 14, 15, 16, 17, 19, 20, 21, 22, 26, 31, 30, 33,
Loss of power.	10, 11, 13, 14, 15, 16, 18, 21, 23, 24, 25, 26, 27, 29, 31, 32, 33,
Combustion failures.	11, 12, 13, 14, 15, 16, 20.
Excessive fuel consumption.	16, 17.
Black exhaust smoke.	11, 12, 13, 14, 15, 16, 18, 20.
Blue/white exhaust smoke.	4, 20, 21, 24, 25, 26.
Low oil pressure.	4, 20, 21, 26, 28, 40, 41, 42, 43, 44.
High oil pressure.	8, 14, 16, 18, 19, 20, 24, 26, 29, 33, 36, 40, 46, 48,
Unusual burning.	7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 21, 22, 26, 28, 30, 31, 32, 33,
Vibration.	13, 14, 23, 26, 30, 45, 47, 48.
Excessive oil pressure.	4, 41.
Engine overheating.	10, 13, 24, 25, 40, 50, 51, 52, 53, 54, 57.
Excessive pressure in carburetor.	26, 27, 28, 29, 34, 36, 37.
Low compression.	10, 26, 27, 31, 32, 38.
Engine starts up and stops.	10, 11, 12.

## Trouble-shooting key

1. Battery charge low.
2. Poor electrode connections.
3. Starter clutch faulty.
4. Wrong grade of oil.
5. Incorrect operating speed.
6. Fuel tank empty.
7. Cut-out control malfunction.
8. Fuel feed pipe blocked.
9. Faulty 29 pump operation.
10. Fuel filter blocked.
11. Air cleaner blocked.
12. Air to fuel ratio.
13. Faulty impeller pump operation.
14. Impeller faulty.
15. Incorrect use of cool-wax system.
16. Failure in cold-start system.
17. Impeller pump control broken.
18. Impeller pump setting incorrect.
19. Valve adjustment incorrect.
20. Low compression.
21. Fuel injection blocked.
22. Wrong type or grade of oil.
23. Accelerator linkage sticking.
24. Suction pipe faulty blocked.
25. Losses in cylinder head gasket.
26. Cool-waxing.
27. Operating temperature incorrect.
28. Exhaust pipe partly blocked.
29. Shaker valves.
30. High pressure pipe blocked.
31. Water cylinder.
32. Radiator overheat period.
33. Plenum pipe broken, worn or seized.
34. Water pump and gaskets worn.
35. Diesel oil clogged or wrong grade of oil.
36. Bearings worn or damaged.
37. Crankcase oil-level low.
38. Crankcase film broken.
39. Oil pump failure.
40. Pressure relief valve stays open.
41. Pressure relief valve stays closed.
42. Ball valve spring broken.
43. Oil pump thermostat pipe defective.
44. Oil filter blocked.
45. Plenum hand-to-air.
46. Incorrect plenum height.
47. Fan damaged.
48. Rotor spring broken.
49. Hydrostatic faulty transmission wrongly assembled.
50. Flammability faulty.
51. Blockage in the cylinder block and/or cylinder head water jackets.
52. Fan belt slack.
53. Radiator blocked.
54. Water pump faulty.
55. Breather pipe blocked.
56. Water pump retaining cradle.
57. Coolant level too low.

**ROCKER COVER****Dismantling**

1. Raise hood.
2. Disconnect breather pipe.
3. Remove oil holding bowl, washer and retaining.
4. Take off rocker cover.
5. Remove and disconnect.

**Assembly**

6. Reverse operations 1 to 5, except:
- a) install a new O-ring seal.

**VALVE LASH ADJUSTMENT**

The valve lash is measured between the rocker arm and lifter and has to be adjusted to 0.280 mm (0.011 in) or 0.32 mm (0.012 in). The procedure is as follows:

1. Disassemble rocker cover.
2. With all 4 cylinder valves in cross-over position, adjust all 1 cylinder valves.
- With all 2 cylinder valves in cross-over position, adjust all 2 cylinder valves.
- With all 3 cylinder valves in cross-over position, adjust all 3 cylinder valves.
2. Assemble rocker cover.

**ROCKER ARM SHAFT****Dismantling**

1. Disassemble rocker cover.
2. Disconnect oil feed pipe.
3. Remove rocker shaft, timing case and endplate.
4. Withdraw complete rocker shaft.

**Assembly**

5. Reverse operations 2 to 4.
6. Adjust valve clearance.
7. Assemble rocker cover.



**SERVICING ROCKER ARM SHAFT**

1. Disconnect rocker arm shaft.
2. Remove shims from both ends of rocker shaft.
3. Remove shaft support.
4. Remove IC 1 valve rocker arms.
5. Remove spring.
6. Remove IC 2 valve rocker arms.
7. Remove washer.
8. Remove shaft support.
9. Remove rod.
10. Remove IC 3 valve rocker arm.
11. Remove shaft support.
12. Remove IC 4 valve rocker arm.
13. Remove valve end oil feed pipe.
14. Remove shaft support.
15. Remove spacer.
16. Repeat operations 2 to 15 for other end of rocker shaft, action is identical.

Check for wear or damage to rocker arms or shaft. The rocker arms should be able to be assembled easily on the shaft, without excessive side play.

**Assembly**


17. Repeat operations 1 to 16, except:
  - a) The free end of the rocker arm shaft has a slot and it has to be assembled as is shown in diagram D-4.
  - b) Lubricate all parts with clean engine oil before assembly.

**INTAKE MANIFOLD****Dismantling**

1. Release head.
2. Disconnect cold-start heater valve.
3. Disconnect cold-start heater fuel pipe.
4. Loosen intake pipe clamp.
5. Remove EGR bottle and washer.
6. Take off manifold, at the same time disconnect all four intake hoses.
7. Remove and discard gaskets.

**Assembly**


8. Install a new gasket.
9. Perform operations 1 to 5.

**EXHAUST MANIFOLD****Dismantling**

1. Release head.
2. Remove the four nuts and washers.
3. Withdraw manifold.
4. Remove and discard gaskets.

**Assembly**

5. Install new gaskets.
6. Perform operations 1 to 2.



**WAVE SPINNING**

**Dismantling and assembly (with cylinder head in place)**

1. Dismantle rocker shaft.
2. Turn crankshaft until at 1 and 4 piston are at total T.D.C.
3. Remove cylinder no. 1 and 4 valve springs with tools P0 87188 and P0 87194-5.
4. Remove collets.
5. Shove release tools P0 87188 and P0 87194-5.
6. Remove spring stops.
7. Remove springs and cones.

**NOTICE:** a) Do not turn crankshaft again until the valves have been reassembled and secured with lock collars.  
b) If a valve spring requires replacement, a complete set should be assembled.

8. Reverse operations 3 to 7.
9. Turn crankshaft until at 2 and 3 piston are at total T.D.C.
10. Repeat operations 3 to 7 for at 2 and 3 cylinder rows.
11. Reverse operations 1 and 3 to 7.



**CYLINDER HEAD**

**Dismantling**

1. Detachable hood.
2. Remove cylinder plug.
3. Detachable battery head.
4. Drain cooling system.
5. Detachable exhaust manifold.
6. Detachable intake manifold.
7. Detachable radiator top hose and connection hose between thermostat housing and water pump.
8. Detachable thermostat cover.
9. Remove high pressure fuel pipe.
10. Detachable (M22/24).
11. Disconnect temperature gauge (thermometer).
12. Disconnect air cleaner gauge (thermometer).
13. Detach oil feed pipe from cylinder head.
14. Remove cylinder head bolt ring nuts and bolts in reverse order to tightenings specified.
15. Remove cylinder head.
16. If necessary, disassemble cylinder housing and piston.
17. Remove cylinder head gasket.

**Assembly**

18. Make sure that all components are thoroughly clean and that contact surfaces are free of grease.




18. Reverse operations 1 to 15, except:
  - a) Place a new cylinder head gasket with a thin coat of sealing paste.
  - b) Tighten up cylinder head fixing nuts and bolts in the correct order, in three equal stages, to a torque of 10 Nm.
  - c) Apply a thin coat of sealing paste to the intake housing gasket of disassembled.
19. Bleed fuel system.
20. Start up engine and run it at approximately 1,200 r.p.m. for two minutes until normal working temperature is reached. (G600 engine).
21. Disassemble motor arm-shaft.
22. Tighten cylinder head fixing nuts and bolts in correct order to a torque of 10 Nm.
23. Assemble motor arm-shaft.
24. Start engine and check that there are no leaks.

#### REASSEMBLING CYLINDER HEAD


##### Dismantling and assembly

1. Disassemble cylinder head.
2. Disassemble valve assembly.
3. Place cylinder head set so its side and bottom faces.



**NOTE:** Keep valves in same order to which they were attached.

4. Loosen cylinder.
5. Remove bolt and washer.
6. Remove push rod.
7. Repeat operations 4 to 8 for remaining push rods.
8. Disassemble thermal housing and gasket.
9. Disassemble rear plate and gasket from cylinder head.
10. Clean all cylinder head openings, leaving them free of surface or other deposits.
11. If there are excessive deposits in the cylinder head water passages, the use of cleaner 88943 Part 88954 is recommended.
12. Check for wear on inside diameter of valve guides.
13. If necessary, extract valve guides with tool P5102.
14. Install new guides with tools P5110 and P5110A. Make sure guides are assembled in correct direction. Both ends are treated, one to 25° and the other to 20° like 20° end is also house-



- set. The 20° angle must be measured from the cylinder base through the top until the opposite end 140.00 mm to 143.00 mm above the top base.
15. Check for excessive piping or noise on either engine.
  16. If necessary, grind valve seats with the following basic striking order tool, valve seat profile cutter, burruster and center file. Remove as little metal as possible and ensure that tight finish.
  17. Carefully fit valves stems and check that they are not seized, even at bottom.
  18. If necessary, machine ground valve usage edge to a 40° angle. Remove as little metal as possible to achieve a fine finish.
  19. Clean valves completely.
  20. Lubricate valves stems with clean engine oil.
  21. If necessary, hold ground valves and their respective seats with oil piping & mounted and a point where a vibration is eliminated.
  22. Carefully seat cylinder head and valves with clean paraffin and have dry.
  23. Lightly lubricate valve stems and insert them in cylinder head.
  24. Check depth of valve head in relation to cylinder head surface. This depth must lie between 1.00 and 2.00 mm.
  25. If a valve exceeds this limit, it must be replaced. Measure valve stems again and if it still does not measure to the limits stated, a replaceable valve seat must be threaded firmly on cylinder valves. In the case of an intake valve, the cylinder head has to be replaced.
  26. Check that cylinder head surface is flat and, if necessary, plane surface up to a maximum of 0.06 mm, bearing in mind that the cylinder head may stand out more than 0.00 mm. This measurement must not be obtained by adding extra washers.
  27. Carefully clean cylinder head.
  28. Reverse operations 1 to 8, except:
    - (1) Fit valves in inverted position.
    - (2) Lightly smear back plate and cylinder head seating points with suitable sealing paste.



**REPLACEMENT VALVE SEATS****Accessible procedure**

Replaceable valve seats may only be assembled to UNIAJUST valves and only on a test stand or external cylinder head assembly.

The assembly of replaceable valve seats is a precision operation and should therefore only be performed by specialised personnel. This operation must never be performed while a valve guide is still mounted.

1. Remove cylinder head.
2. Using a valve guide tooling as centre, machine cylinder head surface (not according to instructions given).

**NOTE:** Work as close as possible to minimum machining dimensions to allow for a possible seat reworking.


3. Remove mounting flange and clean replaceable seat housing.
4. Using valve guide tooling, set valve seat in place by means of an insertion tool made to the specified dimensions.

**NOTE:** Replaceable valve seats must not be hammered into place or forced.


5. Check that replaceable valve seat is fully inserted into the housing and is in a true fit with the open part of cylinder head bore.

6. Remove mounting flange and flange end. If necessary, machine cylinder head surface.

7. Grind valve seat at a nominal angle of 10°, so that after grinding the depth of the valve seat below the cylinder head surface lies between 1.10 and 1.40 mm (specification limited for exhaust valves).




RP 200 FIGURE 3  
A: 2.30 to 2.51 mm



KEY TO FIGURE 2

A:	13.75 to 13.85 mm
B:	11.070 to 11.214 mm



RP 200 FIGURE 4

A:	1.20 mm to 1.27 mm
B:	10.00 mm
C:	0.30 mm
D:	50.00 mm to 51.00 mm
E:	10.24 to 11.25 mm
F:	0.30 mm to 0.40 mm
G:	1.20 mm to 1.27 mm
H:	1.20 mm to 1.27 mm
I:	1.20 mm to 1.27 mm
K:	1.20 to 1.25 mm

**TIMING CASE COVER****Dismantling**

1. Disconnect hoses between engine and front pipe.
2. Remove belt and water cooling constant pulley.
3. Take off crankshaft pulley.
4. Remove water outlet.
5. Remove engine breather pipe.
6. Remove accelerator return spring from injection pump.
7. Remove the four bottom bolts.
8. Disassemble alternator assembly support bracket.
9. Take out timing cover fixing bolts.
10. Take off timing cover cover.
11. Remove and discard gasket.
12. Remove retaining.

**Assembly**

13. Install a new retaining with lug towards engine. (This retaining 3.4 mm back from outside of timing case).
  14. Assemble cover and case gasket.
- NOTE:** Lightly smear gasket with suitable sealing paste.
15. Put on crankshaft pulley so as to center timing cover cover.
  16. Put in and tighten some bolts and washers to secure timing cover.
  17. Remove crankshaft pulley.
  18. Install retaining. Timing cover cover must hold well.
  19. Perform operations 1 to 8, except:
    - a) Tighten crankshaft pulley fixing bolt to a torque of 16 kgm.


**TIMING BELT****Intermediate gears****Dismantling**

1. Disassemble timing case cover.
2. Turn crankshaft and crank on injector pump, camshaft and crankshaft gears are lined up with those of the corresponding intermediate gears.
3. Bend back lock plate.
4. Remove the three nuts.
5. Remove lock pins.
6. Remove lock washers.
7. Remove upper intermediate gear.
8. If necessary, disassemble intermediate gear train.
9. Repeat operations 2 to 5 for lower intermediate gear.



**Assembly**

10. Put in intermediate gear hub, making sure that not all hub holes are lined up with slots of cylinder block.
11. Assemble gears, making sure that lower pump, camshaft and crankshaft gear teeth mesh up lined up with intermediate gear.
12. Reverse operations 3 to 8.
13. Check radial play of gears, which must be between 0.020 and 0.074 mm.



14. Check clearance between intermediate gears by means of a dial gauge or thickness gauge. The clearance must be between 0.085 and 0.102 mm. Check at 4 points of engagement.

**NOTE:** If axial play determined above has full within the prescribed limits, replace timing gears involved.


15. Assemble timing case cover.

**Crankshaft gear****Dismantling**

1. Disassemble upper intermediate gear.
2. Remove the three gear locking nuts and bolts.
3. Remove gear.

**Assembly**

4. Reverse operations 3 and 2, except:
  - a) Make sure gear and camshaft flange bearing are lined up.
  - b) Assemble upper intermediate gear.



**Motor pump gear****Dismantling**

1. Disassemble upper intermediate gear.
2. Remove the three fixing nuts and bolts.
3. Remove gear.

**Assembly**


4. Reverse operations 2 and 3, except:
  - a) Make sure that gear shown is mounted in top side pump bearing.
  - b) Tighten fixing bolts to a torque of 3 kg m.
5. Assemble upper intermediate gear.

**Crankshaft gear****Dismantling**

1. Disassemble lower intermediate gear.
2. Remove shield.
3. Withdraw crankshaft gear.
4. Take out key (if necessary).
5. Remove spacer (if necessary).

**Assembly**

6. Reverse operations 3 to 5.
7. Assemble lower intermediate gear.

**GARREAU****Dismantling**

1. Remove roller arm shaft.
2. Remove upper intermediate gear.
3. Disconnect tachometer drive cable from rear of camshaft housing.
4. Disassemble fuel lift pump.
5. Disassemble camshaft gear.
6. Take off caps.
7. Withdraw camshaft through front of engine. Take care that caps do not damage bearings.
8. Remove fixed bushes (if necessary).

**Assembly**

9. Check that fixed bushes fit correctly planet in cylinder blocking pin.
10. Reverse operations 3 to 7, except:
  - a) Make sure that bushes mounted on gear end Garretta range are fitted up.
11. Assemble upper intermediate gear.
12. Assemble roller arm shaft.




**TIME-S-CASE****Disassembly**

1. Disassemble carburetor.
2. Disassemble injector pump-pen.
3. Disassemble bypass pump.
4. Disassemble carburetor.
5. Remove nuts and bolts securing timing case to cylinder block.
6. Take off timing case.
7. Remove gasket.

**Assembly**

8. Reverse operations 8 to 7, except:
- a. Install new gasket lightly centered with suitable masking points.
9. Assemble injector pump pen.
10. Assemble carburetor.


**FLYWHEEL****Disassembly**

1. Disassemble clutch.
2. Remove the flywheel and lock plates.
3. Remove flywheel.

**Assembly**

4. Reverse operations 2 and 3, except:
- a. Locate flywheel on crankshaft flange so that the countersunk holes of flange line up with the flywheel holes with no bolt.
- b. Tighten flywheel bolts to a torque of 10 kg m, repeat them with new lock plates.
- c. Assemble clutch.

10 - 15 Nm




**PYTHON WHEEL REPAIR****Dismantling**


1. Disassemble flywheel.
2. Drill a hole 6 mm in diameter and up to a depth of 30 mm below the flywheel. The bushing should be 20 mm off at midway point between lower diameter of ring gear and base of one of 60 teeth.
3. Place a solid sheet at base of tooth, above 20 mm hole.
4. Cover flywheel and working point with a thick cloth or insulation against fragments that might fly off.
5. Hold flywheel and hammer cold chisel firmly to splitting point.

**Replacement**

6. Heat ring gear over to a temperature of approximately 200°C. (392°F.). **A. FURNACE**.
7. Place ring gear in flywheel with teeth with point towards base of flywheel, quickly fit ring gear into its housing and let it cool slowly.
8. Assemble flywheel.

**FLYWHEEL HOUSING****Dismantling**

1. Disassemble flywheel.
2. Remove bolts and housing.
3. Remove bolts.
4. Discard housing from base.
5. Reverse operations 3 to 6, except:
  - a. Make sure that flywheel housing and engine block surfaces are thoroughly clean.
  - b. Lightly coat both threads with an adhesive sealing paste.
6. Assemble flywheel.





**CRANKSHAFT REAR RETAINER****Disassembly**

1. Disconnect flywheel housing.
2. Remove bolts and washers.
3. Remove rear bearing together with retainer.
4. Remove oil-drip gasket.
5. Remove retainer from its housing.

**Preparation**

6. By disassembly, the bearing is assembled with its rear face aligned with the rear surface of the housing. Tap out crankshaft flange and, if it is seated, the rear washer must be inserted further into the housing. Then it should be inserted 0.2 mm end, if necessary, a burr 0.2 mm, making 0.4 mm in all. If these operations should not be sufficient the washers' bearing contact surfaces have to be machined.
7. Lubricate washer and its housing with clean engine oil. Place retainer in its housing so that its support surface with lock PD 140-1.
8. Insert oil-drip gasket tightly assembled with suitable sealing paste.
9. Lubricate washer, countersink flange and lock PD 140-2 with clean engine oil.
10. Using tool PD 140-2, install washer assembly and its housing. Make sure it is correctly engaged on shaft hub.
11. Remove tool PD 140-2.
12. Remove operations 1 and 2.



**ENGINES: CHAINCASE****Dismantling**

1. Disconnect flexible hoses from front case and engine.
2. Drain oil from crankcase and collect it in suitable container.
3. Remove nuts and washers retaining front studs to flywheel case.
4. Remove bolts retaining crankcase to flywheel housing.
5. Support crankcase and remove bolts, washers and lockwashers from retaining screws to engine.
6. Detach crankcase from engine.
7. Turnover and disassemble.

**Assembly**


8. Reverse operations 1 to 7, except:
- (a) Check that contact surfaces are clean.
- (b) Fit new gaskets, tightly compressed after suitable seating points.
- (c) Place a new pinion in slot located on crank shaft rear bearing cap.
- (d) Fit crankcase to engine front with specified engine oil.

**CRANKCASE****Dismantling**

1. Disconnect engine crankcase.
2. Remove intermediate gear shaft.
3. Withdraw intermediate gear.
4. Disconnect pump/high pressure pipe.
5. Remove fixing bolts and washers.
6. Withdraw oil pump.

**Assembly**

7. Reverse operations 2 to 6.
8. Assemble engine crankcase.




**DISASSEMBLY, PUMP****Disassembly**

1. Disconnect oil pump.
2. Remove pressure pipe.
3. Remove the two bolts and nut from mounting screw filter pipe.
4. Remove pipe and screw filter.
5. Remove circlips.
6. Remove pump driven gear.
7. Remove key.
8. Remove the two bolts and nuts securing pump plate.
9. Remove pump plate and safety valve.
10. Remove O-ring seal.
11. Check clearance at all points between maximum diameter of internal valve and minimum diameter of external rotor. If it exceeds 6.9524 mm., a new pump must be installed.
12. Check clearance between tip of rotor and pump body. If it is greater than 0.262 mm., a new pump must be installed.
13. If necessary, remove O-ring seal.
14. Remove plug.
15. Remove spring.
16. Remove safety valve.

**Assembly**

17. Reassemble operations 16 to 17 and 1 to 15, except:
  - a) If the safety valve seat has been removed, make it to fit up to its original size.
18. Install a new rotor.



**CONNECTING ROD BEARING****Dismantling**

1. Disconnects oil pump.
2. Turn crankshaft housing to be disassembled to  $\pm$  90°C.
3. Remove nuts from big end bolts.
4. Remove big and cap together with half bearing.
5. Remove half bearing from cap.
6. Remove big end bolts.
7. Turn crankshaft until upper half bearing can be removed.
8. Repeat operations 2 to 7, to dismantle remaining bearings.

**Inspect half bearings for wear or scoring.** If any abnormalities faults, replace complete set.

**Check for wear on crankshaft crosspins with a micrometer.** The diameter of crosspins should be checked both on a horizontal and vertical plane and at both ends.

**Wear and oscillation must not exceed 0.0391 mm.** If above this limit, the crankshaft must be ground or replaced.

**Assembly****B. PISTON POSITION 1 IN B. SHOCK**

- (i) Check that all components are thoroughly cleaned and lubricated with clean engine oil according to specifications.
- (ii) Make sure half bearing large flange connecting rod passes and that they are correctly positioned in their original positions.
- (iii) The connecting rod nuts and bolts are special and whenever they are replaced original parts from the engine manufacturer must be used.
- (iv) Make sure that base of bolt heads is seated correctly on connecting rod sleeves.
- (v) Check that connecting rod and big end bearing caps are assembled with matching identification marks and on left side of engine.
- (vi) Tighten big end nuts to a torque of 7 kg cm.

**PISTONS AND CONNECTING RODS****Disassembly**

1. Disassemble cylinder head.
2. Disassemble big end bearings.
3. Withdraw pistons and connecting rods through top of cylinders.

**Assembly**

Check condition of pistons, rings and liners and if they are in all ways good, replace them.

4. Clean oil pan carefully and lubricate them with clean engine oil according to specifications.

**NOTE:** Please note: ring gaps in piston to suit a new ring each ring gap is at 10° in relation to previous one.

5. While holding piston, insert each piston and connecting rod into top of its respective cylinder. Make sure that the number «FIGURE» is towards front of engine.
6. Assemble big end bearings, but without assembling oil pump.
7. Check height of each piston with tool P0448. At T.O.C. the piston must be located 0.2758 mm below top surface of block.
8. Assemble oil pump.
9. Assemble cylinder head.



**REMOVING PISTONS AND CONNECTING RODS****Dismantling**

1. Disconnect piston and connecting rods.
2. Remove rings (see 202-2000).
3. Remove clips from each piston.
4. Heat pistons to a value equal to a temperature of 120° to 160° C.
5. Carefully extract piston pins.
6. Remove connecting rods from piston/crankpin assembly in ring groove.
7. Inspect piston lip sealing.
8. Check piston pin adjustment.
9. If necessary, extract small end bearing.
10. Place rings in place, remove pin at top of cylinder and check ring gap. This gap must be between 0.020 and 0.030 mm.

**Free piston rings:**

- 1st ring: 0.38 to 0.50 mm.  
 2nd, 3rd and 4th rings: 0.20 to 0.30 mm.  
**Twisted piston rings:**  
 1st, 2nd and 3rd rings: 0.20 to 0.30 mm.  
 4th ring: 0.20 to 0.30 mm.

11. After installing new rings, check vertical clearance of grooves. This clearance must be between the piston rings.

1st and 2nd rings: 0.40 to 0.50 mm.  
 3rd ring: 0.20 to 0.30 mm.

- 4th ring: 0.050 to 0.060 mm.  
**Footed piston rings:**  
 1st and 2nd rings: 0.050 to 0.060 mm.  
 3rd ring: 0.050 to 0.060 mm.  
 4th ring: 0.050 to 0.060 mm.

**Assembly**

12. If necessary, install new small end bearings, aligning bearing lubrication hole with corresponding rod end.
13. With tool 300, check that each rod is perpendicular and parallel. If there is any distortion, it must be rectified.
14. Coat piston in a thin liquid, please immediately with thick grease piston and insert piston pins.

**NOTE:** The piston must move freely off the rod towards cap of its stroke. Join up piston to connecting rods with cavity towards rear bearing rod end big end bearing cap front bearing cover.

15. Install two new clips on each piston pin.




10. Starting from the top, install rings in the following order:
  - 1st. Cylinder ring.
  - 2nd. Internally stepped compression ring.
  - 3rd. Internally stepped compression ring.
  - 4th. Adjustable scraper ring.

**NOTE:** The internally stepped compression rings must be placed with step towards piston head. Please align set-screws plates so that the gap of two rings is at 180° in relation to the previous one.
11. Assemble piston and connecting rods.

## CYLINDER LINERS


### Disassembly

1. Disassemble piston and rods.
2. Remove cylinder head nuts.
3. With pull PZ 100, suitable adapter and hollow hydraulic cylinder, extract liners from cylinders through top of block.




### Replacement

4. Reverse operations 1 to 3, except:
  - a) Cylinder head nuts should be handled and stored with care. The diagnosis defines an hour could cause considerable damage when assembled in block.
  - b) Cast iron liners with flange should not be greased, but have to be replaced by new semi-finished items.
  - c) Before inserting a liner liner, both it and the corresponding cylinder should be carefully cleaned, especially the groove at top of cylinder where liner flange is situated.
  - d) All parts should be thoroughly lubricated before assembly with engine oil.
  - e) Check that length of each liner does not exceed its housing at top of cylinder.
  - f) When it is completely in place, the top of each liner need be between 0.088 and 0.100 mm below top face of block.
  - g) Check condition of piston until all satisfied, replace liner.
  - h) Allow a settling in period before checking liner dimensions of liner.
  - i) Each liner need be clamped in three positions (upper, middle and lower) the settings must be taken with non-magnetic and parallel to center line of block.



**DISASSEMBLY AND REASSEMBLY**

1. Disassemble crankshaft.
  2. Push crankshaft backwards and check axial play between thrust half-washers and crankshaft. The clearance should be between 0.020mm/0.008mm.
  3. If axial play does not lie within these limits, proceed as follows:
  4. Disassemble crankshaft rear bearing.
  5. Take out the two locking bolts.
  6. Remove undersize rear bearing cap together with the two lower thrust half-washers.
  7. Push the two upper thrust half-washers with a wire until they sit on each other.
  8. Replace the two bearings.
  9. Before re-assembling, lubricate all components with clean engine oil.
  10. Place the two main upper thrust half-washers in side housing with flat face towards half bearing.
  11. Place the two new lower thrust half-washers in rear undersize bearing cap and assemble it.
  12. Put in locking bolts and tighten them to a torque of 10 Nm.
  13. Check axial play again.
  14. If axial play is still not right, larger size thrust half-washers must be fitted. Repeat operations 8 to 13.
- NOTE:** Both upper and lower thrust half-washers have to be of the same thickness.
15. Fit undersize crankshaft rear bearing.
  16. Assemble rearcase.



**CRANKSHAFT****Disassembly**

1. Drain engine oil.
2. Separate motor between front axle and engine and between engine and gearbox.
3. Support engine on suitable stands.
4. Disassemble flywheel case.
5. Disassemble big end bearings.
6. Disassemble cross half bearings.
7. Disassemble oil pump.
8. Disassemble crankshaft gear.
9. Remove the eight bolts securing retaining bearing caps.
10. Remove the two bearing caps together with their half bearings.
11. Withdraw crankshaft.
12. Remove upper half bearing from maincase supports.
13. Check all components carefully. Check with a micrometer the wear or pitting on mainshaft journals and bearings. The diameter of journals and bearings should be checked both horizontally and vertically and at both ends. Wear and pitting must not exceed 0.0064 mm. Excessive wear and damage must be replaced.



Bore size of crankpins and front and rear journals may be ground to the following measurements:

- a) Minus 0.024 mm;
- b) Minus 0.008 mm;
- c) Minus 0.002 mm.

If crankshaft requires grinding below 0.002 mm, install a new crankshaft. The width of the crankpin might be increased on grinding, but in no circumstances must it exceed 58.88 mm.

It is important to keep journal and crankpin neck in concentricity. After grinding, rough edges should be removed from lubrication holes. Tufftrid crankshafts must be treated with Tufftriding process after grinding. If this treatment cannot be carried out, a new crankshaft must be assembled.

If the three eccentric positions of the crankshaft rear bearing have been used, the crankshaft flange should be ground.

Grind only the minimum amount of metal from the flange to eliminate warping. The flange should not be machined below a maximum diameter of 115.11 mm.

It is not necessary to apply Tufftriding process to flange. Standard procedures for cleaning and machining.

**Assembly**

14. Reverse operations 8 to 13, except:
  - a) Check that cylinder block and crankshaft lubrication holes are not blocked.
  - b) Check that bearing cap fixing holes are not obstructed. Only bolts supplied by engine manufacturer should be used.
  - c) Make sure all components are thoroughly clean and well lubricated with engine oil.
15. The bearing case are numbered, starting from front of engine. Each bearing cap is also marked with the same radial number as is stamped on block bottom face and they must be matched up.
16. Tighten bolts to a torque of 78 kg cm.
17. Assemble crankshaft thrust half washers.
18. Assemble oil pump.
19. Assemble big end bearings.
20. Assemble flywheel case.
21. Reverse operation 2.
22. Fit flywheel with specified oil.

## SECTION 5

# FUEL SYSTEM

### CONTENTS

	PAGE
Specifications Model 200	1
Specifications Model 400	2
Description	3
Air filter	3
Fuel tank	3
Fuel pump Model 200	3
Fuel Pump Model 400	3
Fuel lines	3
Fuel injection pump	3
Fuel injection	7
Cold weather starting issues	7
Removing and installing the air cleaner filter	7
Removing and installing the air cleaner	8
Removing and installing the fuel tank	8
Removing and installing the fuel tank after off road	8
Removing the fuel tank off road	8
Removing and installing the fuel pump	9
Disassembly and assembly of fuel pump Model 200	11
Disassembly and assembly of fuel pump Model 400	12
Removing and installing the fuel filter	11
Removing the fuel injection pump from the tractor	14
Installing fuel injection pump to the tractor	14
Injection pump setting	16
High idle rpm adjustment	18
Low idle rpm adjustment	18
Removing and installing injectors	19
Setting the injector needles	19
Bleeding the fuel system	20
Hydraulic steering	20



**SPECIFICATIONS Model 300**

Fuel tank location	In upper part of chassis, in front of steering column
Fuel tank capacity	100 l.
Refueling tool	Bottle-on-the-pump
Fuel type	Petrol/gasoline/methanol
Injector	
Type	C.A.V.
Type	E.P.A.
Governor	Mechanical
Maximum revs	11 revs in 200 seconds at 7001 b.p.m.
Maximum full load engine speed	5,280 r.p.m.
High idle (e.g. no load)	2,280 r.p.m.
Percentage of maximum (factory mapping)	100%
Code number on characteristic plate	01W1V100-14.0389
Breakout torque with engine idling in stroke position	32°
Idle idle t.p.m.	300 ± 30
Ignition	
Ignition pressure	0.8 bar/0.08 atmospheres
Cold-weather starting auxiliary device	Electric heater in the intake manifold

## SPECIFICATIONS Model 400

Fuel tank location	In upper part of tractor behind of steering column
Capacity of the fuel tank	95 l.
Sediment trap	SLA-1 on fuel line
Fuel filter	Equipped with replaceable element
Injection pump	
Make	E.A.C.
Type	E.P.A.
Governor	Mechanical
Mixture ratio	11.4:1. In 200 cm <sup>3</sup> max. 100 l.p.m.
Maximum fuel heating pipe outlet	5,289 l.p.h.
High idle l.p.m. No load	2,279 l.p.h.
Dimensions of injection floating coupling	Double
Code number on injection plate	MP 031000 R/1388
Synchronisation with engine timing by injection advance	30° before T.D.C.
Low idle l.p.m.	400 ± 10
Injection	
Elevating pressure	300 atmospheres
Cold weather starting auxiliary device	Electric heater in the intake manifold

**DESCRIPTION**

In the fuel system the fuel is sucked up by the mechanically-operated feed pump, which supplies it at low pressure, through the lines, to the injection pump. This component distributes the fuel at high pressure to the injectors. The moving parts of the injection pump are lubricated by the fuel which passes through it and do not require any additional lubrication. The fuel leak plug allows the excess fuel, which was not injected, to return to the tank.

The cold engine starting motor is fed by means of the fuel line pipe. The various connections must be disconnected before removing any component of the fuel system. All plugs and sealing strips should be kept on hand so as to stop up the fuel connections as soon as any one of them is disconnected. The test connection, used on the cleaning tap to clean any part of the system,

**AIR FILTER (Fig. 1)**

The air cleaner or filter is of the oil bath type and is located in the front part of the bonnet, behind the front grille and above the radiator. It is equipped with a cartridge-type prefilter. The higher-airflow-rate air filtration performance provided by this unit is due to the use of centrifugation, which allows the greater part of the particles which are carried in suspension in the air to be deposited. The only inconvenience with the prefilter requires its emptying from time to time during use.

The air passes through the prefilter and enters the cleaner by the underplate. On reaching the bottom it displaces the oil contained in the lower cup in order to pass on to the cleaner elements. The centrifugal force resulting from the sudden change of direction of the air makes the oil produce a large number of particles traps.

The air continues towards the upper part of the cleaner through the elements, which eliminate the chance of any possible remaining particles.

The oil and particles drawn by the air converge the elements return to the cup where the particles sink to the bottom by sedimentation. In this way the cleaned air reaches the upper part of the cleaner and then goes on to the intake of the engine intake manifold.

The air cleaner requires constant regular attention if its efficiency operation is to be assured. Negligence with the resultant dirt can impair the performance of the engine.




Fig. 1... Cross-section of the air cleaner

The air cleaner may must be removed, cleaned and filled with new oil up to the oil level mark, every two service hours or every day.

Attention must be given to the hose and clips which join the filter outlet to the engine intake manifold, since any defect in these components would cancel the effect of the air filter.

**Fuel tank**

The fuel tank has a capacity of 66 litres and is mounted in the upper part of the tractor, in front of the steering column. This assures a constant flow of fuel by gravity under all conditions. The tank is mounted on rubber diaphragms secured by screws. The

fuel shut-off cock is located at the bottom of the tank and has a quick-fit screw fitting. The filter needs, located at the top of the tank, is provided with a flexible hose clip.

**Fuel pump Model 300**

The fuel pump is of the mechanical-diaphragm type, driven by the engine mainshaft. This pump has a built-in manual valve and a direct-acting solenoid cap through which accumulated water and sediment can be removed. The pump is mounted on the

right-hand side of the engine, between the fuel shut-offcock and the filter. A wire mesh screen, located above the solenoid cap, protects the anti-suck valves located in the upper pump body assembly.

**Fuel pump Model 400**

The fuel pump is of the mechanical-diaphragm type, driven by the engine crankshaft. The pump is mounted on the right-hand side of the engine between the fuel shut-offcock and the filter, and is equipped with

a manual valve. A wire mesh screen, that fits inside the fuel pump cover, protects the anti-suck valves located in the pump body.

**Fuel filter**

The fuel filter is mounted between the fuel pump and the injection pump. This filter protects the latter components of the injection equipment from water, dirt or foreign bodies that might be present in the fuel. Careless driving may clog the filter and impair its operation. On Model 400, the lower part of

the filter is composed of a sediment trap with drain cock through which accumulated water and sediment can be removed. The filter element of the replaceable cartridge trap, must be changed for a new one every 600 working hours. Do not try to clean or wash it; if used, dried sand must be discarded.

**Fuel injection pump**

The fuel injection pump of the C.A.L.V. Type, is a robust, high pressure unit with a built-in mechanical governor controlled to a gear from the engine timing case. If the controls, necessary fuel is used and attention

is given to the fuel filter, the injection pump should give due to very few problems. When servicing the injection pump, follow the recommendations given on pages 13 to 16.

### Fuel injection

The fuel injection spray the engine combustion chamber with the required amount of fuel according to the speed of the engine. The operating pressure of the injector is 250 atmospheres. Do not attempt to service the injectors without adequate protection

and the use of suitable equipment. It is advisable to service them at least once every 1000 working hours. This will require more frequent attention if the fuel is not kept sufficiently clean or if the engine cooling system is not properly attended to.

### Cold weather starting heater

To make cold weather starting easier, there is a heated baffle located in the engine intake which facilitates the preheating and warming of the intake manifold and carburetor airducts. The first clockwise movement made by the starter switch turns the heater on. A second movement in the same direction activates an igniter heater mounted in the intake manifold, so that the heater coil generates a discharge current of 200000 mA full voltage rms. At the same time a small amount of fuel flows from the fuel tank pipe through the heater where it is vaporized and then ignited by the heater coil. A third clockwise movement made by the power switch actuates the warm-up coil and the ignited fuel is drawn inside the engine. The operation of the heater may be checked by removing the plug (A, Fig. 2) from the heater manifold (B, Fig. 2).

If the heater is operating normally, shortly after it has been turned on by the start switch, the flame which is produced inside the manifold by the warm-up function of the heater fuel may be observed through the plug hole.

If the heated baffle is defective it must be replaced.



Fig. 2 - Cold weather starting device.

### TO REMOVE AND REINSTALL THE AIR CLEANER OIL PAN (fig. 2)

- Remove the heat gills from the baffle.
- Open the three side oil pan decompressing the pan oil and filter element (A).
- Assembly is reverse order, making sure that the oil pan is clean and filled with new oil up to the level indicated.

- Before reassembling the oil pan, check the correct placement of the components so as not to damage the rubber seal which ensures the tightness of the closure.

**NOTE:** — It is very important to keep the oil clean as it prevents engine performance from being adversely affected.



Fig. 3 - Removal of the air cleaner.



Fig. 4 - Removal of the air cleaner.

#### REMOVAL AND INSTALLATION OF THE AIR CLEANER ON THE TRACTOR (Fig. 4)

- Disconnect the intake tube (A) that goes from the air cleaner to the intake manifold.
- Remove the pulley and the air cleaner intake elbow (B).

#### REMOVAL AND INSTALLATION OF THE FUEL TANK ON THE TRACTOR

- Remove the hood and instrument panel.
- Remove the steering wheel.
- Close the fuel shut-off cock and disconnect the pipe from the fuel pump to the shut-off cock at the tank.
- Disconnect the upper fuel tank pipe and the exhaust header piping pipe.

#### TO REMOVE THE FUEL SHUT-OFF COCK FROM THE TANK

- Disconnect end plug (at the shut-off valve side) the pipe which goes from the fuel shut-off cock to the fuel pump.

— Take out the four screws (C) and support (D), break the screw by following the procedure indicated with (E).

- Take out the four screws that secure the fuel tank lock brackets.
- Remove the fuel tank.

To install the tank, carry out the above procedure in reverse order, making sure that the rubber dampers are properly mounted the tank and the tank (E).

- Drain the fuel tank.
- Unscrew the fuel tank shut-off cock complete.

**TO REMOVE AND INSTALL THE FUEL PUMP**

(Fig. 8)

- Close the fuel shut-off cock.
- Disconnect the intake and outlet pipes, sealing their ends to prevent the entry of foreign matter.
- Remove the two nuts and washers which mount the pump to the valve lifter cover.
- Remove the pump, spacer ring and gasket.

Install the fuel pump in the reverse by reversing the above procedure making sure that the pump flange face and its seal in the intake pipe are clean.



Fig. 8 - Removing the fuel pump

**Testing a newly installed fuel pump**

- Disconnect the outlet pipe from the pump to the filter, providing a few inches from the pump.
- Crank the engine and check if there is a well defined jet of fuel from the outlet pipe every two revolutions of the engine.

Alternatively this operation can be carried out with

the manual primer, which would give the same result every time the primer is activated, however, it might happen that the engine stops in a position that causes the pump which drives the fuel pump to be in an even higher position, thus making it impossible to operate the manual primer. If such a situation arises, the solution is to restart the engine for one complete revolution.

**Testing the fuel pump before installation**

To test the fuel pump off the tractor, first operate the manual primer, moving the diaphragm in the body of the pump housed, and seal or block the outlet hole with your fingers. If the valves or the diaphragm are defective, the diaphragm will inner fluidly vacuum in the upper part of the tank when the manual primer is released. When placing your fingers in the inlet hole and operating the manual primer, a

constant pressure and resistance to the movement should be observed. When the manual primer is operated with the intake and outlet holes kept free, a characteristic sound should be heard. It should be kept in mind that when the manual primer is operated by hand, it may be applying a greater load to the diaphragm than a normal would when mounted on the engine.




Fig. 5 - Fuel pump Model 200

## Exploded view of the Model 900 fuel pump (Fig. 4)

- 1 - Diaphragm
- 2 - Valve
- 3 - Valve
- 4 - Diaphragm
- 5 - Diaphragm spring
- 6 - Valve
- 7 - Valve seating
- 8 - Seal
- 9 - Valve
- 10 - Valve seating
- 11 - Valve
- 12 - Valve seating
- 13 - Valve seating
- 14 - Diaphragm seating
- 15 - Valve seating
- 16 - Seal
- 17 - Seal
- 18 - Seal
- 19 - Seal
- 20 - Seal
- 21 - Seal
- 22 - Seal
- 23 - Seal
- 24 - Seal
- 25 - Seal
- 26 - Seal
- 27 - Seal
- 28 - Seal
- 29 - Seal
- 30 - Seal
- 31 - Seal
- 32 - Seal
- 33 - Seal
- 34 - Seal
- 35 - Seal
- 36 - Seal
- 37 - Seal
- 38 - Seal
- 39 - Seal
- 40 - Seal
- 41 - Seal
- 42 - Seal
- 43 - Seal
- 44 - Seal
- 45 - Seal
- 46 - Seal
- 47 - Seal
- 48 - Seal
- 49 - Seal
- 50 - Seal
- 51 - Seal
- 52 - Seal
- 53 - Seal
- 54 - Seal
- 55 - Seal
- 56 - Seal
- 57 - Seal
- 58 - Seal
- 59 - Seal
- 60 - Seal
- 61 - Seal
- 62 - Seal
- 63 - Seal
- 64 - Seal
- 65 - Seal
- 66 - Seal
- 67 - Seal
- 68 - Seal
- 69 - Seal
- 70 - Seal
- 71 - Seal
- 72 - Seal
- 73 - Seal
- 74 - Seal
- 75 - Seal
- 76 - Seal
- 77 - Seal
- 78 - Seal
- 79 - Seal
- 80 - Seal
- 81 - Seal
- 82 - Seal
- 83 - Seal
- 84 - Seal
- 85 - Seal
- 86 - Seal
- 87 - Seal
- 88 - Seal
- 89 - Seal
- 90 - Seal
- 91 - Seal
- 92 - Seal
- 93 - Seal
- 94 - Seal
- 95 - Seal
- 96 - Seal
- 97 - Seal
- 98 - Seal
- 99 - Seal
- 100 - Seal

## Exploded view of Model 900 fuel pump (Fig. 5)

- 1 - Valve
- 2 - Valve
- 3 - Valve
- 4 - Diaphragm
- 5 - Valve
- 6 - Valve
- 7 - Valve
- 8 - Valve
- 9 - Valve
- 10 - Diaphragm
- 11 - Diaphragm seating
- 12 - Valve seating
- 13 - Valve
- 14 - Valve
- 15 - Valve
- 16 - Valve
- 17 - Valve
- 18 - Valve
- 19 - Valve
- 20 - Valve
- 21 - Valve
- 22 - Valve
- 23 - Valve
- 24 - Valve
- 25 - Valve
- 26 - Valve
- 27 - Valve
- 28 - Valve
- 29 - Valve
- 30 - Valve
- 31 - Valve
- 32 - Valve
- 33 - Valve
- 34 - Valve
- 35 - Valve
- 36 - Valve
- 37 - Valve
- 38 - Valve
- 39 - Valve
- 40 - Valve
- 41 - Valve
- 42 - Valve
- 43 - Valve
- 44 - Valve
- 45 - Valve
- 46 - Valve
- 47 - Valve
- 48 - Valve
- 49 - Valve
- 50 - Valve
- 51 - Valve
- 52 - Valve
- 53 - Valve
- 54 - Valve
- 55 - Valve
- 56 - Valve
- 57 - Valve
- 58 - Valve
- 59 - Valve
- 60 - Valve
- 61 - Valve
- 62 - Valve
- 63 - Valve
- 64 - Valve
- 65 - Valve
- 66 - Valve
- 67 - Valve
- 68 - Valve
- 69 - Valve
- 70 - Valve
- 71 - Valve
- 72 - Valve
- 73 - Valve
- 74 - Valve
- 75 - Valve
- 76 - Valve
- 77 - Valve
- 78 - Valve
- 79 - Valve
- 80 - Valve
- 81 - Valve
- 82 - Valve
- 83 - Valve
- 84 - Valve
- 85 - Valve
- 86 - Valve
- 87 - Valve
- 88 - Valve
- 89 - Valve
- 90 - Valve
- 91 - Valve
- 92 - Valve
- 93 - Valve
- 94 - Valve
- 95 - Valve
- 96 - Valve
- 97 - Valve
- 98 - Valve
- 99 - Valve
- 100 - Valve

## DISASSEMBLY AND ASSEMBLY OF THE FUEL PUMP (Model 900) (Fig. 4)

- Remove the fuel pump from the intake.
- Thoroughly clean the outside of the fuel pump.
- Remove the clip (27), the support cap (28) and the seal sleeve or sleeve (29).
- Make the seal and the lower body with a fine wire to ensure correct assembly.
- Take out the five screws and their washers (2) while leaving the top cover to the body of the pump.
- Separate the cover and the body.
- Turn the diaphragm (47) and remove it (48). Its spring (49) and the retainer (50). If the diaphragm is defective, it must be replaced with a new one. At the same time, if there is any sign of either of the two springs (49 and 50) being damaged or of the rocker (51) and the lower body being damaged, replace them as well.

**NOTE.** — There is the bottom case of the pump can may be disengaged provided that it does not exceed 0.20 mm. Bear in mind that permeated resin to the case with oil, diaphragm rod and yield leakage can absorb a considerable amount of the volatile liquid, thereby reducing the movement of the diaphragm and impeding the efficiency of the pump.

Valve assembly cannot be repaired. If a valve is defective it must be replaced by a new one. Before installing a new valve, first be sure to dip it in petroleum. If the diaphragm assembly does not work properly it is best to buy a new one.

To assemble fuel pump, carry out the above procedure in reverse order.




Fig. 7 - Fuel pump Model 90

## DISASSEMBLY AND ASSEMBLY OF THE FUEL PUMP Model 800 (Sp. 7)

- Remove the fuel pump from the bracket.
- Thoroughly clean the outside of the pump and mark the upper and lower pump body flanges to ensure reassembly is in the same position.
- Take out the screw (1) and the washer (2) which secure the cover (3) to the upper body (4) and remove the cover and diaphragm (5). If the diaphragm is not in good condition, it should be replaced by a new one.
- Take out the six screws (6) and washers (7) which secure the upper to the lower body and separate them.
- Very carefully remove the valves (8) from their housing in the upper part of the pump. If the valves are defective replace them. Take out the gaskets (9). Assemble the two halves and assemble in reverse order. To assist the valve in its housing, use an appropriate punch in four points of the upper body.
- Remove the lower body (10) and the diaphragm to see if it is not broken, torn or cracked and replace it if necessary. At the same time, check the diaphragm position.
- Remove the spring from the lower body of the

pump (11) and examine it to see if it is bent or noisy. If the spring has to be changed make sure it is replaced with one of the same characteristics.

- Remove the pin (12), the washer (13), the spring (14) and the linkage (15) from the lower body. Check to see if the parts are worn and replace them if necessary.
- Check to see if the upper and lower body flanges are warped. Lightly oil the joint faces if necessary.
- To assemble the pump follow the disassembly procedure in reverse order, taking care that the edge of the diaphragm (10) is flush with the flange of the pump body. If it projects, this is a sign that it has not been correctly assembled. Special care must be taken to maintain pressure in the pump and when firmly tightening the diaphragm set screw.
- Join housing the pin (12), which must be flush with the pump body, use an appropriate punch in three points around the pin to do no damage.
- After sealing the working of the pump, immerse it on the front mounting to measure residual pressure.

## REMOVAL AND INSTALLATION OF THE FUEL FILTER

- Disconnect and plug the fuel pipe at the filter end.

- Remove the filter and take out its filter.
- Install the filter in reverse order.

## To change the Fuel Filter element (Sp. 8 and 9)

- Remove the tool (1) from the upper center of the filter body.
- Detach the filter body (2) from the body (3).

- Check to see if the gaskets have deteriorated.
- Assemble in reverse order, making sure the gaskets are correctly located.

The fuel filter of the Model 1880 has a built-in sediment cup in the base of a transparent glass (Fig. 1), its purpose is to strain-off the impurities not strained in the fuel pump. To remove any impurity, sediment or accumulation of residue, it is only necessary to unscrew the wing nut (D) and let the contents drain from the tank by gravity.



Fig. 1 — Cleaning fuel filter (excavator Model 1880)

In the Model 380 tractor, the sediment cup is located on the fuel pump module. To remove the O.D., loosen the nut of the clip (E), Fig. 10 and once it has been removed unscrew the cap (B), Fig. 10, the bottom or screw (C), Fig. 10 and the gasket (H), Fig. 10, all of which can be easily cleaned. Assembly by following the procedures in reverse order.



Fig. 10 — Cleaning fuel filter (excavator Model 380)

#### TO REMOVE THE INJECTION PUMP FROM THE TRACTOR

If it is necessary to remove the injection pump from the unit, proceed according to the following instructions:

- Remove the high pressure pipe between the pump and the injector, plugging the holes to prevent the entry of foreign matter.
- Remove the low pressure fuel pipes from the intake and outlet connections and plug the holes.
- Disassemble the shut-off and throttle controls with their retaining springs.

#### TO INSTALL THE INJECTION PUMP IN THE TRACTOR

- Carefully clean the surfaces which have to be in contact with the injection pump and its coupling.
- Get the pump (Fig. 11) in place, making sure that

- Remove the screws and washers which secure the injection pump on the mounting flange.
- On the 1880 - Model 380 tractor, disengage the injection pump located in front of the timing gear, the three screws that secure the pump link plate on the timing gear.
- Mark the position of the sprocket gear so it should always position in the event of a engine replacement.
- Carefully take out the injection pump.

the link plates hole is correctly lined up with the timing gear pin.




Fig. 16 - Fuel injection pump.

A - Pump body  
 B - Drive shaft  
 C - Injection valve  
 D - Plunger  
 E - Plunger sleeve  
 F - Plunger sleeve bearing  
 G - Plunger sleeve bearing cap  
 H - Plunger sleeve bearing cap  
 I - Plunger sleeve bearing cap  
 J - Plunger sleeve bearing cap  
 K - Plunger sleeve bearing cap  
 L - Plunger sleeve bearing cap

M - High pressure adjustment screw  
 N - Diaphragm  
 O - Diaphragm seal/valve cover  
 P - Flame Arrestor Filter  
 Q - Seal  
 R - Oil pipe to pump

- the link piston holds engine, by means of the timing gear pin, therefore valves can only be opened in one position when adjusting.
- After the hole and the pin are correctly fitted to, pressure can be put on the pump until the lock flanges match and the both nuts and respective washers can be assembled.
- Before final tightening, it is necessary to align the pump seating marks, as indicated in Fig. 15.

- Check both marks match, tighten the nuts.
- Assemble the low pressure pipes in their respective fuel intake and return connections.
- Assemble the high pressure pipe.
- Re-assemble the shut-off and bypass controls with their return springs.
- Eliminate air from fuel system.

#### INJECTION PUMP SETTING

If the timing marks have been followed according to the marks on the timing gears and on the assembly flanges, which should be extremely aligned (Fig. 15), then the fuel injection pump setting will be correct.

If further adjustment is possible using the minor adjustment, results on the heads of the pump bolts, it is recommended to take these factors, the temperature must be measured (cf. Fig. 10).




Fig. 11 - Identifying the injection pump



Fig. 12 - Making adjustment marks on pump and base

It must be remembered that in order to gain access to these lever adjustment screws, the fuel lines (on the cover) must be broken. Therefore, once the necessary checks have been made, the pump must be sealed again with flexible steel.

After fuel removing the inspection cover, proceed as follows:

- Turn the engine until the piston is at T.D.C. on the compression stroke.
- Loosen number 1 cylinder exhaust valve adjustment screw sufficiently to allow the rocker arm to be moved to one side and the valve not to be taken out. Turn the rocker arm on the shaft so that the valve spring is accessible (use of valve tool No. 3).
- Remove number 1 exhaust valve spring and allow the head of the valve to rest on the piston head.
- Check a dial gauge on the end of the valve stem (see Fig. 13) and adjust to zero on the maximum lift point obtained by turning the engine, probably the T.D.C.
- Turn the engine in the OPPOSITE direction to

start of normal rotation until the piston and valve have traveled a distance of 0.04 mm (either 200 and 8 mm Model 400) downwards in the cylinder.

This is the equivalent of an angular movement of the T.D.C. to the B.D.C. of the flywheel (at 24° Model 500) and 20° (Model 600) and represents the static setting point. However, if previous it is wished to turn the engine beyond this point, that is, 1.20 mm and then return to 0.04 mm (Model 200) or 0.48 mm and return to 8 mm (Model 400) in the normal direction of rotation. This will eliminate any error due to the normal timing gear clearance.

When this point of static adjustment has been determined exactly, the mark (a) (Model 300) or (b) (Model 400) on the injection pump lever should be aligned with the straight end of the adjustment ring (Fig. 14).

If so, the pump adjustment is correct. If this is not so, do not attempt to move the ring inside the pump, as this will not alter the adjustment at all. If it were moved it would then be necessary to remove the pump from the engine and cap it correctly on a test bench.



Fig. 11 - Testing injector pump adjustment.




Fig. 12 - Lever and slot mounted on pump impeller, aligned with the slot.

- To complete adjustment, in the case in which it is not yet carried, proceed as follows:
- Loosen the nuts which secure the injector pump on the mounting flange and turn the body of the pump in the appropriate direction. If after carrying out this last adjustment, the adjusting marks are not aligned, start new ones on the injector pump flange and reiterate the adjustment.
- Once the injector pump adjustment has been completed, turn the engine in the opposite direction to that of normal operation until the piston has moved 8.84 mm (Model 2000) or 8 mm (Model 1900), in order to check that the straight part of the ring slot is now aligned with the slot on the impeller.
- Once the injector pump adjustment has been correctly carried out, already turn the engine in the normal direction of rotation until number 1 piston reaches T.D.C., in order to remove the chisel gauge and reassemble the valve springs.
- TAKE CARE not to turn the engine backwards in the opposite direction, since this would cause the exhaust valve to fall inside the cylinder and

make it necessary to remove the cylinder head to get it out.

- Fit push rod, beam rocker arm, tappet and adjust valves again.



Fig. 13 - Testing engine stops A and B ... Points of engagement with impeller lever.

## HIGH RIDE ADJUSTMENT

To adjust the high ride height, first the carburetor mapped in the injection pump characteristics plane should be used as reference. The fuel flow figures of this table correspond to this speed. Carburetor 504752985012304 (Model 380) and AIP 0100082080 (Model 380); until these values would indicate that the engine should turn at a maximum of 2,300 r.p.m. and 2,300 r.p.m., respectively.

Adjustment of this speed has to be made by means of the high idle screw (Fig. 103), causing to make this valve to rotate and that therefore, about an engine response adjustment in this respect. It will however be tested again once this operation has been carried out.

The engine must not be allowed to operate at a speed above the specified one or serious damage will result.

To carry out this adjustment, proceed as follows:

- Check for possible leaks in the fuel system and correct them if there are. Make sure that there is fuel in the system.
- Put the engine into fuel unit normal operating temperature is reached.
- Fit a tachometer with appropriate extension and adapt it to the center of the crankshaft pulley set 93594.
- Accelerate the engine until the maximum rpm indicated on the tachometer pulse counter/tachometer is reached. If the speed does not reach this figure, turn the high idle adjustment screw (Fig. 103) counter-clockwise until the appropriate speed is obtained. Once adjusted, check it with the tachometer and test the adjustment once again.

## LOW RIDE ADJUSTMENT

To reduce the low ride r.p.m., first run the engine off its minimum operating temperatures. Then set the adjustment screw (Fig. 103), which corresponds to the thermal lever located above the generator arm, so that the engine turns at a minimum r.p.m. of 800 ± 50 r.p.m. (Model 380) or 900 ± 50 r.p.m.

(Model 480). In turning the screw clockwise, engine speed is increased and by turning it counter-clockwise, it decreases.

A new engine cannot be expected to run perfectly until its mechanical surfaces have had time to adjust themselves to one another properly.

## TO REMOVE AND INSTALL THE INJECTOR

- Disconnect and remove the fuel injection pipe from the injector and plug them.
- Remove the fuel tank pipe.
- Remove the fuel pipe and fuel filter that comes with injector.

— Take out the injector gently and evenly.

When installing them, reverse this procedure, taking care to always change the copper washer and to have the bulk nuts correctly tightened.

## TO TEST THE INJECTOR NOZZLES

An effective method of checking the operation of a suspected defective nozzle is as follows:

- Run the engine over at slightly above idling speed.
- Loosen the injector pipe connections at each injector, in turn.
- An even drop in the engine's rpm indicates that the injectors are working evenly. If a chosen drop

to the engine's rpm occurs when a particular injector connection is loosened, take out this injector for repair or replacement.

When a defective injector is found, it is advisable to take out all the others of the same type for overall testing or replacement.

**NOTE.** — Do not attempt to service the injectors without appropriate means and adequate equipment.

## TO BLEED AIR FROM THE FUEL SYSTEM

The presence of air in the fuel system will give rise to poor engine performance and prevent starting. For this reason the system must be bled whenever it is handled.

To bleed the system, carry out the following procedure:

- Check that all connections, made from those that have to be loosened for bleeding purposes, are well tightened.
- Loosen the filter outlet pipe union and operate the fuel pump several strokes until fuel runs out through the filter outlet nozzle. Tighten the outlet pipe.
- Loosen the two injection pump bleeder nozzles and remove the manual pump until fuel runs out through both outlets without bubbles. On松此 the manual pump until fuel runs out through the bottom outlet nozzle first the lower than the upper one.

— Loosen the injection pump supply pipe union and remove the return handle and tighten the union so that fuel runs out through the nozzle without bubbles.

- Loosen the fuel pipe union to the injector.
- Shut the throttle lever at full open position and check that engine shut-off control is fully tightened.
- Operate start motor until fuel runs out through injector union without bubbles.
- Tighten fuel line nuts and check that there are no fuel leakage losses through the pipe or unions.

**NOTE.** — If the fuel supply pipe to the cold weather starting heater has been disassembled for servicing or any other reason, it must be bled. To do this, remove the three pipe union nuts and unscrew the manual pump until fuel runs out through the nozzle without bubbles, and then tighten the valve nuts.

## TROUBLESHOOTING

Problem	Possible Cause	Action
A. Engine fails to start	1. Improper fuel has been used.	Use only recommended fuel.
	2. Fuel does not reach injection ports.	Check fuel lines for kinkages. Inspect the fuel pump and fuel line unions.
	3. Injectors not working properly.	Check to see if filter is clogged.
	4. Injection timing incorrect.	Adjust timing correctly.
	5. Cold weather starting device does not work correctly.	Inspect cold weather starting device.
	6. Air filter dirty.	Inspect air cleaner.
	7. Return pipe restricted.	Check flow of fuel through return line.
	8. Return pipe restricted.	Unblock it.

The majority of these faults can be the cause of loss of engine power.

## TROUBLE SHOOTING

Problem	Possible Cause	Action
B. Fuelline leakages	<ol style="list-style-type: none"> <li>1. Restriction in oil supply.</li> <li>2. Excessive fuel.</li> <li>3. Incorrect networking projects.</li> <li>4. Faulty fitting.</li> <li>5. Improper insulation.</li> </ol>	<ul style="list-style-type: none"> <li>Unblock A.</li> <li>Adjust fuel maximum quantity.</li> <li>Service fittings.</li> <li>Adjust fittings.</li> <li>Use only recommended fuel.</li> </ul>
C. Overheating	<ol style="list-style-type: none"> <li>1. Faulty fitting.</li> <li>2. Incorrect networking projects.</li> <li>3. Excessive film restriction.</li> </ol>	<ul style="list-style-type: none"> <li>Adjust fittings.</li> <li>Service fittings.</li> <li>Unblock A.</li> </ul>

## SECTION 6:

# COOLING SYSTEM

### CONTENTS

### PAGE

Specifications	1
Description	1
Removing and installing the radiator	2
Removing and installing the water pump	3
Disassembling the water pump Model 300	7
Assembling the water pump Model 300	8
Disassembling the water pump Model 400	9
Assembling the water pump Model 400	10
Release cap	11
Theated radiator or thermoset	12
Removing and installing the thermostat	13
Fitting the thermostat	13
Anti-freeze protection	13
Frostbite protection	14
Trouble shooting sheet	15



## SPECIFICATIONS

Type	Description
Height of evaporative condenser:	Water circulation by thermosyphon aided by centrifugal pump and temperature control by thermostats.
Model 300	292.3 mm
Model 400	297 mm
Radiator	With finned plates.
Fan	With two blades of 412 mm diameter.
Cooling circuit capacity:	
Model 300	19.5 liters
Model 400	12 liters
Thermostat	
Valve begins to open	29° - 29°C
Maximum opening at 60°C	38° - 38°C
Fan cut-off detector	18 rpm

## DESCRIPTION

As shown in figure 1, both the components and the flow out of the cooling system are to the conventional type. The only protection required for the system is to ensure that there is no obstruction that may hinder the passage of air through the radiator and that the fan belt has the correct tension.

The cooling system water circulates through the action of the pump and thermo-syphon. The thermo-syphon diverts the flow of water towards the radiator and sends it back again to the block until the time when the engine has reached normal operating temperature. The water is cooled by the air which circulates through the radiator. The fan controls a

short or suction effect, which makes the surrounding air pass through the radiator, added to this action by the fan cooling.

Radiator cap and the cylinder block are provided with various plugs for draining the system after assembly.

The radiator filter which has incorporated a bypass valve which reduces cooling solution evaporation and allows slightly higher temperatures. This cap also incorporates a depression valve to prevent a vacuum from forming when system pressure falls down.




Fig. 1 - Components of the system.

## REMOVING AND INSTALLING THE RADIATOR

(Fig. 2)

To remove the radiator from the unit, carry out the following procedure:

- Remove the hood.
- Remove the cap (B) from the radiator (A).
- Remove the drain plug from:
  - a) The radiator.
  - b) The cylinder block.

When draining the system, if anti-freeze solution has been used, it may be collected in a clean container for later use.

- Disconnect the radiator lower upper (C) and lower (D) hoses.
- Disconnect the clearance bleed manifold hose.
- Remove the top cooling (E) from the radiator (A) by taking out the screws (F).
- Take out the screws (G) which secure the radiator to the chassis (H).
- Take out the lower bolts (H) which secure the radiator to the chassis (H).
- Remove the radiator.

To install the radiator, carry out the above procedure in reverse order.




Fig. 2 — Radiator assembly

### REMOVING AND INSTALLING THE WATER PUMP

To remove the water pump from the tractor, proceed in the following steps:

- Remove the radiator along with the fan cooling.
- Loosen the alternator.
- Take off the fan belt.

— Disconnect the hose that connects the pump to the engine.

— Take out the mounted bolts that secure the water pump on the timing gear case. Remove the pump with its gasket.

To install the pump, reverse the above procedure, making sure that the nuts and bolts are assembled with their washers.




Fig. 4 - Water pump (Model 300)

1 - Pump body	2 - Drive shaft
3 - Flexible coupling	4 - Discharge hose
5 - Pump bearing	
6 - Pump seal	




Fig. 4 - Water pump Model 400

1 - Shaft  
2 - Pump housing  
3 - Pump outlet  
4 - Pump intake

5 - Impeller  
6 - Impeller

**DISASSEMBLING THE WATER PUMP**

(Continued from p. 388)

To disassemble the water pump, carry out the following procedure:

- Remove the key after disengaging the pulley set screw (Fig. 3).
- By means of special tool 318-200 and adapters MP-200-4-05 and 544.070, remove the pulley from the pump (Fig. 4).



Fig. 3 — Removing the pulley




Fig. 4 — Removing the bearing shaft

- Using the above mentioned tool and adapters, extract the bearing shaft from the pump housing by exerting pressure on the end of the shaft by the pulley (Fig. 6).
- Take out bearing and impeller with tool MP-200-06 (Fig. 7).

**NOTE.** — The two bearings and the shaft make up a single assembly and cannot be separated.

- Inspect the impeller and pump housing for possible damage or cracks.
- Check to see if shaft is bent, or if there is play in the bearings.

If there are serious signs of wear, replace the complete shaft.



Fig. 5 — Removing the motor and impeller

**ASSEMBLING THE WATER PUMP Model 300**

Assemble the water pump in the following way:

- Using tool MF-200, press in the shaft bearing assembly until the long end of the shaft directed towards the impeller side of the pump until the bearing is flush with the pump housing (Fig. 10).




Fig. 8 — Installing the shaft bearing assembly.

- Secure the four water pump-to-timing gear screws and nuts.

**NOTE.** — Use new copper washers and make sure that the longest screw is put in the top right part, leading air pump from the front.

- Press the impeller onto the free end of the shaft (Fig. 11) until the face of the fan is 140.5 mm from the face of the pump housing.
- Assemble the water outlet flange with the flange fasteners #1000.
- Insert the water tank screw side towards impeller.
- Press the impeller onto the shaft until there is a clearance of 0.304 O.02 mm between impeller face and pump surface (Fig. 11).



Fig. 9 — Assembling the pump.



Fig. 10 — Installing the shaft bearing assembly.

**NOTE.** — The cover plate from the back of the impeller has to be flushed rear of pump housing. Make sure that the shaft has no clearance when it passes through the pump housing.

**DISMANTLING THE WATER PUMP****Method 400**

- To dismantle the water pump, proceed as follows:
- Remove the lock nut and washer that secured the pump pulley to the impeller shaft.
  - Remove the fan after taking out the four screws that secure it to the pulley (fig. 11).



Fig. 11 — Dismantling the fan




Fig. 12 — Dismantling the pump shaft and impeller assembly

- Take off pulley, using tool MP-100.

- With help of tool MF-200 and adapters MF-200A, extract the shaft with the impeller and remove front shaft (fig. 12).



Fig. 13 — Dismantling the pump shaft and impeller assembly



Fig. 14 — Dismantling the bearing housing, motor, and transmission