




MITSUBISHI
MT160,160D
MT180,180D
MT180H,180HD
REPAIR MANUAL





INDEX

GENERAL DESCRIPTION	1
ENGINE SYSTEM	2
CLUTCH SYSTEM	3
FRONT AXLE AND STEERING LINKAGE SYSTEM	4
TRANSMISSION SYSTEM (Sliding gear type)	5-1
TRANSMISSION SYSTEM (Hydrostatic Transmission)	5-2
BRAKE SYSTEM	6
HYDRAULIC SYSTEM	7-1
HYDRAULIC SYSTEM (Position Control)	7-2
ELECTRICAL SYSTEM	8
OTHERS	9



CHAPTER 1

GENERAL DESCRIPTION



TABLE OF CONTENTS

	Page
Specifications	1-1
Greasing diagram	1-12
Periodical maintenance services	1-13
Lubrication table	1-14
Wiring diagram	1-15
Antifreeze	1-16
Tightening torque	1-17
Serial number location	1-17
Sealants	1-18

Tractor model			MT160	MT160D	MT180	MT180D	MT180H	MT180HD
Type			All purpose wheel tractor					
Body structure			Monocoque type					
Dimensions	Overall length	To end of rear tire	2200 (86-19/32)		2225 (87-19/32)			
		To end of 3-point linkage	2523 (99-11/32)					
	Overall width		975 (38-3/8)		940 (37)	970 (38-3/16)	940 (37)	970 (38-3/16)
	Overall height	To top of steering wheel	1155 (45-15/32)	1165 (45-7/8)	1175 (46-1/4)	1185 (46-21/32)	1175 (46-1/4)	1185 (46-21/32)
	Wheelbase		1300 (51-3/16)					
	Ground clearance		260 (10-1/4)	215 (8-15/32)	280 (11-1/32)	215 (8-15/32)	280 (11-1/32)	215 (8-15/32)
	Gross weight		565 (1246)	615 (1356)	575 (1268)	625 (1278)	575 (1268)	625 (1278)
	Load distribution (without load)	Front axle	260 (573)	310 (684)	260 (573)	320 (706)	260 (573)	320 (706)
		Rear axle	305 (673)		315 (695)	305 (673)	315 (695)	305 (673)
	Turning radius (with brakes)		1850 (72-27/32)					
Engine	Model		MITSUBISHI K3A-13MT		MITSUBISHI K3C-13MT			
	Type		Vertical, 4-stroke cycle, water cooled, overhead valve, in line, diesel					
	Number of cylinders		3					
	Combustion chamber type		Swirl combustion chamber with preheater					
	Cylinder liner		Non liner					
	Bore and stroke	mm (in.)	65 x 78 (2-9/16 x 3)		70 x 78 (2-49/64 x 3)			
	Piston displacement	cc (cu in.)	776 (47.4)		900 (54.9)			
	Compression ratio		23 : 1					
	Firing order		1 - 3 - 2					
	Rated rpm	rpm	2700					
	Max. rpm		2900 ⁺⁰ ₋₇₅					
	Idling rpm		925± 25					
	Max. bare HP (SAE)	HP/rpm	16.5/2700		18.5/2700			
	Max. torque	kg-m/rpm (ft-lb/rpm)	4.5 (32.5)/1900		5.2 (37.6)/1900			

Tractor model			MT160	MT160D	MT180	MT180D	MT180H	MT180HD	
Engine	Compression pressure		kg/cm ² (psi)/rpm	32 (455) /280					
	Number of piston rings			3 compression rings and 1 oil ring					
	Intake valves	Open	deg	At 18° before TDC					
		Close		At 46° after BDC					
	Exhaust valves	Open		At 46° before BDC					
		Close		At 18° after TDC					
	Injection timing			At 21° ± 2° before TDC					
	Valve clearance	Intake valves		mm (in.)	0.25 (0.01) at cold				
		Exhaust valves		0.25 (0.01) at cold					
	Fuel consumption			g/HP/h (oz/HP/h)	220 (7.7)	230 (8.1)			
Direction of rotation			Clockwise (as viewed from front)						
Weight, dry			kg (lb)	125 (276)					
Cooling system	Radiator fin			Corrugate type					
	Radiator cap pressure			kg/cm ² (psi)	0.9 (12.8)				
	Thermostat	Type		Wax pellet type					
		Begins to open	°C (°F)	82 (180)					
		Full open		95 (203)					
		Lift	mm (in.)	8 (0.3) at 95° C (203 °F)					
	Water pump	Type		Centrifugal impeller type					
		Feeding capacity	ℓ /min (U.S.gal/min.)	52 (13.7) at 2600 engine rpm					
	Cooling fan	Diameter	mm (in.)	290 (11-13/32)					
		Number of blades		4					
Blade material		Plastic							
Pulley ratio of fan and crankshaft pulley			1.32						
Drive system			"V" - type belt						

Fuel system	Fuel		Bruns grade No. 2-D fuel oil (ASTM specifications)	
	Fuel injection pump	Type	Bosch "M" plunger in line	
		Model	NIPPON DENSO ND-PFR-3M	
		Diameter of plunger	mm (in.)	5.5 (7/32)
		Cam lift		7 (9/32)
	Fuel injection nozzles	Type	Throttle type	
		Model	NIPPON DENSO ND-DN4SD24	
Injection pressure		kg/cm ² (psi)	120 ⁺¹⁰ ₋₀ (1706 ⁺¹⁴² ₋₀)	
Fuel filter		Paper element type		
Lubrication system	Oil pump	Type	Trochoid type	
		Feeding capacity	ℓ/min. (U.S. gal/min.)	20 (5.28) at 2600 engine rpm
	Oil filter		Full flow paper element filter cartridge type	
	Relief valve setting	kg/cm ² (psi)	4 (57)	
Air cleaner	Type		Cyclone dry air cleaner	
	Filter		Dry paper element cartridge type	
	Cleaning efficiency		More than 99.9%	
	Dust holding	g (oz)	20 (0.7)	
Governor system	Type		Mechanical all-speed control	
	Speed control	rpm	90 ~ 2900	
Electrical system	Generator	Type	Alternator	
		Model	MITSUBISHI AH2053M4	
		Voltage	V	12
		Capacity	A	35
	Starter motor	Type		Magnet type
		Model		MITSUBISHI M002T50381
		Voltage	V	12
Output		kW	1.6	

Tractor			MT160	MT160D	MT180	MT180D	MT180H	MT180HD	
Electrical system	Regulator	Type	Tirrill type						
		Model	MITSUBISHI RQB2220D1						
		Regulator voltage (no load)	V	14.8					
		Warning lamp lighting on voltage		0.5 ~ 3.0					
		Warning lamp lighting off voltage		4.2 ~ 5.2					
	Glow plugs	Type	Sheathed type						
		Rated voltage	V (A)	10.5					
		Resistance capacity (at normal temperature)	Ω	1 ~ 1.2					
	Glow plug indicator	Type	Red heat type						
		Rated current	A	30					
Terminal-to-terminal voltage		V	0.9 ~ 1.1 (at 30A)						
Clutch system	Type	Dry single disc plate diaphragm spring type							
	Clutch disc diameter	mm (in.)	184 x 127 (7-5/16 x 5-1/32)						
	Lining thickness		7.8 (5/16)						
	Torque capacity	kg-m (ft-lb)	11.0 (79.6)						
	Spring pressure	kg(lb)	195 (430)						
Transmission	Number of shift levers	2							
	Speeds	6 - forward, 2- reverse				2-forward, 2-reverse			
	Speed change method	Selective sliding gear type				Hydrostatic type			
	Differential	Bevel gear type with differential lock							
	Differential lock	Foot pedal (right side of transmission case)							

MT160 and MT160D

(2-WD and 4-WD) (at engine speed 2700 rpm)

Speed	Lever position	km/hr	mile/hr	m/sec
F-1	L-1	1.1	0.68	0.31
F-2	L-2	1.7	1.06	0.47
F-3	L-3	2.9	1.80	0.81
F-4	H-1	4.9	3.04	1.76
F-5	H-2	7.1	4.40	2.06
F-6	H-3	13.5 (max)	8.38	3.75
R-1	L-R	1.3	0.87	0.39
R-2	H-R	6.1	3.92	1.75

Tire size: 5-18AG tire

Speed	Lever position	km/hr	mile/hr	m/sec
F-1	L-1	1.1	0.75	0.33
F-2	L-2	1.5	1.12	0.50
F-3	L-3	2.1	1.93	0.96
F-4	H-1	5.3	3.29	1.47
F-5	H-2	7.9	4.91	2.19
F-6	H-3	14.5 (max)	9.00	4.05
R-1	L-R	1.5	0.93	0.42
R-2	H-R	6.7	4.16	1.88

MT180 and MT180D

(2-WD and 4-WD) (at engine speed 2700 rpm)

Speed	Lever position	km/hr	mile/hr	m/sec
F-1	L-1	1.15	0.71	0.32
F-2	L-2	1.78	1.11	0.49
F-3	L-3	3.04	1.89	0.85
F-4	H-1	5.17	3.15	1.52
F-5	H-2	7.75	4.82	2.16
F-6	H-3	15.14	9.39	4.33
R-1	L-R	1.42	0.89	0.41
R-2	H-R	6.56	4.09	1.82

Tire size: 9.5-18ES tire

Speed	Lever position	km/hr	mile/hr	m/sec
F-1	L-1	1.24	0.78	0.34
F-2	L-2	1.96	1.26	0.52
F-3	L-3	3.23	2.00	0.89
F-4	H-1	5.49	3.41	1.52
F-5	H-2	8.18	5.09	2.27
F-6	H-3	15.02	9.34	4.17
R-1	L-R	1.55	0.96	0.43
R-2	H-R	6.94	4.31	1.97

MT180H and MT180HD

(2-WD and 4-WD) (at engine speed 3700 rpm)













Speed	Lever position	km/hr	mile/hr	m/sec
F-1	L	0-5.2	0-3.9	0-1.7
F-2	H	0-16.7	0-10.5	0-4.6
R-1	L	0-3.4	0-2.1	0-0.9
R-2	H	0-8.1	0-5.3	0-2.4

Tire size: 9.5-18ES tire

Speed	Lever position	km/hr	mile/hr	m/sec
F-1	L	0-6.4	0-4.0	0-1.5
F-2	H	0-17.2	0-10.7	0-4.5
R-1	L	0-2.5	0-2.2	0-0.9
R-2	H	0-5.8	0-3.5	0-1.4

Tractor model			MT160	MT160D	MT180	MT180D	MT180H	MT180HD	
Final reduction	Final reduction gear		Spur gear						
	Reduction ratio		11/72 (0.153)						
	Type of rear axle		1/2 floating type						
Power take-off	Power take-off step		3-step			2-step			
	Power take-off HP		HP/rpm		13.6/2700		15.5/2700		
	Power take-off shaft		1-3/8 in. 6-spline SAE standard						
	Power take-off rpm	First		623/2700 engine rpm			606/2700 engine rpm		
		Second		919/2700 engine rpm			1,186/2700 engine rpm		
		Third		1,506/2700 engine rpm					
	Standard power take-off	Shift position	First	540/2660 engine rpm			540/2405 engine rpm		
			Third(second)	1,000/1793 engine rpm			1,000/2278 engine rpm		
	Direction of rotation		Clockwise as viewed from the rear						
Steering	Steering system		Ackerman jant method						
	Axle center		Center pivot type						
	Steering knuckle arrangement		Lemoine type	Reverse Elliott type	Lemoine type	Reverse Elliott type	Lemoine type	Reverse Elliott type	
	Tread adjustment		Not adjustable						
	Axle center swing angle		8						
	Kingpin angle		8	10	8	10	8	10	
	Camber		2.5						
	Caster		3	0	3	0	3	0	
	Toe-in		mm(in.)	6.4±1.5(1/4±1/16)	0~6(15/64)	6.4±1.5(1/4±1/16)	0~6(15/64)	6.4±1.5(1/4±1/16)	0~6(15/64)
	Steering angle		deg	55	53	55	53	55	53
	Steering gear box (inside)		Ball screw type						
	Gear ratio		15						
	Steering wheel diameter		mm(in.)	403 (15-29/32)					
Brake system	Type		Foot operating, internal expansion, waterproof dry type						
	Brake pedal		Seperate with interlocking foot operating type						
	Parking brake and operating		Main brake used hand, operating lock, type						

Brake system	Lining	Length x width x thickness	mm(in.)	119 x 28.5 x 4.0 (4-11/16 x 1-1/8 x 5/32)					
		Number of linings		4					
	Drum diameter		mm(in.)	114 (4-31/64)					
	Brake location			Differential shaft					
	Brake pedal free play		mm(in.)	25 ~ 30 (63/64 ~ 1-3/16)					
Tire	Front AG	Tire size and ply rating		4.00-9-4PR	5-12-4PR	4.50-10-4PR	5-12-4PR	4.50-10-4PR	5-12-4PR
		Tire pattern		Three-rib:F-2	Farm-lug:R-1	Three-rib:F-2	Farm-lug:R-1	Three-rib:F-2	Farm-lug:R-1
		Tire pressure	kg/cm ² (psi)	3.25(46.2)		2.2 (31.3)			
		Outside diameter	mm(in.)	457 (18)	550(21-21/32)	488(19-7/32)	550(21-21/32)	488(19-7/32)	550(21-21/32)
		Tire width		113 (4-7/16)	123(4-27/32)	120(4-23/32)	123(4-27/32)	120(4-23/32)	123(4-27/32)
		Maximum load	kg (lb)	200 (441)	210 (463)	205 (452)	210 (463)	205 (452)	210 (463)
		Type of valve		TR - 13					
		Rim size		3.00Dx9DT	4JAx12	3.00Dx10DT	4JAx12	3.00Dx10DT	4JAx12
	Front ES (option)	Tire size and ply rating		18x7.00-8-4PR	6-12-4PR	20x8.00-10-4PR	6-12-4PR	20x8.00-10-4PR	6-12-4PR
		Tire pattern		Pillow-dia:G-2	All-weather:R-3	Pillow-dia:G-2	All-weather:R-3	Pillow-dia:G-2	All-weather:R-3
		Tire pressure	kg/cm ² (psi)	2.0(28.4)	2.2(31.3)	1.7(24.2)	2.2(31.3)	1.7(24.2)	2.2(31.3)
		Outside diameter	mm(in.)	457 (18)	564(22-7/32)	495(19-15/32)	564(22-7/32)	495(19-15/32)	564(22-7/32)
		Tire width		170(7-3/32)	155(6-3/32)	193(7-19/32)	155(6-3/32)	193(7-19/32)	155(6-3/32)
		Maximum load	kg(lb)	310 (684)	270 (595)	410 (904)	270 (595)	410 (904)	270 (595)
		Type of valve		TR - 413	TR - 13	TR - 413	TR - 13	TR - 413	TR - 13
		Rim size		5.50x8DT	5JAx12	6.00Ix10DT	5JAx12	6.00Ix10DT	5JAx12
	Rear AG	Tire size and ply rating		8 - 16 - 4PR		8 - 18 - 4PR			
		Tire pattern		Farm-lug : R-1					
		Tire pressure	kg/cm ² (psi)	1.0 (14.2)					
		Outside diameter	mm(in.)	783 (30 - 13/16)		840 (33 - 5/64)			
		Tire width		197 (7 - 3/4)		197 (7 - 3/4)			
		Maximum load	kg/(lb)	475 (1047)		515 (1136)			
		Type of valve		TR - 15		TR - 281A			
		Rim size		W6 x 16		W6 x 18			

Tractor model		MT150	MT160D	MT180	MT180D	MT180H	MT180HD		
Tire (option)	Tire size and ply rating	9.5 - 16 - 4PR			9.5 - 18 - 4PR				
	Tire pattern	All-weather - R-3			All-weather - R-3				
	Tire pressure	1.0 (14.2)			1.0 (14.2)				
	Outside diameter	820 (32 - 3/32)			870 (34 - 1/4)				
	Tire width	242 (9 - 17/32)			242 (9 - 17/32)				
	Maximum load	555 (1234)			600 (1323)				
	Type of valve	TR - 15			TR - 219A				
	Rim size	W8 x 16			W8 x 18				
AG tire	Standard tread	Front	720 (28-13/32)	785 (30-29/32)	720 (28-13/32)	785 (30-29/32)	720 (28-13/32)	785 (30-29/32)	
		Rear	740 (29 - 3/32)		740 (29 - 3/32)				
	Max. tread	Front	-	-	-	-	-	-	
		Rear	890 (35)			890 (35)			
ES tire	Standard tread	Front	790 (31-3/32)	800 (31-1/2)	795 (31-5/16)	800 (31 - 1/2)	795 (31-5/16)	800 (31-1/2)	
		Rear	750 (31 - 3/32)		750 (31 - 3/32)				
	Max. tread	Front	-	-	-	-	-	-	
		Rear	840 (33 - 3/32)			865 (34 - 1/16)			
		MT160 (2-WD)			MT180D (4-WD)				
Tread adjustment									
	AG/F			ES F			AG R		
									
	AG/Max-R			ES R			ES Max-R		
									
	AG Max-R			ES F			AG R		
									
AG Max-R			ES R			ES Max-R			


		MT180 & MT180H			MT180D & MT180HD			
Tread adjustment								
	AG F		ES F		AG/R			
	AG Max R		ES R		ES Max R			
	AG F		ES F		AG/R			
Hydraulic system	Control		Lift, hold, down, flow control			Position control, downspeed control and lock		
	Cylinder		Type			Single-acting		
	Diameter of piston		mm (in.)			60 (2 3/8)		
	Stroke of piston					71 (2 13/16)		
	Maximum lift power at end of lower link		kg (lb)			500 (1103)		
	Pressure for pump relief valve setting		kg/cm ² (psi)			135 (1920)		
	Hydraulic pump		Type			Pressure loading gear type		
	Name and model					NACHI GP-3607A		
	Capacity		liters/min (U.S. gallon/min)			12.9 (3.4) at 1700 engine rpm		
	Control valve type		Spool valve, 2-port, 2-position			2 spool valve with unload valve		
	Oil lock valve					In line, non-return valve, flow control valve type		
	Strainer mesh					# 42 x 100 mesh		
	Hydraulic oil					SAE # 68 gear oil same as transmission oil		
Hydraulic external actuator					Optional			
Lifting speed of 3-point linkage		sec						

Tractor model		MT160	MT160D	MT180	MT180D	MT180H	MT180HD	
3-point linkage	Category		JIS "1"					
	Lifting capacity	kg (lb)	500 (1103)					
	Top hitch pin hole dia	mm (in.)	19 (3/4)					
	Lower link stud hole dia		22 (7/8)					
	Width of cross-shaft		683 (26-29/32)					
Drawbar	Type		Fixed type					
	Max. drawbar pull	kg (lb)	-	-	390 (860)	590 (1300)	390 (860)	590 (1300)
	Max. drawbar HP	HP	-	-	-	-	-	-
Electrical system	Battery	Model		NX100 - S6L (S)				
		Capacity	V-Ah	12 - 45				
		Size (length x width x height)	mm (in.)	238 x 129 x 203 (9-3/8 x 5-5/64 x 8)				
		Weight	kg (lb)	14 (30.9)				
		Specific gravity of electrolyte		1,260 [20°C (68° F)]				
		Polarity of ground		Negative				
	Head lamps	Bulbs	V-W	12 - 35, 2 pcs				
		Light switch		Relay type 3 steps, up and down				
	Tractor meter		Engine tachometer					
	Engine lubrication warning lamp	Location		On the instrumental panel				
		Type		Warning tellite				
		Warning lamp lighting pressure	kg/cm ² (psi)	0.2~0.4 (2.8~5.7)				
		Lamp color		Red				
	Water temperature warning lamp	Location		On the instrumental panel				
		Type		Warning tellite				
		Warning lamp lighting temperature	°C (°F)	105 ~ 111 (221 ~ 232)				
		Lamp color		Red				
	Battery charging warning lamp	Location		On the instrumental panel				
		Type		Warning tellite				

Electrical system	Battery charging warning lamp	Warning lamp lights on	V	3.5 ~ 3.0		
		Warning lamp lights off		4.0 ~ 3.2		
		Lamp color		Red		
Safety starter switch	Capacity	V-A		12 - 35 (Momentary 70A)		
	Stroke	mm (in.)		5 ± 0.5 (1/8 ± 1/64)		
Working lamp (optional)	Bulb	V-W		12 - 27		
	Location			At the rear of right hand fender		
Capacities (approximate with fill)	Fuse	A		10		
	Cooling water	liter (quart)		5 (5)		
	Engine oil	liter (quart)		3 (3)		
	Transmission oil	liter (U.S. gal-pint)		1.1 (3.1)		1.4 (3.6)
	Steering gearbox	CC (oz)		200 (6.8)		
	Hydraulic oil			Same as transmission oil		
	Front differential case oil	liter (quart)		2.5 (5)	2.5 (5)	2.5 (5)
	Front differential case oil					
	Fuel tank	U.S. gal-pint		18 (4 - 8)		

These specifications are subject to change without notice.

GREASING DIAGRAM



The greasing part of MT160/D and MT180H/RD are same as MT180/D.

This figure shows MT180D.

PERIODICAL MAINTENANCE SERVICES

● = replacement ○ = clean-up ⊕ = check

Item	Maintenance Interval								Thereafter every
	Initial 50 hrs	100 hrs	150 hrs	200 hrs	250 hrs	300 hrs	350 hrs	400 hrs	
Engine oil	●	●		●		●		●	100
Engine oil filter element	●	■		●		●		●	100
Fuel filter element	○	○		○		○		●	○ 100 ● 400
Air cleaner element	○	○	○	○	○	○	○	●	○ 50 ● 400
Injection nozzle pressure								⊕	400
Transmission oil and HST filter	●	●		●		●		●	● 300 ○ 100
Hydraulic oil filter element	○	○		○	○	○	○	○	50
4WD front axle differential case and front gear case oil	●	○		●		○		●	● 200 ○ 100
Valve clearance	⊕							⊕	400
Cooling water	●	○	⊕	⊕	⊕	⊕	⊕	●	○ 50 ● 400
Specific gravity of battery electrolyte	⊕	⊕		⊕		⊕		⊕	100

[NOTE]

It is advised the intervals mentioned in the above list regarding replacing, cleaning-up and checking are for the standard cases and then desired to make each work so as to meet the requirement depending upon the usage condition of the tractors.

Initial 50 hrs services are for a brand new tractor.

GENERAL DESCRIPTION

LUBRICATION TABLE


Application	Kind of Oil	API classification	Ambient Temperature	Grade (SAE No.)		Description
				Single	Multi	
Engine	Motor oil or Super tractor oil (universal ISTOU)	CC CC	~ 10°C (14°F)	5W	5W-20	Use High grade oil of famous brand.
			20 ~ 0°C (-4 ~ 32°F)	10W	10W-30	
			10 ~ 10°C (14 ~ 50°F)	20W		
			0 ~ 20°C (32 ~ 68°F)	20		
			10 ~ 30°C (50 ~ 86°F)	30		
			30°C (86°F) ~	40	20W-40	
Transmission/ Hydraulic, 4-WD Front Axle	Gear Oil OR * Farm tractor use transmission hydraulic oil or multi-4WD use fluid.	GL-3 or better	Below 0°C (32°F)	75W		Use good grade oil of famous brand. Use good grade oil supplied by famous farm tractor manufacturers or oil companies.
			-10 ~ 30°C (14 ~ 86°F)	80W	80W-90	
			0 ~ 35°C (32 ~ 95°F)	85W	85W 110	
			10°C (50°F) & above	90		
Steering gear oil	Grease	-	All seasons	NLGI - No. 1		Not requiring periodical service. Replace only when overhauling.

• [NOTE]

As transmission oil is also used as hydraulic oil, gear oil with higher viscosity will give a very bad influence on starting behaviour of the engine. From this standpoint this kind of oil is recommendable for the areas of very low air temperature in winter season.

For more details, please ask your MITSUBISHI dealer

oil of
oil of
farm
sup-
farm
only
medical



WIRING DIAGRAM

GENERAL DESCRIPTION

ANTIFREEZE


When the atmospheric temperature is lower than 0°C (32°F) cooling water should be drained off completely or antifreeze solution should be added to prevent the breakdown of the cylinder block due to the frozen cooling water. Percentage of the antifreeze to be added should be a little higher than specified for the lowest atmospheric temperature in your area.

When adding antifreeze solution, the following rules should be observed otherwise, the cylinder block will rust.

- (1) This tractor's engine is of a diesel type and its cylinder block is made of cast iron. Therefore antifreeze solution suitable for such a cast engine block must be used.
- (2) Before adding mixture of antifreeze and water, completely drain cooling water and clean the radiator using a detergent.
- (3) Water to be added to the antifreeze should be a clean soft water.
- (4) When the antifreeze is no longer required, drain and wash the cooling system using a detergent and fill it again with clean water. Do not re-use the antifreeze solution after it has been drained from cooling system.
- (5) Treat antifreeze carefully as it can remove paint from the cylinder block.
- (6) Any antifreeze solution (antifreeze and water), even if it is a permanent antifreeze, should not be used for more than 3 years.
- (7) Confirm that there are no leaks from the hose joints or cylinder head gasket.
- (8) Antifreeze with correct density to suit the climate in your area should be used.
- (9) When antifreeze is used for a long period in winter, measure the specific gravity frequently.

Temperature, mixing ratio and specific gravity of the antifreeze

Freezing point °C (°F)	Percentage of antifreeze %	Specific gravity at 20°C (68°F)
-6.1 (20.7)	15	1.023
-7.3 (15.3)	20	1.029
-12.6 (9.3)	25	1.037
-16.3 (10.8)	30	1.044
-20.5 (-4.2)	35	1.051
-25.2 (-13.0)	40	1.058
-31.3 (-14.2)	45	1.066
-37.6 (-35.7)	50	1.073
-45.3 (-49.4)	55	1.078
	60%	1.085



TIGHTENING TORQUE


Unit: kg-m (lb-ft)

Bolt size	4T	6T	7T	8T
M5	0.2 ~ 0.35 (1.44 ~ 2.53)	0.45 ~ 0.55 (3.25 ~ 3.97)	0.55 ~ 0.65 (3.97 ~ 4.69)	0.65 ~ 0.75 (4.69 ~ 5.42)
M6	0.5 ~ 0.7 (3.61 ~ 5.06)	0.80 ~ 1.00 (5.78 ~ 7.23)	1.0 ~ 1.2 (7.23 ~ 8.68)	1.2 ~ 1.4 (8.68 ~ 10.1)
M8	1.2 ~ 1.7 (8.67 ~ 12.3)	2.0 ~ 2.5 (14.4 ~ 18.1)	2.5 ~ 3.0 (18.1 ~ 21.7)	3.0 ~ 3.5 (21.7 ~ 25.3)
M10	2.1 ~ 3.0 (15.2 ~ 21.7)	4.0 ~ 5.0 (28.9 ~ 36.1)	5.0 ~ 6.0 (36.1 ~ 43.3)	6.0 ~ 7.0 (43.3 ~ 50.6)
M12	4.5 ~ 5.5 (32.5 ~ 39.7)	7.0 ~ 8.0 (50.6 ~ 57.8)	8.5 ~ 9.5 (61.4 ~ 68.6)	9.5 ~ 11.0 (68.6 ~ 79.5)
M14	6.5 ~ 8.0 (46.9 ~ 57.8)	10.0 ~ 12.0 (72.2 ~ 86.7)	12.0 ~ 13.5 (86.7 ~ 97.5)	13.5 ~ 15.0 (97.5 ~ 108.0)
M16	9.0 ~ 11.0 (65.0 ~ 79.5)	13.0 ~ 15.0 (93.9 ~ 108.0)	15.5 ~ 17.5 (112.0 ~ 126.0)	18.0 ~ 20.0 (130 ~ 144)
M18	12.0 ~ 14.0 (87.7 ~ 101.0)	17.0 ~ 19.0 (123 ~ 137)	21.0 ~ 24.0 (152 ~ 173)	25.0 ~ 28.0 (181 ~ 202)
M20	15.0 ~ 17.0 (108.0 ~ 123.0)	20.0 ~ 22.0 (144 ~ 159)	24.0 ~ 28.0 (173 ~ 202)	32.0 ~ 36.0 (231 ~ 260)

SERIAL NUMBER LOCATION


Tractor serial number

It is located at the left side of the clutch housing, specifically upper side of the step.



Engine serial number

It is located at the right hand side of the cylinder block, specifically injection pump side.



Tractor serial number

It is located at the right side of the transmission case specifically upper side

Engine serial number

It is located at the right hand side of the cylinder block, specifically injection pump side.


SEALANTS

Sealants are similar in function to gaskets; they are used to keep liquids (such as lubricants and water) in — and dust, dirt, moisture and chemicals (“enemy” of the tractor) out. In this respect, too much emphasis cannot be placed on

the importance of selecting sealants of the types called for the MITSUBISHI Tractor. The following chart will serve as a rough guide for selecting sealants:

Sealant Selection Chart

	Where to use	Sealant base	Properties (minimum requirements)	Operating temperature
Engine	Threaded parts	Epoxy-modified	<ul style="list-style-type: none"> • Weather resistance • Oil resistance • Heat resistance 	-30°C ~ 200°C (-22°F ~ 392°F)
	Main bearing caps and side seals	Silicone rubber	<ul style="list-style-type: none"> • Weather resistance • Oil resistance • Heat resistance 	60°C ~ 250°C (76°F ~ 482°F)
Chassis	Transmission case, hydraulic case, etc.	Heat resistant synthetic rubber (nonhardening type)	<ul style="list-style-type: none"> • Weather resistance • Oil resistance • Heat resistance • Tear resistance 	-40°C ~ 150°C (-40°F ~ 302°F)
	Brake covers, engine-clutch housing joint, etc.	Special synthetic rubber (hardening type)	<ul style="list-style-type: none"> • Moisture resistance • Weather resistance • Oil resistance • Heat resistance 	40°C ~ 150°C (-40°F ~ 302°F)



types
ollow-
ecting

CHAPTER 2

ENGINE SYSTEM

re




TABLE OF CONTENTS

	Page
Description	2-1
Sectional views	2-2
Construction	2-4
Cylinder head assembly	2-4
Cylinder block assembly	2-6
Engine services	2-10
Engine removal	2-10
Engine installation	2-13
Piston removal	2-13
Piston installation	2-14
Water pump removal	2-14
Cylinder head disassembly	2-14
Cylinder block disassembly	2-15
Inspection	2-16
Reassembly	2-22
Lubrication system	2-29
Description	2-29
Removal and disassembly	2-30
Inspection	2-30
Reassembly	2-31
Fuel system	2-32
Description	2-32
Disassembly	2-36
Inspection	2-35
Reassembly	2-39
Governor system	2-43
Description	2-43
Disassembly	2-44
Inspection	2-44
Reassembly	2-44
Cooling system	2-45
Water pump	2-45
Thermo switch	2-46
Thermostat	2-46
Coolant change	2-47
Rust inhibitors and antifreeze additives	2-47


Air cleaner	2-49
Description	2-49
Air cleaner services	2-49
Periodical maintenance service chart	2-50
Engine maintenance guide	2-51
When to overhaul	2-51
Compression pressure test – how to measure compression pressure	2-52
Engine diagnosis on the basis of compression pressure readings	2-52
Engine diagnosis on the basis of oil consumption	2-52
General working rules on disassembling and reassembling steps	2-52
Troubleshooting	2-54
Specifications and maintenance standards	2-55
Tightening torque	2-66
Application of sealants	2-66
Special service tools	2-67

DESCRIPTION


The engines mounted on MITSUBISHI MT160/D, MT180/D and MT180H/HD water-cooled, 4-stroke cycle, overhead-valve, three cylinders diesel engines.

They are Model K3A for MT160 and MT160D and K3C for MT180, MT180D, MT180H and MT180HD which technology and manufacturing know-how. Their combustion chambers are of swirl type designed to provide improved combustion efficiency and high fuel economy; their


preheating system of glow plug type assures positive cold starting; and their crankshaft, supported at four places, is well balanced to withstand continuous full load without exhibiting any abnormal vibration at all speeds. Each piston is fitted with three compression rings and one oil ring. Full consideration is given to all features of engine construction in order to ensure the reliability of engine performance and to facilitate maintenance services.



Frontal view




Right-hand side view




Left-hand side view

SECTIONAL VIEWS



- | | | | |
|------------------------|------------------|-----------------------|----------------------|
| 1-Water pump pulley | 6-Exhaust valve | 11-Cylinder block | 16-Crank gear |
| 2-Cooling fan | 7-Oil filler cap | 12-Flywheel | 17-Gear case |
| 3-Water pump | 8-Rocker cover | 13-Rear oil seal case | 18-Crankshaft |
| 4-Water outlet fitting | 9-Rocker shaft | 14-Oil pan | 19-Crankshaft pulley |
| 5-Intake valve | 10-Cylinder head | 15-Oil screen | 20-Fan belt |

Longitudinal view



- 21-Fuel injection pump camshaft
- 22-Fuel injection pump
- 23-Injection nozzle holder
- 24-Glow plug
- 25-Air breather pipe

- 26-Valve spring
- 27-Röcker arm
- 28-Valve pushrod
- 29-Piston
- 30-Connecting rod

- 31-Tappet
- 32-Camshaft
- 33-Speedometer driven gear
- 34-Drain plug
- 35-Oil level gauge

Transverse view

CONSTRUCTION


CYLINDER HEAD ASSEMBLY

Cylinder head

The head, made of a special cast iron, is shaped to retain greater rigidity and promote the conduction of excess heat to the coolant. As will be noted in the cross section, the head carries overhead valves arranged for cross-flow intake-air admission and scavenging, with intake port located on the right and exhaust port on the left. The high power capability of the Model K3A and K3C is measurably accounted for the improved volumetric efficiency resulting from this valve configuration.

The pre-chamber (pre-combustion chamber), in which the swirl type of pre-combustion takes place, is of insert type in construction, and is press-fitted into the cylinder head to form its integral part. The pre-chamber is not meant to be removed from the head in engine disassembly.

The valve guides for both intake and exhaust valves are common, there being no need to distinguish between the two. They are of a sintered alloy, impregnated with oil for increased resistance to abrasive wear.



- | | |
|-------------------|----------------------|
| 1-Nozzle holder | 8-Oil filler cap |
| 2-Cylinder head | 9-Rocker shaft |
| 3-Mouth piece | 10-Rocker arm |
| 4-Glow plug | 11-Rocker cover |
| 5-Valve spring | 12-Rocker shaft stay |
| 6-Valve stem seal | 13-Push rod |
| 7-Valve | |


Cylinder head — Cross section

Cylinder head gasket

A steel-and-asbestos gasket is used for the head gasket. Its internal edges for cylinder bores are grommetted with stainless steel sheet to resist the high combustion heat and pressure encountered there. Both faces of the gasket are coated with a sealing compound.

Each replacement gasket comes with its surfaces so treated that no sealing compound is required when installing it during engine reassembly.

The later production of this engine uses gasket whose base material is carbon called "Gra-Foil."




Cylinder head gasket

Valves and valve springs

The material of intake valves is a heat-resistant steel; the head diameter is sized large for increased intake efficiency. The heads of exhaust valves are faced with a special alloy, which is deposited by welding.

Valve springs, made of a high-carbon spring steel, have their bottom ends shaped specially so that they will solidly seat on the cylinder head. Their top ends are identified by red enamel. There are no differences in spring retainers and retainer locks between intake and exhaust valves.



So that no lube oil will find its way into the cylinder head through the sliding clearance between valve stem and guide, a valve stem seal is fitted to the guide.

Rocker arms, shaft and stays

The arms are a special cast iron in material, each arm is casehardened by gas carburization. A lube oil hole is drilled in the top part of the arm.


The rocker shaft is fabricated from carbon-steel pipe stock, its hollow serves as oil passage. Those parts of the shaft on which rocker arms are mounted are induction-hardened.

There are three shaft stays made of an aluminum alloy by casting. The stay on the rear side has an internal oilway drilled in such a way as to convey the lube oil coming from the cylinder head. The stay for the rear side is also usable for the front side.

Crankcase ventilation system


This system refers to the arrangement designed to feed back the blowby gas (occurring in the crankcase) to the air breather pipe, so that the gas (which is high in combustible content) will be drawn into the air inlet side and then into the cylinders.

The space inside crankcase is communicated to the space inside the rocker cover through the tappets and the space around the pushrods.



Crankcase ventilation system

CYLINDER BLOCK ASSEMBLY



- | | | |
|------------------|----------------------|--------------------------------|
| 1-Front plate | 4-Oil seal | 7-Main bearing, No. 1 |
| 2-Cylinder block | 5-Bearing cap, No. 1 | 8-Main bearing, flanged, No. 3 |
| 3-Oil seal case | 6-Cap bolt | 9-Cap side seal |


Cylinder block assembly – Exploded view

Cylinder block

The material of the block is a special cast iron whose composition is carefully controlled to present surfaces adapted to sliding contact with pistons. In other words, liners are not used in this block. Four ribs are cast out of the block for four main bearings, of which No. 3 bearing is flanged to take up the axial thrust.

These bearings are of shell type constructed according to the tri-metal concept: a sintered copper alloy (Kelmet type) deposited on the steel backing, with an overlay of a tin-lead alloy for improved initial wearing-in action. The whole surface is flash-plated.


The bushing supporting the front journal of camshaft is a special copper alloy deposited on the backing. (The early production of this engine is not equipped with this bushing.)



No. 3 bearing as thrust-and-journal bearing

Crankshaft

The crankshaft is a carbon-steel precision forging, whose sliding-contact surfaces at journals, crankpins and sealed portions are induction-hardened. It is an integral piece, well balanced and shaped for high rigidity.



Crankshaft

Flywheel and ring gear


The flywheel is made of a cast iron. The pilot bearing for holding the clutch main shaft end is a ball bearing.

The ring gear is made of a carbon steel and shrink-fitted to the flywheel; its gear teeth are induction-hardened.

Pistons, piston pins and piston rings

The piston is an aluminum-alloy die casting, and possesses a minimized inertial mass so that the high-speed load on the main bearings is greatly reduced. Its diameter is cam-ground and tapered to optimize its fit in the bore when the block comes up to the normal operating temperature.


The piston pin is a hollow forging, whose finished surface is casehardened by carburization; it rotates in the piston but press-fitted into the connecting rod, thereby presenting a semi-floating type of small end connection.



Piston and piston pin

The three compression rings are of a special cast iron. The top ring (compression) and oil

ring are plated with hard chromium at their sliding faces.



Piston and piston rings

Connecting rods

The connecting rod has its big end split horizontally and its shank forged into "I" shape in cross section for greater rigidity. The bearing in the big end is of the same tri-metal type as the main bearings. The bearing shells are flash-plated.



Connecting rod

Front plate and gear case


The front plate is bolted to the cylinder block; it is a steel plate, located in place by a positioning pin above the camshaft gear and another pin below the injection pump gear. A gasket is used between this plate and the block.

To the left-hand rear face of this plate is secured the hydraulic pump gear bearing housing together with the gear case.

The gear case is an aluminum casting secured to the front plate, and houses the front bearing for the hydraulic pump gear and also other parts associated with the governor. It should be noted that the gear case serves also as stoppers for the camshaft and idle gear.

Camshaft and timing gears


The camshaft is a high-carbon steel forging having three journals by which it is fitted into and held by the cylinder block. Its journal and cam faces are induction-hardened for increased resistance to wear. Lube oil is pressure-fed from cylinder block to each camshaft journal. By a recess or notch provided in the rear journal, lube oil is intermittently supplied through the cylinder head in order to lubricate the rocker arms and related parts of the valve mechanism. An oil hole which permits an excess of the oil to return to the oil pan is drilled in the rear end of the shaft.



Camshaft

Valve timing

Intake valve opens	18° Before Top Dead Center
Exhaust valve closes	18° After Top Dead Center
Intake valve closes	46° After Bottom Dead Center
Exhaust valve opens	46° Before Bottom Dead Center
Fuel injection timing	21° Before Top Dead Center



Valve timing diagram

The valve timing data, listed above, presuppose that the valve clearance has been accurately set to meet the specification for each valve.

Helical gears, finished by shaving and crowning for greater durability and quieter running, are used for the timing gears.


Hydraulic pump gear

The gear for driving the hydraulic pump is located at the left-hand end part of the gear case. The rear end face of the shaft of this gear has a groove for Oldham coupling. The pump is connected to the bearing housing directly.

Tappets and pushrods

The tappet, pot-like in shape, is heat-treated in a carburizing gas furnace and has its bottom face hardened by chilling. Thus, it is highly resistant to wear. Relative to the center of its cam, the center of the tappet is slightly offset in order to avoid uneven wear of its bottom face riding on the cam.

The pushrod is a steel bar, whose end portions are flame-hardened.



Offset between tappet and cam


Fuel-injection-pump camshaft

This injection pump is of "in-line" type and is driven by the camshaft built in the engine side. Its material is a high-carbon steel, the cam faces being induction-hardened.

A ball bearing is used to support the front part of this camshaft; the tip of the front part is shaped to admit the governor shaft. The rear end face has a groove for Oldham coupling. It is through this coupling that the oil pump is driven.

moving and crowd
quieter running

hydraulic pump is
part of the gear
shaft of this gear
ring. The pump
ring directly.



Injection-pump camshaft

is heat treated
has its bottom
s, it is highly
e center of its
slightly offset
of its bottom

Oil pan
The oil pan is a steel-sheet vessel having a
drain plug located at the lowest point of its
bottom.



Oil pan

end portions


chair

" type and
the engine
f. the cam

the front
out part is
rear end
ing. It is
pump is

Speedometer driven gear

This driven gear is of high-speed automotive
type and provides good durability. It is mounted
on the center part of the left side of cylinder
block and is driven by the camshaft



(Rear view)

- 1 O-ring (small)
- 2 O-ring (large)
- 3 Sleeve
- 4 Driven gear shaft
- 5 Camshaft
- 6 Cylinder block

Speedometer driven gear

ENGINE SERVICES

Besides the daily or routine services required on the engine, repair and replacement services have to be carried out at times depending on the internal conditions of the engine. For the latter class of services, the whole engine may have to be dismantled from the tractor or some of its components may have to be dismantled and taken down with the engine remaining in place. In either case, it is essential that the work be performed in a clean place, with a clean floor and a surrounding space large enough to handle the engine or its components freely.

Use of the prescribed tools (special tools) in addition to the common tools is another essential requirement. The standard practices for engine servicing include the following:

- (a) Have a hoisting or lifting means ready for use. Some of engine components are too heavy to handle with bare hands.
- (b) The exterior surfaces of any part or component must be cleaned before its removal.
- (c) Have a full assortment of hand tools (including special tools) ready for use. Make sure they are clean.
- (d) There should be an adequate number of trays and pans for holding disassembled parts in an orderly manner, plus plenty of washing fluid and wiping cloths. A supply of clean compressed air is desirable.

A repair or replacement service is usually occasioned by an operating difficulty or failure of one or more components of the engine. If the service involves removal of one or more of the below-named engine parts, it is not necessary to take down the engine from the tractor; the service can be carried out with the engine in place.

- (1) Cylinder head. (This includes the valve mechanism.)
- (2) Pistons.
- (3) Fuel-injection pump or oil pump.


- (4) Water pump.
- (5) Gear case cover, timing gears or related parts.

ENGINE REMOVAL


In the event of the flywheel or clutch needing a repair service, the engine must be taken down, complete with the radiator, front axle and chassis, by detaching it from the clutch housing. The method of separating the engine from the clutch housing is detailed in the section for CLUTCH.

The engine removal procedure for replacing crankshaft or cylinder block is as follows:


- (1) Bring the tractor to the place of work, letting it stand on the level floor, and drain the engine oil pan.



- (2) Drain the engine cooling system by opening the cock on the cylinder block.




- (3) Unlatch and open the bonnet, and undo the headlight wire connectors inside. Remove hinge bolts and take down the bonnet.





Lighting wire connectors


- (4) Disconnect cables from the battery terminals: disconnect the minus (-) cable first and the plus (+) cable next.



- (5) Remove safety covers and engine covers
 (6) Undo all electrical connectors and disconnect wires from their terminals.




- (7) Loosen the clamp on the manifold-side end of air cleaner hose, and pull off this end. Loosen the bolt on air cleaner band, and remove the air cleaner.




Removing air cleaner

- (8) Remove the bolt and unit securing the air cleaner mounting bracket in place, and take off the bracket.
 (9) Disconnect upper and lower hoses of the radiator from the engine side, loosening the clamps on hose connections.



Removing radiator hose


ENGINE



Mounting bolts

Removing radiator mounting bolt


- (10) Loosen radiator mounting bolts, right and left, and take down the radiator from the chassis.
- (11) Disconnect fuel return pipe from fuel tank.
- (12) Turn off fuel filter cock, and remove the fuel pipe between filter and injection pump.
- (13) Disconnect engine control rod from governor lever.
- (14) Disconnect drag link from steering lever.



Removing drag link


- (15) Disconnect oil pipes from the hydraulic pump, making sure that "O" rings come out of the pipe connections.

In case of MT180H/HD, remove cooler outlet pipe and cooler in let pipe.




Removing oil pipe (engine side)

- (16) Place a jack under the clutch housing, and operate the jack to push up the housing lightly.
- (17) Remove the bolts securing the chassis: there are two bolts on front side and a total of eight on right and left sides. Remove the chassis gently.



Removing chassis



- (18) Hitch a wire-rope lifting sling to the engine hanger bolts, and operate the hoist to take up the weight of the engine.
- (19) Remove the bolts securing the engine to the clutch housing. As necessary, pry open the joint to sever the engine from the housing by using a flat-tip (plain) screwdriver. Pull the engine (in suspended state) off the housing.

NOTE


The bolts securing the fuel tank bracket need not be removed.

- (20) Bring the engine over to and set it on the work stand: the engine is now ready for disassembly.

<4-WD TRACTOR>

If the machine is a 4-WD tractor, two more steps must be carried out just before taking up the weight of the clutch with a jack in Step (17), above. The two additional steps concern the universal joint:

- (a) Remove the front and rear universal-joint covers.
- (b) Pick out the front universal-joint circlip, pull out the pin, and disconnect the joint.



Cover

ENGINE INSTALLATION

The procedure of re-installing the engine is reverse of the foregoing removal procedure.


PISTON REMOVAL

To remove the pistons, proceed as follows (with the engine in place):

- (1) Drain oil pan.
- (2) Drain the cooling system by opening the cock on the lower part of the radiator.
- (3) Remove air cleaner cap. Unlatch and open the bonnet.
- (4) Disconnect cables from the battery terminals, undoing the terminal connection of minus (-) cable first and that of plus (+) cable next.
- (5) Remove safety guards, right and left.
- (6) Loosen the clamp on air cleaner hose at manifold side, and disconnect the hose. Loosen the air cleaner band bolt, and take down the cleaner.
- (7) Remove the bolts securing air cleaner bracket in place, and take off the bracket.
- (8) Disconnect the radiator upper hose from the engine.
- (9) Disconnect the tractor meter wire at engine side.
- (10) Disconnect the fuel return pipe from the fuel tank.

ENGINE

- (11) Undo the wire connectors of glow-plug and water-temperature wires.
- (12) Remove the bolts securing the alternator brace to cylinder head.
- (13) Disconnect the exhaust manifold (complete with muffler) from the cylinder head.
- (14) Disconnect and remove fuel injection pipes.
- (15) Remove the nuts fastening down the rocker cover, and take off the cover.
- (16) Remove the bolts securing the rocker stays, and take off the three stays complete with rocker arms and shaft.
- (17) Pull out the pushrods one by one.
- (18) Loosen the cylinder head bolts sequentially in the ascending order of numbers as shown below and remove the cylinder head.



Cylinder head bolt loosening sequence


- (19) Remove the cylinder head gasket.
- (20) Disconnect tie rod from knuckle arm.
- (21) <4-WD TRACTOR>
Remove the front and rear universal-joint covers; pick out the front circlip; pull off the pin; and disconnect the universal joint.
- (22) Remove the bolts securing the oil pan to the cylinder block, and take off the oil pan, taking care not to distort it. Remember, the sealing compound used in this joint may not permit the oil pan to separate easily.
- (23) Remove the cap nuts on each connecting-rod big end, take off the cap, and push out the piston assembly from block top.

PISTON INSTALLATION

To re-install the pistons, carry out the foregoing procedure in the reverse order. Be sure to clean each part thoroughly before installing it, and to oil it just before it is inserted or fitted if it is a rotary or sliding part.

WATER PUMP REMOVAL

It is necessary to take down the radiator from the chassis in order to remove the water pump.




Removing water pump


CYLINDER HEAD DISASSEMBLY

Carry out the Steps (1) through (19) of piston removal procedure, outlined above. Set the removed cylinder head assembly on the bench, and proceed as follows:

- (1) Remove nozzle holders.
- (2) Disconnect glow-plug lead wires, and remove the plugs.
- (3) Using the valve lifter, remove each valve in this manner: Compress the spring with the lifter; take off retainer locks; and pick out retainer, spring and valve in that order. Place the removed parts in trays or pans, separating them into three groups, one group for each cylinder. Be sure to identify each part for the cylinder it has been servicing.



Cylinder head assembly



Removing tie rod


- (4) Disconnect water bypass hose, and remove thermostat fitting.

CYLINDER BLOCK DISASSEMBLY

- (1) Take down the engine from the machine.
- (2) Remove the cylinder head assembly, as outlined in piston removal procedure, above.
- (3) Remove the water pump and electrical parts and components as outlined in respective paragraphs.
- (4) After pulling out the pushrods, draw out the tappets, taking them out from the cylinder block top.
- (5) Remove the speedometer driven unit.
- (6) Loosen the nut securing the crank pulley, and take off the pulley and washer.
- (7) Take down the flywheel: loosen the flywheel bolts just a little at a time.
- (8) Remove the rear plate and rear oil seal case.
- (9) Turn over the cylinder block upside down, and remove the oil pan and oil screen.
- (10) Remove the hydraulic-pump gear bearing housing and the gear case. Just before detaching the gear case, be sure to remove the inspection peep hole cover and to disconnect the stopper spring and tie rod from the pump control rack.


NOTE

It is very important that, before the gear case is removed, the injection pump control rack should be disconnected from the tie rod. As mentioned previously, the front plate is bolted to the cylinder block, the bolts being run in from inside the gear case. Be careful not to remove the plate together with the gear case and also not to disturb the dowel pins.



Removing gear case

- (11) Remove the fuel injection pump.
- (12) Remove the governor weight securing bolt, and take out the weights.
- (13) Remove the set screw on pump camshaft.
- (14) Remove oil filter and oil pump assembly, and draw out the pump camshaft.



Removing timing gears

- (15) Remove timing gears and detach the front plate from cylinder block.
- (16) The push rods, tappets and speedometer driven unit having all been removed, draw out the engine crankshaft.
- (17) Open the big end of each connecting rod by removing the cap. Push out each piston assembly from block top.


NOTE

Have all removed parts laid out in groups, identifying each part for the cylinder from which it was taken. It is a standard practice to assign a reference number to each cylinder and use that number to refer to the group of parts, which of course include bearing shells, piston rings, etc. Never drive out the combination of piston and connecting rod; push on the mating face of big end with a wooden stick, as necessary, not to damage the bearing shell.



Removing piston complete with connecting rod

- (18) Use the piston pin setting tool (special tool) to separate piston pin from piston in the manner illustrated here. Lay down the connecting rod on the tool body, fit the pushed tool to the piston pin in place, and press down the pushed tool to force the pin out. Never use a hammer to drive on the pushed tool.



Removing piston pin

NOTE


- a) Never drive off the pin. If the pin is seized in the piston, it may be necessary to replace piston, pin and connecting rod with new ones.
- b) Do not apply a press force of more than 3000 kg (6615 lb) to the special tool.
- (19) Remove the main bearing caps. Set aside the removed caps and bearings separately in groups, each marked for its journal, so that the same combination as before can be reproduced at the time of reassembling. Before removing caps, read the crankshaft end play and write the reading down for reference.

- (20) Take off the crankshaft.

INSPECTION**Cylinder head**

- (1) Wash the cylinder head clean. Before doing so, visually examine it for evidence of cracking, water leakage or any damage.

- (2) Check to be sure that the internal oil passages are all clear.
- (3) Using a straightedge and feeler gauge, check the gasketed surface for flatness.




Checking the gasketed surface for flatness

Valve guides

- (1) Take diameter measurements on valve guide and stem to find out the radial clearance by subtraction; if the determined clearance exceeds the limit, replace the guide or valve, or both.
- (2) To remove the guide for replacement, drive it out of the cylinder head by giving a push to the bottom side of the guide. Use the valve guide remover.


To install the replacement guide, press it into the hole until its trailing portion measures 12 ± 0.5 mm (0.5 ± 0.02 in.) from cylinder head top, as shown below. After pressing the guide in, check the radial clearance by inserting its valve stem just for a trial: if the clearance is too small, ream the guide to produce a proper radial clearance.



Pressing in of valve guide

Valve seats

- (1) Visually inspect each valve seat for seating contact pattern and for damage and, as necessary, repair it by lapping in the usually manner to the seat angle and diameter specified.




Valve seat angle and diameter

- (2) An insert-type valve seat in service is subject to beating action of its valve and might force itself, though very gradually, into the cylinder head, thereby presenting a phenomenon of "seat sinkage," which is primarily due to creeping effect of stressed metal. This sinkage shows up as an increment in the as-installed length of valve spring.

Measure the length of each valve spring in place and, if the increment (corresponding to the sinkage) is found to exceed the limit, replace the whole cylinder head.

In measuring the as-installed length, it is permissible to read the distance between the bottom end of spring to the top face of spring retainer. In such a case, the thickness (measured in advance) of the retainer must be subtracted from the reading. The retainer (actually the flange) thickness is $1.7^{+0.3}_0$ mm ($0.067^{+0.0118}_0$ in.).




Measuring as-installed length of valve spring

ENGINE

Valves

- (1) Visually inspect the seating face and stem of each valve for wear and damage, and repair or replace the valve, as necessary.
- (2) A valve whose head is worn down to the limit of "T" value must be replaced.
- (3) Inspect the valve for localized wear at three places in particular, which are indicated in the illustration, and repair or replace the valve, as necessary. Make sure that the top end face and other surfaces of the stem as shown by arrows are smooth and that there are no dents nor groovy depressions on the stem.



Valve springs

- (1) Cracked, worn or otherwise damaged springs must be replaced.
- (2) A weakened valve spring, the weakness being evidenced by its reduced free length or spring rate, must be replaced.
- (3) Check each spring for squareness. Never re-use distorted valve springs.


Rocker arms and rocker shaft

- (1) Take diameter measurement on rocker arms and rocker shaft to determine the clearance between the two. Replace the arms if the clearance exceeds the service limit.

- (2) A rocker arm whose end face for pushing down the valve stem is badly worn must be replaced. The same consideration is required for the adjusting screw, whose end face comes into contact with the top of the pushrod: if this face is found badly worn, replace the adjusting screw.


Cylinder block

- (1) Visually inspect the cylinder block before and after washing it clean. If any crack or serious damage is noted, replace the cylinder block.
- (2) Check the camshaft front journal bushing for wear. If the bushing is worn beyond the service limit or damaged beyond repair, remove it by using the special tool (installer) and replace it with new one.



Removing camshaft bushing


- (3) Clean the water jackets of the cylinder block, removing water scales and rust, if any.
- (4) Check each cylinder bore for wear and inspect the bore wall for scoring, scuffing and other types of surface flaw, to determine whether repair by reboring or honing is necessary or not. To take micrometer readings for wear determination, be sure to measure at three levels, 1, 2 and 3, in two directions, A and B, as shown, thereby producing a total of six readings.
- (5) If the piston rings are the only parts to be renewed, there being no need of reboring or honing the cylinder bores, check the amount of "ridge" formed on the top portion of the bore and, as necessary, remove the ridge by reaming. The bore should be honed after this reaming.



Measuring cylinder bore diameter

Pistons, piston pins and piston rings


- (1) Burnt, grooved or badly scuffed pistons must be replaced.
- (2) Measure the piston diameter at its skirt in the direction perpendicular to the piston pin to determine its radial clearance in the cylinder. If the piston is found excessively worn, replace it.



Measuring the piston outside diameter

- (3) Check the side clearance of each ring in the groove and, as necessary, replace the ring.

To measure the side clearance of No. 1 ring, which is taper, hold the ring face flush with the land face, and insert a feeler gauge between the piston and the bottom (flat) side of the ring.




Checking ring side clearance

- (4) Piston rings whose joint gap is too large must be replaced. To check the gap, place the ring in the cylinder bore and push it down with the piston inserted upside down.


ENGINE

When the ring is located at the least worn part (lower section) of the cylinder, take out the piston and read the gap with a feeler gauge.



Connecting rods

- (1) To check each connecting rod for bend and twist, the connecting rod aligner must be used. Fit the connecting rod to the aligner and, if the rod is found to be excessively distorted, that is, bent or twisted, repair or replace it.
- (2) Check the big end for thrust clearance by fitting the big end to the crankpin and by using a feeler gauge. If the clearance is noted excessively large, replace the connecting rod.




Crankshaft


- (1) A distorted crankshaft must be straightened or, if the distortion is too large to correct, be replaced. Distortion here refers to the bow, if any, of the crankshaft, which can be measured with a dial indicator in the usual manner.

- (2) Inspect the surfaces of journals and crankpins for burning and damage and, as necessary, repair these surfaces by grinding to the next undersize. Grinding to an undersize necessitates replacement of the existing bearings by the corresponding undersize ones.

When grinding the journals and crankpins, be sure to finish the corner radii to 2.5 mm (0.1 in.).




- (3) Check the crankshaft end play and, if the measured play is in excess of the specification, replace the No. 3 main bearing. End play measurement is valid only when the crankshaft is set in place in the normal condition, with its main bearings fitted correctly and its bearing cap bolts tightened to the prescribed torque value. Use a dial gauge in the illustrated manner to read the end play.




Main bearings and connecting-rod bearings

- (1) Inspect the bearing shells, paying particular attention to the tri-metal surface for evidence of flaking. Burnt, pitted or wiped shells and shells showing bad contact pattern must be replaced.
- (2) Mike the main bearings and connecting-rod bearings and also the crankshaft journals and crankpins to determine, on the basis of ID readings and OD readings, the amount of oil clearance available in each fit. (A press gauge can be used instead.)



Measuring main bearing ID



Measuring connecting rod (crankpin) bearing

When reading the bearing ID, whether it is a main bearing or a crankpin bearing, be sure that the bearings shells are tight in the usual manner, with the cap bolts torqued to the specification. If the clearance determined by computing with the ID and OD readings exceeds the limit, replace the bearings or, if mere bearing replacement does not produce the specified clearance,


grind the crankshaft journals and crankpins to the next undersize and use the undersize bearings.

Timing gears and hydraulic pump gear

Inspect these gears for tooth contact pattern, tooth wear and damage and, as necessary, replace them. Inspect the Oldham coupling groove formed of the end of the pump gear; if this groove is disfigured or damaged, replace the gear.

Camshaft


- (1) If the running clearance between the camshaft journal and its hole provided in the block is too large, then either the camshaft or the block must be replaced. This clearance is to be determined by measuring journal diameter and hole diameter.
- (2) Visually inspect the cam faces for damage, and check each cam for cam height by miking. Replace the camshaft if any of the cams is in bad condition in regard to cam height and face.



Measuring cam height on engine camshaft

Fuel-injection-pump camshaft


Inspect and check this camshaft as in the case of engine camshaft. Additionally, inspect the shaft end, which is shaped for Oldham coupling: the camshaft must be replaced if the coupling end is disfigured.



Measuring cam height on injection-pump camshaft

Tappets

- (1) A tappet whose bottom face is flaked, grooved or cracked must be replaced.
- (2) Check each tappet for radial clearance by miking its OD and hole ID. Be sure to replace the tappet if the clearance is found to exceed the limit.



Engine tappets

Pushrods

- (1) A pushrod which is excessively worn at either end must be replaced.
- (2) Check each pushrod for straightness by rolling it on a surface plate. If it is bowed or otherwise distorted, straighten it in the usual manner or replace it.

Speedometer driven unit

Inspect this unit for wear and damage at its gear and shaft. Be sure, at the time of installing this unit, that the "O" ring is in good condition.


REASSMBLY

Cylinder head

To reassemble, use reverse of disassembly procedure. Observe the following rules:

- (1) Install valve guides, making sure that each guide protrudes out of the top of the head to the specified height. (The method of installing them is explained in "Inspection," above.)
- (2) Fit the valve stem seal to each valve guide, making the seal settle snugly on the guide end.
- (3) Oil valve stems, and insert them into the guides. Put on valve springs, retainers and locks, in that order.
- (4) Build up the rocker mechanism by proceeding as follows: Hold the front stay with its mounting bolt hole coming on the right-hand (nozzle) side. Insert the rocker shaft into the stay so that the identifying mark (3-mm or 0.1-in. dia. hole) on the end of the shaft faces the right-front side (the in pump). Mount the outer front rocker and secure it in place by fitting snap ring; mount the inner front rocker, thus completing the reassembly of the first group.

Reassemble the second and third groups similarly, ending with the fitting of the rear-most snap ring; set the whole mechanism on the cylinder head; and secure it to the head by bolting. Be sure to use seat washers on the bolts for front and rear stays.




Rocker arms and shaft

- (5) Run the glow plugs into the head, and tighten them to the prescribed torque

value. (Gaskets are not required because of the tapered seal feature.)

- (6) Mount the nozzle holders. The mounting bolts must be tightened equally, and to the prescribed torque value. Use new gaskets on the holders.
- (7) Connect lead wires to the glow plugs in place.
- (8) Do not apply any sealant to the cylinder head gasket: the replacement gasket comes with its surfaces coated with sealant.
- (9) When securing the cylinder head to the block, be sure to tighten its bolts sequentially to make sure that the pressure will be equalized. This is accomplished by running all bolts in till they become finger-tight, and then tightening them with a torque wrench gradually and in two or three steps, each time moving the wrench from one bolt to another in the sequential order indicated by the numbers and tightening to the prescribed torque limit in the final step.




Cylinder head tightening order

- (10) Several kinds of gaskets and packings are used on the cylinder head. Be sure to use new gaskets and packings in reassembly. Also, be sure to use the prescribed sealant at the places specifically designated.
- (11) To adjust the valve clearance, proceed as follows:
 - (a) Valve clearance adjustment should be carried out with the piston in top dead

center on compression stroke when the engine is cold.


Be sure to tighten the cylinder head bolts to the specified torque before adjusting the valve clearance.



Adjusting valve clearance

- (b) To bring the No. 1 cylinder piston to top dead center on compression stroke, align the timing (TDC) mark on the crank pulley with that on the gear case by turning the crankshaft in normal direction, as shown below. Now, the intake and exhaust valves of the No. 1 cylinder are ready to be checked. Check the clearance and, if it is incorrect, adjust it by turning the adjusting screw.

Be sure to align the timing marks perfectly or the valves are moved away from the correction position, making it impossible to obtain the correct valve clearance.



Timing marks

ENGINE

- (c) Next turn the crankshaft 240 degrees in normal direction to bring the No. 3 cylinder piston to top dead center on compression stroke. Having made sure that the timing marks are perfectly aligned, check and adjust the valve clearance on this cylinder.
- (d) Further turn the crankshaft 240 degrees, and similarly adjust the valve clearance of No. 2 cylinder valves.

Cylinder block

The procedure of building the cylinder block assembly is as follows:


NOTE

- a) Clean all parts thoroughly. Make sure oil holes are clean and clear, sliding surfaces free of any foreign matters, and rotary parts capable of smooth rotary motion.
- b) Before fitting a part, be sure to oil it lightly.
- c) Do not re-use the gaskets, packings, "O" rings and the like that have been removed in disassembly. Use new sealing parts in reassembly.
- d) Use of sealant is specified for some joints and fits. Be sure to use the sealant where its use is prescribed.
- e) Adhere to the standard practice of tightening bolts or nuts sequentially on a part secured by a plurality of bolts or nuts (in order to avoid distorting the part) and to use a torque wrench on bolts for which a torque limit is specified. Even those bolts or nuts for which no torque limit is specified must be tightened to a certain limit established for the type and size of the bolts or nuts. Under-tightening or stripped screw threads are usually a result of ignoring the fact that a so-called "torque limit" is synonymous to required tightening torque.

- f) Important clearances, end plays and thrust plays are specified to be within a certain range or to take a certain value. In the process of reassembly, be sure to check and double-check such a clearance or play.


The sequence of steps for reassembling the engine is exactly reverse of the disassembly. However, a large number of reassembling steps involve special techniques, treatments, checks for meeting specific requirements, and adjustments. Those steps will be described.

- (1) When installing the camshaft front journal bushing into the cylinder block, use the installer and press in the bushing so that the oil holes in the bushing and cylinder block are aligned. It is advisable to put a mark indicating oil hole position on the front face of cylinder block with a soft pen before installing the bushing for the convenience of aligning the holes and also of checking after the installation of the bushing is completed



Installing camshaft front journal bushing


- (2) Fit the main bearing shells to the caps and to the half-bores formed of the block, making sure that each shell is correctly positioned.



Securing main bearing caps


- (3) Oil the crankshaft journals and crankpins, and set the crankshaft in place.
 (4) Put on main bearing caps and secure them by tightening their bolts to the prescribed torque value.

Each cap has an arrow mark and numeral cast out: refer to these marks and position the cap correctly. When installing Nos. 1 and 4 caps, be sure to apply sealant to their mating faces.




Fitting side seal of main bearing cap

- (5) Check the end play of crankshaft.
 (6) Apply sealant to the periphery of the side seals, and push them into the front and rear caps. This completes the installation of the crankshaft.



Fitting directions of side seals


- (7) To the rear oil seal case of crankshaft, fit the oil seal; and install the seal case with its gasket, securing the case fast to the cylinder block.



Installing oil seal case

- (8) Using the piston pin setting tool (three-piece tool), combine piston with connecting rod in the following manner:
 (a) Fit piston pin to the pushrod (tool), and run guide (tool) all the way into pushrod.
 (b) Insert the combination of pushrod, pin and guide into the piston from the guide side, passing the pushrod through the small end of connecting rod, making sure that the front arrow mark (on piston crown) and the identifying mark on connecting rod come on the same side (top side).

Before inserting the pin, be sure to oil it as well as the small end.



Pressing in piston pin



- (c) Rest the whole work (piston, pin and connecting rod with pushrod and guide) on the tool body, bringing the notch of the guide into register with the notch provided in the tool body; and turn the guide by 90°, making sure that the small end is snugly settled in the recess of the body. Again, check to be sure that the front mark on piston crown and the identifying mark of the rod are both on top side and pointing upward.
- (d) Using a press and applying a force of anywhere between 500 and 1500 kg (1103 and 3308 lb), push the pin into the connecting rod. Should the pin go in with a push of less than 500 kg (1103 lb) or greater than 1500 kg (3308 lb), the connecting rod or pin and piston must be replaced. The guide (tool) serves to locate the pin in the prescribed position. After pressing the pin in, turn the pushrod by 90° and take off the combination from the tool body.

NOTE

- a) After combining piston with connecting rod, check to be sure that the pin is centered on the axis of connecting rod. If the pin is found displaced to one side, check the tool and, after correcting it as necessary, use it to push the pin back to the center position.


- b) As stated previously, restore all parts to their original positions in reassembly. Remember, piston and pin constitute a set and must not be interchanged. Be sure, too, that the three pistons are of the same size (same mark).

- (9) Fit the rings to the piston, discriminating the three compression rings, as shown, and distributing the gaps equiangularly. The side face of each ring with the maker and size marks comes on top side. When installing the oil ring with expander, be sure to position the expander tube opposite to the gap of the ring.



- (10) Insert the three combinations (piston and connecting rod) into the cylinders from the gasketed surface, using a ring band on each piston to embrace its rings. Make sure that the ring gaps are correctly distributed and that the arrow mark on piston crown points toward the front end of the engine. On the crankshaft side, connect the connecting rods to respective crankpins, with

the bearings fitted properly, and secure the caps by tightening their bolts to the prescribed torque value.



Inserting piston-connecting rod combination


(11) Install the front plate, with its gasket properly positioned and doweling the plate securely.

(12) Turn over the crankshaft to bring No. 1 piston to top dead center position.

(13) Fit the key into the keyway formed of crankshaft, and install the crankshaft gear.

(14) Set idle gear in place, matching its "1" mark to the "1" mark on crankshaft gear. If the crankshaft front bearing is already in place, the latter "1" mark may be hard to see and, in such a case, reference should be made to the engraved line, instead of the "1" mark, that is provided on the side face of gear boss. Fit the guide seals coated with sealant to the front and rear main bearing caps at this time by pushing the seals in, and have the cap bolts tightened to the torque limit.


Insert the camshaft assembly into the cylinder block, positioning its gear in such a way as to bring its match mark "2" into register with the mark "2" on idler gear. Similarly install the injection-pump camshaft, making the match mark "3" of its gear to the mark "3" of idle gear. Finally, install the hydraulic pump drive shaft, meshing its gear with camshaft gear.



Timing gears

(15) Attach the governor weight assembly to the injection-pump camshaft gear.


(16) After installing governor parts, install the gear case, with its gasket properly set, while inserting the tie rod and its stopper spring into the cylinder block.



Securing gear case to cylinder block

(17) Put on the crank pulley, followed by its washer and nut, and tighten the nut to the torque limit.

(18) Fit the gasket to the block, and install the rear plate.



Securing rear plate to cylinder block


ENGINE

- (19) Attach the oil screen, and install the oil pan.
- (20) Turn over the cylinder block. While slowly rotating the camshaft or the speedometer driven gear shaft, install the driven unit, making sure to fit its "O" ring correctly.

Apply sealant such as Three-Bond #2 to the periphery of the sleeve.

To reassemble the driven gear unit, proceed as follows:


- Fit "O" ring in the groove in the sleeve.
- Apply EP (extreme-pressure) type grease to the periphery of driven gear shaft, especially to its "O" ring surface, and insert the shaft.
- Secure the shaft to the sleeve by inserting the spring pin, being sure that the groove of the pin faces outward and that the tip of the pin is not protruded beyond the periphery of the sleeve.
- Put "O" ring to the groove on the periphery of sleeve. After completing reassembly, check to be sure that the gear shaft rotates smoothly.



- | | |
|---------------------|--------------------|
| 1-Driven gear shaft | 4-"O" ring (small) |
| 2-Sleeve | 5-Spring pin |
| 3-"O" ring (large) | |


Reassembling driven gear unit

- (21) Oil the tappets liberally, insert them into the holes, and follow them with pushrods, making sure each pushrod fits snugly.



Inserting tappets

- (22) Install the cylinder head assembly on the block, as outlined in the preceding section.
- (23) Install the injection pump assembly: refer to the section dealing with the fuel system.



Installing injection pump


- (24) Install the oil pump and filter: refer to the section covering the lubrication system. Be sure to apply sealant to the screw threads of the oil pressure switch when installing this switch.
- (25) Install the fuel filter.
- (26) Install the water pump and cooling fan.
- (27) Install the starter and alternator. For this installation work, refer to the section dealing with the electrical system.

LUBRICATION SYSTEM

DESCRIPTION

The oil pump is of trochoidal type; it is driven from the rear end of the injection-pump camshaft through an Oldham coupling. The discharge pressure is kept at a constant level by a check valve.

The oil filter is of full-flow type. Discharged oil is cleaned while flowing through the cartridge of this type oil filter before entering the cylinder block.



- | | |
|-----------------------|--------------------|
| 1-Oil filter | 7-Oil pan |
| 2-Check valves | 8-Oil filler cap |
| 3-Oil pump | 9-Rocker arm |
| 4-Oil pressure switch | 10-Rocker shaft |
| 5-Camshaft | 11-Camshaft |
| 6-Oil screen | 12-Oil level gauge |

Engine lubrication scheme

Engine oil information

For the present engine, the engine oil is prescribed to be of API classification at CC or above, whose viscosity rating is as follows:

Air temperature	Grade (SAE No.)	
	Single	Multi
Below -10°C (14°F)	5W	5W-20
$-20^{\circ}\sim 0^{\circ}\text{C}$ ($-4^{\circ}\sim 32^{\circ}\text{F}$)	10W	10W-30
$-10^{\circ}\sim 10^{\circ}\text{C}$ ($14^{\circ}\sim 50^{\circ}\text{F}$)	20W	
$0^{\circ}\sim 20^{\circ}\text{C}$ ($32^{\circ}\sim 68^{\circ}\text{F}$)	20	
$10^{\circ}\sim 35^{\circ}\text{C}$ ($50^{\circ}\sim 95^{\circ}\text{F}$)	30	
30°C (86°F) & above	40	20W-40

The oil in the oil pan should be changed every 100 hours of engine operation. The first oil change should be effected after 50 hours of initial operation.

Here's the method of changing the oil. When the engine is still hot after a substantial duty run, drain the oil pan completely, and add the fresh oil through the filler (whose cap is atop the rocker cover) until the oil surface comes up to the upper level mark on the level gauge. After filling up the oil pan, run the engine a minute or so and then re-check the level.

Oil filter

This cartridge-type filter is easier to handle because its body and filtering element are integral. It has a built-in check valve on the upstream side, which is arranged to respond to the differential pressure across the element. When this pressure exceeds 1 kg/cm^2 (14.2 psi) (due, invariably, to a dirty element), the valve opens to allow the oil to bypass the element, causing an unfiltered oil to flow into the cylinder block in order to maintain an adequate supply of lube oil to the running parts of the engine. The filter element is prescribed to be replaced by a new one every 100 hours. The first replacement should be effected after 50 hours of initial operation.




Oil filter

ENGINE

Oil pump

The oil pump is of the trochoid type and is located at the right side of the cylinder block, behind the fuel injection pump. It has a built-in check valve; this valve limits the discharge pressure to 4 kg/cm^2 (57 psi).


When the check valve operates to relieve the excess pressure, part of the discharged oil is bled out into a line leading to the oil pan. The running parts of the pump are two: inner rotor and outer rotor.



Oil pump — Exploded view

Oil pressure switch

This switch is located at the rear right-hand side of cylinder block, and senses the oil pressure by means of its diaphragm to close the circuit when the pressure falls to anywhere between 0.15 to 0.30 kg/cm^2 (2.13 to 4.27 psi.) As this switch operates, the warning lamp lights up to alert the operator. Whenever this lamp lights (except when the engine is started), the engine must be promptly shut down to search for the cause of low oil pressure condition.



REMOVAL AND DISASSEMBLY

Oil filter

The filter can be loosened and removed with bare hands. If the filter is too tight to turn, use a filter wrench (available in the market).


Oil pump

The oil filter must be removed to take down the oil pump. Separate the pump cover assembly from the body and take off the gasket.

INSPECTION


Oil pump

If the clearance of the outer rotor in the body is too large, replace the rotor assembly. To measure this clearance, use a feeler gauge, as shown.




Checking outer-rotor clearance in the body

If inner rotor clearance in outer rotor (as measured in the manner shown with a feeler gauge) is too large, replace the rotor assembly.



Checking inner-rotor clearance in the outer rotor

Using a straightedge and feeler gauge, check the side clearance between the outer rotor and the pump cover. The body or rotors, or both, must be replaced if the clearance is found too large.




Checking rotor side clearance

Be sure to replace the "O" ring, which seals the joint between body and cover.

Oil pressure switch

Test the removed pressure switch in a test circuit arranged as shown, with variable oil pressure applied to its oil side, in order to see if the switch opens and closes its contact at the specified pressure values. If the switch does not close at a falling pressure between 0.15 to 0.30 kg/cm² (2.13 to 4.27 psi), replace it by a new one.



Oil pressure switch testing circuit

REASSEMBLY

Oil filter

The filter can be installed with bare hands to torque it in place. The required tightening torque is from 1.1 to 1.3 kg-cm (0.08 to 0.09 lb-ft). When fitting the filter, be sure that its "O" ring is snug in the groove. Oil the "O" ring when fitting it to the groove. After completing the whole installation work, observe the oil filter, when the engine is running, to be sure that no oil leaks from the filter.

Oil pump

Oil the inner and outer rotors; attach the gasket to the pump body; set the rotors in the body; fit "O" ring; put on the pump cover; and secure the pump by tightening its bolts.


Oil pressure switch

Apply sealant to the screw threads of the switch body just before running it into the hole. Apply sealant sparingly so that the oil sensing hole of the switch will not be clogged.

FUEL SYSTEM

DESCRIPTION


Fuel oil in the tank flows by gravity through the fuel filter to the injection pump, by which it is pumped to the three injection nozzles through injection pipes. The injection nozzle is in the holder, and has its spraying tip exposed to the combustion chamber. Some of the oil reaching the nozzle from the top of the nozzle holder is spilled into overflow pipe and returns to the fuel tank.



Fuel system components

Fuel filter

This filter is complete with a cock at its inlet and two air-vent screws. The filtering element is a pleated paper unit easy to install and remove and high in filtering performance.




Fuel filter

Fuel injection pump


Each pumping element consists essentially of a barrel, plunger, spring, tappet, control pinion and delivery valve. Three such elements are contained in a single valve body to constitute an injection pump.

The injection pump is mounted on the right-hand side of the engine cylinder block, with its "smoke-set" device facing outward and its adjusting plates coming on the inboard side.

The three tappets ride on the three cams of the pump camshaft by their rollers and convert the rotary motion of the cams into a reciprocating motion for driving the plungers up and down in their barrels.



"Control rack" side of pump



Adjusting plate side of pump

- Injection quantity control

The three plungers move up and down by the same amount: the plunger stroke is constant. "Injection quantity" refers to the amount of fuel injected through the nozzle into the cylinder for each slug of fuel delivered under very high pressure by the pumping element. (For test and adjusting purposes, the value of injection quantity is specified for so many slugs or, to say the same thing, plunger strokes.)


Injection quantity is varied, not by varying the plunger stroke (which is fixed), but by angularly displacing the plungers in place. This angular displacement of three plungers in unison is accomplished by the control rack, whose teeth are meshed with three control pinions. The control rack moves straight; its linear movement causes all three pinions to turn, thereby causing the plungers to turn around their axes.

The pinion is mounted on the control sleeve surrounding the lower portion of the plunger. The plunger is capable of reciprocating in but angularly restrained by the sleeve.

The control force for actuating the control rack comes from two sources: the fuel control lever used by the operator and the governor operating in response to engine speed.

Injection quantity decreases when the rack moves to the right (towards STOP → mark) and it increases when the rack moves to the left.

ENGINE



- | | |
|------------------|------------------------|
| 1-Air vent screw | 11-Spring |
| 2-Stopper | 12-Delivery valve |
| 3-Control rack | 13-Valve seat |
| 4-Return spring | 14-Plunger barrel |
| 5-Gasket | 15-Adjusting plate |
| 6-"O" ring | 16-Control pinion |
| 7-Plunger | 17-Upper seat |
| 8-Lower seat | 18-Plunger spring |
| 9-Tappet | 19-Pump body (housing) |
| 10-Valve holder | |

Injection pump – Cross section

• Smoke-set device

The smoke set unit restricts the maximum fuel injection rate from the injection pump and reduces the amount of exhaust smoke. The stopper is held by a spring in the illustrated position. This position is the smoke set position. When starting the engine, pull the speed control lever fully toward the maximum speed, and the tie rod (with the stopper spring) moves the control rack, which overcomes the spring force and moves in the direction of the arrow, thus allowing over-injection for easy engine starting. On engines with an ungleich device described under the following item c, however, the operations described under item d are required.


Ungleich Device

When an overload is imposed on the engine during operation, the engine speed falls and the function of the governor moves the speed control rack in the direction that fuel injection is increased against the smoke set spring to provide larger torque. To ensure an optimum increase of the injection during


operation, the ungleich set plate which controls the motion of the smoke set stopper is provided. This injection increase characteristic (ungleich effect "L") provides proper torque performance suitable for the work machine between the maximum output point and maximum torque point.

Resetting Ungleich Device and Starting Engine


To start the engine, push the speed control lever in all the way in the stop direction and then move it to the fully opened position, and the ungleich set plate will be reset and an excessive injection state created.



"Smoke-set" device




Ungleich Device



Ungleich Effect "L"

- Injection-quantity equalizing adjustment


The three pumping elements are required to deliver the same quantity of fuel for each control rack position. The requirement is satisfied by allowing the two plunger barrels to be angularly repositioned while the third barrel is kept fixed in place. There are two adjusting plates, each functioning as a cam to angularly reposition the barrel.



Cam mechanism for equalizing injection quantities


- Delivery valve

This is a spring-loaded valve similar in construction to a relief valve. In operation, the valve opens when the plunger rises to develop a very high fuel pressure within the barrel. As the pressure falls, the valve snaps back to its closed position in such a way as to draw back a tiny amount of fuel from the injection pipe. By this retracting action, the nozzle is prevented from producing an after-injection dribble. In other words, each injection is sharply articulated.



Injection nozzles and nozzle holders

The nozzle holder and nozzle constitute a unit, as will be noted in this partial cutaway view.



Nozzle holder and nozzle — Sectional view

In operation, the highly pressurized shot of fuel admitted into the top part of the holder acts on the face, near the spray tip, of the needle valve and forces the needle valve upward against the force of the spring to burst into the combustion chamber through the spray orifices in the tip. The drop of fuel pressure to terminate the shot is so abrupt that the needle valve seats itself sharply. Fuel spilled from the nozzle returns through overflow pipe to the fuel tank.

DISASSEMBLY

NOTE

- Do not remove the two adjusting plates (locking the two rotatable plunger barrels) if pump testing equipment is not available. It is on the equipment (pump tester) that the pump can be adjusted and set for proper injection quantity.
- Internal moving parts, particularly plungers, barrels, delivery valves and the like, are high-precision parts and, upon pump disassembly, must be protected against rusting. Be sure to keep them immersed in a clean diesel fuel contained in a suitably sized pan or tray.

ENGINE

Fuel filter

Remove the retaining nut, pick out "O" ring, and take out the element.

Fuel injection pump

- (1) Disconnect fuel injection pipes from delivery valve holders.
- (2) Removing the pump mounting bolts allows the pump to be taken down. Just before lifting the pump off, have the tie rod disengaged from the control rack inside. To gain access to this rod, the side cover must be removed.
- (3) Place the removed pump on the bench, and disassemble each pumping element in the following manner:

NOTE

During this disassembly, be sure to measure the thickness of the adjusting shims (indicated as (17) in the exploded view) and write down the reading and also the number of shims as reference data for reassembly.

- (a) Remove delivery valve holder (11).
- (b) Pick out delivery valve spring, valve (2) and "O" ring.
- (c) Remove gasket and delivery valve seat.
- (d) Straighten the lock plate, which restrains the tappet guide pin; push in the tappet (18) just a little and pull off the guide pin with pincers. Take out the tappet (18). Shims (17) and lower seat (16) will come out.
- (e) Pick out spring (15) and upper seat (14).
- (f) Pull down and remove pinion (13).
- (g) Draw out plunger and barrel (3) from the delivery valve side of pump housing.


Be sure to group the delivery valve, plunger and barrel, so that these and related parts (pinion, spring, seats and shims) will be restored to the place to which they belong.




- | | |
|------------------------|--------------------------|
| (1) Valve holder | (11) Plate |
| (2) Delivery valve | (12) Control rack |
| (3) Plunger and barrel | (13) Control pinion |
| (4) Air vent screw | (14) Upper seat |
| (5) Hollow screw | (15) Plunger spring |
| (6) Pump housing | (16) Lower seat |
| (7) Return spring | (17) Adjusting shim |
| (8) Stopper | (18) Tappet |
| (9) Adjusting plate | (19) Ungleich set plate |
| (10) Tappet guide pin | (20) Ungleich set spring |

Fuel injection pump Exploded view


- (b) Remove the stroke-set stopper by pulling off split pin and taking off washer and return spring. Draw out control rack (12).



Removing plunger



Removing tappet



Removed delivery valve

NOTE


Do not remove the injection-quantity adjusting plates since this removal makes it necessary to test the pump on a bench tester. If necessary to remove these plates, be sure to mark the plates and pump body to aid reassembly.

Nozzle holders

- (1) From each nozzle holder, disconnect overflow pipe.
- (2) Similarly disconnect injection pipe.
- (3) Loosen nozzle holder securing bolts, and remove the holder assembly.
- (4) Break apart the nozzle holder assembly in the following manner:
 - (a) Grip the holder body in the vise; put the wrench to the retaining nut and loosen the body. Use soft metal pads (aluminum or copper) between vise jaws and holder

body to protect the body when tightening the vise.

- (b) Take out shim washer, pressure spring, flange, pressure pin and distance piece in that order.
- (c) Take nozzle out of retaining nut. If the nozzle will not come easily, shake it loose by tapping on it lightly with a wooden mallet. Be careful not to damage the needle valve part in the nozzle.



Disassembled nozzle holder

INSPECTION**Fuel filter**

Visually examine the filtering element and, if it is found clogged, deteriorated or damaged condition, replace it.



Fuel injection pump

- Delivery valve seat


If the seat is found with evidence of poor seating contact, replace it.

- (1) In addition to the above requirement, each pumping element has to meet the following requirement as proof of a proper fit of the plunger in its barrel: Into the barrel removed upon injection pump disassembly, insert its plunger about 15 ~ 20 mm (0.59 ~ 0.79 in.) of the way, leaving a third of its length outside the barrel, while holding the barrel horizontal, then angle up the barrel slowly by about 60°. This

should cause the plunger to slide in all the way by its own weight to evidence a proper fit. If the plunger goes inward in a free-falling manner or becomes stuck on the way, then the pumping element must be replaced.



(2) Upon disassembly, inspect plungers and barrels for signs of rusting, burning or any other malfunction, and repair or replace pumping elements as necessary. Each plunger inserted into its barrel should be capable of smooth sliding motion when pushed and pulled.



• Plunger and barrel

(1) When the injection pump is in disassembled state, check the fit of the delivery valve piston in the bore by holding the valve with fingers as shown. First, let down the valve all the way into the bore, and give thumb pressure to the bore. This should raise the valve a little and release of thumb pressure should allow it to settle into seated condition; if the valve remains seated without responding to the thumb pressure, its fit in the bore is too loose.

- Control rack and pinions

Inspect the rack and pinions for tooth wear and damage. Badly worn or damaged rack and pinions must be replaced.

- Tappet

Inspect each tappet for wear at its sliding surface, roller and shaft. A damaged or excessively worn tappet must be replaced.

Injection nozzles

- (1) Inspect each nozzle for damage, paying particular attention to its needle valve. If the needle valve is not seating tight, as evidenced by its contact pattern, or if any part of the nozzle is damaged, replace the whole nozzle assembly.
- (2) Check to be sure that pressure springs are in good condition, free from any signs of weakening.
- (3) Each nozzle assembly must be tested for spray pattern after its reassembly. The testing method will be explained in "Re-assembly," below.

REASSEMBLY

Fuel filter


- (1) When setting the element, be sure that the "O" ring fits snugly. With the element set properly and "O" ring in place, tighten the retaining nut fully.
- (2) Secure the filter assembly to the support.

Fuel injection pump

- (1) Insert the barrel into the pump housing by aligning its notch with the dowel of adjusting plate.
- (2) Fit "O" ring to valve holder.
- (3) Insert spring seat, gasket and valve assembly into the valve holder, and run the holder into the pump housing. With the wrench, tighten the holder in place to compress the "O" ring fully.


- (4) Feed the control rack into the pump housing.

- (5) Install pinions, positioning each pinion in such a way as to index its tall tooth (sided by deep valleys) to the engraved line on the rack.



Meshing the rack with pinions


- (6) Insert the upper seat and its spring into each pumping element.



Pumping element parts

- (7) Combine plunger with lower spring seat, and insert the combination, bringing the "L" mark on plunger flange to control rack side.


- (8) Insert the tappets, each tappet being complete with shim. Be sure that guide pin holes in tappet and pump housing are aligned. Attach lock plate and, through the plate, insert guide pin. After installing the guide pins, lock the pins by bending the plate sharply.



Installing tappet

- (9) Install the smoke-set device, positioning its return spring and washer correctly, and lock it by inserting split pin.
- (10) Adjust and set the reassembled injection pump in the following manner:

- (a) A proper amount of shim must be used on the mounting seat when positioning the pump in place. Engage the tie rod (linked to the governor lever) with the control rack, and fit the tie rod spring. Shim stocks are available in nine thicknesses: 0.2 to 1.0 mm (0.01 to 0.04 in.), the thickness increment being 0.1 mm (0.004 in.).




Mounting injection pump

- (b) Reconnect the fuel feed line to the pump, admit fuel oil into the pump, and

vent air out of this line by loosening the air vent screw.

- (c) In the present engine, fuel injection is prescribed to begin at 19° before top dead center. In other words, each pumping element of the pump is required to start delivering a slug of fuel when the piston in its corresponding cylinder comes to a position of 19° (crank angle) B.T.D.C. on compression stroke. This start, that is, injection timing, can be checked in the following way:

- Take No. 1 cylinder as the reference. Remove the delivery valve holder, delivery valve and spring, and install the holder only, so that the fuel will continuously spill out from the holder.
- Slowly turn over engine crankshaft by hand until the fuel ceases to overflow from the holder and, right then at the crank pulley, observe the timing mark to see if the piston (in No. 1 cylinder) is at 19° B.T.D.C.; if not, increase or decrease the thickness of the shim on the mounting seat.




Checking injection timing

- The moment the fuel ceases to overflow corresponds to the start of injection. Increase the shim thickness to retard the timing and vice versa. Changing the thickness by 0.1 mm (0.04 in.) produces a change of about 1° in timing.
- The start of injection can be checked at the end of injection pipe, with

the delivery valve and spring in place and with the injection pipes properly installed: this is an alternate checking method. In this case, disconnect No. 1 pipe from its nozzle holder. Using a socket wrench at the crank pulley nut, gradually turn over engine crankshaft to let No. 1 pumping element force fuel out of the pipe. The moment the fuel starts swelling out of the pipe is the start of injection. This will occur approx. 1 deg. behind the standard injection timing.

- (d) After making sure that the injection timing is correct, install the tie rod cover. When installing the cover equipped with damper spring, keep the tie rod pushed in the direction of increasing the speed.




To set the high engine speed, proceed as follows:

- ① With the damper spring in free state (the adjusting bolt backed), set the engine speed to the "A" rpm by means of the high-speed set bolt. After setting, lock the set bolt with lock nut.

Specification


Model	"A" rpm
K3A-13MT	2840 $\begin{matrix} 0 \\ -40 \end{matrix}$
K3C-13MT	2840 $\begin{matrix} 0 \\ -40 \end{matrix}$



- ② Run in the damper spring adjusting bolt to set the engine speed to the "B" rpm, and lock the bolt with lock nut. (Apply Super Three-Bond #20 to the threads of the bolt before locking.)

Specification

Model	"B" rpm
K3A-13MT	2850 $\begin{matrix} +30 \\ -25 \end{matrix}$
K3C-13MT	2850 $\begin{matrix} +30 \\ -25 \end{matrix}$



- ③ Seal the adjusting bolt with sealing cap.
 ④ Seal the high-speed set bolt with wire and cachet.

Injection nozzles and nozzle holder assemblies

- (1) Fit nozzle assembly, distance piece and pressure pin to retaining nut.

- (2) Fit shim, spring and flange to body, and tighten the body and retaining nut together by torquing to the prescribed value.


NOTE

The body may be gripped in the vise, but not the retaining nut. This is because the nozzle might suffer distortion if the nut is clamped between the vise jaws.

- (3) Fit gasket and nipple to the body.
 (4) When installing the nozzle holder assemblies, be sure to use new gaskets and tighten the securing bolts to the prescribed torque value.
 (5) Prior to installing the overhauled nozzle holder assemblies, test each for "start of injection" pressure, spray pattern, "after injection" dribbling and fuel atomization.

(a) Start-of-injection pressure test

A nozzle tester must be used to determine the pressure at which the nozzle starts spraying. If the pressure noted on the nozzle under test is at variance with the specification, increase or decrease the shim thickness. Changing the thickness by 0.1 mm (0.04 in.) changes the start-of-injection pressure by about 10 kg/cm² (142 psi).



Start-of-injection pressure test

(b) Spray pattern test

Operate the tester lever rather slowly to see if the nozzle shoots out fuel


intermittently. A small amount of fuel is discharged in this test at such a pressure as will allow the needle valve to chatter and, therefore, spray intermittently with some low tone sound. The test is often called "chattering test." A good spray is characterized by fine atomization and straightforward jetting.



Good Bad Bad
Spray patterns in chattering test

(c) After-injection dribbling test

See if the nozzle dribbles after each injection. A dribbling nozzle must be replaced. In the chattering test, fuel might ooze out to form a globule of fuel at the nozzle tip but, since this is due to the chattering action of the needle valve, such a globule need not be taken as a cause of nozzle replacement.



Good Bad Bad
Dribbling in test condition

(d) Atomization test



Operate the tester lever rapidly, at a rate of about 800 strokes per minute to make the nozzle spray out with full force. Visually observe the spray to see if it consists of uniformly fine particles of fuel, straight in direction and having no fissures.

GOVERNOR SYSTEM

DESCRIPTION

The principal device in the governor is three flyweights mounted on injection-pump gear to move its sliding shaft in linear direction. This shaft pushes the governor lever ahead, and the lever is connected to the control rack through the spring loaded tie rod.

In operation, the flyweights spread apart and contract according as engine speed rises and falls. As the speed rises, the flyweights pushes its sliding shaft to pull out the control rack in the direction of decreasing injection quantity to reduce engine speed. In the steady-state condition, this push by flyweights is counterbalanced by the force of governor spring acting on the governor shaft.



- | | |
|-------------------|------------------------|
| 1-Injection pump | 9-Pump gear |
| 2-Governor spring | 10-Gear shaft |
| 3-Tie rod | 11-Tie rod |
| 4-Governor lever | 12-Needle bearing |
| 5-Governor weight | 13-Needle bearing |
| 6-Guiding shaft | 14-Governor spring |
| 7-Gear case | 15-Speed control lever |
| 8-Governor shaft | |

Governor mechanism

DISASSEMBLY

- (1) Remove fan belt. (Refer to the section dealing with the cooling system.)
- (2) Remove crank pulley nut, and take off the pulley.
- (3) Remove the fuel injection pump. (Refer to the section dealing with the disassembly of fuel injection pump.)
- (4) Remove the gear case. (Refer to the removal method outlined in Cylinder block.)
- (5) Take out governor spring, taking care not to disfigure the spring.
- (6) Remove nut, washer and governor spring lever; and take out speed control lever from the gear case.
- (7) Remove nut, washer and spring lever; loosen the bolt securing the governor lever; and remove the lever.
- (8) Remove the governor weight assembly and sliding shaft from the pump camshaft.
- (9) From the governor lever, take off the tie rod and spring.


INSPECTION

Governor weights assembly

Inspect the sliding and rotating portions of the weight assembly, and replace the assembly if any part is excessively worn or damaged badly. Be sure that the sliding shaft is capable of smooth sliding motion.

Governor lever


That part of the governor lever in contact with the sliding shaft must be inspected for wear. Similarly, the connection of the tie rod with the control rack must be inspected. Inspect the tie rod spring, too.



Governor lever

Governor spring

Check this spring for evidence of weakening, inspect it for leakage, and replace it if it is found in defective condition.



Governor weight assembly and sliding shaft


Needle bearings

Check to be sure that the needle bearings on the governor lever shaft which is held by the gear case, are in good condition, free from excessive wear.

REASSEMBLY

Reassemble the governor mechanism by reversing the sequence of disassembling steps. After reassembly, move the rotating and sliding parts by hand to be sure that they all move smoothly.

COOLING SYSTEM




Schematic coolant circuit diagram

WATER PUMP

Construction

Engine coolant is set in recirculation by the water pump, a centrifugal pump mounted on the front end of cylinder block. The pump casing, shaped like a bracket, is bolted to the front end of cylinder block and, by its protruding end, holds the pump shaft through a double-row ball bearing. The inner portion of the shaft carries the pump impeller and the outer portion, outside of the casing, carries a bracket, to which the cooling fan hub and pulley are bolted.

The space between the two rows of balls, surrounded by the casing, is filled with grease; there is no need to give lubricating attention to this bearing. A seal unit is fitted to the shaft, right next to the bearing, to isolate the coolant space from the grease-filled space.



Water pump - Cross section

Removal

- (1) Drain the coolant space of the engine by opening the drain cock, located on the left-hand side of the cylinder block.
- (2) Disconnect water hoses from the pump.
- (3) Remove fan belt.
- (4) Remove cooling fan.
- (5) Remove the mounting bolts and take down the pump.

ENGINE

Inspection

• Water pump

- (1) Inspect the as-removed pump for crack in the casing, evidence of failure in the seal unit and damage to the impeller.
- (2) Spin the impeller by hand to see if the shaft rotates rough and, if so, the pump should be replaced as a whole.
- (3) Inspect the fan blades and hub for damage.
- (4) Check the fan belt for permanent stretch. A stretched or otherwise deteriorated belt must be replaced. Cracks in the belt mean that the belt is aged too much to stand further use.

• Bypass hose


Check the hose for cracks, deterioration or other defects.

Installation

• Water pump and fan belt

Install the pump by reversing the sequence of removing steps and, after putting on the belt, adjust its tension as follows:

The belt is in properly tensioned condition if its middle part between alternator pulley and crank pulley deflects 10 to 12 mm (0.4 to 0.5 in.) when pushed with a fingertip. To adjust the tension, displace the alternator in place. After displacing the alternator to give a proper tension to the belt, tighten the support bolt and brace bolt good and hard.




Adjusting fan belt tension

NOTE

Check to be sure that the bypass hose is installed away from the cooling fan.

THERMO SWITCH

This switch is installed on the cylinder head, on the front end face of its right-hand part. The actuating element, built in the switch body, responds to the change in coolant temperature and closes the switch contact at 108 ~ 114° C (226 to 237° F) of rising coolant temperature. As the switch closes, the warning lamp lights up to alert the operator, telling him to take a necessary step, namely, reducing the load, refill the cooling system as necessary or check the cooling-system components for the cause of abnormal temperature rise.




Thermo switch

THERMOSTAT

The thermostat, located in the path of returning coolant, has a wax-pellet expanding and contracting in response to the rise and fall of coolant temperature. By its expanding and contracting movements, the pellet actuates the valve to control the coolant flowrate in the return line to the radiator. When coolant temperature is low, a little coolant is admitted by the thermostat direct into the suction side of the pump, thereby reducing the flowrate through the radiator.

Installation

To install the thermostat, first secure the thermostat fitting by tightening its mounting bolts (2 pcs) good and hard, and place the thermostat in it, as shown. Then install the water outlet fitting with its arrow mark up after placing its gasket. Installing this fitting the other way round will cause damage to the thermostat. Be sure to apply Three-Bond #4 to the nipple when installing it to the thermostat fitting.



- | | |
|------------------------|---------------------|
| 1 Water outlet fitting | 5 Water bypass hose |
| 2 Thermostat | 6 Thermostat |
| 3 Nipple | 7 Water pump |
| 4 Thermostat fitting | |

Installing thermostat

Inspection

- (1) The thermostat valve remains seated (closed) when coolant temperature is down. The temperature at which the valve starts unseating itself is specified; similarly, the temperature at which the valve reaches its full open position is specified.

To test the thermostat to see if it meets these specifications, the thermostat must be taken down and placed in a pool of water, whose temperature can be raised and lowered. Remember, the thermostat is insensitive to the pressure of engine coolant.

A thermostat not meeting the specifications must be replaced.

- (2) When tested as above, the thermostat valve should remain seated tight at the ambient

temperature, that is, when the water is cold; if not, it means that the wax-type element is defective or has failed to require replacement of the thermostat as a whole.

Functional specifications

Item	Standard
Valve opening temperature	82°C (180°F)
Valve full-open temperature	95°C (203°F)

NOTE

The wax-pellet type thermostat will be stuck closed if its sensing part is damaged, causing the engine to overheat.

COOLANT CHANGE

Soft water should be used in the cooling system; hard water is likely to foul up the water side of the system in a relatively short time by forming scales and sludges — substances that interfere with smooth conduction of heat from metal to the coolant. Even soft water, if used too long, becomes high in the concentration of scale- and sludge-forming impurities.

Twice a year, or at least once a year, clean the whole cooling system by vigorous flushing and fill up the system with a fresh batch of coolant.

RUST INHIBITORS AND ANTIFREEZE ADDITIVES

It is recommendable that a rust inhibitor, which is commercially available in most of auto supply stores, should be added to the coolant in order to retard the formation of rust and sludges in the cooling system. In areas where the lowest temperature is anticipated to be below the freezing point, an antifreeze compound should be added to the coolant in an proportion appropriate for the lowest expected sub zero temperature.

ENGINE

A typical antifreeze compound is effective to the extent and degrees illustrated. Its percent concentration in the coolant (cooling water) and

the corresponding temperature level, down to which the coolant will not freeze, are as listed in this chart:

Antifreeze concentration (%)	13	23	30	35	45	50	60
Freezing temperature [°C (°F)]	5 (23)	10 (14)	15 (51)	20 (-4)	30 (-22)	40 (-40)	50 (-58)

AIR CLEANER

DESCRIPTION


The air cleaner is composed of three stages of air cleaning: 1st stage is a wire-netting for keeping out larger dusts such as straw, weed, etc. 2nd stage is a cyclone-type centrifugal dust remover. 3rd stage is a paper-element cleaner. Incoming air entering the 2nd stage is set in swirling motion by cyclonic vanes, so that heavy dust particles are flung off the air stream. The air then enters the 3rd stage, in which it has to flow through microscopically small pores formed in the filtering paper and leaves fine dust particles on the outer surfaces of the pleated paper wall.

The heavy dust particles centrifugally separated from the air fall into a dust cup. The fine dust particles left on the paper element can be removed by air-blasting.

AIR CLEANER SERVICES

After each 100 hours of operation, empty the dust cup, and clean the paper element, first with a blast of compressed air and, if this does not remove the deposited dust completely, then by washing with a non-sudsing water-detergent mixture.

If the machine is worked in a dusty area, the above-mentioned servicing interval of 100 hours should be shortened.



- | | |
|-----------|------------|
| 1-Body | 3-Dust cap |
| 2-Element | 4-Vane |

Partial cutaway view of air cleaner

PERIODICAL MAINTENANCE SERVICE CHART


	○ ... Check, adjust or replenish	□ ... Clean	● ... Replace	△ ... Drain	
Time to check or adjust					Remarks
Check and service point	Before operation (on delivery)	After first 50 hours	Every 100 hours	Every 200 hours	Every 400 hours
Engine proper					
Low, damaged and leaky points	○				
Exhaust fume, noise, and vibration	○				
Additional tightening of engine parts		○			○
Valve clearance		○		○	
Engine idle speed		○	○		
Engine compression pressure					○
Lubrication system					
Engine oil	○	●	●		
Oil filter		●	●		
Fuel system					
Fuel	○				△
Fuel tank				□	
Fuel filter			□	●	△
Injection pump					○
Nozzle				○	
Intake system					
Air cleaner (filter, paper type)			□	●	
Cooling system					
Cooling water	○	●		●	△
Fan belt	○				
Electrical system					
Check of each instrument (oil lamp)	○				
Starter motor, alternator, regulator				○	●
Glow plug			○		

ENGINE MAINTENANCE GUIDE

When to overhaul


The object of engine overhauling is to reproduce, as closely as possible, the vitality and capability which the engine had when it was new. The symptoms that justify the decision to overhaul the engine are two: reduced power output and high consumption of fuel and lube oil, both being concurrent and attributable to internal deterioration inside the engine.

There is no method nor test that verifies the internal deterioration so accurately and quickly as compression test. With a special pressure gauge and its adaptor and fittings, one can readily measure the "compression" pressure on each cylinder of the engine and tell, from the readings taken, whether the engine should be overhauled or not.



Pressure gauge, adaptor and fittings for engine "compression" test

In a diesel engine, low power output could often be due to some malconditions in the injection system - damaged injection nozzles, mistimed injection, low injection pressure, etc. These malconditions, if present, call for overhauling of the injection system components or for re-timing of the injection.



Fuel injection pump

Suppose that the engine has ceased to develop full power, so that you have to decide whether the engine should be overhauled or not. The right approach begins with posing these questions to yourself:

- Is fuel or oil consumption appreciably higher than before?
- Is it harder to start up the engine?
- Does the engine make more noise, coming from inside, than before?


If the answer is yes to all these questions, read "compression" pressures by the method to be described and, if the readings are too low (as compared with the specification), it means that the engine needs overhauling because it is internally deteriorated, that is, its internal running parts are excessively worn - cylinder bores, pistons, piston rings and valves.

If, however, the readings (compression pressure) are adequately high, then the injection system should be blamed for the low power output.

In conducting a "compression" pressure test, it should be borne in mind that the pressure rise occurring above the piston in the cylinder is affected by the speed with which the piston rises or compression stroke. It is for this reason that the specification (a certain pressure which

ENGINE

a brand-new engine should be capable of developing) is based on a specific speed of engine cranking.



Nozzle tester

Compression pressure test – how to measure compression pressure


- (1) Remove the preheater plug of the cylinder to be checked.
- (2) Run the pressure-gauge adaptor into the threaded hole just vacated by the plug, and tighten the adaptor good and hard. Tie the gauge line, complete with the compression pressure gauge, into the adaptor. The gauge is now rigged up.
- (3) Start cranking the engine with the speed control lever fully pushed in so that no fuel oil will be injected and read the engine speed just when the cranking speed has reached a steady level. Read the pressure gauge indication: this reading is the “compression” pressure of that cylinder.
- (4) Carry out the foregoing steps on the next cylinder to read its “compression” pressure.

NOTE

Taking a reading only on one cylinder and assuming the other cylinders to produce the same pressure reading – this is a practice likely to result in an unwise decision. In the present engine, take three readings, one on each cylinder. •

Engine diagnosis on the basis of compression pressure readings

- (a) Compression pressure of a brand-new engine could be slightly increased as the piston rings, valve seats, etc. wear in. As the engine parts wear down after “run-in” period, compression pressure lowers gradually.
- (b) If the readings are down to the limit (repair limit), the engine should be overhauled.




Measuring “compression” pressure

Engine diagnosis on the basis of oil consumption

Another yardstick is oil consumption: if the current oil consumption is higher by more than 50% than the normal consumption, the engine is probably in need of overhauling.

General working rules on disassembling and reassembling steps

- (a) Cleanliness is absolutely essential for successful work, with respect to the place of work, shop facilities such as benches and fixtures, the engine parts handled, the tools and materials.
- (b) Use of right kinds of tools is another essential.
- (c) Before disassembling the engine, drain water, lube oil and fuel completely. Check oil for contamination. Also check the qualities of the oil and fuel.



General hand tools

- (d) Never try to economize sealing parts in rebuilding the engine. "O" rings, oil seals, gaskets and packings are "expendable" items in most cases.
- (e) Read the instructions given in the manual, paying particular attention to the special notes, hints and warnings.
- (f) Crank the engine by hand to be sure it will run smoothly before mounting it on the machine.

TROUBLESHOOTING

Starting difficulties

Symptoms and possible causes	Remedy
<p>Starting run is slow</p> <ul style="list-style-type: none"> a) Lube oil is too high in viscosity b) Battery has run down c) Aged battery d) Defective connections of cable clamps with battery terminal posts e) Starter is defective f) Defective drive parts in power train 	<ul style="list-style-type: none"> a) Replace by a low-viscosity lube oil b) Recharge. c) Replace. d) Clean battery terminals and cable clamps, correct loose clamps. e) Overhaul, repair or replace. f) Check the clutch for O.H.
<p>Defective fuel injection system</p> <ul style="list-style-type: none"> a) Air is present in fuel b) Fuel filter is clogged c) Injection pressure is low d) Poor spray pattern e) Unsatisfactory fuel delivery from injection pump f) A wrong kind of fuel is used g) Fuel injection timing is too advanced 	<ul style="list-style-type: none"> a) Carry out an air bleeding operation on fuel lines. b) Clean or replace. c) Adjust injection pressure d) Clean or replace nozzle. e) Overhaul or replace injection pump f) Replace by No. 2-D fuel oil or a lower-viscosity fuel oil in severe cold season. g) Adjust fuel injection timing.
<p>Poor compression</p> <ul style="list-style-type: none"> a) Improper valve clearance b) Defective valve seats c) Seized valve stems d) Broken valve springs e) A leaky cylinder head due to blown gasket f) Piston rings are seized in the grooves g) Piston rings, pistons or cylinders are excessively worn 	<ul style="list-style-type: none"> a) Adjust valve clearance. b) Repair by relapping. c) Replace valves and valve guides. d) Replace valve springs. e) Replace gasket f) Replace pistons and piston rings. g) Overhaul engine.

Symptoms and possible causes		Remedy
Glow plugs	a) Glow plugs are burnt out b) Glow plugs do not become red hot	a) Replace glow plugs. b) Check and correct lead wire connections.
Governor	a) Governor control lever is set to a wrong position b) Governor spring is off	a) Reset it to the start position. b) Correct.

Not enough output power

Symptoms and possible causes		Remedy
Poor compression		Refer to a), poor compression "Starting difficulties," above.
Maladjusted fuel injection system	a) Improper fuel injection timing b) Injected fuel quantity is not enough c) Fuel injection pressure is too low	a) Adjust fuel injection timing. b) Overhaul or replace injection pump. c) Check injection nozzles and adjust pressure.
Fuel is not reaching injection pump	a) Air is trapped in fuel circuit b) Fuel filter is clogged c) Fuel tank is not clean	a) Check connectors and retighten. b) Clean filter or replace element. c) Clean fuel tank.
Insufficient intake air	Clogged air cleaner	Clean air cleaner and replace element.
Overheating	a) Cooling water shortage b) Loose fan V-belt c) Radiator is clogged or leaking d) Fuel injection is mis-timed e) Engine oil shortage	a) Add cooling water. b) Adjust or replace V-belt. c) Clean or replace radiator. d) Adjust fuel injection timing. e) Add engine oil.

Engine oil consumption rate is high

Symptoms and possible causes		Remedy
Oil leakage	a) Defective oil seals b) Blown gear case gasket c) Loose gear case mounting bolts d) Loose drain plug e) Loose oil pipe connectors f) Blown rocker cover gasket g) Loose rocker cover mounting bolts	a) Replace oil seals. b) Replace gasket. c) Retighten. d) Retighten. e) Retighten. f) Replace gasket. g) Retighten.

ENGINE

Symptoms and possible causes		Remedy
Pumping up of oil	<ul style="list-style-type: none"> a) Piston ring gaps are not positioned correctly b) Bent or twisted connecting rods c) Worn piston rings d) Worn pistons or cylinders 	<ul style="list-style-type: none"> a) Correct. b) Replace connecting rods. c) Replace piston rings. d) Replace pistons or re-bore the cylinders
Oil down	<ul style="list-style-type: none"> a) Defective stem seals b) Worn valves or valve guides 	<ul style="list-style-type: none"> a) Replace stem seals. b) Replace valves or valve guides.

Abnormal sound or noises

Symptoms and possible causes		Remedy
Crankshaft main bearings	<ul style="list-style-type: none"> a) Worn bearings b) Worn crankshaft c) Fused bearings 	<ul style="list-style-type: none"> a) Replace bearings or grind the crankshaft. b) Grind the crankshaft. c) Replace bearings and check lubrication system.
Connecting rods and connecting rod bearings	<ul style="list-style-type: none"> a) Worn connecting rod big end bearings b) Worn crankshaft pins c) Bent connecting rods 	<ul style="list-style-type: none"> a) Replace bearings. b) Grind the crankshaft. c) Correct bend or replace.
Pistons, piston pins and piston rings	<ul style="list-style-type: none"> a) Worn cylinders b) Worn piston pins c) Seized pistons d) Seized pistons and worn or broken piston rings 	<ul style="list-style-type: none"> a) Re-bore and grind cylinders to oversize and replace pistons. b) Replace pistons. c) Replace pistons and grind cylinders d) Replace pistons and piston rings
Camshaft and others	<ul style="list-style-type: none"> a) Worn camshaft b) Excessive valve clearance c) Worn timing gear d) Worn fan pulley bearing 	<ul style="list-style-type: none"> a) Replace camshaft. b) Adjust. c) Replace gear d) Replace bearing.

Engine run is not smooth

Symptoms and possible causes		Remedy
Fuel injection pump	<ul style="list-style-type: none"> a) Injection quantity varies from one cylinder to another b) Malfunctioning of control rack c) Worn delivery valves d) Poor atomization of fuel sprayed from nozzles 	<ul style="list-style-type: none"> a) Adjust fuel injection quantity or replace defective parts. b) Overhaul, check and repair the fuel injection pump. c) Replace delivery valves. d) Replace nozzles.
Governor	<ul style="list-style-type: none"> a) Malfunctioning of governor b) Weakened governor spring 	<ul style="list-style-type: none"> a) Check governor shaft and correct. b) Replace spring.

ENGINE

SPECIFICATIONS AND MAINTENANCE STANDARDS

Engine proper

All values in mm (in.) unless otherwise indicated

Description	Type	Standard value	Repair limit	Service limit
Compression pressure	K3A, K3C-13MT	32 kg/cm ² (455.2 psi)/280 rpm	26 kg/cm ² (369.8 psi)	Approx. 22 kg/cm ² (312.9 psi)
Pressure difference between cylinders (max)		2.5 kg/cm ² (35.6 psi)		
Injection order		1-3-2		
Injection timing		21° ± 1.5° B.T.D.C. (when started at smoke set position)	21° ± 2°	
Cylinder head				
Bottom surface flatness (distortion)		0.05 (0.0020) max.	0.1(0.0039)	
Valve guide L.D. (both intake and exhaust valves)		6.6 (0.2598)		
Valve seat angle (both intake and exhaust valve)		45°		
Valve seat width (both intake and exhaust valves)		1.3 to 1.8 (0.0512 to 0.0709)	2.5 (0.0984)	
Valve seat sinkage				-1 (-0.0394)
Valve timing				
Intake valve opened		18° B.T.D.C.		
Intake valve closed		46° A.B.D.C.		
Exhaust valve opened		46° B.B.D.C.		
Exhaust valve closed		18° A.T.D.C.		
Valve clearance (both intake exhaust valves)		0.25 (0.0098) (when engine is cold)		
Valve				
Valve head diameter				
Intake valve		27.2 (1.079)		
Exhaust valve		25.2 (0.9921)		
Overall length		114.5 (4.5079)		
Stem O.D.		6.6 (0.2598)		
Clearance between stem and guide				
Intake valve				0.10(0.0039)
Exhaust valve				0.15(0.0059)
Valve face angle		45°		
Valve head thickness(margin)		1.0 (0.0039)		0.5(0.0197)
Valve spring				
Free length		43 (1.6929)		41.7(1.6417)
Installed load/Installed length		14.0 ± 0.7 kg (30.9 ± 1.5 lbs.)/36 (1.42)		-15%
Squareness		1.5°		3°

Description	Type	Standard value	Repair limit	Service limit
Rocker arm Rocker arm I.D. Clearance between rocker arm and shaft		18.9 (0.7441)		0.2(0.0079)
Cylinder block Camshaft hole I.D. Front Center Rear Cylinder bore Oversize finish tolerance Taper of cylinder Top surface flatness (distortion)	 K3A K3C	 45 (1.7716) 44 (1.7323) 34 (1.3386) 65 (2.5591) 70 (2.7559) 0 to 0,03 (0 to 0.0012) 0.01 (0.0004) max. 0.05 (0.0020) max.	 +0.2 (+0.0079) +0.2 (+0.0079)	 +0.95 (+0.0374) +0.95 (+0.0374) 0.1 (0.0039)
Piston Material O.D. (skirt end) Clearance between piston and cylinder Oversize	 Solid type Aluminum alloy K3A K3C	 65 (2.5591) 70 (2.7559) 0.25 (0.0098), 0.50 (0.0197) 0.75 (0.0295)		0.3(0.0118)
Piston pin O.D. Clearance between piston pin and piston Clearance between piston pin and connecting rod	 Semi-floating type	 19 (0.7480) Press-fitting load : 500 to 1,500 kg (1,102.3 to 3,306.9 lbs.)		0.08(0.0031)
Piston ring Type and number of rings Compression ring No. 1 No. 2 No. 3 Oil ring	 Barrel type Tapered ring Tapered ring	 3		

ENGINE

Description	Type	Standard value	Repair limit	Service limit
Ring width				
Compression ring				
No. 1 to No. 3		2.5 (0.0984)		
Oil ring		4.0 (0.1575)		
Ring side clearance				
Compression ring				
No. 1		0.06 to 0.12 (0.0024 to 0.0047)		0.30 (0.0118)
No. 2		0.05 to 0.09 (0.0020 to 0.0035)		0.20 (0.0079)
No. 3		0.04 to 0.08 (0.0016 to 0.0031)		0.20 (0.0079)
Oil ring		0.03 to 0.07 (0.0012 to 0.0028)		0.20 (0.0079)
Ring end gap		0.15 to 0.40 (0.0059 to 0.0157)		1.5 (0.0590)
Connecting rod				
	Forged I-beam			
Bend and distort on big end thrust clearance		0.05 (0.0020) max. 0.1 to 0.35 (0.0039 to 0.0138)		0.50 (0.0197)
Connecting rod bearing				
	Kelmet metal with backing metal			
Oil clearance				0.15 (0.0059)
Undersize		0.25 (0.0098), 0.50 (0.0197) 0.75 (0.0295)		
Crankshaft				
	Fully counterbalanced			
Bend		0.05 (0.0012) max.		
End play		0.06 to 0.1 (0.0024 to 0.0040)		0.50 (0.0197)
Journal O.D.		32 (2.0473)	+0.15 (+0.0059)	-0.25 (-0.0098)
Pin O.D.		42 (1.6535)	+0.15 (+0.0059)	-0.25 (-0.0098)
Undersize Finish dimensions				
Journal				
	U.S. 0.25	51.735 to 51.750 (2.0368 to 2.0374)		
	U.S. 0.50	51.485 to 51.500 (2.0270 to 2.0276)		
	U.S. 0.75	51.235 to 51.250 (2.0151 to 2.0157)		
Crankshaft Pin				
	U.S. 0.25	41.700 to 41.715 (1.6417 to 1.6429)		
	U.S. 0.50	41.450 to 41.465 (1.6319 to 1.6325)		
	U.S. 0.75	41.200 to 41.215 (1.6220 to 1.6226)		