


TRACTOR

85



FERRARI
MACCHINE AGRICOLE



INTRODUCTION

IDENTIFICATION OF TRACTOR

The serial number of the machine is stamped on the right side of the gear box (Fig. 1). Always state the tractor serial number when placing any order for spare parts and asking for technical assistance.




Figure 1. Identification of tractor.

FOREWORD AND RECOMMENDATIONS

The following technical literature is delivered with each Ferrari tractor:

- OWNER'S MANUAL (operation and maintenance instructions)
- ENGINE HANDBOOK
- DIRECTIONS AND SUGGESTIONS FOR USERS OF FERRARI TRACTORS
- CERTIFICATE OF GUARANTEE

Reading the present manual for use and maintenance is essential to make full use of possibilities and performance of your Ferrari tractor.

As present manual refers to essential information only, it is strongly recommended for users going through handbook "DIRECTIONS AND SUGGESTIONS FOR USERS OF FERRARI TRACTORS".

You will find therein helpful suggestions for best efficiency and trouble-free operation be achieved.

SPARE PARTS

It is strongly recommended that only ORIGINAL REPLACEMENT PARTS should be used. Orders must be made in accordance with the instructions contained in the Spare Parts Catalogue.

If a copy of the spare parts catalogue is not at hand, contact a Ferrari's Authorized Representative.

TECHNICAL ASSISTANCE

FERRARI MACCHINE AGRICOLE place their Technical Assistance Service at Customer's disposal in order to solve any problem concerning use and maintenance of their machines.

CUSTOMERS may send their requests in writing to

O.M. FERRARI S.p.A.

Via Valbrina, 414

42045 LUZZARA (Reggio Emilia - ITALIA)

Tel. (0522) 835524 (5 lines)

Telex 630144 FEAMAC

The Makers reserve the right to modify the machine to any requirement of a commercial construction character without obligation to update this publication promptly.



CONTENTS

	Page
GUARANTEE	3
TRACTOR DATA SHEET	6
SERVICING	
Tyre inflation	9
Filling	9
CONTROLS AND INSTRUMENTS OF TRACTOR	
Controls and indicators on dashboard	11
Controls for drive and work operations	12
USE OF TRACTOR	
Running in	13
Starting oil engine	13
Stopping the engine	14
Use of tractor	14
Power take-off	15
Synchronization of upper power take off	15
implement power take-off either upper or lower	16
Front and rear differentials locking lever	16
Hydraulic implement filter	17
Connection for implements	18
Towing hook	20
Track variation	21
MAINTENANCE	
Lubrication and inspections	23
Inspections and adjustments	26
Hydraulic system	27
HYDRAULIC SYSTEM	
System inspection	30
TROUBLE SHOOTING	
Hydraulic filter	32
Hydraulic steering	34



TRACTOR DATA SHEET

OVERALL DIMENSIONS OF THE TRACTOR

(See figure 2)




Figure 2 Overall dimensions in mm.

ENGINE

The tractor is normally equipped with a Lombardini LDA 672 engine. Engine main specifications are the following:

Type: three cylinder, four stage, air cooled Diesel engine.

Maximum rate: 3000 rpm

Maximum power: 45 HP

Upon request different types of engine are available.

CLUTCH

Dry single plate clutch

Upon request, large diameter double clutch controlled through a single pedal to disengage the shaft drive from the power take off.



SPEED SELECTION

Speed selection is allowed through a range selector

(HIGH, LOW, REVERSE) and three speed gearing. The gearbox is provided also of the 7th speed used for road movement operation.

TYRE SIZE	SPEED km/h											
	FORWARD						REVERSE					
	LOW			HIGH			LOW			HIGH		
	1	2	3	1	2	3	7	1	2	1	2	3
9.5-20	1,50	2,70	4,70	6,20	11,00	19,00	26,00	2,70	5,20	9,00	11,00	19,00

Note: with 7.50-18 tyres, the max. speeds decrease approx. 10%.

DRIVE AND STEERING

Drive on the front and rear wheels through locking differentials. Hydraulic steering with jack acting on the central joint.

WHEELS AND TYRES

Front wheels: 9.5-20 tyres

Rear wheels: 9.5-20 tyres

Track variation is allowed on both axles

Tyres 7.50-18 are available on request.

TYRE SIZE	TYPE	INFLATING PRESSURE
Front 9.5-20	Tractor Agricultural 4 pr	1.4 to 1.5 kg/50 cm ²
Rear 9.5-20	Tractor Agricultural 4 pr	1.3 to 1.4 kg/50 cm ²
Front 7.50-18	Tractor Agricultural 4 pr	1.2 to 1.3 kg/50 cm ²
Rear 7.50-18	Tractor Agricultural 4 pr	1.1 to 1.2 kg/50 cm ²

BRAKES

Service brakes: hydraulic type on front and rear wheels. A pedal controls the special servocentrated pump for simultaneous braking of all wheels.

Parking and emergency brakes: hand-lever controlled, mechanical design, acting on rear wheels.

ELECTRIC EQUIPMENT

Rated voltage 12 Volt

Battery capacity 90 Ampere (two 45 Ampere batteries are provided).

Batteries are recharged through alternator and voltage regulator.

Lighting system and horn are tested and approved for road circulation.

HYDRAULIC LIFTER

Independent hydraulic circuit.

Pump directly coupled to engine. Control valve ensuring an automatic adjustment of work depth and effort. Hydraulic jack for lifting, 2 or 3 point hitch connection. Allowable load at arms: 1000 kg approx.

POWER TAKE-OFF

The tractor is normally equipped with two rear power take-off:

- An upper power take-off providing two-speed range independent from tractor speed, a clutch makes it possible the synchronized rotation with all gears/hit speed range.
- A lower power take-off providing two-speed range independent from the tractor (speed range is the same as the upper power take-off).

The two power take-off are standardized according ASAE T 3/8I. Dimensions are quoted in fig. 3. Rotation is clockwise.

UPPER AND LOWER TAKE-OFF SPEED		
POSITION OF CONTROL LEVER	ENGINE RPM	
	2.400	3.000
1	640	670
-1	750	940

TOWING HOOK

Adjustable in two positions. Class "B" approved for road circulation.

Dimensions are shown in fig. 3.

TRACTOR WEIGHT

Weight of the tractor in running order is 1300 kg. Allowed ballast: 200 kg.




Figure 3 Dimensions of power take-off and towing hook



SERVICING

TYRE INFLATION

1 FRONT WHEELS	Tyres type Tractor Agricola 4 pr. 9.5-20; inflating pressure 1.4 to 1.5 kg/cm ²
2 REAR WHEELS	Tyres type Tractor Agricola 4 pr. 9.5-20; inflating pressure 1.3 to 1.4 kg/cm ²

FILLING


1 FUEL TANK	Capacity 16 liters Use Diesel fuel (decanced fuel if possible)
2 ENGINE AND AIR FILTER	For lubricant types and capacity see engine handbook
3 GEAR BOX	Capacity 15 kg Use BP Energol GR-XP 220 (ISO) oil, or oil AGIP F1 ROTRA HYPOID SAE 90
4 REAR AXLE HOUSING	Capacity 10 kg Use BP Energol GR-XP 220 (ISO) oil, or AGIP F1 ROTRA HYPOID SAE 90
5 HYDRAULIC SYSTEM	Capacity 7 kg Use BP Energol HL 88 oil or AGIP OSO 65 oil
6 TILLER HOUSING	Capacity 1.5 kg Use BP Energol GR-XP 220 (ISO) oil, or AGIP F1 ROTRA HYPOID SAE 90
7 BRAKING SYSTEM RESERVOIR	Capacity 0.250 kg Use BP DISC BRAKE F. U/D oil or AGIP BRAKE F. U/D oil



CONTROLS AND INSTRUMENTS OF TRACTOR

CONTROLS AND INDICATORS ON DASHBOARD

(See Figure 4).



1. Signal of directional lights on (GREEN)
2. Signal of directional lights for trailers (GREEN)
3. Signal of headlights fully on (BLU)
4. Signal of fuel reserve in use (RED)
5. Signal of power feed for battery recharge (RED) (optional)
6. Signal of low oil pressure to engine (RED)
7. Key switch
- E. Lights circuit ave.
- G. No circuit ave.
- I. All circuits ave.
2. Engine starting
8. Switch for directional lights and flashers
9. Switch for lights and noise
10. Multiple revolution-counter and hour-meter (3-scale instrument)
 - Outer scale reads engine rpm
 - Intermediate red scale reads power take-off rpm in 2nd speed. Whatever the equipment used, it is recommended to keep constantly at about 750 rpm (red reference notch).
 - Inside red scale reads power take-off rpm in 1st speed. Whatever the equipment used, it is recommended to keep constantly at about 550 rpm (red reference notch).
 - The four-digit hour-meter reads the actual hours of engine operation.

Figure 4. Controls and indicators on dashboard



CONTROLS FOR DRIVE AND WORK OPERATIONS

(See fig. 5)




Figure 5 Controls for drive and work operations




USE OF TRACTOR

RUNNING-IN

During the running-in period (first 80 hours of operation) special care should be taken. Consult the handbook

"Directions and Suggestions for Users" for detailed information.

During and upon completion of running-in the operations described under fig. 6 are to be carried out.



[A] ENGINE

After 20 hours: change oil

After 50 hours: clean and set fuel injectors

- During the first 80 hours: avoid heavy-duty and extended work.

[C] HYDRAULIC SYSTEM

During the first 80 hours: inspect frequently, if required take action for adjustment as prescribed page 301.

After 80 hours: change oil (BP EAFRGOL - L 100 or AGIP OSO 55)

[D] MAIN UNITS

During the first 80 hours: inspect all main units (engine, gear box, drive system, attachments, control linkage, etc.) for security of attachment frequently.

[B] AIR FILTER

After 20 hours: clean the filter element

After 80 hours: change oil

* For detailed instructions consult "Directions and Suggestions for Users"

Figure 6 Instructions for running-in

STARTING OF ENGINE

- For additional information about engine operation, refer to the appropriate instruction booklet (owner's manual).
- For normal starting, proceed as follows (see figure 7):

- Make sure that the engine stop switch is fully pushed in.
- Make sure that all control levers (2) are in NEUTRAL position.

- Bring accelerator control lever (3) to half-way position.
- Insert key in switch (4) and turn it to position "2".
- When motor is started, release key which will revert directly to position "1".

Note

In case of failure to start, wait a few seconds prior to doing the starting sequence again, not to cause battery (running down).



Consult the engine handbook for additional information.





Figure 7. Controls for starting the engine

USE OF TRACTOR

OPERATION SEQUENCE

1. Press clutch pedal (fig. 8, detail 1).



STOPPING THE ENGINE

1. Bring all control levers to NEUTRAL position.
2. Before turning off the engine, let it run for a few minutes at low RPM to make cooling easier (this is most advisable after a long run time).
3. Pull engine stop knob (fig. 7, detail 1).

WARNING

Do not try stopping the engine by bringing switch key to position "0" because the engine would keep on running. Long operation of engine with power off may adversely affect the battery.

4. Remove key from switch.
5. After the engine stops, fully push the stop knob (1), otherwise the engine will not start next time.

Figure 8. Operation sequence

2. Select the desired speed range (Low, Hi, Reverse) through lever (2).
3. Select the desired speed gear (1st - 2nd or 3rd) through lever (2).
4. Gradually release the clutch lever.
5. Regulate the position of the accelerator hand lever so that the engine runs evenly and without exhaust smoke.
6. For all subsequent operations and manoeuvres, use the accelerator pedal only.

WARNING

- In the event any resistance is encountered when engaging the desired gear or selector particularly during running in, always depress



the clutch pedal over and over again. DO NOT FORCE LEVERS AND ALWAYS MAKE USE OF CLUTCH.

- The selector control lever is to be engaged WHEN TRACTOR IS AT STOP only.




Figure 9. Use of 7th speed

USE OF 7th SPEED (See figure 9)

Whatever the speed previously engaged in the range selector (HI, LOW REV), it is bypassed by engagement of the lever in the 7th gear-box position. This position makes the tractor proceed forward or reverse at maximum speed and hence is used for fast road movement operations.

WARNING

If the gearshift lever is brought back from the 7th speed to any other gear-box speed, the range selector automatically comes into operation again.

Therefore for example, shifting from the 7th speed to the 3rd speed, if the range selector was in the reverse position, the tractor will switch from a speed of about 25 km/h forward to a speed of about 9 km/h in reverse.

Thus before shifting from 7th speed to others, it is ESSENTIAL TO CHECK THE SPEED ENGAGED IN THE RANGE SELECTOR BY OBSERVING THE POSITION OF THE POINTER. It is recommended as well to keep the range selector ever in the "NEUTRAL" position when shifting to 7th speed.

The manufacturer is not responsible for any damage caused to operator, tractor or third parties due to improper use of the range selector and gearshift lever(s).

POWER TAKE-OFF

The tractor is equipped with two power take-off (see fig. 10):

- Lower power take-off providing two independent speeds for operating in seahorse implements.
- Upper power take-off providing two independent speeds as the lower shaft speed ratio and additional provisions for synchronization of speeds with the entire gearshift range.

All specifications relating to power take-off (dimensions, rotation speed etc.) are stated under "TRACTOR DATA SHEET" and fig. 3.

SYNCHRONIZATION OF UPPER POWER TAKE-OFF

The synchronized power take-off is driven by the bevel pinion of the rear axle when the rotating control lever is engaged (fig. 10, detail 3).

When tractor is at stop, power take-off does not rotate, switching from forward movement to reverse, rotation direction of the power take-off is reversed as well.

Whatever the speed engaged, synchronized power take-off performs 0.250 revolutions per revolution of the wheel(s).



The synchronized power take-off essential scope is towing driving-wheel trailers. The trailer tyre sizes and reduction ratios must be selected on the basis of the number of revolutions made by the power take-off.

POWER TAKE-OFF SYNCHRONIZER CONTROL LEVER

The control lever is located on right-hand side of the rear axle box (see fig. 10).

Control lever to be actuated as follows:

1. Depress clutch pedal.
2. To have power take-off engaged, push lever (1) DOWN.
3. To have it released, pull lever (1) UP.

IMPLEMENT POWER TAKE-OFF (EITHER UPPER OR LOWER)

OPERATING SEQUENCE

1. Depress clutch pedal.
2. Engage power take-off in the desired speed by bringing the proper lever (Fig. 10) to position 1 (Low speed) or to 1' (High speed).

CAUTION

Make sure the control lever is properly engaged.

3. Gradually release clutch pedal.



FRONT AND REAR DIFFERENTIALS LOCKING LEVER

The proper control lever to be actuated as follows (see fig. 11):

1. For LOCKING the differentials, stop tractor and pull control lever (1) UP beyond the detent (2).
2. TO UNLOCK the differentials, release the control lever (1) from the detent (2) and take it DOWN.

WARNING

- When engaging the differentials locking lever, slightly steer the tractor in right hand and left hand to make locking engagement easier.



- 1 Upper power take-off (independent or synchronized)
- 2 Guard for power take-off (to be put on either power take-off when not in use)
- 3 Synchronized power take-off control lever
- 4 Independent power take-off control lever
- 5 Gearshift lever
- 6 Range selector lever
- 7 Electrical connector for trailer
- 8 Towing hook

Figure 10. Power take-off and controls



- DO NOT ENGAGE differentials locking when tractor is under stress.
- TO DISENGAGE locking, depress a lever pedal to unlock the wheels thereby allowing the locking sleeves to disengage.
- Do not go round bends with the differential locked.
- Do not keep the differential locked when unnecessary.




Figure 11. Locking of differentials

HYDRAULIC IMPLEMENT LIFTER

The hydraulic lifters mounted on "FERRARI 85" tractors may be used as described hereinafter.

1. "Stationary" position.
2. Floating operation.
3. Controlled position and effort.

HYDRAULIC LIFTER LEVER

The control lever acts as follows (see fig. 12):

1. LEVER UP: the implement holder raises.
2. LEVER DOWN: the implement holder lowers.
3. LEVER FULLY DOWN: the implement holder gets "floating".




Figure 12. Control system of implement holder hydraulic lifter

"STATIONARY" OR "FLOATING" POSITION

Note

Make sure the controlled effort lever (fig. 13, item 1) is disengaged (position 10 of graduated scale).

"STATIONARY" USE

"Stationary" position makes it possible to lead and hold the implement in any position inside or outside the ground according to the position selected with the lifter lever (fig. 12, item 1). Implement movement depends upon lever motion.



"FLOATING" USE

"Floating" use releases completely the lifter arms, motion of which gets free. In this instance the lifter is used only to lower the implement at the beginning of each stroke and, during work, the implement follows the ground surface.

CONTROLLED EFFORT LEVER

The controlled effort lever makes it possible adjusting the hydraulic lifter sensitivity as follows (see fig. 13):

1. LEVER AHEAD the number "10" of graduated scale: the implement acts with full power and is less sensitive when resistance is encountered.
2. LEVER BACK the number "0" of graduated scale: the implement gets more sensitive and tends to raise when resistance is encountered.




Figure 13 Use of the controlled effort hydraulic lifter

Note

The controlled effort lever can be used only in conjunction with the 3 point hitch.

APPLICATION OF CONTROLLED EFFORT

The controlled effort provision is particularly designed for all carried implements (viz no wheel and no bearing geared units) which should work in even deep soil work in even deep soil.

With an appropriate setting of the effort control lever, the implement height varies according to the resistance offered by the soil. The tractor runs more smoothly and the speed is almost constant.

Operate the controls as follows (see fig. 13):

1. Lower the implement by gradually bringing the lifter control lever to "DOWN" position.
2. Keep actuating the lever until the implement gets steady in required depth.
- Lock the lever stop (4) to bring it to same position in starting any stroke.
3. Adjust the lifter sensitivity actuating lever (1) as shown in figure 13.

CONNECTION FOR IMPLEMENTS

The tractor is equipped with a two or three point hitch. Consult booklet "DIRECTIONS AND SUGGESTIONS FOR USERS" for instructions concerning connection provisions.

CONNECTION OF A TILLER

(see fig. 14)

Connect the tiller joint (1) to the tractor implement holder by means of pins (2). Connect the tiller arms (3) to joint (1) by means of the appropriate pins (4). Connect tiller attachments to lifter arm (5) through the appropriate levers (6). Adjust the position of the implement with the adjustment nuts (7). The working depth of tiller is controlled according to requirements by moving the side slides of tiller. This is done removing screw (8) and placing it into another hole. Make same adjustment on both sides of the tiller.

Connect universal joint (9) to the power take-off shaft. Depress the safety button (10) and make sure the joint goes beyond the catch. Then insert the clutch end of universal shaft provided with a safety button (10) onto the tiller shaft and bring the universal shaft (tractor side) back to catch position.




Figure 14. Tiller connection

PLough CONNECTION

(see fig. 15)

1. Connect arms (1) to tractor flanges located in the lower portion of rear hubs and fasten through appropriate pins.
2. Connect stiffening tie-bars (2) to arms (1) and flanges located on the axle shaft supports of rear wheels 5.
3. Connect sprog (3) to tractor implement holder through appropriate pins (4).
4. Connect plough to arms (1) and sprog (3) locking it through pins (5).
5. Connect plough to lifter arms through vertical tie bars (6).
6. Adjust the length of the two lifting tie-bars so that plough lifting is limited to a strictly essential level only.

CONNECTION FOR DRIVING WHEEL TRAILERS

1. Connect the trailer universal joint to the synchronized power take-off shaft (upper shaft).
2. Engage the parking brake lever of trailer into the corresponding socket.
3. Connect the tractor electrical system to the trailer through a 7-hole connector (fig. 15, item 12).
4. Engage the synchronized power take-off control lever as described and shown (see fig. 10).
5. If the trailer is a dump body model provided with hydraulic hoist, arrange connection of tractor hydraulic system to trailer body equipment through the appropriate quick hydraulic intake (fig. 10, item 5) fitted on the tractor (not on all).




Figure 15. Plough connection

LIFTING OF TRAILER BODY

For body lifting follow procedure outlined (see fig. 16).

1. ACTIVATE the hydraulic lifter control lever until arms (2) are fully raised.
2. Make sure the controlled effort lever (3) is in "0" position of the graduated scale.
3. Lift the dump body of trailer by pushing FORWARD lever (4) of the control valve.

TOWING HOOK

The tractor is provided with a road towing hook. See fig. 3 for basic dimensions.

The towing hook can be located either under or above the power take off location shown in fig. 1C1.




Figure 16. Hydraulic lifting of trailer body



TRACK VARIATION

GENERAL

To meet the working requirements of the various implements and cultivations, all tractor models provide track variation.

ADJUSTMENT OF FRONT AND REAR TRACKS

The discs of rear and front wheels are adjustable. Position of wheels and resulting tracks appears in fig. 17.


To dismantle wheel and discs, lift the tractor rear or front portion by means of a jack placed beneath the tractor body.

Note


In arranging for adjustment of front and rear tracks, make sure the tyre is up be positioned in the forward movement rotation direction shown by an arrow on tyre sidewall.

Front and rear wheels should be constantly symmetrical about the tractor longitudinal axis.

SECTION VIEW OF FRONT AND REAR WHEELS



1. Tyre
2. Rim
3. Adjustable disc
4. Wheel hub



POSITION	1	2	3	4	5
Tyre 9.5-20	900 mm	1000 mm	1170 mm	1185 mm	1050 mm
Tyre 7.50-18	800 mm	930 mm	1040 mm	1130 mm	960 mm

Figure 17 Variation of front and rear tracks



MAINTENANCE

LUBRICATION AND INSPECTIONS

Make prescribed operations as listed hereinafter at the intervals stated. ("hours" are intended to be the actual working hours of the machine).

Lubricants to be used are quoted in table "SERVICING INSTRUCTIONS" at the beginning of present manual.

EVERY 8 HOURS (DAILY)

ENGINE: check oil level (when required, top it up).

AIR FILTER: under exceptional dusty conditions the filtering element should be cleaned. Procedure to be as follows:

- release clips on collar (1) and remove cup (2),
- clean the filtering element (3) by means of gasoline or solvent. If the filtering screen is clogged or damaged, replacement will be necessary,
- clean cup (2) with gasoline and fill it with clean oil (same oil as for engine) up to level (4),
- where a "cyclone" filter is installed, clean pre-cleaner with gasoline or solvent.




Figure 18. Engine air filter

POINTS TO BE GREASED (EVERY 25 HOURS)

GENTLE PLATE: grease 1 point

STYLING JACK JOINT: grease 3 points

HYDRAULIC LIFTER ARMS: grease 2 points

UNIVERSAL JOINTS: grease 4 points

PIVOTS OF GEARSHIFT LEVER, SELECTOR LEVER, POWER TAKE-OFF LEVER: grease 3 points

PIVOTS OF BRAKE AND CLUTCH CONTROL PEDALS: grease 2 points.

EVERY 60 HOURS (MAXIMUM INTERVAL)

AIR FILTER: cartridge should be cleaned in complying with the foregoing and oil be changed. Intervals for cleaning depend upon ambient conditions, however never exceed 60 hours.

EVERY 100 HOURS

ENGINE: change oil.

HYDRAULIC SYSTEM RESERVOIR: check the level. With implement holder and steering control jacks fully drawn back, oil level should be at approx. 20 mm from reservoir edge (see fig. 19).




Figure 19. Oil level of hydraulic system and brake system reservoirs



GEARBOX: check oil level (see fig. 20).

REAR AXLE BOX: check oil level (see fig. 21).

BRAKES SYSTEM: SERVICING: check oil level (see fig. 19).




Figure 20. Oil level of gearbox




Figure 21. Oil level of rear axle box

EVERY 200 HOURS

FUEL SYSTEM: clean the filtering element, in following procedure outlined (see fig. 22):

- disjoin the outlet tube fitting;
- unscrew bolt (1), remove cup (2) and filtering cartridge (3);
- clean filtering element (3) w/ gasoline or solvent and replace it if screen is found to be clogged or damaged;
- clean cup (2) with gasoline or Diesel fuel;
- reassemble filtering element (3) in making sure seal (4) is in order and accurately seated in groove.




Figure 22. Fuel filter

HYDRAULIC SYSTEM: replace filtering cartridge of hydraulic system reservoir. Operating sequence (see fig. 23):

- remove flange (1) and fiber unloosing screws (2);
- screw off filtering cartridge (3) from flange (1);
- screw down the new cartridge onto the flange. Reinstate the flange and fasten it through screws (2).

BRAKES: verify efficiency of service brakes and parking brake. If necessary take action for controls in following procedure outlined later in this booklet.



CLUTCH: verify efficiency of control system. If necessary take action for adjustment in following procedure outlined later in this booklet.




Figure 23. Adjustment of the differential locking control

EVERY 500 HOURS

HYDRAULIC SYSTEM: change oil (see fig. 101)

GEARBOX: change oil (see fig. 24).

REAR AXLE BOX: change oil (see fig. 25).




Figure 24. Oil filling plug for gearbox



Figure 25. Oil filling plug for rear axle box



INSPECTIONS AND ADJUSTMENTS (GENERAL)

Information and specifications given here below refer to adjustment operation to be carried out on "Ferguson 85" tractors exclusively.

Direction for any overhaul and repairs are contained in a purpose issued publication.

BRAKES

Service brakes

1. SYSTEM INSPECTION: If the braking action is found to be delayed, bleed the system through bleed valves located on the brakes cylinders (fig. 26, item 2). When bleeding is complete top off oil level in reservoir by adding new oil.

WARNING

To bleed air from the braking system, disjoin pipe (5) from the pump fitting and have air exhausted in the rear circuit. Connect pipe (5) again and take action for bleeding the front circuit.

2. BRAKES ADJUSTMENT: If the idle stroke of pedals is found to be excessive, adjust the brake shoes as follows (see fig. 26):

- turn screw (3) so cause internal cams to get in touch w/ jaws;
- verify the brake pedal stroke and make sure that wheels are turning free;
- actuate the brake pedal when machine is running, this will allow the brake jaws to self-center;
- check adjustment of the control cables of the parking brake; if necessary follow procedure outlined

Parking brake (see fig. 26)


If the braking action is found to be poor, adjust control cables through nuts (8) fitted on control lever of the parking or emergency brake.

Note

If braking shoes are found to be worn out, the internal lever of the hand brake is allowed to come in touch with hubs. This will eliminate the braking action. Replacement of shoes is then necessary.



- 1 Oil delivery pipe to cylinder
- 2 Bleed valve
- 3 Adjusting screw for braking shoe opening
- 4 Braking shoe



- 5 Oil pipe from pump reservoir
- 6 Servocontrolled braking pump
- 7 Oil reservoir for braking system
- 8 Adjusting nuts for control cables

Figure 26. Bleeding of brake system and brake adjustment



CLUTCH

1. The clutch pedal should make an idle stroke of approx. 15 mm prior to obtaining disengagement of clutch.
2. If the idle stroke is insufficient (clutch slippage) or excess or disengagement is not complete; adjust the release control rod (see fig. 27) through adjusting nut (2) until an idle stroke of 15 mm is obtained.
3. In the event of unsuccessful adjusting procedure, have the clutch disassembled and inspected in a specialized workshop.




Figure 27. Clutch adjustment

LOCKING OF THE DIFFERENTIALS

Periodically make sure the differential locking system is properly adjusted. A correct adjustment is achieved by following procedure outlined (see fig. 28).

1. Make sure that equalizer springs (1) are 2 mm approx. from spring retainer rings (2). Control lever to be in "LOCKED" position.

2. If adjustment is found to be improper, proceed through the purpose-fitted nuts (3).




Figure 28. Differential locking adjustment

HYDRAULIC SYSTEM

GENERAL


A schematic diagram of the hydraulic system is shown in fig. 29.

In the event of unsatisfactory or improper lifting of implements despite of smooth operation of the engine, the same procedure as described in pages concerning the hydraulic system maintenance is to be followed.

ELECTRICAL EQUIPMENT

Tractor circuits are provided with protection fuses located under the engine-hood (see fig. 30).

The elementary wiring diagram including appliances supplied on request, is shown in fig. 31.



- | | |
|----------------------------|--|
| 1. Hydraulic pump | 6. Hydraulic steering valve |
| 2. Hydraulic oil reservoir | 7. Main control valve |
| 3. Filter on oil return | 8. Cutter jack |
| 4. Relief valve | 9. Control lever for implement up and down |
| 5. Steering jack | 10. Working depth adjusting lever |

Figure 29. Hydraulic system diagram




Figure 30. Fuse-box of electrical equipment




Figure 31. Electrical equipment



HYDRAULIC SYSTEM

SYSTEM INSPECTION

GENERAL

All necessary operations for an accurate inspection are described here below. Overhaul of the hydraulic system will ensure it is in the ideal working order. Recommended steps for setting valves are outlined as well. Strictly follow prescribed procedure.

CHECKING OF OPERATING PRESSURE

Preliminary operations

- Install a pressure gauge with 250 kg/sq cm end-of-scale (minimum) in the hydraulic pump delivery fitting (see fig. 32).

Note

Location of hydraulic pump on engine body may be different from that indicated in fig. 32. Location may vary according to the engine installed on tractor.

- Start the tractor engine and maintain it operating at 2000 RPM approx.




Figure 32. Installation of pressure gauge on the hydraulic pump delivery

STEERING SYSTEM OPERATING PRESSURE

(see fig. 33 and fig. 34)

- Through the steering wheel steer tractor wheels to right or left as far as practicable (steering jack to be fully extended or retracted).
- Make sure pressure gauge reading is 100 to 110 kg/cm². If reading is different, adjust setting through valve (fig. 33 or fig. 34, item 11) of the hydraulic power steering unit by screwing on or off adjusting screw (2) after removing valve cap (3).




Figure 33. Setting of the hydraulic power steering valve (example A)




Figure 34. Setting of the hydraulic power steering valve (example B)



OPERATING PRESSURE OF HYDRAULIC LIFTER (see fig. 35)

- Place lever (2) in the "LIFT" position and lever (1) in "C" on the graduated scale.
- Fully depress lever (3) to direction shown in the figure and hold it in place. Make sure that pressure gauge reads 100 to 120 kg/sq.cm.
- If not, make sure that no hydraulic leakage occurs in the main control valve, remove cover (4) and clean valves located beneath.

CAUTION

Do not tamper with adjusting nut (5) on main control valve.

ADJUSTMENT HAS BEEN ACCOMPLISHED BY TRACTOR MANUFACTURER AT TIME OF INSTALLATION.




Figure 35. Check of hydraulic lifter operating pressure

RELIEF VALVE OPERATING PRESSURE

- Fully depress lever (fig. 36, item 3) to direction shown and hold it in place.
- Steer wheels to right or left as far as practicable (jack to be at the way extended or retracted). Make sure that pressure gauge reading is 130 to 140 kg/sq.cm.
- If pressure is found to be lower, set properly the hydraulic system relief valve (see fig. 36) by screwing on or screwing off adjusting nut with a screw-driver. Remove cap prior to taking action.

WARNING

Operating pressure in the hydraulic system never to exceed 170 kg/sq.cm




Figure 36. Setting of the hydraulic system relief valve



TROUBLE SHOOTING

HYDRAULIC LIFTER

(see fig. 37)

Note

Any failure in lifter operation is generally caused by improper or contaminated oil. When changing or refilling oil, rig duty adheres to directions furnished by manufacturer and exercise good cleaning and house-keeping practices.

TROUBLE	PROBABLE CAUSE AND REMEDY
a. Lifter will not come up (even at max.)	1. Insufficient oil level. Fill oil reservoir. 2. Jamming pilot valve (14) caused by impurities contained in oil. Unscrew the four screw holding cover (26), unlock valve and clean. To prevent trouble from taking place again, carefully clean oil filter cartridge on return (see fig. 23).
b. Lifter does not lower. (This may be encountered in the case of a new apparatus after a fairly extended inactivity from final test).	1. Jamming of shaft (3). Dismount cover (22), place the control lever in down position. Unlock shaft gently tapping on
c. Jumping of lifter in coming up.	1. Insufficient oil level. Fill oil reservoir 2. Air drawn into the suction line. Check connectors for proper tightening and replace packings. Bleed tubing by squeezing. 3. Air drawn through the pump oil seal. Replace oil seal.
d. Lifter does not remain in place, it rises or falls with jerking action. When engine is off, rod creeps down.	1. Leaking check valve (16). Take off cover (26); remove valve and clean valve seat. If seat and valve are found to be in good conditions and trouble is still encountered; change oil filter oil and clean cartridge. 2. Oil seepage through piston seal or seal rings of cylinder cap, or through seating located between the body of the distributor block and the housing. Replace seal.
e. Poor lifting power. Anomalous overheating of the system.	1. Pump low efficiency. Overhaul pump or replace it. 2. Improper setting of relief valve (9, 10). Remove cover (26) and replace spring. 3. Valve plunger (9) and seat (10) are out of order and allow oil seepage. Replace the valve. 4. Impurity on the pilot valve seat (14). Take off cover (26), remove valve and clean valve seat. 5. Pilot valve seat worn out (14). Overhaul distributor block.
f. When lifter arms are fully "up", rod is valve cut-off.	1. Jamming of shaft (3). Dismount cover (22), place control lever in down position and release shaft by tapping. 2. Improper setting of the valve in stop. Lift lifter arms (fig. 38, detail 11, through lever (7); adjust lever (7) with a screwdriver (4) until engine speed rate is caused to increase hydraulic circuit not under pressure and correct.
g. Escape of operated oil through the breather plug.	1. Oil level too high or too low. Top off oil to recommended level. 2. Air drawn through the suction line. Tighten the fittings, inspect welds, replace gasket. 3. Air drawn through pump oil seal. Replace oil seal.




Figure 37. Hydraulic filter control valve




Figure 38. Adjustment of UP limit stop rod



HYDRAULIC STEERING

TRROUBLE	PROBABLE CAUSE AND REMEDY
a. Incorrect steering movement.	1. Air in the steering jack. Bleed the system. 2. Jack packings are faulty. Replace all jack seals. 3. Hydraulic steering valve dirty. Where valve of fig. 33 is fitted, disassemble and clean restrictors. Where valve of fig. 34 is provided, disassemble and clean valve piston and verify that springs are not broken.
b. Excessive force required to rotate the steering wheel.	1. Differential locking engaged. Release it. 2. Improper adjustment of filter in filter. Lower the filter. If trouble is not solved, no low suggestions given under section "I" concerning break shooting of hydraulic filter.

CAUTION

In the event the above described inspection as well as circuit cleaning and replacement of worn out packings do not sufficient to solve the trouble encountered, HAVE THE HYDRAULIC POWER STEERING UNIT REPLACED WITHOUT DISMANTLING ANY HYDRAULIC POWER STEERING UNIT REPAIR SHALL BE MADE EXCLUSIVELY BY MANUFACTURER OR AUTHORIZED PERSONNEL. THE MANUFACTURER DISCLAIMS ALL LIABILITY OR REQUEST OF WARRANTY IF HYDRAULIC POWER STEERING UNIT APPEARS TO BE TAMPERED WITH.

HOW TO ORDER SPARE PARTS

NOTE

When ordering, always state:

- TYPE AND MODEL OF THE MACHINE
- SER. NO. NUMBER OF THE MACHINE
- CODE NUMBER OF THE PART
- REQUIRED QUANTITY
- REQUIRED DELIVERY TERMS
- ADDRESS OF THE ORDERING FIRM

HOW TO IDENTIFY A PART

Identify the piece required on the figure (the whole machine has been split into well defined units, as shown by the index of the figures).

- Read the code number. If the said number does not have any symbol alongside it, it is valid for all machines listed on the top right of the figure. If the code number has one or more symbols alongside it, or if a piece has more than one number and symbols alongside them, the right one must be identified by reading the meaning of the symbols.

For better machine-running, greater security and guarantee, always ask for ORIGINAL SPARE PARTS.

SYMBOLS USED IN THE SPARE PARTS CATALOGUE

(The numbers mentioned are only an indication)

- ROUND - etc.

Indication of validity for type of machine

Example:

The parts indicated are valid only for the machine model "1200".

- SQUARE - etc.

Indication of validity of the indicated part

Example:

* 585001 The part indicated is valid for machines
with serial N° 585001

585002 → The part indicated is valid from machine
from Serial N° 585002 onwards

TRIANGULAR - etc.

The parts of validity for the subsequent indicated alongside TRIANGULAR SYMBOL. Same is valid for the subsequent

Subassembly symbols

ENGINES

6-3000P It indicates an engine type 6-3000P

ROTAVATORS WITH FIXED HOOD

100-100 It indicates a rotavator with 100 cm fixed hood

ROTAVATOR WITH ADJUSTABLE HOOD

100-120 It indicates a rotavator with 120 cm adjustable hood

ADJUSTABLE DISC WHEEL

5-00-12 Shows the adjustable disc wheel type 5-00-12

FIXED DISC WHEEL

6-5-16 Shows the fixed disc wheel type 6-5-16

LENGTH TO BE SHOWN

100 Shows that the item is long 100 mm

PUMPS

S-985 It indicates a hydraulic pump type S-985

ELECTRIC SYSTEM

EXPORT It indicates an electrical system for export type machines

JOINT

1284 Indicates a joint type 1284

CUTTING BARS

120 It indicates a cutting bar 120 cm wide

CUTTING BAR TEETH

30-38 It indicates teeth with centre distance 30 mm

TYPE OF MACHINE

99 Shows the machine model 99

- ASTERISKS

Indication of validity for standard parts, parts on request parts made by another manufacturer

* A.R. The part thus indicated is supplied only at Customer's request

⊕ STANDARD The part thus indicated is standard make or assembly

⊖ Ditta S.p.A. The part thus marked is supplied for the Customer's indicated

- ABBREVIATIONS

= Left

= Right

SEE NEXT

FACE

SPARE PARTS CATALOGUE

AGRICULTURAL TRACTOR MOD. 85

INDEX OF ILLUSTRATIONS

Fig. C1009A-1	Body (1st part)
Fig. C1009B-1	Body (2nd part)
Fig. C1107	Clutch and control
Fig. C1109A	Double clutch (1st part)
Fig. C1109B	Double clutch (2nd part)
Fig. C1206	Gear case
Fig. C1306A	Gear box (1st part) (For all machines)
Fig. C1306B	Gear box (2nd part) (Straight - tooth gears)
Fig. C1306C	Gear box (2nd part) (Elasto gears)
Fig. C1306D	Gear box (3rd part) (Straight - tooth gears)
Fig. C1306F	Gear box (3rd part) (Elasto gears)
Fig. C1407A	Gear box shifting mechanism (1st part)
Fig. C1407B	Gear box shifting mechanism (2nd part)
Fig. C1511	Differential, front
Fig. C1606-1	Intermediate housing
Fig. C1706A	Rear axle, housing
Fig. C1706B	Rear axle, gears and control
Fig. C1906	Rear axle, shaft and differential
Fig. C2107A-1	Front hydraulic brakes
Fig. C2107B-1	Rear hydraulic brakes
Fig. C2206A	Implement after - Two-point hitch
Fig. C2206B	Implement after - Three-point hitch
Fig. C2606A	Electrical system (1st part)
Fig. C2606B	Electrical system (2nd part)
Fig. C2807	Accessories
Fig. C2905	Wheels
Fig. F1103-2	Rotary cultivator, drive shaft
Fig. F1301A-1	Rotary cultivator, case and components
Fig. F1301G-2	Rotary cultivator, fixed hood

HYDRAULIC EQUIPMENT

Refer to figures H00007 through H00533

FERRARI


10045 FERRARI - P.R. 10022-025674 IS JUNEL.

CARROZZERIA (1^a PARTE)
BODY (1^a PART).
CARROSSERIE (1^{re} PARTIE)
CARROZERIA (1^a PARTE)

85-86-86RS

1a-0677 2a-0278

No. ORDIN.	9	11.0033.271	25	16.0032.205	-	11.0022.415	
PARTE N.	10	11.0033.277	26	16.0032.206	-	16.0032.220	
No. ORDIN.	11	84.3943.260	27	16.0032.207	-	11.0022.416	
DETALI N.	12	84.3724.250	28	16.0032.208	36	42.0090.000	
No. REF.FRENCH	13	85.3264.000	29	16.0032.209	37	85.0154.010	
1	16.0032.245	14	84.3755.000	-	16.0032.204	38	85.5162.000
	16.0032.245	15	84.3810.020	27	11.0032.427	41	11.0032.31
-	16.0032.246	16	84.3812.020	28	16.0017.500	41	08.0032.22
-	16.0032.247	17	08.0015.314	29	04.2004.050	42	85.4147.000
2	11.0032.901	18	80.4020.000	30	01.4550.000	43	85.7150.000
3	11.0032.902	19	10.0002.258	31	11.0032.429	-	85.7005.000
4	87.4020.010	20	16.0032.226	32	85.9570.000	44	85.7004.000
5	11.0032.547	21	84.3755.050	33	83.5160.000	45	85.6146.000
6	84.3522.000	22	86.3205.000	34	82.8597.000	46	16.0032.204
7	87.4517.000	-	88.3411.000	35	85.3275.000	47	10.0032.201
8	16.0032.870	23	86.3205.000	36	85.3205.000	48	16.0032.200
	16.0032.870		88.3411.000	-	85.3235.000		84.3443.050
	16.0032.870	24	84.3012.000	37	16.0032.271		



F.P.S. 4-289

Diagramma di servizio
Numero di parte
Numero di catalogo
Numero di catalogo
Numero di catalogo

LDAB73-B33
LDAB32



DOPPIA FRIZIONE
DOUBLE CLUTCH
EMBRAYAGE DOUBLE
ZWEIFACH AUFBLICK
EMBRAGUE DOUBLE

LDAB73-B30
LDAB30


C1009A	
C1009A	1

No. CHIAVI
 KEY NO.
 No. CHIAVI
 FEUILLE NO.
 No. RE-LAENG A.

1	16.0032.267*	29	86.2811.000
2	16.0032.268*	30	16.0032.221
3	16.0032.264*	..	16.0032.227
4	44.3750.000*	31	84.3818.000
5	46.35.2.000*	32	85.3728.000
6	81.4720.000*	33	81.4581.000
7	44.3687.000*	34	84.3643.000
8	46.41.10.000*	35	16.2032.264
9	44.2921.000*	..	16.2032.262
10	86.42.20.000*	36	11.2032.264
11	SL.3254.000	37	86.2666.000
12	44.2813.000	38	16.2032.265
13	11.3001.000	39	11.3002.221
14	36.2106.000	40	86.2007.010
15	36.0684.000	41	84.3570.000
16	6.0002.012	42	81.4546.000
17	04.9210.000	43	16.0032.226
18	85.2653.000	44	86.3683.000
19	16.0032.211	45	16.0032.223
20	16.0032.252	..	16.0032.205
21	25.4587.000	..	16.0032.224
22	84.3673.000	..	16.0032.206
23	86.2482.000	46	86.3278.000
24	84.3700.000	47	84.3812.000
25	16.0032.235	48	16.0032.275
26	16.0032.200	49	16.0032.263
27	16.0032.200	50	16.0032.264
28	16.0032.200	51	81.4644.000



N. ORD. N.	N. ORD. N.	N. ORD. N.	N. ORD. N.
1 16.0202.210	11 16.0016.212	21 81.4.702.000	21 80.394.000
2 81.0505.000	12 83.1.32.000	22 96.3645.000	22 86.2862.000
3 84.3585.000	13 80.8235.000	23 16.0216.200	23 84.3543.000
4 82.6538.000	14 16.0016.012	24 80.2054.000	24 16.0216.001
5 16.0016.716	15 F1.4541.000	25 16.0216.716	25 16.0216.804
6 81.4581.000	16 80.2.29.000	26 16.0216.900	26 86.3276.000
7 88.0060.000	17 16.0016.803	27 80.2047.000	27 86.2955.000
8 89.1395.000	18 16.0016.210	28 16.0216.011	28 16.0216.013
9 11.0016.903	19 84.3875.000	29 16.0216.902	29 16.0216.200
10 11.0016.208	20 84.3842.000	30 81.4644.000	



FERRARI


FRIZIONE E RELATIVO COMANDO
CLUTCH AND CONTROL
EMBRAYAGE ET COMMANDE D'EMBRAYAGE
KUPPLUNG UND ENTSPRECHENDE STEUERUNG
EMBRAGUE Y MANOS

45045 LUZI FERRARI - TPI 165321 0000045 LINKE



85-86-86RS

2a - 0278

No. ORD. N.	No. ORDIN.	No. OHÖIN.
1 81.29.74.000	11 81.5044.000	2 86.0066.000
2 16.0016.902	12 16.0016.201	22 81.4581.000
3 16.0015.901	13 16.0016.900	23 16.0032.234
4 80.3278.000	14 81.9124.050	24 82.6039.000
5 84.0735.000	15 81.9124.010	25 84.3686.000
6 86.0554.000	16 16.0016.200	26 81.0505.000
7 84.3643.000	17 83.1129.000	27 16.0032.218
8 80.2554.000	18 80.1996.000	28 84.3017.000
9 85.1202.000	19 11.0016.903	29 86.3155.000
10 16.0015.915	20 11.0016.239	




T.P. 5. 1. 280




N°. ORDIN.


- 1 81.0647.000
- 2 81.2151.000
- 3 80.0105.000
- 4 16.0025.013
- 5 16.0025.211
- 6 96.1353.000
- 7 94.0755.000
- 8 16.0055.260
- 9 20.2600.000
- 10 20.2650.000
- 11 11.0006.071
- 12 00.1025.010
- 13 00.2756.000
- 14 16.0016.514 ▲
- 15 16.0016.515 ▲
- 16 16.0005.515
- 17 11.0005.020
- 18 05.0512.000
- 19 85.2628.000
- 20 84.3603.000
- 21 85.3113.000
- 22 11.0205.904
- 23 86.2109.000
- 24 11.0205.905
- 25 16.0005.512
- 26 85.1400.000
- 27 16.0005.901
- 28 16.0005.911
- 29 50.3533.000




No. ORDIN.	No. ORDIN.	No. ORDIN.
1 80.2172.000	12 84.4275.000	23 80.1220.000
2 80.1289.000	13 81.2708.000	24 16.5016.204
3 16.0016.G.212	14 16.0016.201	25 85.1150.000
4 81.2004.010	15 80.1389.000	26 80.1126.000
5 84.4467.000	16 81.2502.000	27 16.2016.205
6 80.1264.000	17 80.0047.000	28 16.2016.206
7 16.2016.015	18 16.0016.211	29 16.2016.207
8 16.2016.013	19 86.2019.000	30 81.2562.000
9 F1.2708.010	20 16.0016.218	31 81.1246.000
10 16.2016.209	21 81.0731.000	32 16.0016.212
11 80.1135.000	22 16.2016.100	




Nr.	ORDIN.
1	E1.2556.000
2	16.0305.216
3	16.0305.203
4	16.0305.219
5	16.0305.206
6	16.0305.205
7	80.1333.000
8	16.0305.131
9	16.0025.105
10	16.0025.104
11	E1.2802.000
12	80.0057.050
13	16.0025.251
14	80.1149.000
15	84.4227.060
16	16.0005.100 C
-	16.3006.100 C
17	80.2092.000
18	16.0005.215
19	16.2005.101 C
-	16.3006.101 C
20	16.0005.200
21	81.2/31.240
22	81.4843.000
23	84.25/1.000
24	16.0005.221
25	85.2191.000
26	16.0005.202
27	16.0005.217
28	16.0005.216
29	84.7229.010
30	16.0005.157
31	85.0114.000 ID 2 mm
-	85.0114.010 ID 3 mm
-	85.0114.020 ID 5 mm
32	81.2731.030
33	16.0305.103
34	16.0305.102
35	80.1400.030






No. UNITA

1	16.000D.105	1	16.000D.210
2	16.000S.135	2	16.000S.221
3	16.000S.114	3	16.000S.221
4	16.000S.267	4	16.000S.221
5	16.000S.267	5	16.000S.221
6	16.000S.160	6	16.000S.221
7	16.000S.114	7	16.000S.221
8	16.000S.114	8	16.000S.221
9	16.000S.114	9	16.000S.221
10	16.000S.114	10	16.000S.221
11	16.000S.114	11	16.000S.221
12	16.000S.114	12	16.000S.221
13	16.000S.114	13	16.000S.221
14	16.000S.114	14	16.000S.221
15	16.000S.114	15	16.000S.221
16	16.000S.114	16	16.000S.221
17	16.000S.114	17	16.000S.221
18	16.000S.114	18	16.000S.221
19	16.000S.114	19	16.000S.221
20	16.000S.114	20	16.000S.221
21	16.000S.114	21	16.000S.221
22	16.000S.114	22	16.000S.221
23	16.000S.114	23	16.000S.221
24	16.000S.114	24	16.000S.221
25	16.000S.114	25	16.000S.221
26	16.000S.114	26	16.000S.221
27	16.000S.114	27	16.000S.221






Nu. ORDIN.

- 1 16.0305.201
- 2 80.1225.000
- 3 16.0305.109
- 4 81.2558.000
- 5 85.0100.200 0,2 mm
- 6 85.0100.210 0,2 mm
- 7 85.0100.220 0,5 mm
- 8 80.1366.300
- 9 81.2767.010
- 10 16.0205.210 ■■■
- 11 16.0205.209 ■■■
- 12 16.0205.206 ■■■
- 13 80.1400.000
- 14 85.0205.100 0,2 mm
- 15 85.0205.010 0,2 mm
- 16 85.0205.020 0,5 mm
- 17 16.0305.207
- 18 80.1210.000
- 19 84.4578.000
- 20 81.2731.200
- 21 16.0205.111
- 22 16.0205.113
- 23 16.0205.114
- 24 16.0205.112
- 25 81.2740.000
- 26 11.0300.225
- 27 85.0130.300 0,2 mm
- 28 85.0130.210 0,2 mm
- 29 85.0130.220 0,5 mm
- 30 80.1402.200
- 31 00.2121.000





N° ORDIN.

- 1 10.0005.301
- 2 90.1229.000
- 3 10.0001.109
- 4 91.2060.000
- 5 85.0100.000 10.2 mm
- 6 85.0100.010 10.3 mm
- 7 85.0100.020 10.5 mm
- 8 30.1368.000
- 9 81.2767.010
- 10 16.0005.277
- 11 16.0005.275
- 12 15.0005.273
- 13 83.1400.000
- 14 85.0057.000 10.2 mm
- 15 85.0057.010 10.3 mm
- 16 85.0057.020 10.5 mm
- 17 16.0005.207
- 18 90.1710.000
- 19 94.4576.000
- 20 91.2731.000
- 21 16.0005.111
- 22 16.0005.110
- 23 16.0005.214
- 24 16.0005.112
- 25 16.0005.213
- 26 81.2780.000
- 27 11.0000.220
- 28 85.0130.030 10.2 mm
- 29 85.0130.010 10.3 mm
- 30 85.0130.020 10.5 mm
- 31 80.1422.000
- 32 82.2127.010



No. C.R.O. N.
1 43.7562.000
2 16.0035.900
3 86.2555.200
4 84.3043.250
5 16.0005.210
6 83.1575.010
7 16.0035.710
8 16.0005.120
9 16.0005.900
10 16.0005.002
11 16.3005.250
12 80.31.83.000
13 16.0025.228
14 01.0031.319
15 16.0055.243
16 84.7432.000
17 16.0005.258
18 41.1562.048
19 83.1070.000
20 16.0005.251


A B




Nr. CUDIN N.

1	16.00005.120
2	01.00001.319
3	16.00006.251
4	16.00005.242
5	16.00005.261
6	01.00001.000
7	16.00005.240
8	16.2158.000
9	PA 74.32.000
10	16.00005.260
11	PA 1150.000
12	PA 74.16.000
13	16.00005.220
14	PA 2045.020
15	PA 2049.050
16	PA 2049.050
17	31.45.19.000
18	16.00005.234
19	16.00005.2615
20	PA 1115.000
21	PA 30.02.020
22	16.00005.260
23	16.00005.131
24	16.00005.253
25	16.00005.200
26	PA 7E37.020
27	15.0034.900
28	16.00005.016
29	16.00005.120
30	16.00005.127
31	PA 3788.000
32	PA 31.17.020
33	PA 30.02.000
34	32.13.75.000
35	15.00005.215
36	14.00005.129
37	16.00005.252
38	PA 1308.000
39	16.00005.121
40	16.00005.244
41	16.00005.236
42	41.1550.048
43	PA 1120.070
44	01.00001.020
45	16.00005.255

T.P.S. 4-JDS


Significato d. simboli

C1407B

45046 LUZZARNO (PIEMONTE) TEL. (0321) 816624 - 816661

1a 0677


No. ORDIN.	No. O-RD N.	No. ORDIN.	No. O-RD N.
1	81.4643.000	14	16.0010.236
2	84.3755.050	15	16.0010.221
3	'1.001' 107	16	90.0064.000
4	'1.0013 207	17	81.2973.060
5	65.3452.000	18	95.0163.000 10.2 mm ²
6	'6.0010 110	19	95.0163.000 10.3 mm ²
-	'6.0010 110 incl.	20	95.0163.000 10.5 mm ²
7	'6.0010 205	21	80.1423.000
8	'6.0010 105	22	16.0010 102
9	'8.0010 202	23	16.0010 108
10	'8.0010 104	24	92.0010 902
11	'8.0010 204	25	94.3755.050
12	'8.0010 200	26	88.3222.000
13	'8.0010 103	27	16.0010 303



42035 LUCCA (IRE) TEL. 0523/03524 IS-LINES

1a 0677

No. ORD. N.	No. ORDIN.	No. ORDIN.
1 85 2758 000	21 1E 0008.220	27 95.0114.000 0.2 mm
2 85 13618.000	22 81 2670.000	28 95.0114.010 0.2 mm
3 81 2658.000	23 1E 0008.219	-
4 1E 05018.204	24 81.2781.000	29 81 2757.000
5 1E 0000.210	25 8D 1430.000	30 1E 0008.212
6 81 2669.000	26 8D 7210.000	31 1E 0008.206
7 85 0140.000 0.2 mm	27 8D 3207.000	32 1E 0008.209
8 85 0140.010 0.2 mm	28 1E 0008.225	33 1E 0008.211
9 85 0140.020 0.5 mm	- 1E 0008.249	34 01.2846.000
10 8D 1426.000	29 92.8471.000	35 8D 1422.000
11 1E 0008.102	30 1E 0008.102	36 8D.2.62.000
12 1E 0008.101	31 8E 2259.000	
13 81 2758.002	32 84.0571.000	
14 1E 0008.221	33 91.4543.000	
15 1E 0008.222	34 8D 2125.050	
16 1E 0008.214	35 8D 1430.000	
17 8D 3217.040	36 1E 0008.213	
18 1E 0008.208		
19 84 7416.000		
20 85 1022.000		
21 1E 0008.207		
22 81 2922.000		
23 1E 0008.208		



1.P.0.4.108


34

C1706B


Separazione orizzontale



No. ORDIN.	No. ORDIN.	No. ORDIN.
1 80.0064.000	16 80.2452.000	30 10.0010.203
2 16.0010.103	17 81.2973.000	31 81.2959.000
3 16.0010.204	18 86.2160.000 (3,2 mm)	32 80.1430.000
4 16.0010.104	- 86.0161.000 (3 mm)	33 80.2778.000
5 16.0010.202	- 86.0162.000 (0,5 mm)	34 80.1257.000
6 16.0010.200	19 86.1403.000	35 16.0010.106
7 16.0010.201	20 16.0010.102	36 84.3921.020
8 16.0010.200	21 16.0010.108	37 86.4102.000
9 16.0010.225	22 86.1346.000	
10 16.0010.105	23 16.0010.221	
11 16.0010.207	24 80.1130.020	
12 16.0010.107	25 21.0021.079	
13 84.3765.050	26 21.2021.078	
14 81.4843.000	27 92.3010.902	
15 16.0010.101	28 16.0010.010	
- 16.0010.100	29 86.0322.000	



No ORD N.	15	80.6216.000	34	80.3291.000	60.4612.000
PART N.	16	80.1232.000	35	16.0012.122	51 16.0012.214
No ORD N.	17	16.0012.203	36	16.0012.131	52 16.0012.220
SESTANTE N.	18	16.0012.218	37	16.0012.130	- 16.0012.220
N. REFERENZA	19	80.1175.000	38	84.7479.050	53 16.0012.271
1	82.1070.000	20	82.6041.000	39	82.6038.000
7	16.0012.202	21	16.0012.210	40	80.2591.000
3	81.3050.000	22	16.0012.217	41	81.0570.010
4	80.0153.000	23	82.6042.000	42	81.2849.000
5	16.0012.201	24	16.0012.215	43	16.0012.205
E	E1.4767.000	25	16.0012.204	44	80.1403.000
7	84.4064.000	26	E1.4317.000	-	80.1400.050
E	83.8745.000	27	84.4454.000	45	E1.2636.000
E	16.0012.010	28	85.0257.040	46	16.0012.206
10	84.3642.060	29	B1.2777.000	47	16.0012.012
11	85.2952.000	30	80.1422.000	48	80.4296.050
12	16.0012.211	31	16.0012.200	49	84.0921.020
13	16.0012.212	32	85.2797.000	50	80.4021.000
14	16.0012.213	33	16.0012.013	-	80.4012.000



I.P.3.4-789


Numero di riferimento
Referenz-Nr.
Nº de referencia
Referencenummer
Referencenummer

161.940 ■ 161.841

C1605	
C1605	1

No. D.R.G.N.

- | | |
|----|-------------|
| 1 | 16.0008.223 |
| 2 | 80.3057.050 |
| 3 | 15.001F.212 |
| 4 | 85.262E.300 |
| 5 | 85.3512.000 |
| 6 | 86.37D1.000 |
| 7 | 16.0008.050 |
| 8 | 16.0008.211 |
| 9 | 16.0008.220 |
| 10 | 09.0011.310 |



FERRARI


FRENI IDRAULICI ANTERIORI
FRONT HYDRAULIC BRAKES
FREINS HYDRAULIQUES ANTERIEURS
VORDERE HYDRAULISCHE BREMSEN

75RS-85-86

4294 FERRARI REF. NO. 10521.00000 (5 LISTS)

1x-0177 2x-0677


Nr. C-101N	Nr. ORDIN.	Nr. ORDIN.
1 11.0021.915	46 86.0091.000	50 86.1326.000
2 11.0021.279	-- 86.0000.000	-- 86.1326.000
3 86.3753.000	47 82.6040.000	51 86.3153.000
4 81.7505.000	48 86.1267.000	52 84.0817.000
5 11.0021.902	-- 86.1267.000	-- 84.0817.000
6 11.0021.903	49 18.2032.259	53 11.0021.411
7 18.0021.904	-- 18.0032.219	54 83.1108.000
8 11.0021.905	-- 11.0032.410	-- 83.1108.000
9 16.0021.902	-- 11.0032.454	55 11.0021.412
10 16.0021.903	-- 16.0032.259	56 82.3142.000
11 86.2100.000		
12 81.4780.000		
13 11.0021.203		
14 11.0021.204		
15 84.3102.000		
16 84.3771.000		
17 82.3143.005		
18 86.3584.000		
19 86.3595.000		
20 87.3140.002		
21 87.3140.004		
22 87.3140.007		
23 87.3140.009		
24 87.3140.011		
25 87.3140.012	= 86.0021.4440	
26 82.3875.000		
27 84.3994.000		
28 86.4162.000		
29 82.5000.000		
30 82.5007.000		
31 82.6005.000		
32 82.6005.020		
33 11.0021.907		
34 16.0021.900		
35 11.0021.907		
36 84.3798.00		
37 86.3448.000		
38 16.0021.905		
39 16.0021.901		
40 11.0021.908		
41 16.0022.903		
42 11.0026.263		
43 16.0021.328		
44 11.0029.263		
45 82.7102.000		
46 82.7102.030		
47 82.7102.000		
48 82.7102.020		
49 82.7102.030		
50 81.7505.000		
51 11.0021.906		
52 11.0021.278		
53 16.0021.200		
54 16.0021.923		
55 11.0021.910		
56 16.0021.903		
57 16.0021.923		
58 86.0091.020		
59 86.0090.020		
60 82.4043.002		
61 86.2091.010		
62 86.2090.010		




C2107A	1
--------	---



No. D.F.DIN.	No. OF-D.N.
1 86.2153.000	27 82.0140.302
2 84.0640.060	28 82.0140.304
3 84.066.000	29 82.0140.306
4 02.3250.090	30 82.0140.308
5 01.4824.000	31 82.0140.307
6 06.0226.030	32 82.0875.000
7 05.5173.000	33 84.0064.000
8 00.1932.000	34 48.41.02.000
9 94.3561.000	35 41.0141.002
10 11.0029.004	- 41.0141.004
11 82.0140.011	36 02.0141.200
12 82.0140.012	37 82.0141.202
13 82.0140.013	- 82.0141.205
14 16.0022.002	38 82.0140.303
15 16.0021.905	39 80.056.000
16 11.0021.912	
17 86.2255.000	
18 82.0805.000	
19 11.0021.913	
20 16.0021.906	
21 16.0021.903	
22 86.2358.000	
23 84.0755.050	
24 02.0140.008	
25 02.0141.000	
26 82.0140.002	
27 82.0141.301	
28 82.0141.307	





N°. ORDININ

85.30150.0100	16.00027.211.300
85.30189.7.0001	16.00027.210.100
85.30465.1016	88.3253.300
85.31224.1010	89.1.796.1200
11.10027.3229	18.00037.2000
81.4044.200	05.3205.2010
62.6020.300	85.14815.2012
16.00027.210.100	85.30189.7.0011
85.31221.1221	85.14752.0101
16.00027.200.100	16.00027.204.705
16.00027.205.500	16.00031.205.500
16.00029.205.100	16.00029.205.100
16.00029.205.800	16.00029.205.800
*	16.00029.202
80.6240.203 *	80.6240.203
85.1499.2012	85.1499.2012
85.0021.2012	85.0021.2012
85.1.799.3005	85.1.799.3005
85.00360.0005	85.00360.0005
81.1930.300	81.1930.300
81.0625.8910	81.0625.8910

T.P.S. 4-108


Segnale sono divisi da

* A RICHIESTA


G2206A

No. C.R.E.N.


- 1 16.0031.234
- 2 86.0300.300
- 3 18.0001.265
- 4 86.0700.300
- 5 85.140E.000
- 6 16.0020.211 ~ 16.0048.445
- 7 80.5709.000
- 8 16.0031.241 DS ○
- 9 16.0031.242 SN ○
- 10 16.0028.20D DS ●○
- 11 16.0028.201 SN ●○
- 12 91.4.004.000 ○
- 13 80.8039.395
- 14 16.0031.222 SS ○
- 15 16.0031.221 SN ○
- 16 16.0020.212 ●○
- 17 81.4820.000
- 18 11.0031.253
- 19 80.8039.075
- 20 16.0028.210 DS ●○
- 21 16.0028.211 SN ●○
- 22 16.0031.200 LS ○
- 23 16.0001.201 SN ○
- 24 84.3543.066
- 25 86.4172.029
- 26 86.4172.030 ○




No. ORDIN.	No. UD. DIN.
1	82.5444.000
2	82.5454.000
3	10.0017.501
4	10.0017.505
5	82.5322.010
6	82.5324.030
7	82.5436.000
8	82.5400.000
9	82.5452.000
10	82.5405.000
11	82.5437.000
12	82.5401.000
13	81.4517.030
14	84.3522.000
15	80.1874.020
16	11.0017.913
17	82.5322.010
18	82.5436.000
19	82.5400.000
20	11.0017.954
21	11.0017.954
22	81.7640.020
23	86.1936.030
24	84.3561.000
25	84.3542.000
26	81.4531.000
27	81.4527.000
28	11.0031.217
29	86.1941.000
30	82.5461.000



A



B



C




No. D.P.O. N.

- 1 82.5404.000
- 2 82.5423.000
- 3 82.5425.000
- 4 82.5443.000
- 5 82.5432.000
- 6 82.5420.050
- 7 82.5420.000
- 8 82.5422.020
- 9 82.5422.070
- 10 82.5422.030
- 11 82.5422.000
- 12 82.5423.000
- 13 82.5423.020
- 14 82.5462.000
- 15 82.5462.050
- 16 82.5445.050


No. D.P.O. N.

- 17 81.4574.000
- 18 84.3666.000
- 19 80.2505.000
- 20 82.5407.000
- 21 82.5461.000
- 22 16.0017.900
- 23 82.5467.000
- 82.5468.000
- 24 81.4545.000
- 25 84.3570.050
- 26 84.3666.010
- 27 81.2057.050
- 28 82.5138.000
- 29 82.5411.050
- 30 82.5412.050
- 31 86.0255.050
- 32 84.3798.050
- 33 82.5413.050
- 34 85.4001.050


D



E





F



No. GR.DIN.

- 1 11.0065.015
- 2 10.7025.000
- 3 03.0065.106
- 4 02.0065.107
- 5 10.7015.250
- 6 11.0065.526
- 7 E2.E7E1.000
- 8 16.0065.011○*
- 9 16.0066.011●*
- 10 16.0066.013○*
- 11 16.0066.010○
- 12 16.0066.010●
- 13 16.0066.012●



1.0.5.4.280

1	2	3
4	5	6
7	8	9
10	11	12
13	14	15



* A.R.

C2807


1	2	3
4	5	6
7	8	9
10	11	12
13	14	15

N°. ORDIN

- 1 86.4382.002 *
- 2 86.4051.000 *
- 3 84.4084.000 *
- 4 20.0010.911 *
- 5 84.8642.000
- 6 84.8654.000 ▲
- 7 84.8810.000
- 8 84.8812.000 ▲
- 9 84.9113.000
- 10 84.9117.000 ▲
- 11 86.4177.000
- 12 86.4357.000 ▲
- 13 11.0013.915
- 14 11.0013.013 ▲
- 15 11.0013.914
- 16 11.0013.912 ▲
- 17 84.3921.020
- 18 84.4030.010 ▲
- 19 81.4750.000
- 20 81.4757.000



Nº ORDEN.	8	82.6016.000	12	89.4299.000
PART NO.	9	11.0045.209	19	84.3993.000
Nº ORDEN.	10	11.0045.207	20	84.3921.000
PART NO.	11	92.0002.000	21	81.4767.000
Nº REFERENCIA	12	11.0045.208	22	80.8039.000
1	11.0045.202	13	11.0045.205	
2	11.0045.212	14	85.1482.000	
3	11.0045.208	15	80.8039.000	
4	11.0045.211	16	1.0023.207	
5	80.1232.030	-	1.0042.223	
6	01.0001.283	17	1.0045.204	
7	11.0045.210	-	16.0547.201	




TIP. 5 - 126

Diagrama de montaje
Diagramm der Montage
Diagramma di montaggio
Diagrama de montagem
Diagrama de montagem



E1483	1
F1103	2

Nº. OFICINA.	..	05.0104.020 (0,5 mm)	26	23.0340.234
PART. N.º	'2	07.0040.101	27	07.0040.206
Nº. OFICINA	13	91.2059.000	28	81.2030.000
OFICINA N.º	14	07.0040.102	29	07.0040.228
Nº REFERENCIA	15	07.0040.227	30	84.4482.000
1	62.1045.000	16	81.4717.050	
2	60.2198.050	17	86.2597.000	
3	80.3253.000	18	81.0043.060	
4	07.0040.010	19	07.0040.903	
5	80.6567.000	20	11.0042.900	
6	05.3040.211	21	85.0089.000 (0,1 mm)	
7	85.2186.000	-	85.0089.010 (0,2 mm)	
8	07.0040.011	-	85.0085.020 (0,3 mm)	
9	07.0040.904	22	82.8576.000	
10	81.2042.002	23	60.1277.050	
11	86.0104.000 (0,2 mm)	24	07.0040.214	
-	86.0104.010 (0,3 mm)	25	03.0040.901	



Nr. ORD N.
 PART No
 Nr. ORD N.
 0137P/1 00c
 No. REFERENZA

- 1 11.0043.255
- 2 11.0043.255
- 3 11.0043.257
- 4 81.4.916.060
- 5 84.3843.060
- 6 84.3801.060
- 7 86.3951.000
- 8 84.4160.000
- 9 81.5617.000
- 10 11.0043.241
- 11 81.4721.000
- 12 11.0043.236
- 13 11.0043.237
- 14 86.3879.050
- 15 11.0043.243
- 16 11.0041.208
- 17 11.0043.245
- 18 11.0043.103
- 19 11.0041.207
- 20 11.0043.244
- 21 11.0046.700
- 22 11.0043.246
- 23 11.0043.247
- 24 86.3925.000
- 25 86.3917.010
- 26 11.0042.932
- 27 11.0046.030
- 28 05.4002.010
- 29 01.0001.485
- 30 16.0032.931
- 31 16.0233.900



HOW TO PLACE WATERWORKS PARTS

- 1** MACHINE TYPE
- 2** SYSTEM TYPE
- 3** PUMP ACCORDING TO THE INSTALLED ENGINE (delivered as assembly)
- 4** HYDRAULIC DISTRIBUTOR (delivered as assembly)
- 5** POWER STEERING ACCORDING TO MODEL INSTALLED (delivered as assembly)
- 6** CONNECTING LINES
- 7** REFER TO THE SUITABLE FIGURE
- 8** VALIDITY NOTES (each is considered as stated in the spare Parts Catalogue)



IMPIANTO IDRAULICO - IDROSTERZO E SISTEMI A POSIZIONE E SERVOSTERZO ATTIVATO

HYDRAULIC EQUIPMENT - HYDROSTEERING AND POSITION SERVOSTEERING WITH AUTOMATIC POSITION CONTROL

EQUIPEMENT HYDRAULIQUE - DIRECTION HYDRAULIQUE ET DISTRIBUTEUR AVEC REGLAGE AUTOMATIQUE DE LA POSITION AINSI QUE DE L'EFFORT DE TRAVAIL
AMPLIO HYDRAULISCHE - HYDRAULISCHE ANTRIEB UND DISTRIBUATOR MIT AUTOMATISCHEM POSITIONIERUNG DER ANTRIEBSSTRENGHEIT

75

ta-0777


	COSTRUZIONE	TIPO	NO. ORDINAZIONE	FIGURA DI ATTACCO	MOTORE
A	PIRELLA	AM 2.004	83.580.000	H00501-231	RD921
B	PIRELLA	AM 2.005	83.580.000	H00501-231	RD924
C	DANFOSS	GRUPPO 100	83.580.000	H00506-511	
	TRUZ	400000	83.580.000	H00507-521	
	TRUZ	400000	83.580.000	H00508-531	

- No. C.R. 500
- 1 83.580.000-A*
 - 2 83.580.000-B*
 - 3 83.580.000-C*
 - 4 83.580.000-D*
 - 5 83.580.000-E*
 - 6 83.580.000-F*
 - 7 83.580.000-G*
 - 8 83.580.000-H*
 - 9 83.580.000-I*
 - 10 83.580.000-J*
 - 11 83.580.000-K*
 - 12 83.580.000-L*
 - 13 83.580.000-M*
 - 14 83.580.000-N*




VALVOLA REGOLATRICE DI PRESSIONE
PRESSURE RELIEVE VALVE
SOUPAPE DE RÉGLAGE
SÜDPREßGEGE

No. DI LISTA	1
1	83.580.000-A00
2	83.580.000-B00
3	83.580.000-C00
4	83.580.000-D00
5	83.580.000-E00
6	83.580.000-F00
7	83.580.000-G00
8	83.580.000-H00
9	83.580.000-I00
10	83.580.000-J00
11	83.580.000-K00
12	83.580.000-L00
13	83.580.000-M00
14	83.580.000-N00



	No. ORDIN.
1	11.0027.021▲
	11.0026.3126▲
	11.0029.388*▲
	11.0027.021*▲
2	11.0027.026▲
	11.0029.206▲
	11.0029.205▲
	11.0027.020▲
3	11.0029.388*▲
4	11.0027.024
5	11.0029.001*▲
6	11.0027.023
7	11.0029.035
8	11.0029.034
9	11.0021.006

	COSTRUTTORE MANUFACTURER CONSTRUCTEUR KONSTRUKTFLUP	TIPPO TYPE No. DE COMMANDE BESTELLNUMMER	No. ORDINAZIONE PART No. No. DE COMMANDE BESTELLNUMMER	FIGURA E DETTAGLIO FIGURE & INDEX No. FIGURE & DETAIL BILDO UND CIRKELNR.	MOTORE ENGINE MOTOR MOTOR
A	MOTORIDRIVE	AM 2.74-06	83.6009.000	0-H00526-112	LDA 873 LDA 832
B	CRPOZ		83.6051.000	1-H00531-1H1	
C	TRW	H04-07	03.6166.000	1H00530-1S1	



SCHEMA
WIRGRAM
SCHEMA
SCHERMA
No. 16 0029.999

T.P.M. 4 130


Double clutch	▲ LDA673 ▲ LDA832	DOPPIA FRIZIONE ▲ 673 ▲ 832 DOUBLE DROSS CLUTCH ▲ 673 ▲ 832 DOUBLE EMBRAYAGE ▲ 673 ▲ 832 DOPPI F KUPPLUNG ▲ 673 ▲ 832	* INDICARE LUNGHEZZA * STATE THE LENGTH * INDICER LA LONGUEUR * ANZEIGEN DIE LÄNGE
---------------	----------------------	--	---

H0000?

Z1 POMPA CON ALBERO CONICO
 CONICAL SHAFT PUMP
 POMPE A ARRE CONIQUE
 KONISCHWEISER PUMP


Nr. OFIDIN.

- 1 82.5810.000
- 2 82.2192.000
- 3 82.2462.010
- 4 82.4822.000
- 5 82.3185.000
- 6 82.2170.000
- 7 1.0027.217
- 8 82.2108.000
- 9 82.3185.000
- 10 82.7914.000


U1 VALVOLA REGOLATRICE DI PRESSIONE
 MAX. PRESSURE RELIEF/F VALVE
 SOUPAPE DE REGLAGE
 ZUGSPANNER/ER

Nr. OFIDIN.


- 1 82.58183.000
- 2 82.2348.000
- 3 84.3571.000
- 4 83.5034.000
- 5 82.4113.000
- 6 82.5035.000
- 7 82.4113.000



V1

N°. OF DIN


- 1 16.0029.236
- 2 61.7514.030
- 3 86.2854.020
- 4 94.3566.020
- 5 11.0021.069
- 6 65.2570.020
- 7 81.4751.030
- 8 52.6962.020
- 9 16.2029.700
- 10 11.0029.951
- 11 86.2854.050
- 12 94.3566.020
- 13 61.4589.010
- 14 56.2597.020



Y1


No. ORD'N

- 1 RE. 0327.000
- 2 RE. 5812.000
- 3 31.0551.000
- 4 84.4230.000
- 5 80.9325.000
- 6 80.9325.000
- 7 81.4793.000
- 8 84.4040.000
- 9 80.9325.000
- 10 80.2239.040
- 11 80.9303.000
- 12 90.3106.000
- 13 80.9324.000
- 14 80.2176.000
- 15 80.9326.000
- 16 80.4250.000
- 17 82.8000.000
- 18 71.0029.285 4.1.32
19. 84.1271.000



II

No. ORD. N.R.	No. CHIN.
1 10.0027.700	17 94.2992.060
2 80.3725.000	18 81.4785.060
3 84.2840.060	19 80.3771.000
4 85.3426.000	20 80.3774.000
5 84.3755.200	21 82.9318.010
6 K0.9318.000	22 K0.2080.010
7 K0.5775.000	23 K0.3282.020
8 K1.5626.000	24 K0.2040.025
9 K0.5020.000	25 K0.3056.000
10 84.2907.000	26 80.9312.000
11 82.2010.000	27 64.4005.200
12 81.1950.000	28 61.4798.200
13 80.1180.000	29 80.3335.000
14 85.2750.000	30 80.9275.200
15 11.3030.226	31 1.10.226.905
16 81.1955.200	




Alb. SERV. DANFOSS
 497064/02

S1

N. ORDIN.

- 1 11.0026.011
- 2 86.2440.040
- 3 11.0026.221
- 4 56.1407.090
- 5 90.0480.200
- 6 80.4223.050
- 7 18.3029.201
- 8 88.3068.000
- 9 88.3468.000
- 10 80.0193.000
- 11 92.57.0.000
- 12 11.0026.220
- 13 40.8040.000
- 14 82.0141.000
- 15 03.5007.000
- 16 82.4141.000
- 17 63.5007.000
- 18 82.4141.050
- 19 63.5040.000
- 20 82.4141.000
- 21 86.2019.000



FERRARI

DISTRIBUOTORI A POSIZIONE E SFORZO CONTROLLATO

CERPOZ (per dettagli vedi fig. H00532A + B)

DISTRIBUTOR PROVIDED WITH AUTOMATIC DEPTH

CONTROL (see detail fig. H00532A and B)

DISTRIBUTEUR AVFC REGLAGE AUTOMATIQUE DE LA

PROFONDEUR AINSI QUE DE L'EFFORT DE TRAVAIL

(vedi fig. H00532A + B)

00053225-RS (Rev. 1) - Tel. 0322 837521 (01000) AR25/77/1986 UNO KRAFT Verz. 00053225-RS


85-86-86 RS

16-10-77

R2**SC COU RITA x 85-86 RS**

No. ORDIN.

- 1 16.0221.355
- 2 86.3720.000
- 3 82.5881.000
- 4 86.3726.000
- 5 84.3725.000
- 6 84.3837.000
- 7 83.5036.000
- 8 84.3807.000
- 9 84.3120.000
- 10 84.2520.000
- 11 84.4110.000
- 12 83.5036.000
- 13 84.3907.000
- 14 11.2077.212 *
- 15 82.4113.000 *
- 16 82.5980.000 *
- 17 11.3029.254 *
- 18 80.3700.000

825855/90**No. 825860038 -**

T.P. 5 - 6-100

00053225-RS
 00053225-RS
 00053225-RS

*** A RICHIESTA**
*** ON REQUEST**
*** SUR DEMANDE**
*** SUR ANFAANGE**

H00531

DISTRIBUTORE A POSIZIONE E SFORZO CONTROLLATO
(distribuiti la parte)

DISTRIBUTOR PROVIDED WITH AUTOMATIC DEPTH CONTROL
(distribuiti la parte)

DISTRIBUTEUR AVISÉ REGLAGE AUTOMATIQUE DE LA
PROFONDEUR AINSI QUE DE L'EFFORT DE TRAVAIL
(distribuiti la parte)

VERTEILER MIT AUTOMATISCHEM FESTSTELL- UND DER
ARBEITSTIEFE UND KRAFT (Anzeigetafel) (distribuiti la parte)

FERRARI


42045 ULL225 RA (PE) TFI INERTIA KNEEJOINT UNITE

85-86-86 RS

1a-1077

R1

No. ORDIN.	No. ORD N.	No. ORDIN.	No. ORDIN.
1	82.1006.000	14	82.5991.001
2	82.1166.000	15	82.1072.000
3	82.5991.006	16	82.2621.000
4	82.2314.000	17	82.3664.000
5	82.4570.010	18	82.5991.005
6	82.5994.042	19	82.5991.024
7	82.5994.038	20	85.1130.000
8	82.5994.039	21	82.5991.003
9	86.1972.000	22	82.5991.002
10	82.5994.040	23	82.5991.006
11	82.5994.041	24	81.4570.010
12	82.1297.000	25	82.5984.008
13	84.2675.000	26	82.5991.007



FERRARI

DISTRIBUTORE A POSIZIONE E SPORZO CONTROLLATO
(dettagli 2a parte)

DISTRIBUTOR PROVIDED WITH AUTOMATIC DEPTH CONTROL.
(det. 2nd part)

DISTRIBUTEUR AVEC REGLAGE AUTOMATIQUE DE LA
PROFONDEUR AINSI QUE DE L'EFFORT DE TRAVAIL
(det. 2ème partie)

VERTDISTRI MIT AUTOMATISCHER FESTSTELLUNG DER
ARBEITSTIEFE UND KRAFT (det. 2. Teil)


4304 102269A (PER TEL. 0522 836624 ITALIA).

85-86-86 RS

1a-1077

R1

N. DI ORDIN.	N. DI ORDIN.
1	82.2255.000
2	84.0571.000
3	82.5984.030
4	82.5984.024
5	90.2195.000
6	80.2206.000
7	80.3195.000
8	82.5984.023
9	82.5984.022
10	82.5984.025
11	82.5984.020
12	82.5984.026
13	82.5984.021
14	82.5984.027
15	82.5984.020
16	82.5984.029
17	82.5984.028
18	80.3185.000
19	82.5984.035
20	80.1174.000
21	82.5984.017
22	82.5984.018



24

22

1a-1077-4-520

Spese di spedizione esclusa
Postage not included
Gebühren für die Versandfracht nicht enthalten
Gebühren für die Versandfracht nicht enthalten

▲ FORNIRE SOLDI ACCOPPIATI
▲ DELIVERED ONLY MATCHED

▲ FOURNIR SCULPMENTS COUPLES
▲ LIJFEN PAAREN

H00532 B



FERRARIVOLANTE DI GUIDA E MANETTA COMANDO ACCELERATORE
STEERING WHEEL AND ACCELERATOR CONTROL LEVER
VOLANT ET MANETTE DE COMMANDE ACCELERATEUR
LENKRAD UND STEUERKNEBEL F. FESTSTELLVORLAGE**85-86-86 RS**

320H-1.0774PA REI TEL. 0522/825524 - 5 CIRHEI

1n-1077

N1

- No. C.R.C.I.N.
- 1 86 5030.010 86.5030.010
 - 2 86 5030.020 86.5030.020
 - 3 81.4747.020
 - 4 84.3892.050
 - 5 82.8020.020 82.8020.020
 - 6 86 2095.000
 - 7 85 7004.000
 - 8 86 6146.000
- 828020020



T = 3 - 5.000

LEADER 1000
LEADER 1000
LEADER 1000
LEADER 1000

H00633