

1350R | 1350R (EU)
1350R X-Series
(SN 188601 and Before)

1500R | 1500R (EU)
1500R X-Series
(SN 190801 and Before)

1650R | 1650R (EU)
1650R X-Series

Skid-Steer Loader
Operator's Manual

50940264 Rev. N 04/22

Original Instructions



WARNING

This product can expose you to lead which is known to the State of California to cause cancer and birth defects or other reproductive harm.

For more information go to www.P65Warnings.ca.gov

WARNING

Breathing diesel engine exhaust exposes you to chemicals known to the state of California to cause cancer and birth defects or other reproductive harm.

- **Always start and operate the engine in a well-ventilated area.**
- **If in an enclosed area, vent the exhaust to the outside.**
- **Do not modify or tamper with the exhaust system.**
- **Do not idle the engine except as necessary.**

For more information go to www.P65warnings.ca.gov/diesel.



MANITOU EQUIPMENT AMERICA, LLC WARRANTY

Manitou Equipment America, LLC under the GEHL®, MUSTANG by MANITOU®, MANITOU®, brand warrants new MANITOU Group equipment to the Original Retail Purchaser to be free from defects in material and workmanship for a period of twelve (12) months or Two Thousand Hours (2000 h) from the Warranty Start Date which occur first.

MANITOU Group WARRANTY SERVICE INCLUDES:

Genuine XPRT parts and labor costs required to repair or replace equipment at the selling dealer's business location.

MANITOU Group MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND, EXPRESS OR IMPLIED (INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR PARTICULAR PURPOSE), EXCEPT AS EXPRESSLY STATED IN THIS WARRANTY STATEMENT.

ANY OF THESE LIMITATIONS EXCLUDED BY LOCAL LAW SHALL BE DEEMED DELETED FROM THIS WARRANTY; ALL OTHER TERMS WILL CONTINUE TO APPLY.

SOME STATES DO NOT PERMIT THE EXCLUSION OR LIMITATION OF THESE WARRANTIES AND YOU MAY HAVE GREATER RIGHTS UNDER YOUR STATE LAW.

MANITOU Group WARRANTY DOES NOT INCLUDE:

1. Transportation to selling dealer's business location or, at the option of the Original Retail Purchaser, the cost of a service call.
2. Used equipment.
3. Components covered by their own non- MANITOU Group warranties, such as tires, batteries, trade accessories and engines.
4. Normal maintenance service and expendable, high-wear items.
5. Repairs or adjustments caused by: improper use; failure to follow recommended maintenance procedures; use of unauthorized attachments; accident or other casualty.
6. Liability for incidental or consequential damages of any type, including, but not limited to lost profits or expenses of acquiring replacement equipment.
7. Liability for consequential damages as an unfavorable environment (chemicals, dust, salt, corrosion and erosion...)
8. Repairs completed outside MANITOU Group network and/or by personnel not trained by MANITOU Group.

No agent, employee or representative of MANITOU group has any authority to bind of MANITOU group to any warranty except as specifically set forth herein.

This agreement has been prepared in multiple languages, including but not limited to, English, Spanish, and French (Canada). In the event of any inconsistency, the English version shall apply and be binding upon the parties.

50940703/A1219



1350R, 1500R, 1650R Skid-Steer Loader

Operator's Manual

TABLE OF CONTENTS

Introduction	1
Safety	13
Safety Equipment	39
Indicators and Controls	47
Operation	83
Maintenance	125
Troubleshooting	163
Specifications	187
Index	201

MACHINE INFORMATION

Purchased from	
Date of Purchase	
Loader Model Number	
Loader Serial Number	
Engine Serial Number	



EC DECLARATION OF CONFORMITY

1. Manufacturer: **Manitou Equipment America, LLC**
2. Address: **One Gehl Way
West Bend, WI 53095 U.S.A**

3. Technical Construction File Location: **Manitou Interface and Logistics Europe**

4. Authorized Representative: **Manitou Interface and Logistics Europe**
5. Address: **Rue DesAndains 2
Perwez, 1360
Belgium**

6. **We hereby declare that the machine listed below conforms to EC Directives: 2014/30/EU (EMC), 2006/42/EC (Machinery) and 2000/14/EC (Noise Emission), as amended by 2005/88/EC.**
7. In accordance with EN/ISO Standards: **EN474-1 and EN474-3**
8. Designation: **EARTH-MOVING MACHINERY/LOADERS/COMPACT**
9. Model: **1350R, 1500R, 1650R SKID LOADER**
10. Serial Number:
11. Net Installed Power - KW
12. Sound Power Levels – (measured): - dB(A)
(guaranteed): - dB(A)
13. Directive / Conformity Assessment Procedure / Notified Body:

2000/14/EC	Annex VIII, full Quality Assurance	TÜV Industrie Service GmbH – TÜV SÜD Group Westendst. 199, D-80686 München GERMANY
-------------------	---	---

14. Name:
15. Position/Title:
16. (Signature)
17. Place:
18. Date:

The EC Declaration of Conformity document was provided with the machine if it is manufactured to comply with specific requirements of European Union. Please refer the individual Declaration of Conformity issued with the machine for exact details.

CHAPTER 1

INTRODUCTION

Safety Symbol and Signal Words

Manitou Group, in cooperation with the Society of Automotive Engineers, has adopted this:



Safety Alert Symbol

This symbol identifies potential safety hazards, which, if not properly avoided, could result in injury. When you see this symbol in this manual or on the machine, you are reminded to **BE ALERT!** Your personal safety is involved!

Signal Words



The word “**DANGER**” indicates an imminently hazardous situation, that, if not avoided, will result in serious injury or death.



The word “**WARNING**” indicates a potentially hazardous situation that, if not avoided, could result in serious injury or death.



The word “**CAUTION**” indicates a potentially hazardous situation that, if not avoided, may result in minor or moderate injury.

***Important:** The word “**IMPORTANT**” indicates situations that can result in possible damage to the machine.*

***Note:** The word “**NOTE**” indicates special or particularly useful information.*

Contents and Use of this Manual

This Operator’s Manual provides information about the safe and proper operation and maintenance for the machine. Major points of safe operation and maintenance are detailed in the Safety section of this manual, starting on page 13.

This manual also includes general troubleshooting and specification information about the machine.

Follow the instructions in the Operator's Manual Safety, Operation and Maintenance chapters, concerning accident prevention regulations, safety and occupational regulations, and machine and traffic regulations. Manitou Group is not liable for injury or damage resulting from the failure to follow these regulations.

 **CAUTION** Improper operation, inspection and maintenance of the machine can cause injury or death. Read and understand the contents of this manual **COMPLETELY** and become familiar with the machine before operating it.

It is the owner's or employer's responsibility to fully instruct each operator in the proper and safe operation and maintenance of the machine.

A storage location is provided inside the operator's compartment for storing this Operator's Manual. After using this manual, return it to the storage location.

This manual is considered a permanent part of the machine and should be with the machine at all times. If the machine is resold, include this operator's manual as part of the sale.


Replace this manual promptly if it becomes damaged, lost or stolen.

Some illustrations and photos in this manual may show doors, guards and shields open or removed for informational purposes only. BE SURE all doors, guards and shields are in their proper operating positions BEFORE starting the engine to operate the machine.

Because of ongoing product improvements, information included in this manual may not exactly match the machine. Manitou Group reserves the right to modify and improve products at any time without notice or obligation.

Machine Orientation

“Right” and “left”, as described in this manual, are determined from a position sitting in the operator’s seat and facing forward.



1. Attachment Bracket	7. Lift Arm Support Device	13. Fuel Cap Cover
2. Restraint Bar	8. Auxiliary Couplers	14. Seat Plate (according to ISO 7096)
3. Front Work Lights	9. Roll-Over / Falling Object Protective System (ROPS/ FOPS)	15. Tie-Down
4. Tilt Cylinder	10. Lift Cylinder	16. Rear Work Lights
5. Lift Arm	11. Reflectors	
6. Tires	12. Tail Lights (Position Lights)	

Proper Machine Use

**WARNING**

Improper use of the machine can result in property damage, injury or death.

The machine is designed only for moving earth, coarse gravel or ballast and rubble. Use with approved attachments is also allowed – See “Fields of Application” on page 6. Use in any other way is considered as contrary to the intended use. Compliance with, and strict adherence to, the conditions of operation, service and repair as specified by the manufacturer, also constitute essential elements of the intended use.

The machine was designed and built according to the best available technology and approved safety regulations in the countries where it is sold. It is impossible, however, to completely safeguard against abusive, improper use. The operator must always consider potential safety risks and hazards during operation. Accident prevention regulations, all other generally recognized regulations on safety and occupational medicine, and all road traffic regulations must be observed at all times.

The machine must be maintained in proper operating condition. Any damaged or malfunctioning parts must be repaired or replaced immediately.

Do not make any unauthorized modifications to the machine. Unauthorized modifications made to the machine may relieve the manufacture of liability for any resulting damage or injury.

Service and Registration

When ordering service parts, provide complete information about the part and the quantity required. Also, provide the model and serial numbers of the machine. For your safety and continued proper operation, use only genuine service parts. Record the model and serial numbers in the spaces on this page for quick reference.

Model and Serial Numbers

Loader Model Number

Loader Serial Number



Engine Model Number

Engine Serial Number



Introduction

Legal Notices

Software IP

Any extraction, decompilation, modification, duplication, or distribution of onboard software is strictly prohibited. Manitou shall have no liability for and hereby disclaims all direct and indirect liability for the consequences resulting from the use of any prohibited onboard software. Contact MANITOU for any request to correct or adapt onboard software for the purposes of interoperability.

Data Privacy

Manitou connected machines are equipped with boxes that collect technical data concerning the machines (such as geolocation, operating, and component data). This data, which is organized, processed, and enriched by Manitou's own algorithms and knowledge, constitutes a protected database in accordance with Article L.341-1 of the French Intellectual Property Code.

It is strictly forbidden to access all or part of this database or to use this data (whether or not intentional) without Manitou's express authorization. In the event that Manitou authorizes an individual to access all or part of this database, Manitou, as producer of this database, only grants the user a personal, non-exclusive, and non-transferrable right to use the database, and only via access to a computer platform hosted on a server owned or controlled by Manitou.

In any case, the following activities are strictly prohibited:

- any extraction, reproduction, representation, reuse by making available to the public, diffusion, or transfer, whether permanent or temporary, on any support, and by any means and in any form whatsoever, of all or a qualitatively or quantitatively substantial part of the contents of the database,
- any extraction, reproduction, representation, reuse by making available to the public diffusion, transfer, or repeated and systematic extraction of qualitatively or quantitatively insubstantial parts of the contents of the database when these operations clearly exceed the conditions of normal use of the database by the user of the machine for his or her own needs,
- any use of a means of circumventing technical measures for the protection of databases the source code of the software embedded in the boxes, in accordance with Article L.331-5 of the Intellectual Property Code.

In the event that the above measures are absolutely essential to enable the use of the software, in accordance with its intended purpose, or to obtain the information necessary for interoperability with other independently created software, the user must first contact Manitou, which may, at its sole discretion, take necessary measures or provide access to only the information strictly necessary for interoperability.

Any violation of these prohibitions is likely to constitute an infringement for which Manitou may take legal action.

Fields of Application

Note: Refer to “Payloads/Capacities” on page 190 for specific bucket rated payload capacities.

The attachments determine how the machine is used.

 **WARNING** **Contact CEA Attachments at: <http://www.ceattachments.com/ContactUs.aspx> for information about available attachments approved for use with the machine.**

Contact your CEA Attachments (<http://www.ceattachments.com/ContactUs.aspx>) before using attachments or equipment not approved by Manitou Group. Use of non-approved attachments or unauthorized modifications is prohibited.

Using Attachments

Read all documentation provided with attachments to learn how to safely operate and maintain them.

Do not use the machine for any applications or purposes other than those described in this manual or manuals supplied with attachments. See the following “Fields of Application” table for information about approved attachments and their uses. Contact your dealer before using attachments or equipment not approved by Manitou Group. Use of non-approved attachments or unauthorized modifications is prohibited.

Table 1: Fields of Application

Model	Attachment	Width	Height	Depth	Capacity
1350R	Dirt / Construction Bucket	1372 mm (54 in.)	506 mm (19.9 in.)	808 mm (31.8 in.)	0.28 m ³ (9.8 ft. ³)
		1524 mm (60 in.)	505 mm (19.9 in.)	983 mm (38.7 in.)	0.31 m ³ (11.0 ft. ³)
		1562 mm (61.5 in.)	505 mm (19.9 in.)	983 mm (38.7 in.)	0.32 m ³ (11.3 ft. ³)
	Dirt / Construction Bucket w/Spillguard	1562 mm (61.5 in.)	612 mm (24.1 in.)	808 mm (31.8 in.)	0.40 m ³ (14.1 ft. ³)
	Light Material Bucket	1372 mm (54 in.)	597 mm (23.5 in.)	983 mm (38.7 in.)	0.43 m ³ (15.0 ft. ³)
		1524 mm (60 in.)	597 mm (23.5 in.)	983 mm (38.7 in.)	0.48 m ³ (16.9 ft. ³)
		1676 mm (66 in.)	597 mm (23.5 in.)	1021 mm (40.2 in.)	0.54 m ³ (19.0 ft. ³)
	Pallet Forks	N/A	N/A	1067 mm (42 in.)	N/A
		N/A	N/A	1219 mm (48 in.)	N/A
1500R	Dirt / Construction Bucket	1524 mm (60 in.)	505 mm (19.9 in.)	983 mm (38.7 in.)	0.31 m ³ (11.0 ft. ³)
		1562 mm (61.5 in.)	505 mm (19.9 in.)	983 mm (38.7 in.)	0.32 m ³ (11.3 ft. ³)
	Dirt / Construction Bucket w/Spillguard	1562 mm (61.5 in.)	612 mm (24.1 in.)	808 mm (31.8 in.)	0.40 m ³ (14.1 ft. ³)
	Light Material Bucket	1524 mm (60 in.)	597 mm (23.5 in.)	983 mm (38.7 in.)	0.48 m ³ (16.9 ft. ³)
		1676 mm (66 in.)	597 mm (23.5 in.)	1021 mm (40.2 in.)	0.54 m ³ (19.0 ft. ³)
	Pallet Forks	N/A	N/A	1067 mm (42 in.)	N/A
		N/A	N/A	1219 mm (48 in.)	N/A

Table 1: Fields of Application

Model	Attachment	Width	Height	Depth	Capacity
1650R	Dirt / Construction Bucket	1524 mm (60 in.)	505 mm (19.9 in.)	983 mm (38.7 in.)	0.31 m ³ (11.0 ft. ³)
		1562 mm (61.5 in.)	505 mm (19.9 in.)	983 mm (38.7 in.)	0.32 m ³ (11.3 ft. ³)
		1778 mm (70 in.)	531 mm (20.9 in.)	902 mm (35.5 in.)	0.46 m ³ (16.1 ft. ³)
	Dirt / Construction Bucket w/Spillguard	1562 mm (61.5 in.)	612 mm (24.1 in.)	808 mm (31.8 in.)	0.40 m ³ (14.1 ft. ³)
		1778 mm (70 in.)	660 mm (26.0 in.)	965 mm (38.0 in.)	0.59 m ³ (20.9 ft. ³)
	Light Material Bucket	1676 mm (66 in.)	597 mm (23.5 in.)	1021 mm (40.2 in.)	0.54 m ³ (19.0 ft. ³)
		1778 mm (70 in.)	600 mm (23.6 in.)	1021 mm (40.2 in.)	0.57 m ³ (20.3 ft. ³)
	Grading / Low Profile Bucket	1778 mm (70 in.)	541 mm (21.3 in.)	1062 mm (41.8 in.)	0.55 m ³ (19.4 ft. ³)
	Pallet Forks	N/A	N/A	1067 mm (42 in.)	N/A
		N/A	N/A	1219 mm (48 in.)	N/A

Vibration Information

Compact construction equipment is generally used in harsh environments. This type of usage can expose an operator to uncomfortable levels of vibration. It is useful to understand exposure to vibration levels when operating compact equipment and what can be done to reduce vibration exposure. As a result, equipment operation can be more efficient, productive and safe.

An operator's exposure to vibration occurs in two ways:

- Whole-Body Vibration (WBV).
- Hand-Arm Vibration (HAV).

WBV issues are primarily addressed in this manual, because evaluations have shown that operation of mobile compact construction equipment on worksites typically results in HAV levels less than the allowed exposure limit of 2.5 m/s^2 . Member States of the European Union must comply with the Physical Agents (vibration) Directive, 2002/44/EC.

Effective control of vibration exposure for an operator involves more than just vibration levels on the machine. The worksite, how the machine is used, and proper training all play important roles in reducing vibration exposure.

Vibration exposure results from:

- Worksite conditions.
- How the machine is operated.
- The machine characteristics.

Common causes of high WBV levels:

- Using a machine that is improper for the task.
- Worksite with potholes, ruts and debris.
- Improper operating techniques, such as driving too fast.
- Incorrect adjustment of the seat and controls.
- Other physical activities while using the machine.

Vibration Measurement and Actions

The vibration directive places the responsibility for compliance on employers. Actions that should be followed by employers include:

- Assess the levels of vibration exposure.
- Determine from this assessment if operators will be exposed to vibration levels above the limits stated in the directive.
- Take appropriate actions to reduce operator's exposure to vibration.
- Provide operators with information and training to reduce their exposure to vibration.
- Keep good records and update operations and training on a regular basis.

If the assessment concludes that vibration level exposure is too high, one or more of the following actions may be necessary:

1. Train operators:
 - Perform operations (accelerating, steering, braking, etc.) in a smooth manner.
 - Adjust the controls, mirrors and seat suspension for comfortable operation. Do not make adjustments when the machine is in use.
 - Travel across the smoothest parts of the worksite and avoid ruts and potholes.
2. Choose proper equipment for the job:
 - Use machines with the proper power and capacity.
 - Select machines with good suspension seats.
 - Look for controls that are easy to use.
 - Ensure good visibility from the operator's position.
3. Maintain the worksite:
 - Smooth ruts and fill potholes in traffic areas whenever possible.
 - Clean up debris frequently.
 - Vary traffic patterns to avoid exposure to rough terrain.
4. Maintain equipment. Check that seat suspension and all controls work smoothly and properly.

Vibration Levels

See “Vibration Levels” on page 195 for a table listing typical whole-body vibration levels for the machine.

Fire Extinguisher Location

An installation location for a fire extinguisher is shown in Figure 1.

Important: Installation of a fire extinguisher according to DIN-EN 3 must be performed by an authorized dealer.

Note: A fire extinguisher is neither included as standard equipment nor available as an option from Manitou Group.

Important: Inspect the fire extinguisher at regular intervals as recommended by the fire extinguisher equipment manufacturer.



Figure 1 – Fire Extinguisher Location

Manufacturer Information

Products described in this manual are manufactured by Manitou Group.

Note: Not all models and options described in this manual are available in all areas.

Indicator and Operation Symbols

 Safety Hazard	 Parking Brake	 High-Speed	 Float	 Hydraglide™	 Pre-Heat
 Fasten Seat Belt	 Charging Fault	 Intake Restriction	 Hydraulic Oil Filter Warning	 Hydraulic Oil Temp Warning	 Elevated EGT Temp
 DPF Regen Accept	 DPF Regen Inhibited	 Regen Maintenance	 DPF Regen	 Engine Oil	 Oil Pressure Warning
 Engine Stop	 Engine Start	 Engine Run	 Engine Malfunction Shutdown	 Coolant Temp Warning	 Self-Leveling
 Hitch Lock	 Hitch Unlock	 Windshield Washer	 Rear Washer	 Safety Hazard	 Safety Hazard
 Windshield Wiper	 Rear Wiper	 Fan	 Temperature	 Heater	 Read Operator's Manual
 Horn	 Engine Oil Filter	 Work Light	 Diesel Fuel	 Fuel Filter	 Fuel Level
 Chaincase Oil	 Grease Lubrication Point	 Fast	 Slow	 Hydraulic System	 Beacon
 Lock	 Unlock	 Service Hours	 Lift Point	 Tie-Down	 Engine Power
 Power-A-Tach® Warming Circuit	 High-Flow Forward	 High-Flow Reverse	 Aftertreatment Error		

CHAPTER 2

SAFETY



This safety alert symbol means **ATTENTION! ALWAYS BE ALERT! YOUR SAFETY IS INVOLVED!** This symbol is used throughout this operator's manual and on the decals on the machine.



DANGER

The word "**DANGER**" indicates an imminently hazardous situation, that, if not avoided, will result in serious injury or death.



WARNING

The word "**WARNING**" indicates a potentially hazardous situation that, if not avoided, could result in serious injury or death.



CAUTION

The word "**CAUTION**" indicates a potentially hazardous situation that, if not avoided, may result in minor or moderate injury.

Before operating the machine, read and study the safety information in this manual. Be sure that everyone who operates or works with the machine is familiar with the safety precautions. It is essential to have competent and careful operators, who are not physically or mentally impaired, and are thoroughly trained in the safe operation of the machine and the handling of loads. It is recommended that the operator be capable of obtaining a valid motor vehicle operator's license.

The use of the machine is subject to certain hazards that cannot be eliminated by mechanical means, but only by exercising intelligence, care and common sense. Such hazards include, hillside operation, overloading, instability of the load, poor maintenance and using the machine for a purpose for which it is not intended or designed.

Manitou Group always takes operator's safety into consideration during the design process. Guards and shields are provided, which protect the operator and bystanders from moving parts and other hazards. Operators must be alert, however, because some areas cannot be guarded or shielded without preventing or interfering with proper operation. This Operator's Manual, and decals on the machine, warn of additional hazards, and these warnings should be read and observed closely.

Replace a lost or damaged Operator's Manual. Always store this operator's manual in the storage compartment provided for it.

Do not use the machine for any application or purpose other than those described in this manual, or in manuals supplied with any attachments used with the machine.

Some photographs in this manual may show doors, guards or shields open or removed for illustrative purposes only. Be sure that all doors, guards and shields are in their proper operating positions before starting the engine to operate the machine.

Different applications may require optional safety equipment. Users must evaluate the work-site hazards and equip the machine and the operator as necessary. The information in this manual does not replace any applicable safety rules and laws. Before operating the machine, learn the rules and laws for the local area. Be sure the machine is equipped as required in accordance with these rules/laws.

Remember that some risks to your health may not be immediately apparent. Exhaust gases and noise pollution may not be visible, but these hazards can cause permanent injuries.

Work crew members should observe and monitor terrain and soil conditions at the worksite, along with traffic, weather-related hazards and any above- or below-ground obstacles and hazards.

The operator must ALWAYS be conscious of the working environment. Operator actions, the environmental conditions and the job being performed require the full attention of the operator so safety precautions can be taken.

Mandatory Safety Shutdown Procedure

Before cleaning, adjusting, lubricating or servicing the machine, or leaving it unattended:

1. Move the drive controls to their neutral position.
2. Lower the lift arm and attachment completely. If the lift arm must be left in the raised position, BE SURE to properly engage the lift arm support device. See “Lift Arm Support” on page 44.
3. Move the lift/tilt and auxiliary hydraulic controls to their neutral positions.
4. Move the throttle to the low idle position. Allow the engine to idle for five minutes if the engine was operated under full load.
5. Apply the parking brake and lock out work hydraulics by raising the operator restraint bar.
6. Shut off the engine and remove the key.
7. Before exiting, move the lift/tilt control(s) to verify that the controls do not cause movement of the lift arm and hitch.
8. On machines equipped with the battery disconnect switch, always turn the switch to the “OFF” position when parking the machine inside an enclosure.

Safety Reminders

Before Starting

- To ensure safe operation, replace damaged or worn-out parts with genuine, original service parts. For example, using incorrect fasteners could lead to a condition in which the safety of critical assemblies is dangerously compromised.

- The machine is designed and intended for use only with Manitou attachments or Manitou-approved attachments. To avoid possible personal injury, equipment damage and/or performance problems, use only approved attachments that are within the operating capacity of the machine. Contact your dealer or Manitou Americas for information about attachment approval and compatibility with specific machine models. Manitou Group cannot be responsible if the machine is used with non-approved attachments.
- Read the operator's manual provided with each attachment before using it.
- Optional kits are available through your dealer. Because Manitou cannot anticipate, identify and test all of the attachments owners may want to install on their machines, please contact Manitou Group for information on approval of attachments, and their compatibility with optional kits.
- Remove all trash and debris from the machine each day, especially from within the engine compartment, to minimize the risk of fire.
- Always face the machine and use the hand-holds and steps when getting on and off the machine. Do not jump off the machine.
- Keep the operator's area, steps and hand-holds free of oil, dirt, ice and unsecured objects.
- Never use ether starting aids. Engine pre-heating is used for cold weather starting. Engine preheating can cause ether or other starting fluid to detonate, causing injury or damage.
- Always perform a daily inspection of the machine before using it. Walk around the machine and look for damage, loose or missing parts, leaks, etc. Repair as required before using the machine.
- Wear safety goggles and head protection while operating the machine. The operator must wear protective clothing when appropriate.
- Adjust the seat to allow full actuation of the controls. Never adjust the seat during machine operation. After adjustments, make sure the seat is securely locked in place before using the machine.
- Before working on or with the machine, remove jewelry and tie back long hair. Do not wear loose-fitting garments, such as, scarves, ties, unzipped jackets, etc., which could become caught in the moving parts of the machine and cause injury.
- If a lighting system is installed, check its operation before working in darkness.
- Always keep windows, lights and mirrors clean. Poor visibility can cause accidents.
- Warn all nearby personnel before starting the machine.
- Below-ground hazards also include water mains, tunnels and buried foundations. Know what is underneath the worksite before starting to dig. Contact the North American One-Call Referral System at 8-1-1 in the U.S., or 1-888-258-0808 in the U.S and Canada, for the local "Digger's Hotline" number or the proper local authorities for utility line locations. Accidental contact/rupture with/of any electrically charged conductor or gas line can result in electrocution or an explosion.

- Machine stability is affected by:
 - The load being carried.
 - Height of the load.
 - Machine speed.
 - Abrupt control movements.
 - Driving over uneven terrain.

DISREGARDING ANY OF THESE FACTORS CAN CAUSE THE MACHINE TO TIP, WHICH COULD THROW THE OPERATOR OUT OF THE SEAT OR MACHINE, AND COULD RESULT IN DEATH OR SERIOUS INJURY. Because of this, ALWAYS operate the machine with the seat belt fastened and the restraint bar lowered. Do not exceed the machine's Rated Operating Capacity. See "Payloads/Capacities" on page 190. Carry the load low. Move the controls smoothly and gradually, and operate at speeds appropriate for the conditions.

- Exhaust fumes can kill. Do not operate the machine in an enclosed area unless there is adequate ventilation. Internal combustion engines deplete the oxygen supply within enclosed spaces and may create a serious hazard. Operators should also be aware of any open windows, doors or duct work into which exhaust gases may be carried, exposing others to danger.
- When parking the machine and before leaving the seat, check the restraint bar for proper operation. The restraint bar, when raised, deactivates the lift/tilt controls, auxiliary hydraulics, and applies the parking brake.

Additional Safety Equipment

- Certain operations require use of additional safety equipment. Install additional safety equipment if conditions require – for example, when using a hydraulic breaker, a polycarbonate front window may be required.
- Never attempt to alter or modify the ROPS/FOPS or any other protective structure, by drilling holes, welding or re-locating fasteners. Any serious impact or damage to the system requires a complete integrity re-evaluation, and the replacement of the system may be necessary.
- Laminated glass or polycarbonate protection for the front, side or rear windows may also be required depending upon particular work conditions.
- Contact your dealer for available safety guards if there is any risk of objects striking the operator's cab.

During Operation

- ALWAYS fasten the seat belt securely and properly. Never operate the machine without the seat belt fastened around the operator.
- Only start the engine and only operate the controls while seated in the operator's seat.
- Always keep hands and feet inside the operator's compartment while operating the machine.

- Operator visibility is limited in certain areas; ROPS/FOPS posts, attachments, the lift arm, items in the cab, etc., can obstruct the operator's view and could mask hazards or people in the area around the machine. It is very important the operator is aware of these masked visibility areas before operating the machine, especially on busy worksites.

To reduce the hazards posed by masked visibility areas:

- Use caution when raising or lowering attachments; masked visibility areas can change dramatically when attachments and/or the lift arm is moved.
- Look around the machine before operating. Objects near the machine and close to the ground can be difficult to see from the operator's position.
- Always look in the direction of travel, including reverse. A back-up alarm is not a substitute for looking behind you when operating the machine in reverse.
- Keep bystanders out of, and away from, the work area.
- Keep the lift arm as low as possible while traveling.
- Additional equipment may be installed on the machine to serve as visual aids (e.g., mirrors, CCTV systems) that provide visibility to areas masked by the machine structure. Keep all machine components that affect visibility in a clean, properly adjusted state and in good working order.
- Use a signal person if you cannot see the entire work area clearly, in high traffic areas, and whenever the operator's view is not clear.
- Stay alert for people moving through the work area. When loading a truck, the operator should always know where the driver is.
- Be aware of overhead obstacles. Any object near the lift arm could represent a potential hazard, or cause the operator to react suddenly and cause an accident. Use a spotter or signal person when working near bridges, phone lines, worksite scaffolds, or other obstructions.
- Check indicators and displays for normal conditions after starting the engine. Check the operation of the controls. Listen for unusual sounds and remain alert for other potentially hazardous conditions.
- Control the machine cautiously and gradually until fully familiar with all the controls and handling.
- New operators must learn to operate the machine in an open area away from bystanders. Practice with the controls until the machine can be operated safely and efficiently.
- Stop the engine and place the controls in the lock-out position before mounting attachments. Check that attachments are securely fastened and locked — with the hitch locking pins passing all the way through the attachment — on the lift arm before working.
- Be aware that attachments affect the handling and balance of the machine. Adjust the operation of the machine as necessary when using attachments.
- Do not overload the machine. See "Payloads/Capacities" on page 190 for the load limits.
- Do not raise or drop a loaded bucket or attachment suddenly. Abrupt movements under load can cause serious instability.

- Never activate the float function with the bucket or attachment loaded or raised, because this will cause the lift arm to drop.
- Do not raise the restraint bar while traveling. Raising the restraint bar abruptly applies the parking brake, which can cause the machine to tip forward.
- Do not drive into materials at high speeds to avoid being thrown forward and injured.
- Do not use the machine to lift or transport people. Never carry riders. Do not allow others to ride on the machine or attachments.
- Use extra care on loose ground. Working heavy loads over loose, soft ground or uneven terrain can cause dangerous side-load conditions and possible tip-over and injury. Traveling with a suspended load or an unbalanced load can also be hazardous.
- Stay away from the edges of loading docks, ramps, ditches, excavations, retaining walls, overhangs, trenches and other weak support surfaces.
- When near an excavation or ditch, be sure the surrounding ground has adequate strength to support the combined weight of the machine and load.
- When operating on inclines or ramps, always travel with the heavier end of the machine toward the top of the incline for additional stability.
- Never travel over obstacles or slopes that will cause the machine to tilt severely. Travel around any slope or obstacle that would cause the machine to tilt greater than 10°.
- Avoid steep slopes. Do not make sharp turns on slopes. Drive up and down slopes, not across them. Drive slowly on slopes. Keep the heavy end of the machine pointed uphill.
- Avoid sharp turns and high speeds while carrying loads, especially on slopes. The stability of the machine is reduced during sharp turns, and the load may shift, greatly increasing the possibility of an overturn.
- Do not turn the machine when lifting loads. As loads are lifted, stability decreases, which can increase the possibility of a rollover.
- Avoid slowing suddenly while carrying a load. Sudden slowing can cause the load to fall off the attachment, or cause the machine to tip over.
- Do not turn off the ignition keyswitch while traveling. Turning off the ignition will cause sudden braking, which may cause the machine to tip.
- Reduce speed before shifting from high to low travel speed. Down-shifting from high- to low-speed drive while traveling at high speed may cause the machine to tip and can cause injury, loss of control and damage to the machine.
- If the machine becomes unstable and starts to tip, keep the seat belt fastened, hold on firmly and brace yourself. Keep hands and feet inside the operator's compartment. Lean away from the point of impact and stay with the machine. If tipping occurs, DO NOT jump from the machine. The machine is equipped with rollover protection, which can only protect the operator while in the operator's seat. Trying to escape from a tipping machine can result in death or serious personal injury.
- If temperatures are changing, be cautious of dark and wet patches when working or traveling over frozen ground.

- In cold weather, avoid sudden travel movements and stay away from even slight slopes. The machine can slide sideways on icy slopes.
- Snow accumulation can hide potential hazards. Use care while operating and while using the machine to clear snow.
- Never allow anyone under a raised lift arm. Lowering the lift arm or a falling load can result in death or serious personal injury.
- Slow down the work cycle and use slower travel speeds in congested or populated areas. Use commonly understood signals so other members of the work crew can warn the operator to slow or halt work in a potentially hazardous situation.
- Do not use the machine in an environment where the hot muffler could present a fire hazard, such as hay or straw storage facilities.
- Exposed hydraulic hoses could react with explosive force if struck by falling or overhead items. NEVER allow hoses to be hit, bent or interfered with during operation. Extra guards may be required. Replace any damaged hoses immediately.
- If the machine becomes damaged or malfunctions, stop the machine immediately and lock and tag it. Repair the damage or malfunction before using the machine again.
- NEVER start the engine if there is any indication that maintenance or service work is in progress, or if a warning tag is attached to the controls.
- Do not place limbs near moving parts. Severing of body parts can result.
- If unable to exit out the front of the cab, remove the rear window by pulling the emergency rear window release triangle until the window seal is pulled out of the window frame, then push the window out of the frame.



Applications with Load-Handling Devices

- Specific procedures are required, when using load-handling devices (e.g., slings, chains, etc.) for transporting and placing loads. For example, assistance from other people is needed when lifting and lowering pipes, culverts or containers:
 - The machine may only be used with load-handling devices if the necessary safety devices are in place and functional.
 - The load must be secured to prevent it from moving, slipping or falling.
 - Persons guiding the load must stay in visual contact with the operator.
 - The operator must guide the load to the ground as soon as possible and avoid any rotating or swinging movements.
 - The machine may be moved with a raised load only if the path of the machine is level.
 - Persons attaching or securing loads may only approach the machine from the side, after the operator has given permission. The operator may only give permission after the machine and the attachment are stationary.

- Do NOT use any lifting attachments (slings, chains) that are damaged or of inadequate rated capacity.

Parking the Machine

- Never leave the operator's seat without lowering the lift arm/attachment flat on the ground or engaging the lift arm support device(s), and then stopping the engine and removing the ignition key.
- When shutting the machine down for the day, plan ahead so the machine will be on a firm, level surface away from traffic and away from high walls, cliff edges and any area of potential water accumulation or runoff. Lower the attachment and lift arm to the ground. There should be no possibility of unintended or accidental machine movement.
- If the machine must be parked on a slope, park across the slope and chock the wheels to prevent movement.
- To avoid collisions when parking on streets, use barriers, caution signs, lights, etc., so the machine can be easily seen at night.
- After the machine has been parked properly, shut the machine down according to the "Mandatory Safety Shutdown Procedure" on page 14.

Electrical Energy

- ALWAYS maintain a safe distance from electric power lines and avoid contact with any electrically charged conductor or gas line. Accidental contact or rupture can result in electrocution or an explosion. Contact the North American One-Call Referral System at 8-1-1 in the U.S., or 1-888-258-0808 in the U.S and Canada, for the local "Digger's Hotline" number or the proper local authorities for utility line locations BEFORE starting to dig!
- Before working near power lines (either above ground or buried cable-type), always contact the power utility and establish a safety plan with them.
- Depending upon the voltage in the power line and atmospheric conditions, strong electric shocks can occur if the bucket is closer than 3 m (10 ft.) from the power line. Higher voltages and rainy weather can further increase the safe operating distance.
- If the machine comes into contact with a live wire:
 - Do not leave the machine.
 - If possible, drive the machine out of the danger area.
 - Warn others not to approach or touch the machine.
 - Have the live wire de-energized.
 - Do not leave the machine until the wire has been safely de-energized.
- Work on the machine's electrical system must be performed only by trained technicians.
- Inspect and check the machine's electrical equipment at regular intervals. Problems found, such as loose connections or scorched cables, must be repaired before using the machine.

- Only use proper, original equipment fuses/circuit breakers with the specified current rating. Turn off the machine immediately if there is any indication of a problem with the electrical system.

Maintenance

- Only trained and authorized personnel, with a full awareness of safe procedures, should be allowed to operate or perform maintenance or service on the machine.
- Use warning tag/control lockout procedures during service. Alert others that service or maintenance is in progress by tagging the operator's controls — and other machine areas if required — with a warning notice.
- Never attempt to bypass the ignition keyswitch to start the engine. Use only the jump-starting procedure described in this manual. See “Jump-starting” on page 92.
- Never use your hands to search for hydraulic fluid leaks. Instead, use a piece of paper or cardboard. Escaping fluid under pressure can be invisible and can penetrate the skin and cause serious injury. If any fluid is injected into your skin, see a doctor at once. Injected fluid must be surgically removed by a doctor or gangrene may result.
- Do not attempt to loosen or disconnect any hydraulic lines, hoses, fittings, covers or caps without first relieving hydraulic circuit pressure. Relieve hydraulic pressure by performing the “Mandatory Safety Shutdown Procedure” on page 16 and slowly loosening the hydraulic reservoir filler cap. Be careful not to touch any hydraulic components that have been in recent operation. Failure to heed this warning could result in severe burns.
- Do not attempt to remove the radiator cap after the engine has reached operating temperature or if it is overheated. At operating temperatures, engine coolant is extremely hot and under pressure. Always wait for the engine to cool before attempting to relieve pressure and remove the radiator cap. Failure to heed this warning could result in severe burns.
- Do not work on hot engines, cooling systems or hydraulic systems. Wait for the engine to cool. When engine lube oil, gearbox lubricant or other fluids require changing, wait for fluid temperatures to decrease to a moderate level before removing drain plugs.

Note: *Temperatures below 49°C (120°F) will reduce the chances of scalding exposed skin while allowing the fluid to drain quickly and completely. Do not let the fluid fully cool, because drain time will be substantially increased.*

- Do not run the engine if repairs are being performed alone. There should always be at least 2 people present if the engine must be run during service. Both persons must maintain visual contact with each other. Keep a safe distance away from all rotating and moving parts.
- Always wear safety glasses with side shields when striking metal against metal. In addition, it is recommended that a softer (chip-resistant) material be used to cushion the blow. Flying metal debris can cause serious injury to the eyes or other parts of the body.
- If the lift arm is raised, do not allow anyone underneath it and/or do not exit the machine unless the lift arm support is properly applied. See “Lift Arm Support” on

page 44. Disconnecting or loosening any hydraulic line, hose, fitting or component, parts failure, and venting hydraulic pressure all can cause the lift arm to drop.

- Use solid support blocking. Never rely on jacks or other inadequate supports when maintenance work is being done. Never work under any equipment supported only by jacks.
- Do not use the lift or tilt hydraulics to lift or support the machine for maintenance or service.
- At least 2 people must be present if the engine must be run during service. Both persons must maintain visual contact with each other. Keep a safe distance away from all rotating and moving parts.
- Safety-critical parts must be periodically replaced. Replace the following potentially flammable components as soon as they begin to show signs of deterioration:
 - Fuel system flexible hoses and the fuel filler cap.
 - Hydraulic system hoses, especially the pump outlet lines. Replace hydraulic hoses every 6 years from the date of manufacture, even if they do not appear damaged. The date of manufacture (month or quarter and year) is indicated on the hydraulic hoses. See “Hydraulic Hose Maintenance” on page 150.
- Do not modify the ROPS/FOPS unless instructed to do so in installation instructions. Modifications such as welding, drilling, cutting or relocating fasteners, can weaken the structure and reduce the protection it provides. A damaged ROPS/FOPS cannot be repaired – it must be replaced.
- Unauthorized modifications to the machine can cause injury or death. Never make unauthorized modifications to any part of the machine. Any modification made without authorization from Manitou Group could create a safety hazard, for which the machine owner would be responsible.
- Keep mounting brackets and hose and cable routing straps tight. Hose routings should have gradual bends.
- After cleaning the machine, examine all fuel, lubricant and hydraulic oil lines for leaks, chafe marks and damage. Tighten any loose connections and repair or replace parts as necessary.
- Always use the proper tools while working on the machine. Inappropriate tools could break or slip, causing injury, or they may not adequately perform intended functions.
- Hydraulic line and hoses must be routed and fitted properly. Make sure no connections are interchanged.
- Do not use the machine when maintenance is scheduled to be performed. Postponing maintenance can result in a serious reduction of the service life of the machine, more serious and costly equipment failures, and contribute to unsafe operating conditions.
- When handling oil, grease and other chemical substances, follow the product-related safety requirements Material Safety Data Sheet (MSDS) carefully to prevent burning or scalding.
- If the Information Center Electronic Display is broken, avoid contact with any leaking LCD fluid. Wipe any LCD fluid off of skin with a cloth and wash the area with mild soap and water. Thoroughly rinse LCD fluid from eyes with clean water for several

minutes and seek medical assistance. If LCD fluid is swallowed, rinse mouth thoroughly with clean water, then drink a substantial volume of water and induce vomiting and seek medical assistance.

- Keep fuel and other fluid reservoir caps tight. Do not start the engine until caps have been secured.

Battery Hazards

- Sparks and open flames can set off explosive battery gas from incidental contact or static discharge. Turn off the engine and all switches when working on batteries. Keep battery terminals tight. Contact between a loose cable clamp and a terminal post can create an explosive spark.
- Before performing electrical service or electrical welding on the machine, disconnect the negative battery cable from the negative battery terminal.
- When disconnecting cables from the battery terminals, remove the cable connected to the negative terminal first. When installing a battery, connect the positive terminal cable first.
- When using jumper cables, connect the positive cable first. The final negative cable connection, at the metal frame of the machine being charged or jump-started, should be as far away from the battery as possible. When removing the jumper cables, disconnect the negative cable from the metal frame first.
- When jump-starting from another machine, do not allow the machines to touch. Wear safety glasses or goggles while battery connections are made.
- Do not jump-start the machine if it has a frozen battery because battery could explode. Thaw a frozen battery before charging it or attaching jumper cables.
- Flush eyes with water for 10-15 minutes if battery acid is splashed in the face. Anyone swallowing battery acid must have immediate medical aid.
- On machines equipped with the battery disconnect switch, always turn the switch to the “OFF” position when parking the machine inside an enclosure.

Fire Hazards

- The machine has several components that operate at high temperature under normal operating conditions, primarily the engine and exhaust systems. Also, the electrical system, if not properly maintained or if damaged, can arc or produce sparks. These conditions make it extremely important to avoid circumstances where explosive dust or gases can be ignited by arcs, sparks or heat.
- It is recommended that a 2.27 kg (5 lb.) or larger, multi-purpose “A/B/C” fire extinguisher be mounted in the operator’s compartment. Check the fire extinguisher periodically and be sure that work crew members are trained in its use.
- Add fuel, oil, antifreeze and hydraulic fluid to the machine only in a well ventilated area. The machine must be parked with controls, lights and switches turned off. The engine must be turned off before refueling or performing service checks.
- Do not smoke while filling the fuel tank, while working on the fuel or hydraulic systems, or while working around the battery.

- Static electricity can produce dangerous sparks at the fuel-filling nozzle. Do not wear polyester, or polyester-blend clothing while fueling. Before fueling, touch the metal surface of the machine away from the fuel fill to dissipate any built-up static electricity. Do not re-enter the machine but stay near the fuel filling point during refueling to minimize the build-up of static electricity. Do not use cell phones while fueling. Make sure the static line is connected from the machine to the fuel truck before fueling begins.
- Ultra-Low Sulfur Diesel (ULSD) poses a greater static ignition hazard than earlier diesel formulations. Avoid death or serious injury from fire or explosion; consult with your fuel or fuel system supplier to ensure the entire fuel delivery system is in compliance with fueling standards for proper grounding and bonding practices.
- Always immediately replace the fuel filler cap after refueling.
- Take care to avoid spilling combustible fluids, such as oil or fuel, on a hot engine. Oil from leaks can ignite on hot components. Repair any damaged or leaking components before using the machine.

Crystalline Silica Exposure



Exposure to crystalline silica (found in sand, soil and rocks) has been associated with silicosis, a debilitating and often fatal lung disease. Comply with all applicable rules and regulations for the workplace. Wear approved respiratory protection or use water spray or other means if there is no other way to control the dust.

A Silica rule “29 CFR 1929.1153” by the U.S. Occupational Safety and Health (OSHA) indicates a significant risk of chronic silicosis for workers exposed to inhaled crystalline silica over a working lifetime. Refer to the rule for more information regarding exposure limits and hazard prevention.

Transporting the Machine

Obey federal, state and local over-the-road regulations. Check restrictions regarding weight, height, width and length of a load. The hauling vehicle, trailer and load must all be in compliance with applicable regulations. See “Loading and Transporting the Machine on a Transport Vehicle” on page 115.

Lifting the Machine with a Crane

Only lift the machine according to the following guidelines:

- Do not lift the machine without an approved lift kit installed. Contact your dealer for available lift kits for the machine.
- The crane and rigging equipment must have sufficient capacity. See “Weights” on page 189.
- Secure the machine against unintentional movement. Use taglines as needed.
- Do not lift the machine with persons on or in the machine.
- Any person guiding the crane operator must be within sight or sound of the crane operator.

- Lift the machine only with the standard bucket installed, with the bucket empty and in the transport position.
- Persons must stay clear of, and out from under, the machine when it is lifted.
- Fasten the rigging equipment so the machine is level when it is lifted.
- Attach the rigging equipment only at the lift points on the properly attached lift kit. Lift the machine according to “Lifting the Machine Using a Crane or Hoist” on page 117.

Loading and Transporting the Machine

- Load and transport the machine according to “Loading and Transporting the Machine on a Transport Vehicle” on page 115.
- The transport vehicle must support the weight, and accommodate the height, width and length of the machine. See “Dimensions” on page 196 and see “Weights” on page 189.
- Remove any dirt, snow or ice from the loading ramps and transport platform, to prevent slipping.
- Secure the machine to the transport vehicle according to “Loading and Transporting the Machine on a Transport Vehicle” on page 115 to prevent unintentional movement.

Safety Decals

The machine has decals that provide safety information and precautions around the machine. These decals must be kept legible. If missing or illegible, they must be replaced promptly. Replacements can be obtained from your dealer. If there is a decal on a part that is replaced, be sure that the decal is applied to the replacement part.

New Decal Application

Surfaces must be free of dirt, dust, grease and foreign material before applying the decal. Remove the smaller portion of the decal backing paper and apply the exposed adhesive to the clean surface, maintaining proper position and alignment. Peel the rest of the backing paper and apply hand pressure to smooth out the decal surface. Refer to the following pages for proper decal location.

ANSI-Style Safety and Information Decals





Figure 2 – ANSI-Style Safety and Information Decal Locations

Note: Refer to Figure 2 on page 26 for decal locations.

A




Located on the front panel below the door, behind the attachment hitch.

DANGER: AVOID INJURY OR DEATH

- Keep out from under work tool, unless lift arm is supported.
- No riders! Never use work tool as work platform.

B



Located on the inside of the right lift arm pillar.

WARNING: AVOID INJURY OR DEATH

- Keep safety devices working.
- Jump start per Operator's Manual procedure.
- Clean debris from engine compartment daily to avoid fire. Keep fire extinguisher nearby.
- Do not use hands to find hydraulic leaks. Escaping oil under pressure can be invisible and penetrate skin.
- Allow radiator to cool before removing cap. Loosen cap slowly to avoid burns.
- Keep guards, screens and windows in place.
- Do not smoke while fueling or servicing machine.

C



Located next to the fuel filler neck.

USE PROPER DIESEL FUEL ONLY!


D



Located on the bottom of the side panels behind the rear wheels (both sides), and on the bottom outside corners of the front panel (both sides).

Tie-down point. Only use tie-down points indicated on machine when transporting machine.

E



Located near the fuel filler neck.

IMPORTANT: DIESEL FUEL REQUIREMENTS

- Use only Ultra-Low Sulfur Diesel (ULSD) fuel.
- Use of diesel fuel with more than 15 PPM of sulfur will damage the engine.

Note: Refer to Figure 2 on page 26 for decal locations.

F



Located on the side of the ROPS/FOPS.

WARNING: Crush Hazard

- Be sure lock mechanism is securely engaged before working under ROPS/FOPS. Read instructions for use in Operator's Manual.


G



USE PROPER HYDRAULIC FLUID ONLY!

Located near the hydraulic fluid reservoir filler neck.

H



Located inside the engine compartment.

WARNING: ROTATING FAN

- Keep hands out or stop engine.

I



Located on the left door pillar, facing the operator.


DANGER: AVOID INJURY OR DEATH

- Keep hands, feet and body inside cab when operating
- Keep out from under lift arm unless lift arm is supported
- Always follow "Mandatory Safety Shutdown Procedure"

WARNING: AVOID OVERTURN

- Carry load low; Wear seat belt
- Do not exceed Rated Operating Load.
- Avoid steep slopes and high speed turns
- Travel up and down slopes with heavy end uphill

J




Located inside the engine compartment.

IMPORTANT

- Do not use ether or other starting fluids to start this engine — warranty may be voided.

Note: Refer to Figure 2 on page 26 for decal locations.

K




Located inside the engine compartment.

WARNING: HOT SURFACE

- Do not touch hot engine or hydraulic system parts.

L




Located on the right door pillar, facing the operator.

WARNING: AVOID INJURY OR DEATH

Always follow "Mandatory Safety Shutdown Procedure."

- 1) Lower equipment to ground.
- 2) Reduce throttle, stop engine.
- 3) Apply brake; remove key.
- 4) Check safety interlocks.

M



Located on the left door pillar, facing the operator.

WARNING: AVOID INJURY OR DEATH

- Maintain 3-point contact during entry and exit
- Inspect work area; avoid all hazards
- Look in the direction of travel; Keep children and bystanders away
- Start and operate machine only from the operator's seat
- Never carry riders; Do not lift personnel in bucket.
- Operate only in well-ventilated area
- Keep away from electric power lines, avoid contact
- Do not wear loose clothing while operating or servicing machine
- Wear any needed Personal Protective Equipment

Note: Refer to Figure 2 on page 26 for decal locations.

N



Located on the bottom of the ROPS/FOPS operator enclosure.

WARNING: Crush Hazard

- Be sure lock mechanism is securely engaged before working under ROPS/FOPS.
- Read instructions for use in Operator's Manual.

O




Located behind the operator's seat above rear window

WARNING: AVOID INJURY OR DEATH

- Read Operator's Manual and all safety signs before using machine.
- The owner is responsible to ensure all users are instructed on safe use and maintenance.
- Check machine before operating; Service per Operator's Manual.
- Contact dealer (or manufacturer) for information and service parts.

P



Service Decal – Located on the inside of the left lift arm pillar.

Q





Located on the front of the lift arm cross-member.

WARNING: AVOID INJURY OR DEATH

- Before operating with attachment, check engagement of loader attachment bracket locking pin to the attachment.


Note: Refer to Figure 2 on page 26 for decal locations.

(R)



Located on attachment bracket (power hitch only)

(S)



Located on attachment bracket (manual hitch only)

(T)




Located on the left lift arm near the lift arm support.

DANGER

- Hose removal or component failure can cause lift arm to drop. Always use lift arm support device when leaving lift arm raised for service.

ISO-Style (Used Internationally) Safety and Information Decals



**Figure 3 – ISO-Style (Used Internationally)
Safety and Information Decal Locations**

Note: Refer to Figure 2 on page 26 for decal locations.

(A)

A



B



Located on the front panel below the door, behind the attachment hitch.

DANGER: AVOID INJURY OR DEATH

A) Keep out from under work tool, unless lift arm is supported.

B) No riders! Never use work tool as work platform.

(B)

A



B



C



D



E



F



Located on the inside of the right lift arm pillar.

WARNING: AVOID INJURY OR DEATH

A) Safety alert / Keep safety devices in place and in working order.

B) Fire hazard / Do not smoke while fueling or servicing the machine. Clean debris from the engine compartment to avoid fires. Keep fire extinguisher nearby.

C) Run-over hazard / Jump-start the machine only according to the operator's manual. See "Jump-starting" on page 92.

D) Oil injection hazard / Do not use hands to find hydraulic leaks. Escaping oil under pressure can penetrate skin. Use a piece of cardboard to find leaks.

E) Burn hazard / Allow radiator to cool before removing cap. Loosen cap slowly to avoid burns.

F) Suffocation hazard / Operate only in a well-ventilated area.

(C)



Located next to the fuel filler neck.

USE PROPER DIESEL FUEL ONLY!


(D)



Located on the bottom of the side panels behind the rear wheels (both sides), and on the bottom outside corners of the front panel (both sides).

Tie-down point. Only use tie-down points indicated on machine when transporting machine.


(E)



Located on the interior surface of the rear window in the lower left corner. Designates emergency egress location.

Note: Refer to Figure 2 on page 26 for decal locations.

F



Located on the side of the ROPS/FOPS.

WARNING: Crush Hazard

- Be sure lock mechanism is securely engaged before working under ROPS/FOPS. Read instructions for use in Operator's Manual.


G



USE PROPER HYDRAULIC FLUID ONLY!

Located near the hydraulic fluid reservoir filler neck.

H



Located inside the engine compartment.

WARNING: ROTATING FAN

- Keep hands out or stop engine.

I

A



B



C



D



Located on the left door pillar, facing the operator.

DANGER: AVOID INJURY OR DEATH

WARNING: AVOID OVERTURN

- Forward tip hazard: Carry load low, do not exceed Rated Operating Load.
- Fasten seat belt.
- Side tip hazard: Avoid steep slopes and high-speed turns. Travel up and down slopes with heavy end uphill.
- Crush hazard: Keep out from under lift arm unless lift arm is supported. Keep hands, feet and body inside cab when operating.

Note: Refer to Figure 2 on page 26 for decal locations.

J


Located on the right door pillar, facing the operator.

DANGER: AVOID INJURY OR DEATH

A  **A) Crush hazard: Keep out from under lift arm unless lift arm is supported.**

B  **B) Crush hazard: Hose removal or component failure can cause lift arm to drop. Always use lift arm support device when leaving lift arm raised for service.**

C  **C) Side tip hazard: Avoid steep slopes and high-speed turns. Travel up and down slopes with heavy end uphill.**

D  **D) Crush hazard: Keep hands, feet and body inside cab when operating.**

K

Located inside the engine compartment.

WARNING: HOT SURFACE

- Do not touch hot engine or hydraulic system parts.

L

Located on the left door pillar, facing the operator.

WARNING: AVOID INJURY OR DEATH

Always follow “Mandatory Safety Shutdown Procedure.”


- 1) Lower equipment to ground.
- 2) Reduce throttle, stop engine.
- 3) Apply brake; remove key.
- 4) Check safety interlocks.

Note: Refer to Figure 2 on page 26 for decal locations.

(M)

Located on the left door pillar, facing the operator.

SAFETY ALERT



A

B

C

D

E

F

- A) Check machine before operation according to *Operational Checks* starting on page 83. Contact dealer (or manufacturer) for information and service parts.
- B) Maintain 3-point contact during entry and exit.
- C) Inspect work area. Avoid all hazards. Look in direction of travel. Keep children and bystanders away.
- D) Start and operate machine only from the operator's position with the seatbelt fastened.
- E) Keep away from power lines; avoid contact.
- F) Wear any needed Personal Protective Equipment. Do not wear loose clothing while operating or servicing machine.

(N)

Located on the bottom of the ROPS/FOPS operator enclosure.


WARNING: Crush Hazard



- Be sure lock mechanism is securely engaged before working under ROPS/FOPS.
- Read instructions for use in Operator's Manual.

(O)


Located behind the operator's seat above rear window



WARNING: AVOID INJURY OR DEATH

- Read Operator's Manual and all safety signs before using machine.
- The owner is responsible to ensure all users are instructed on safe use and maintenance.
- Check machine before operating; Service per Operator's Manual.
- Contact dealer (or manufacturer) for information and service parts.


(P)



Service Decal – Located on the inside of the left lift arm pillar.

Note: Refer to Figure 2 on page 26 for decal locations.

Q





Located on the front of the lift arm cross-member.

WARNING: AVOID INJURY OR DEATH


- Before operating with attachment, check engagement of loader attachment bracket locking pin to the attachment.

R




Located on attachment bracket (power hitch only)

S



Located on attachment bracket (manual hitch only)

T




Located on the left lift arm near the lift arm support.

DANGER

- Hose removal or component failure can cause lift arm to drop. Always use lift arm support device when leaving lift arm raised for service.

Product and Component Plate Locations



Product and Component Plates

1. Operator protective system plate: with, e.g., model, certification and operator protective system serial number.
2. Seat plate according to ISO 7096
3. Product plate: with Product Identification Number and, e.g., model/type designation.
4. Engine plate: with, e.g., type designation, product and serial numbers.
5. Component plate hydrostatic pump: with, e.g., product and serial numbers.
6. Component plate drive motor: with, e.g., product and serial numbers.

CHAPTER 3

SAFETY EQUIPMENT

! WARNING Become familiar with all safety devices on the machine before starting. Know how to stop the machine before starting it. The machine is designed and intended to be used only with Manitou Group-approved attachments or accessories. Manitou Group cannot be responsible for operator safety if the machine is used with unapproved attachments.

Guards and Shields

Guards and shields are provided on the machine, wherever possible without effecting machine operation, to protect against potential hazards. In many places, safety decals are also provided to warn of potential hazards and/or to display special operating procedures.

! WARNING Read and thoroughly understand all safety decals before operating the machine. Do not operate the machine unless all factory-installed guards and shields are properly installed and secured in place.

Operator's Position

Operator's Seat

! WARNING Never adjust the seat during machine operation. Adjust the seat only when the machine is stopped and the restraint bar is in the raised position. After adjustments, make sure the seat is securely locked in place before using the machine.

Horizontal adjustment: The seat is mounted on rails to allow forward and back horizontal position adjustment.

Use lever (A, Figure 4) to move the seat forward or back as desired. Release handle (A) when the seat is in the desired position. Make sure the seat is locked in position after adjusting.



Figure 4 – Operator's Seat Horizontal Adjustment

Seat suspension

Seat suspension can be adjusted as necessary to compensate for the driver's weight and preferred seat suspension stiffness.

Mechanical suspension: While sitting in the operator's seat, rotate knob (Z, Figure 5) as necessary to adjust seat suspension so weight indicator (X) is set to the approximate weight of the operator.

Air Suspension (optional): Use knob (V) to adjust air suspension as desired.




Figure 5 – Operator's Seat Suspension Adjustment

Seat Belt

WARNING Always fasten the seat belt

before operating the machine and keep it fastened during machine operation.

Repair or replace any damaged seat belt and clasp parts before operating the machine. Do not operate the machine if the seat belt is not fastened and working properly. After an accident, the seat belt strap is stretched and must be replaced with a new strap installed by an authorized dealer.

Important: Keep seat belt(s) clean. Use only soap and water to wash seat belt(s); cleaning solvents can damage the seat belt(s).

Fastening/Unfastening the Seat Belt

Remove hard, edged or fragile objects from your pockets or clothes that might lie between the seat belt and your body.

Fasten the seat belt around your hips and waist and insert tongue (F, Figure 6) into clasp (G) until it clicks securely in place. Slack in the seat belt should automatically retract into seat belt spool (H).

Make sure the seat belt is not twisted when it is fastened, and that it is fastened over the hips and not the stomach.

Unfasten the seat belt by pressing button (I).



Figure 6 – Seat Belt / Upper Torso Restraint

WARNING If the seat belt spool does not retract the slack in the seat belt, have it serviced immediately. Repair or replace any damaged seat belt and lock parts before operating the machine.

Upper Torso Restraint (Option)



WARNING

Always wear the upper-torso restraint (J, Figure 6) when operating in high speed.

The seat belt should always be fastened during operation.

Important: *Inspect the seat belt(s) for damage before use, and replace if damaged. Keep seat belt(s) clean. Use only soap and water to wash seat belt(s). Cleaning solvents can cause damage to seat belt(s).*

Operator Restraint Bar

Lower operator restraint bar (C, Figure 7) after entering the operator's compartment and sitting in the seat. The restraint bar is securely anchored to the ROPS/FOPS. The operator must be seated with the restraint bar in its lowered position to start or operate the machine.



Figure 7 – Operator Restraint Bar

The position of the restraint bar in the lowered position can be adjusted. To adjust:

Loosen jam nut (D, Figure 8), and rotate rubber stop (E) in or out to the desired position. Tighten jam nut (D) to lock rubber stop (E) in position.

Important: *Make sure rubber stops (E) are adjusted evenly.*




Figure 8 – Restraint Bar Lowered Position Adjustment



WARNING

Never electrically or mechanically defeat the operator restraint bar or seat switch.

Safety Interlock System (Hydraloc™)



WARNING

NEVER attempt to bypass or defeat the safety interlock system. Serious personal injury or death could result.

The Hydraloc™ safety interlock system provides for operator safety. The interlock system:

- Prevents the engine from starting unless the operator is sitting in the operator's seat with the restraint bar lowered.
- Disables the lift arm, auxiliary hydraulics, attachment tilt and wheel drive hydraulics if the restraint bar is raised, the ignition keyswitch is turned off or the operator's seat is not occupied.

***Note:** Once started, the auxiliary hydraulic circuit will stay detented in the "on" position for continuous operation with the restraint bar raised and operator out of the seat. See "Auxiliary Hydraulic System" on page 80.*

Safety Interlock System Test

Each time before using the machine, check the safety interlock system daily for proper operation:

Seat Switch Test

With the engine off and the restraint bar lowered, unfasten the seat belt, and lift your weight off the seat. Try to start the engine. If the engine starts, turn off the engine, troubleshoot and correct the problem. Contact your dealer if necessary.


Restraint Bar Test

With the engine running, raise the restraint bar. Test each of the controls. The lift arm, hitch and drive should move only slightly. If there is any significant movement, troubleshoot and correct the problem immediately. Contact your dealer if necessary.

Parking Brake

The machine is equipped with a spring-applied, hydraulically-released parking brake. The parking brake is automatically applied when the restraint bar is lifted, the operator's seat is not occupied, or the engine is shut off. The brake can also be applied manually by pressing button (K, Figure 9) on the control keypad on the right door pillar.

Button (K) is illuminated when the ignition keyswitch is in the ON/RUN position and the parking brake is applied.



ROPS/FOPS


The ROPS/FOPS (Roll-Over/Falling Object Protective Structure) is designed to protect the operator from falling objects and during a tip-over accident, if the operator is secured inside the operator's compartment by the seat belt and restraint bar.

⚠ WARNING Never operate the machine with the ROPS/FOPS raised or removed.

Rear Window Emergency Exit

To use the emergency exit function, pull on yellow warning tag (M, Figure 10) at the top of the window and remove the seal. Push or kick out the window to allow exit from the machine.

to reinstall the window, see your local automotive glass specialist.



Lift Arm Support

The lift arm support prevents the raised lift arm from lowering unexpectedly. The lift arm support must be applied whenever the lift arm is left in the raised position.

⚠ WARNING A falling lift arm could result in severe injury or death. Never allow anyone under a raised lift arm without the lift arm support applied.

If the lift arm must be left in the raised position, **BE SURE** to properly apply the lift arm support.

The operator must not leave the operator's position if the lift arm is in the raised position unless the lift arm support is properly applied.

Applying and disengaging the lift arm support requires two people – one person inside the machine and another person outside the machine to apply and/or disengage the support device.

The lift arm support must be kept in proper operating condition at all times.

***Important:** A second person on the outside of the machine is required to assist with applying the lift arm support.*

Engage Lift Arm Support

1. Empty and remove the attachment (See “Connecting Attachments” on page 98).
2. Bring the machine to a complete stop on a level surface.
3. Lower the lift arm fully.
4. Stop the engine.
5. Have an assistant remove the lift arm support from its storage location on the left side of the machine. Remove lynchpin (S, Figure 11) holding lift arm support (T) up against the lift arm. Allow lift arm support (T) device to pivot down into contact with the lift cylinder.
6. Restart the engine.



Figure 11 – Lift Arm Support Storage Lynchpin Removal

7. Use the lift control to raise the lift arm until lift arm support (T, Figure 12) drops over the end of the lift cylinder and around the cylinder rod.
8. Slowly lower the lift arm until the free end of the support device contacts the top end of the lift cylinder (U).
9. Check the support device to ensure it is secure against the cylinder end.
10. Stop the engine.
11. Move the lift control to verify the control does not cause the lift arm to move.
12. Unfasten the seat belt, remove the ignition key and take it with you. Exit the machine using the hand-holds.




Figure 12 – Lift Arm Support Engaged

Disengage Lift Arm Support

⚠ WARNING The safest method of installing and removing the lift arm support device requires two people – one person inside the machine and another person outside the machine to disengage the support device.

1. Start the engine.
2. Raise the lift arm fully.
3. Stop the engine.
4. Verify that the lift arm is being held in the raised position by the safety interlock system.

Important: With the key switch OFF and the solenoid valve working properly, the lift arm will stay raised when the lift control is moved to lower the lift arm. If the valve does not hold the lift arm and it begins to lower do not leave the operator's compartment. Instead, lower the lift arm against the lift arm support and exit the machine. Then, contact your dealer immediately to determine why the lift arm lowers while the key switch is OFF.

5. Have an assistant raise lift arm support (T, Figure 13) until it contacts the lift arm. Reinstall lynchpin (S) through post (V) on the lift arm to secure lift arm support (T) in the storage position.
6. Fold lynchpin ring (W) over post (V) to lock lynchpin in place.




Figure 13 – Lift Arm Support Storage Position



CAUTION

To prevent damage to the lift cylinder, do not lower lift arm until the lift arm support is secured in the storage position.

Battery Disconnect Switch

The battery disconnect switch is located in the engine compartment. Turning the switch to the OFF position disconnects the battery from the electrical system.



Figure 14 – Battery Disconnect Switch



CAUTION

On machines equipped with the battery disconnect switch, always turn the switch to the “OFF” position when parking the machine inside an enclosure.

CHAPTER 4

INDICATORS AND CONTROLS



WARNING

Become familiar with all controls before operating the machine. Know how to stop the machine before starting it. The machine is designed and intended to be used only with Manitou-approved attachments or accessories. Manitou cannot be responsible for operator safety if the machine is used with unapproved attachments.




Figure 15 – Controls (Hand/Foot Control Option Shown)

A. Accessory Keypad (page 51)	F. HVAC Vent Nozzle	K. Right Hand Control (page 67)
B. Ignition Keyswitch (page 59)	G. Cup Holder	L. Operator's Seat (page 39)
C. Information Center Electronic Display (page 53)	H. Foot Controls (page 67)	M. Optional Lights/Lockout Keypad (page 52)
D. Control Keypad (page 48)	I. Throttle Control (page 60)	
E. Electrical Accessory Socket	J. Left Hand Control (page 67)	

Control Keypad

Control Keypad Indicators

Note: Control panel indicators are visible only when the indicator lamps are activated.




Table 2: Control Keypad Indicators

Indicator	Description	Details
	High-Speed Travel Range Indicator	Indicates high-speed travel range is activated.
	Lift Arm Float Indicator	Indicates lift arm float is activated.
	Hydraglide™ Indicator	Indicates Hydraglide™ lift arm cushion is activated.
	Engine Pre-heat Indicator	Is lit when ignition keyswitch is in the ON/RUN position and engine pre-heat is required; goes out when engine pre-heat is complete.
	Seat Belt Reminder Indicator	Is lit when ignition is turned on as a reminder to lower the operator restraint bar and fasten the seat belt.
	Battery Voltage Warning Indicator	Indicates battery charging system malfunction. During normal operation this indicator should be OFF.

Table 2: Control Keypad Indicators

Indicator	Description	Details
	Engine Air Filter Restriction Indicator	Indicates engine air filter requires service. See “Engine Air Cleaner” on page 143. During normal operation this indicator should be OFF.
	Hydraulic Oil Filter Warning Indicator	Indicates hydraulic oil filter requires service. See “Changing Hydraulic Oil Filter” on page 148. During normal operation this indicator should be OFF.
	Hydraulic Oil Temperature Warning Indicator	Indicates hydraulic temperature is too high. During normal operation this indicator should be OFF.
	Engine Malfunction Indicator	Is lit when the engine electronic control unit (ECU) has detected an error condition. Refer to “Engine Diagnostic Trouble Codes (DTC)” on page 175.
	Coolant Temperature Warning Indicator	Indicates coolant temperature is too high. During normal operation this indicator should be OFF.
	Engine Oil Pressure Warning Indicator	Indicates engine oil pressure is too low. During normal operation this indicator should be OFF. IMPORTANT! Immediately shut down the engine if this indicator is lit. Correct the problem before restarting the engine.

Control Keypad Buttons




Table 3: Control Panel Buttons

Button	Description	Function
	Parking Brake	Engages / disengages parking brake.
	Beacon / Position / Work Lights	Activates optional beacon, position, and/or work lights. See “Beacon/Position/Work Lights” on page 74.
	Self-Leveling Cancel	Cancels self-leveling function. LED above button is on when self leveling is off.
	Power-A-Tach [®] System Hitch Lock	Press and hold to lock attachments onto optional Power-A-Tach [®] System Hitch.
	Power-A-Tach [®] System Hitch Unlock	Press and hold to unlock attachments onto the optional Power-A-Tach [®] System Hitch to allow attachment removal.
	High-Flow Forward	Press to activate the high-flow auxiliary hydraulics in a forward flow.
	High-Flow Reverse	Press to activate the high-flow auxiliary hydraulics in a reverse flow.

Accessory Keypad Indicators/Buttons




Table 4: Accessory Keypad Buttons

Button	Description	Function
	HVAC Button	Turns cab heat/cool on/off. Low, medium and high settings are available. See “HVAC (Option)” on page 74.
	HVAC Blower Fan Button	Turns cab HVAC blower fan on/off. Low, medium and high settings are available. See “HVAC (Option)” on page 74.
	Windshield Wiper Button	Turns windshield wiper on/off. Slow, medium and fast settings are available. See “Windshield Wiper/Washer” on page 75.
	Windshield Washer Button	Activates windshield washer. See “Windshield Wiper/Washer” on page 75.
	Rear Window Wiper Button	Turns rear window wiper on/off. Slow, medium and fast settings are available. See “Windshield Wiper/Washer” on page 75.
	Rear Window Washer Button	Activates rear window washer. See “Windshield Wiper/Washer” on page 75.

Optional Lights/Lockout Keypad Indicators/Buttons




Figure 19 – Road Lights Keypad Indicators/Buttons

Table 5: Optional Road Lights Keypad Buttons

Button	Description	Function
	Beacon / Position / Work Lights Button	Operates optional road lights, and works with main control keypad to control the beacon and position lights. If all lights are off, one press activates the beacon and all position lights; a second press additionally turns on the road lights. If the work lights are on, pressing this button turns off the work lights and turns on the road lights. If the road lights are on, all lights turn off if this button is pressed.
	High-Beam Button	Activates optional road lights high-beam.
	Hazard Lights Button	Activates optional flashing road hazard lights. Operates even if the ignition switch is off.
	Hydraulics Lock-out Button	Activates optional lift and tilt hydraulics lock-out. Used when driving the machine on roadways. See "Transport Hydraulics Lock-out (Option)" on page 95.
	Left Directional Button	Activates optional flashing road lights left directional indicator.
	Right Directional Button	Activates optional flashing road lights right directional indicator.

Information Center Electronic Display

The information center electronic display is located on the right door pillar. It provides the following functionality:

- Displays operational status such as engine fuel tank level, engine RPM, coolant temperature, service hours and system voltage.
- Displays error fault codes and input/output diagnostic data.
- Configures displays settings.




Figure 20 – Information Center Electronic Display

M. Navigation Rocker Button – Used for general screen navigation and other various functions, depending upon screen and context.	P. Increase Brightness/Return Button – Used for different functions depending upon screen and context: • Used to increase display brightness. Corresponds to the ☀ symbol on the display screen. • Used to return to previous screen. Corresponds to the ↶ symbol on the display screen.
N. OK Button – Used for various functions, depending upon screen and context.	Q. Decrease Brightness Button – Used to decrease display brightness. Corresponds to the ☀ symbol on the display screen.

O. Regen/Return Button – Used for different functions depending upon screen and context:

- Switches to the Regen display mode if the  symbol is displayed on the screen. Also initiates DPF regeneration if all appropriate conditions are met.
- Used to return to previous screen. Corresponds to the  symbol on the display screen.

R. Regen Inhibit Button – Press for 5 seconds to inhibit DPF reset regeneration. Displays the  symbol.

⚠ WARNING If the LCD is broken, care must be taken with any leaking fluid. If LCD fluid gets onto your skin, wipe with a cloth and wash the area with mild soap and water. If LCD fluid gets into your eyes, thoroughly rinse your eyes with clean water for several minutes and seek medical assistance. If LCD fluid is swallowed, rinse your mouth thoroughly with clean water, then drink a substantial volume of water and induce vomiting. Then seek medical assistance.

Information Center Electronic Display Symbols

The following table describes symbols used in the information center electronic display.

Note: Values may not display for all parameters, depending upon installed options and equipment.

Table 6: Symbols Descriptions

Symbol	Description	Symbol	Description
 n/min	Engine crankshaft revolutions per minute.		Real-time fuel consumption rate. Displayed in gallons/hour (SAE) or liters/minute (METRIC).
	Accumulated operation time. Time is displayed in hours, and accumulates when the engine is running.		Display brightness increase. Press button (P, Figure 20) when this symbol is displayed to increase screen brightness.
	Battery charging circuit voltage.		Display brightness decrease. Press button (Q, Figure 20) when this symbol is displayed to decrease screen brightness.
	Fuel level in fuel tank.		Return to previous. Press button (O, Figure 20) when this symbol is displayed to return to the previous screen.
	Coolant temperature.		Diesel Particulate Filter (DPF) regeneration. See “Diesel Particulate Filter (DPF) Regeneration Procedures” on page 118.

Table 6: Symbols Descriptions

Symbol	Description	Symbol	Description
	Percentage of engine power based on load.		Diesel Particulate Filter (DPF) regeneration inhibit. See “Diesel Particulate Filter (DPF) Regeneration Procedures” on page 118. <i>Note: Strike-through line through the symbol is displayed in red when DPF regeneration is inhibited.</i>
	Ambient engine compartment temperature.		Diesel Particulate Filter (DPF) regeneration in-progress (elevated temperature). See “Diesel Particulate Filter (DPF) Regeneration Procedures” on page 118.
	Power-A-Tach® System Warming Circuit (1650R Models - SN 191901 and Up)		Aftertreatment Error Engine Emission System Failure. Indicates an error or fault with emission critical components. NOTE: Engine derate will occur if error/fault not corrected.

Information Center Electronic Display Screens

Note: Values may not display for all parameters, depending upon installed options and equipment.

Table 7: Status, Maintenance and Error Code Screens



Display Mode	Description
Status Screens	
	Dual Gauge Display A. Fuel level. B. Engine coolant temperature. C. Accumulated operation time. <i>Note: Time is displayed in hours, and accumulates when the engine is running.</i> D. Amber error condition warning. Causes DM1/DM2 errors screen(s) to display. See page 58. E. Red critical error warning. Causes DM1/DM2 errors screen(s) to display. See page 58. F. Engine coolant temperature amber warning region. Indicates elevated coolant temperature. G. Engine coolant temperature red stop warning region. Indicates serious coolant overheating condition. <i>Note: Running the engine in an overheated condition can damage the engine.</i> H. Fuel level amber warning region. Indicates low fuel level. I. Fuel level red stop region. Indicates almost empty fuel tank.
	Quad Gauge Display Displays four different status parameters simultaneously. To change the displayed parameters, press and hold the ok button (N, Figure 20) until orange bar (T) displays. Press the left/right side of navigation rocker button (M, Figure 20) to select the parameter and press the top/bottom of navigation rocker button to change the selected parameter. Press the ok button again to dismiss orange bar (T).

Table 7: Status, Maintenance and Error Code Screens




Display Mode	Description
	Single Gauge Display Displays single real time operating parameters. Switch between parameters using the navigation button (M, Figure 20). Used for various functions, depending upon screen and context.
	Regeneration Screens These screens are associated with Diesel Particulate Filter (DPF) regeneration procedures and maintenance. See “Diesel Particulate Filter (DPF) Regeneration Procedures” on page 118.
Secondary Screens	
All Secondary Screens	Secondary screens are accessed by holding down the ok button (N, Figure 20) for 10 seconds while the Dual Gauge Display screen is displayed. Press the left/right side of navigation rocker button (M, Figure 20) to switch between secondary screens.
	Revision Screen Displays information center electronic display software information.

Table 7: Status, Maintenance and Error Code Screens

Display Mode	Description
UNITS SAE METRIC 	Units Screen Press the top/bottom of navigation rocker button (M, Figure 20) to switch between SAE or metric units for values displayed in screens.
LANGUAGE ENGLISH SPANISH 	Language Screen The press the top/bottom of navigation rocker button (M, Figure 20) to switch between English or Spanish language for values displayed in screens.
0 of 0  DM1 SPN: 0 FMI: 0 OCI: 0 	DM1 Screen Displays engine, drive system, control, and safety system error code message information. Number of available messages is displayed at the top left of the screen (T). Use buttons (P and Q, Figure 20) to scroll through the messages. See "Engine Diagnostic Trouble Codes (DTC)" on page 175 for specific error code details.
0 of 0  DM2 SPN: 0 FMI: 0 OCI: 0 	DM2 Screen Continuation of error code message display along with DM1 Screen. Number of available messages is displayed at the top left of the screen (T). Use buttons (P and Q, Figure 20) to scroll through the messages. See "Engine Diagnostic Trouble Codes (DTC)" on page 175 for specific error code details.

Table 7: Status, Maintenance and Error Code Screens

Display Mode	Description																															
DIAGNOSTICS INPUTS <table><tr><td>Float</td><td>☐</td><td>Alternator</td><td>☐</td></tr><tr><td>Hydro Glide</td><td>☐</td><td>KP Ignition Run</td><td>☐</td></tr><tr><td>High Gear</td><td>☐</td><td>KP Ignition Start</td><td>☐</td></tr><tr><td>Aux Detent</td><td>☐</td><td>KP Seat Switch</td><td>☐</td></tr><tr><td>Air Filter Clog</td><td>☐</td><td>KP Restraint Bar</td><td>☐</td></tr><tr><td>Hyd Filter Clog</td><td>☐</td><td></td><td></td></tr><tr><td>High Hyd Temp</td><td>☐</td><td></td><td></td></tr><tr><td>Engine Pressure</td><td>☐</td><td></td><td></td></tr></table> Input Status Displays input information from electronic control modules, showing real-time machine component/control state. Status colors indicate the following: • Green – Active • Black – Inactive	Float	☐	Alternator	☐	Hydro Glide	☐	KP Ignition Run	☐	High Gear	☐	KP Ignition Start	☐	Aux Detent	☐	KP Seat Switch	☐	Air Filter Clog	☐	KP Restraint Bar	☐	Hyd Filter Clog	☐			High Hyd Temp	☐			Engine Pressure	☐		
Float	☐	Alternator	☐																													
Hydro Glide	☐	KP Ignition Run	☐																													
High Gear	☐	KP Ignition Start	☐																													
Aux Detent	☐	KP Seat Switch	☐																													
Air Filter Clog	☐	KP Restraint Bar	☐																													
Hyd Filter Clog	☐																															
High Hyd Temp	☐																															
Engine Pressure	☐																															
DIAGNOSTICS OUTPUTS <table><tr><td>High Gear</td><td>☐</td><td>Float</td><td>☐</td></tr><tr><td>Self Level</td><td>☐</td><td>Marker Lts</td><td>☐</td></tr><tr><td>Hydro Glide</td><td>☐</td><td>Rear Work Lts</td><td>☐</td></tr><tr><td>Fuel Pump</td><td>☐</td><td>Front Work Lts</td><td>☐</td></tr><tr><td>Glow Plug</td><td>☐</td><td>KP Beacon Lts</td><td>☐</td></tr><tr><td>Starter</td><td>☐</td><td>KP Dome Lt</td><td>☐</td></tr><tr><td>All Tach Lock</td><td>☐</td><td>Disable Park Brake</td><td>☐</td></tr><tr><td>All Tach Unlock</td><td>☐</td><td>Tilt/Lift</td><td>☐</td></tr></table> Output Status Displays output information from electronic control modules, showing real-time feedback state of machine components. Status colors indicate the following: • Green – Active • Black – Inactive. • Yellow – Standby or Not Applicable • Red – Short Circuit	High Gear	☐	Float	☐	Self Level	☐	Marker Lts	☐	Hydro Glide	☐	Rear Work Lts	☐	Fuel Pump	☐	Front Work Lts	☐	Glow Plug	☐	KP Beacon Lts	☐	Starter	☐	KP Dome Lt	☐	All Tach Lock	☐	Disable Park Brake	☐	All Tach Unlock	☐	Tilt/Lift	☐
High Gear	☐	Float	☐																													
Self Level	☐	Marker Lts	☐																													
Hydro Glide	☐	Rear Work Lts	☐																													
Fuel Pump	☐	Front Work Lts	☐																													
Glow Plug	☐	KP Beacon Lts	☐																													
Starter	☐	KP Dome Lt	☐																													
All Tach Lock	☐	Disable Park Brake	☐																													
All Tach Unlock	☐	Tilt/Lift	☐																													

Controls

Ignition Keyswitch

The Ignition keyswitch is located near the top of the right door pillar. Ignition keyswitch positions are:

- **OFF Position** : With the key turned fully counterclockwise, power from the electrical system is disconnected from the controls and instruments. This is the only position from which the key can be inserted or removed.
- **ON/RUN Position** : With the key turned one position clockwise from the OFF position, electrical power is supplied to all controls and instruments.
- **START Position** : With the key turned and held fully clockwise, the electric starter engages. Release the key to ON/RUN position when the engine starts.



Figure 21 – Ignition Keyswitch

Throttle Controls

On machines equipped with throttle knob (Q, Figure 22), engine speed is controlled with throttle knob and optional foot throttle (P, Figure 24), if installed.

Throttle knob (Q) is the primary throttle control. The throttle is set with the knob to the desired idle/run position.




Figure 22 – Throttle Knob

On machines equipped with throttle lever (T, Figure 23), engine speed is controlled with throttle lever and optional foot throttle (P, Figure 24), if installed.

Throttle knob (T) is the primary throttle control. The throttle is set with the lever to the desired idle/run position.




Figure 23 – Throttle Lever

On machines equipped with optional throttle pedal (P, Figure 24), the pedal can be used to increase engine speed whenever additional power is required. When the optional pedal is released, the engine returns to the speed set by throttle knob (Q, Figure 22).




Figure 24 – Throttle Pedal

Travel Drive, Lift and Tilt Controls

The machine is equipped with one of three control systems:

- T-Bar Controls: see “T-Bar Controls” on page 61.
- Joystick Controls: see “Joystick Controls” on page 64.
- Hand and Foot Controls: see “Hand and Foot Controls” on page 67.

T-Bar Controls

On T-bar-equipped machines, the left T-bar controls the travel drive, and the right T-bar controls the attachment lift and tilt.




Table 8: T-Bar Controls

Ref.	Control	Description
A	Left T-Bar	Controls drive forward, reverse, turn, and speed. See “Drive Control (Left T-Bar)” on page 62.
B	Right T-Bar	Controls lift arm raise/lower, float, and attachment tilt. See “Lift/Tilt Control (Right T-Bar)” on page 63.
C	Two-Speed Selection Button	Toggles between high- and low-speed travel modes. See “Two-Speed Drive (Option)” on page 69.
D	Horn Button	Activates horn.
E	Hydraglide™ Button	Activates Hydraglide™. See “Hydraglide™ Ride Control System (Option)” on page 73.
F	INACTIVE	Button is inactive on T-Bar Controls.
G	Auxiliary Hydraulics Rocker Switch	Controls auxiliary hydraulics flow direction and amount. See “Auxiliary Hydraulic System” on page 80.
H	Auxiliary Hydraulics Continuous Flow Latch Trigger	Works with Auxiliary Hydraulics Rocker Switch to latch/unlatch auxiliary hydraulics continuous flow. See “Auxiliary Hydraulic System” on page 80.

On machines equipped with T-bar controls, the left T-bar controls the drive, and the right T-bar controls the lift/tilt.

Drive Control (Left T-Bar)

Forward, reverse, travel speed and turning maneuvers are controlled using the left T-bar (Figure 26):

- A. To go forward, push the left T-bar forward.
- B. To go in reverse, pull the left T-bar rearward.
- C. To turn right, twist the control clockwise.
- D. To turn left, twist the control counter-clockwise.




Figure 26 – Drive Control (Left T-Bar)

For gradual turns, twist the T-bar slightly; for sharp turns, twist the T-bar further.

Turns while moving forward or in reverse can be made by twisting the T-bar while also pushing it forward or pulling it back.

Moving the T-bar farther from neutral increases the speed steadily to the maximum travel speed.

Note: *Tractive effort decreases as speed increases. To get maximum tractive effort, move the T-bar only slightly away from the neutral position.*

Note: *The engine will stall if the control is moved too far forward when loading the bucket.*

⚠ WARNING Be sure the controls are in neutral before starting the engine. Operate the controls gradually and smoothly. Excessive speed and quick control movements without regard for conditions and circumstances are hazardous and could cause an accident.

Lift/Tilt Control (Right T-Bar)

Lift arm raise and lower, and attachment tilt are controlled using the right T-bar (Figure 27):

- A. To lower the lift arm, push the right T-bar straight forward.
- B. To raise the lift arm, pull the right T-bar straight rearward.
- C. To tilt the attachment forward and down, twist the right T-bar clockwise.
- D. To tilt the attachment up and back, twist the right T-bar counter-clockwise.




Figure 27 – Lift/Tilt Control (Right T-Bar)

The lift arm can be tilted while raising or lowering by twisting the T-bar while also pushing it forward or pulling it back.

Note: *The speed of the lift/tilt motion is proportional to the amount of T-bar movement and engine speed.*

Joystick Controls

On joystick-equipped machines, the left joystick controls the travel drive, and the right joystick controls the attachment lift and tilt.




Table 9: Joystick Controls

Ref.	Control	Description
A	Left Joystick	Controls drive forward, reverse, turn, and speed. See “Drive Control (Left Joystick)” on page 65.
B	Right Joystick	Controls lift arm raise/lower, float, and attachment tilt. See “Lift/Tilt Control (Right Joystick)” on page 65.
C	Two-Speed Selection Button	Toggles between high- and low-speed travel modes. See “Two-Speed Drive (Option)” on page 69.
D	Horn Button	Activates horn.
E	Hydraglide™ Button	Activates Hydraglide™. See “Hydraglide™ Ride Control System (Option)” on page 73.
F	Float Button	Activates Float. See “Lift Arm Float” on page 71.
G	Auxiliary Hydraulics Rocker Switch	Controls auxiliary hydraulics flow direction and amount. See “Auxiliary Hydraulic System” on page 80.
H	Auxiliary Hydraulics Continuous Flow Latch Trigger	Works with Auxiliary Hydraulics Rocker Switch to latch/unlatch auxiliary hydraulics continuous flow. See “Auxiliary Hydraulic System” on page 80.

Drive Control (Left Joystick)

Forward, reverse, travel speed and turning maneuvers are controlled using the left joystick (Figure 29):

- A. To go forward, push the left joystick forward.
- B. To go in reverse, pull the left joystick rearward.
- C. To turn right, push the left joystick to the right.
- D. To turn left, push the left joystick to the left.
- E. To go forward and to the right, push the left joystick forward and to the right.
- F. To go rearward and to the right, pull the left joystick rearward and to the right.
- G. To go forward and to the left, push the left joystick forward and to the left.
- H. To go rearward and to the left, pull the left joystick rearward and to the left.




Figure 29 – Drive Control (Left Joystick)

⚠ WARNING Be sure the joystick controls are in neutral before starting the engine. Operate the controls gradually and smoothly. Excessive speed and quick control movements without regard for conditions and circumstances are hazardous and could result in loss of control and cause an accident.

Moving the joystick farther from neutral increases the speed steadily to the maximum travel speed. Tractive effort decreases as speed increases. For maximum tractive effort, move the joystick only slightly away from the neutral position. The engine may stall if the control is moved too far forward when loading the bucket.

Lift/Tilt Control (Right Joystick)

Lift arm raise and lower, and attachment tilt are controlled using the right joystick (Figure 30):

- A. To lower the lift arm, push the right joystick straight forward.
- B. To raise the lift arm, pull the right joystick straight back.
- C. To tilt the attachment forward and down, move the right joystick to the right.
- D. To tilt the attachment up and back, move the right joystick to the left.




Figure 30 – Lift/Tilt Control (Right Joystick)

- E. To lower the lift arm while tilting the attachment forward and down, move the right joystick forward and to the right.
- F. To lower the lift arm while tilting the attachment up and back, move the right joystick forward and to the left.
- G. To raise the lift arm while tilting the attachment forward and down move the right joystick rearward and to the right.
- H. To raise the lift arm while tilting the attachment up and back, move the right joystick rearward and to the left.

Note: *The speed of the lift/tilt motion is directly proportional to the amount of joystick movement and engine speed.*

Hand and Foot Controls

On hand and foot controlled-equipped machines, the hand controls are used to control the travel drive, and the foot controls are used to control the attachment lift and tilt.




Figure 31 – Hand and Foot Controls

Table 10: Hand and Foot Controls

Ref.	Control	Description
A	Left Hand Control	Controls travel drive forward, reverse, turn, and speed. See “Drive Control (Hand Controls)” on page 68.
B	Right Hand Control	Controls travel drive forward, reverse, turn, and speed. See “Drive Control (Hand Controls)” on page 68.
C	Two-Speed Selection Button	Toggles between high- and low-speed travel modes. See “Two-Speed Drive (Option)” on page 69.
D	Horn Button	Activates horn.
E	Hydraglide™ Button	Activates Hydraglide™. See “Hydraglide™ Ride Control System (Option)” on page 73.
F	INACTIVE	Button is inactive on Hand and Foot Controls.

Table 10: Hand and Foot Controls


Ref.	Control	Description
G	Auxiliary Hydraulics Rocker Switch	Controls auxiliary hydraulics flow direction and amount. See "Auxiliary Hydraulic System" on page 80.
H	Auxiliary Hydraulics Continuous Flow Latch Trigger	Works with Auxiliary Hydraulics Rocker Switch to latch/unlatch auxiliary hydraulics continuous flow. See "Auxiliary Hydraulic System" on page 80.
I	Left Foot Control	Control lift arm raise and lower. See "Lift/Tilt Control (Foot Controls)" on page 69.
J	Right Foot Control	Controls attachment tilt. See "Lift/Tilt Control (Foot Controls)" on page 69.

Drive Control (Hand Controls)

Forward, reverse, travel speed and turning maneuvers are controlled using the hand controls (Figure 32):

- A. To go forward, push both hand controls forward.
- B. To go in reverse, pull both hand controls rearward.
- C. To turn right, push the left hand control farther forward than the right.
- D. To turn left, push the right hand control farther forward than the left.
- E. To spin turn clockwise, push the left hand control forward and pull the right hand control rearward.
- F. To spin turn counter-clockwise, push the right hand control forward and pull the left hand control rearward.

Left Hand Control



Right Hand Control




Figure 32 – Drive Control (Hand Controls)

⚠ WARNING Be sure the controls are

in neutral before starting the engine. Operate the controls gradually and smoothly. Excessive speed and quick control movements without regard for conditions and circumstances are hazardous and could cause an accident.

Moving the hand controls farther from neutral increases the speed steadily to the maximum travel speed. Tractive effort decreases as wheel speed increases. For maximum tractive effort, move the hand controls only slightly away from the neutral positions. The engine will stall if the hand controls are moved too far forward when loading the bucket.

Lift/Tilt Control (Foot Controls)

Lift arm raise and lower, and attachment tilt are controlled using the foot controls (Figure 33):

- A. To lower the lift arm, push the front of the left foot pedal down.
- B. To raise the lift arm, push the back of the left foot pedal down.
- C. To tilt the attachment forward and down, push the front of the right foot pedal down.
- D. To tilt the attachment up and back, push the back of the right foot pedal down.



Note: The speed of the lift/tilt motion is directly proportional to the amount of pedal movement and engine speed.

Two-Speed Drive (Option)

Model 1650R machines equipped with the two-speed drive options have two travel speed ranges:

- Low-speed range: 0 - 12,6 km/h (7.8 mph).
- High-speed range: 0 - 19,3 km/h (12.0 mph).

Note: Speed varies slightly with tire size.

Note: See “Travel Speeds” on page 194 for speed ranges for all models and configurations.


⚠ WARNING Reduce speed before shifting from two-speed to single-speed drive. Down-shifting from high speed to low speed drive while traveling at high speed may cause the machine to tip and can cause injury, loss of control and damage to the machine.

Press button (C, Figure 34) to switch between high and low two-speed drive ranges. When the high-speed two-speed drive range is activated, the high-speed indicator (H) on the control pad is lit.

Left T-Bar



Left Joystick



Left Hand Control



Figure 34 – Two-Speed Drive Control Button

Lift Arm Float

⚠ WARNING Make sure the attachment is lowered to the ground before activating the lift arm float. Activating float with the lift arm raised will cause the lift arm and attachment to fall to the ground, which can cause severe injury or death.

⚠ WARNING The float mode can be used where the engine has stopped, is unable to be started, and lowering the lift arm is necessary to allow the operator to exit the machine.

Float allows the lowered lift arm to follow the ground contour while traveling over changing ground conditions.

To activate lift arm float:

On T-Bar Controls

1. Lower the attachment to the ground.
2. Push Right T-Bar (B) all the way forward (Figure 27) into the detent (“float”) position. This position allows the lowered lift arm to “float” while traveling over changing ground conditions.
3. To remove lift arm from the detent (“float”) position, pull the Right T-Bar (B) out of the detent position. This returns the lift arm to normal operation.

On Joystick Controls


1. Lower the attachment to the ground.
2. Press button (A, Figure 35) to activate float:
 - Press button (A) momentarily to apply float momentarily.
 - Press and hold button (A) for 5 seconds to activate continuous float. Press button (A) again to deactivate continuous float.

The float indicator () on the control pad is lit when float is activated on Joystick Control types.


On Hand and Foot Controls

1. Lower the attachment to the ground

Right T-Bar



Right Joystick



Right Hand Control




Figure 35 – Lift/Tilt Control (Foot Controls)

2. To place the lift arm in the detent (“float”) position, use your toes to push the left pedal all the way down (A) into the detent. This position allows the lowered lift arm to “float” while traveling over changing ground conditions.

To remove lift arm from the detent (“float”) position, use your heel to push the left pedal down (B) out of the detent position. This returns the lift arm to normal operation

Hydraglide™ Ride Control System (Option)

⚠ WARNING When Hydraglide™ ride control is activated, the lift arm may drop slightly without a load, or several inches with a heavy load.

⚠ WARNING Do not use Hydraglide™ when using pallet forks.

Hydraglide™ cushions lift arm loads during transport. It provides a smoother ride over uneven surfaces.

Press button (E, Figure 36) to activate Hydraglide™ ride control. Press button (E) again to deactivate.

When Hydraglide™ is activated, the Hydraglide™ indicator (🚧) on the control pad is lit.

Note: Hydraglide™ is automatically deactivated when the machine is shut off.


Important: Do not use Hydraglide™ when digging. Precise control of the digging operation is difficult when Hydraglide™ is activated.

Activate Hydraglide™ when driving on public roads, for lighter loads, and for light off-road transport. Deactivate Hydraglide™ when working with heavy loads, such as when picking up excavated material.

Right T-Bar



Right Joystick



Right Hand Control





Figure 36 – Hydraglide™ Control Button

Beacon/Position/Work Lights

The optional beacon, the rear red position lights, and the front and rear work lights are all operated using button (Z).

Note: The rear work lights and red position lights are located at the top of the rear door. The front work lights are located at the top front corners of the ROPS/FOPS.

The beacon/position/work lights control button is located on the control keypad.



- **Beacon and Position Lights:** Press button (Z) once to activate the beacon and the rear position lights. LED (Y) is lit when the beacon and the red position lights are on.
- **Beacon, Position and Front Work Lights:** Press button (Z) twice to activate the beacon, the rear red position lights and the front work lights. LED (U) is lit when the beacon, the position lights, and the front work lights are on.

Note: If the optional road lights are installed, this turns on both front and rear work lights. Also, if the roads lights are on, they toggle off when the work lights turn on

- **Beacon, Position, and Front and Rear Work Lights:** Press button (Z) three times to activate the beacon, the rear red position lights, and the front and rear work lights. Both LEDs (Y and U) is lit when the beacon, the red position lights, and the front and rear work lights are on.

Note: If the optional road lights are installed, this turns off all lights.


- **Off:** Press button (Z) a fourth time to turn off the beacon, the red position lights and the work lights. Both LEDs (Y and U) are off when the beacon and all lights are off.

HVAC (Option)

Machines with optional heat/cool have two control buttons on the accessory keypad on the left door pillar for controlling the heater fan and heater temperature.

- A. **Cab Heat/Cool:** Controls cab heat/cool. Press button as desired to set cab heat/cool; subsequent pressings increase heat from low to high. LEDs above the button are lit according to the low, medium and high heat settings.

NOTE: Cab heat/cool requires fan to be activated by pressing button (B).




- B. **Fan Speed:** Controls cab air circulation fan. Press button (B) once for low setting, twice for medium, and three times for high. LEDs above the button are lit according to the low, medium and high fan settings. Press button (A) a fourth time to deactivate air circulation fan.

Windshield Wiper/Washer

Machines may be equipped with a wiper and washer on the rear window, machines equipped with a cab door are equipped with an additional wiper and washer on the front windshield.

- A. **Windshield Wiper:** Controls the front windshield wiper on machines equipped with a cab door. Press button (A) once for continuous setting, twice for 3 second delay, and three times for 6 second delay. LEDs above the button are lit according to the selected setting. Press button (A) a fourth time to deactivate the front windshield wiper.
- B. **Rear Window Wiper (EU only):** Controls the back window wiper. Press button (B) once for continuous setting, twice for 3 second delay, and three times for 6 second delay. LEDs above the button are lit according to the selected setting. Press button (B) a fourth time to deactivate the rear window wiper.
- C. **Windshield Washer:** Push and hold button (C) to activate the windshield washer spray and wiper. Release the button to stop the spray; wiper continues for 5 seconds.
- D. **Rear Window Washer (EU only):** Push and hold button (C) to activate the rear window washer spray and wiper. Release the button to stop the spray; wiper continues for 5 seconds.




Dome Light

The dome light is located on the right side of the ROPS/FOPS headliner.

When the ignition is off, if the dome light is centered, the light is activated by either sitting in the operator's seat or by pressing certain buttons on the control keypad.

Note: The light will deactivate after approximately 10 seconds, if the ignition is turned on, or if the light is rotated by pressing to either side (T, Figure 40).



When the ignition is on, the light is activated by rotating it to either side (T, Figure 40); the light is deactivated by rotating it to the center.

If the light is centered, the light will activate when the ignition is turned off.

Note: The light will deactivate after approximately 10 seconds, if the ignition is turned on, or if the light is rotated by pressing on either side (T, Figure 40) of the light.

Accessory Plug

The 12V accessory plug (C, Figure 41) is located at the bottom of the right door pillar.



Figure 41 – Accessory Plug

Battery Disconnect Switch

The battery disconnect switch (D, Figure 42) is located inside the engine compartment. Turn the switch to the OFF position to disconnect the battery from the electrical system.




Figure 42 – Battery Disconnect Switch

Attachment Mounting

The machine is equipped with either the standard manual All-Tach® hitch or optional Power-A-Tach® system hitch for mounting a bucket or other attachments.


All-Tach® Hitch

A manual latch lever (E, Figure 43) engages the latch pins, which lock the attachment onto the hitch. While standing outside the machine, rotate the lever all the way to the right (as viewed while facing back at the machine from the front) to engage the locking pins to lock the attachment onto the hitch. Rotate the lever all the way to the left to disengage the locking pins. Refer to “Connecting Attachments” on page 98 for more information.



⚠ WARNING To prevent unexpected release of the attachment from the hitch, be sure the locking lever is rotated all the way to the right (as viewed while facing back at the machine from the front) and the locking pins (F, Figure 44) extend down through the attachment frame.

Locking pins (F) must be fully extended through the holes in the attachment frame before using the attachment. The attachment could fall off if it is not locked on the hitch and cause serious injury or death.



Power-A-Tach® System

Buttons (G and H, Figure 45) on the control keypad are used to operate the Power-A-Tach® System hitch. Refer to “Connecting Attachments” on page 98 for more information.

Note: The Power-A-Tach® system hitch will not operate if the restraint bar is raised.

1650R Models - SN 191901 and Up: The Power-A-Tach® System is equipped with a warming circuit. The warming circuit reduces the amount of time required to operate the hydraulic cylinder in cold temperatures. It is recommended to use this circuit when the temperature is below 32°F (0°C). Continuous use of the warming circuit is recommended when the temperature is below 0° F (-18° C).




Figure 45 – Power-A-Tach® Control Buttons

To retract the hitch pins to the unlocked position:

With the machine running, and the parking brake disengaged, press and hold the Power-A-Tach® unlock button (H, Figure 45) on the control keypad until flags (P, Figure 46) move as far as they can to the center of the hitch.

1350R/1500R/1650R - SN 191900 and Before: To extend the hitch pins to the locked position:

With the machine running, and the parking brake disengaged, press and hold the Power-A-Tach® lock button (G, Figure 45) on the control keypad until flags (Q, Figure 46) move as far as they can to the outside of the hitch.




Figure 46 – Power-A-Tach® Hitch

1650R - SN 191901 and Up: To extend the hitch pins to the locked position:

With the machine running, and the parking brake disengaged, press the quick attach lock button (G, Figure 45) on the control keypad. The flags (Q, Figure 46) will move to the outside of the hitch.

Activating The Warming Circuit (1650R Models - SN 191901 and Up)

Press the Power-A-Tach[®] System lock (extend) button on the control keypad once to activate the warming circuit and to extend the locking pins. The warming circuit icon on the Information Center Electronic Display becomes visible at this time. Pressing the lock (extend) button a second time suspends the warming circuit. Further subsequent presses of the lock (extend) button cycles the operation back and forth through the first and second push sequences. If the loader's warming circuit was active at shutdown of the engine, upon restart of the loader, the warming circuit will still be active.

***Note:** It is safe to operate the loader with the warming circuit on or off, it won't affect the performance of the loader.*

Table 11: Warming Circuit and Power-A-Tach Latching Pin Operation

Interlock Control	Engaged	Disengaged	Disengaged
Parking Brake	Engaged	Engaged	Disengaged
Pin Motion	No motion	Lock (Extend) Only	Lock (Extend) & Unlock (Retract)
Warming Circuit Operational	No	Yes	Yes

⚠ WARNING To prevent unexpected release of the attachment from the hitch, be sure the latch pins are secure by verifying that the pin flags (Q, Figure 46) have moved fully to the outside of the hitch and the locking pins (F, Figure 47) extend down through the attachment frame.

Locking pins (F) must be fully extended through the holes in the attachment frame before using the attachment. The attachment could fall off if it is not locked on the hitch and cause serious injury or death.




Figure 47 – Hitch Locking Pins

Auxiliary Hydraulic System


Auxiliary hydraulics are used with attachments requiring hydraulic power.

⚠ WARNING Always be sure the auxiliary hydraulic control is in neutral before starting the engine or disconnecting the auxiliary hydraulic couplers.

Auxiliary Hydraulic Couplers

Auxiliary hydraulic couplers (Figure 48) are located on top of the lift arm on the left side.

***Note:** Cover (G) is not present on all machines.*



Auxiliary Hydraulics Control

Rocker switch (F, Figure 49) controls the direction and amount of auxiliary hydraulics flow.

Auxiliary hydraulics control is proportional: the farther switch (F) is moved from center, the higher the flow through the auxiliary circuit. Flow direction is reversed when rocker switch (F) is moved in the opposite direction.

To latch continuous auxiliary hydraulic flow, hold the rocker switch (F) in either direction and push the trigger button (G). When the rocker switch and trigger are released, continuous flow should be enabled.


Note: Continuous flow amount is controlled using engine speed.

To cancel continuous flow, either push trigger button (G) or move rocker switch (F) in either direction.

Right T-Bar



Right Joystick



Right Hand Control





Figure 49 – Auxiliary Hydraulics Control Rocker Switch

High-Flow Auxiliary Hydraulic Control (Optional for 1650R Models)

In addition to a standard-flow auxiliary hydraulic system, loaders may be equipped with a reversible high-flow auxiliary hydraulic system. The couplers are located on top or inside of the right lift arm. The high-flow auxiliary hydraulic system is used for operating certain hydraulic attachments (e.g., cold planer, snowblower) that require higher flows.

The high-flow auxiliary switch controls the direction of hydraulic oil flow. Push the right button for forward flow (J, Figure 50), or the left button for reverse flow (I, Figure 50). Pushing the right button will pressurize the high-flow male coupler. To disengage, push and release the button. Turning off the machine, raising the restraint bar, or restarting the engine will also reset the high-flow to neutral.



WARNING

Only connect high-flow attachment couplers to the high-flow auxiliary couplers.

CHAPTER 5

OPERATION

Before Starting the Engine



WARNING

Before starting the engine and operating the machine:

- Review and comply with all safety recommendations in the Safety chapter of this manual.
- Know how to stop the machine before starting it.
- Fasten and properly adjust the seat belt(s) and lower the operator restraint bar.

Before starting the engine and running the machine, refer to “Safety Equipment” starting on page 39 and “Indicators and Controls” starting on page 47. Become familiar with the safe operation of the machine and the various operating controls, indicators and safety devices on the machine.

Operational Checks

Pre-Start Checks

Complete the following checks before starting the engine and using the machine. Correct/repair any problems before using the machine.

Table 12: Pre-Start Checks

Check	Refer To:
Fuel tank filled?	“Adding Fuel” on page 139.
Engine oil level correct?	“Checking Engine Oil Level” on page 137.
Hydraulic system oil level correct?	“Checking Hydraulic Oil Level” on page 147.
Engine coolant level correct?	“Checking Coolant Level” on page 145.
Windshield washer reservoir filled?	“Windshield Washer Reservoir” on page 158.
Grease fittings properly lubricated?	“General Lubrication” on page 132.
V-belt condition good/tension adjustment correct?	“V-Belt Maintenance” on page 144.
Tires properly inflated/tire condition good?	“Tires” on page 153.
Lights, signals, indicators, warning lights, indicators and horn operating properly?	“Control Keypad” on page 48, “Controls” on page 59.
Windows, lights and steps clean?	
Attachment securely fastened to hitch?	“Connecting Attachments” on page 98.

Table 12: Pre-Start Checks

Check	Refer To:
Overall machine condition (including attachments) for bends, cracks, broken, loose or missing parts, etc.	
Engine cover securely closed and latched?	
Rags, tools, debris and other loose objects removed? (check especially after maintenance)	
Approved warning triangle, hazard warning light and first aid kit in the machine?	
Perform safety interlock system test	See "Safety Interlock System Test" on page 42.
Seat position correctly adjusted?	"Operator's Seat" on page 39.
Seat belt fastened?	"Seat Belt" on page 40.

Checks During Operation

Complete the following checks after starting the engine and during operation.

Table 13: Checks During Operation

Check	Refer To:
After Starting the Engine/During Operation	
Engine oil pressure and charge indicator lights not on?	"Control Keypad" on page 48.
Parking brake released after starting engine and before operating machine?	
Coolant temperature indicator light not on?	"Control Keypad" on page 48.
Perform restraint bar safety interlock system test.	See "Restraint Bar Test" on page 42.
Steering operating properly?	"Controls" on page 59.
Engine exhaust excessively smoky?	
Anyone hazardously close to the machine?	
When Driving on Public Roads	
Attachments in transport position?	"Attachment Transport Position" on page 96.

Cab Entry and Exit

⚠ WARNING Use only steps (A, Figure 51) and handles (B) on the machine when entering/exiting. Keep the steps and the handles clean to ensure a secure hold at all times. Never use the controls as hand holds. Remove dirt (oil, grease, earth, snow and ice) from handles (B), steps (A) and your shoes before entering the cab.

Always face the machine when entering/exiting. When entering/exiting the cab.

Do not jump on or off the machine. Never climb onto or exit a moving machine.

Opening/Closing the Cab Door (Option)

Operate the door latch outside the cab using button (C, Figure 52) on the exterior door handle.

Lock/unlock the door using the ignition key in the key slot in button (C).



Figure 51 – Cab Entry/Exit Handles/Steps



Figure 52 – Cab Exterior Door Handle

Operate the door latch inside the cab using lever (D, Figure 53) located along the interior door frame.



Figure 53 – Cab Interior Door Handle

Important: If the door is removed for any reason, make sure to re-connect the door electrical connection (E, Figure 54) when the door is replaced.




Figure 54 – Cab Door Electrical Connection

⚠ CAUTION Operating the machine with the door electrical connection (E) disconnected can result in damage to the machine not covered under warranty.

Starting the Engine

⚠ WARNING Be familiar with the “Mandatory Safety Shutdown Procedure” on page 14 before starting the machine. Always perform this procedure before exiting the machine.

Note: The machine cannot be push- or tow-started. Attempting to push/tow start the machine may damage the drive systems of both the machine and the push/tow vehicle.

⚠ WARNING Do not use starting fluid (ether). An explosion can result, which can cause engine damage, injury or death.

1. If the machine is equipped with the battery disconnect switch, check that switch is the “ON” position. See “Battery Disconnect Switch” on page 76.
2. Carefully step up onto the back of the bucket or attachment and grasp the hand-holds. enter the operator’s compartment and sit in the operator’s seat. Adjust the seat as required. See “Operator’s Seat” on page 39.

⚠ CAUTION All controls must be within easy reach. The operator must be able to move all controls through the complete range of motion.

3. Close the door, if so equipped. Perform the seat switch safety interlock test on page 42.
4. Fasten the seat belt(s). See “Fastening/Unfastening the Seat Belt” on page 40.

⚠ WARNING Always fasten the seat belt before operating the machine. Repair or replace any damaged seat belt and lock parts before operation.

5. Lower the operator restraint bar.

Important: The operator restraint bar must be lowered before the engine can be started.

6. Place the lift/tilt, drive and auxiliary hydraulic controls into the neutral position.
7. Make sure no persons are hazardingly close to the machine.
8. Turn the ignition key one detent clockwise to the ON/RUN  position. If the engine is cold, the pre-heat  indicator activates. For information about starting in colder ambient temperatures, see “Cold-Starting” on page 88.
9. When the pre-heat  indicator goes out, turn the ignition key all the way clockwise to the START  position to engage the starter.




Figure 55 – Ignition Keyswitch

Important: The recommended limit of continuous starter engagement is 15 seconds, and the starter must never be energized for more than 30 seconds. If the starter is energized for 20-30 seconds, the ignition should be turned off for one minute or longer. To protect the starter (DPF Models), the E-ECU system turns off the starter circuit if it is energized for 30 seconds or longer. The starter will remain de-energized for 30 seconds more before the engine can be restarted.

Important: If the engine fails to start within 15 seconds, turn the key all the way counter-clockwise to the OFF position and check for engine error codes on the information center display (page 53). Allow the starter to cool for 20 seconds and repeat steps 8 and 9.

Cold-Starting

If operating in temperatures below 32°F (0°C), the following are recommended:

- Replace the engine oil with the proper viscosity oil according to the engine operator's manual.
- Make sure the battery is fully charged.
- Install an optional block heater on the engine. A block heater is recommended for starting in temperatures below 20°F (-7°C). Contact your dealer for engine heater options.
- 1650R Models - SN 191901 and Up: If equipped with the optional Power-A-Tach System, use the warming circuit.

Run the engine at 1800 rpm with no load for 5 minutes to warm the engine and hydraulic fluid to operating temperature before operating the machine.

Note: Depending upon coolant temperature, 50° F (10° C) or below, the low idle engine speed is automatically increased during a five minute warm-up period or until the coolant reaches a specified temperature.

Important: In ambient temperatures below -10° C (14° F), an engine block heater is recommended and is required below temperatures below -15° C (5° F) to reduce starter load and aid engine warm up. Starting the machine at these temperatures without a block heater will result in multiple glow/crank cycles or possible extended cranking time approaching 20 seconds.

After Starting

1. Check that the charge () and oil pressure () indicators go out after the engine starts.

Important: If the charge () and/or the engine oil pressure () indicators do not go out when the engine is running, shut down the engine immediately and correct the problem. Damage to the engine may result if engine is run and the problem is not corrected.

2. Press the parking brake button on the control keypad to release the parking brake.


Note: The parking brake ((P)) indicator on the control keypad is lit when the parking brake is engaged.

3. Perform restraint bar safety interlock system test on page 42.
4. Check for proper steering operation.
5. Check for excessively smoky exhaust (“Engine Troubleshooting” on page 163):

- Black smoke indicates poor and/or incomplete diesel fuel combustion.
- Blue smoke indicates engine oil combustion.
- White smoke indicates incomplete diesel combustion and/or coolant in the combustion chamber. Watch for persons hazardously close to the machine after starting and during machine operation.

Important: Do not run the engine at full throttle until it reaches operating temperature, or damage to the engine can result. Perform the following warm up procedure after starting before using the machine.

Important: Do not run the engine at high speed (above 20% of full throttle) for extended periods when the machine is not under load. Damage to the engine can result.



Warm Up

 **WARNING** Do not operate the machine until the hydraulic system reaches operating temperature. When cold, hydraulic response is slow and can be unpredictable, presenting an unsafe condition. Damage to the machine can also result.

1. After starting, allow the engine to run at low idle with no load for a minimum of 5 minutes without operating the drive, lift, tilt or auxiliary functions.
2. Run the engine at 1800 rpm with no load for 5 minutes.
3. Raise the lift arm so the attachment is off the ground.
4. Extend and retract each of the cylinders several times with no load.
5. Travel slowly forward and backward several times.
6. In cold weather, tilt the attachment all the way forward and keep it there for 20-25 seconds. Repeat this step until the attachment tilt speed is normal.

Run-In Period

The performance and service life of the machine is heavily dependent on using the machine carefully during its first 100 operating hours.

- Do not operate the machine at the maximum rated operating capacity.
- Do not run the engine at a high speed for extended periods of time.
- Increase the load gradually while varying the engine speed.
- Follow the maintenance schedule. See “Maintenance Schedules” on page 127.

Stopping the Machine

When stopping the machine, perform the “Mandatory Safety Shutdown Procedure” on page 14. Raise the operator restraint bar, unfasten the seat belt(s) and grasp the hand-holds while climbing out of the operator’s compartment.

Important: Do not stop the engine at full throttle. Damage to the engine can result.

Note: The machine is equipped with a spring-applied automatic parking brake. The parking brake is applied when the operator restraint bar is lifted, the operator’s leaves the operator’s seat, the engine is shut off, or the parking brake switch is actuated.

Engine Stalling

 **WARNING** If the engine should stall for any reason during operation, always turn the ignition keyswitch all the way counter-clockwise to the OFF position and place the lift/tilt, drive and auxiliary hydraulic controls into the neutral positions before re-starting the engine according to “Starting the Engine” on page 87.

Parking the Machine

Park the machine away from traffic on firm, level ground. If this is not possible, park the machine across the incline and block the tires to prevent movement.

After performing the “Mandatory Safety Shutdown Procedure” on page 14, perform the following:

- Check for coolant, fuel and/or oil leaks. Inspect all hoses, working components, covers and chassis for damage or advanced wear. Check for loose or missing parts. Repair or replace damaged, leaking, worn or otherwise compromised components before starting the machine again.
- Fill the fuel tank. See “Fluid Capacities/Lubricants” on page 187 for proper fuel specifications.
- Remove any dirt and/or debris from the engine compartment.
- Remove any mud/dirt from the chassis. Clean any dirt or water from the cylinder rod surfaces to prevent corrosion and protect the cylinder seals.
- If parking the machine for an extended period, lock the cab door (if so equipped) and the engine compartment. Take the keys with you.

Brake Release Operation (Option)

The machine may have, as an option, a brake release system installed. The brake release system releases the parking brake, allowing the machine to be towed for short distances.

⚠ WARNING Before utilizing the brake release, be sure to secure the machine with wheel chocks or tow lines. Verify the travel path of the machine is clear of personnel before operating the brake release system.

1. Locate the brake release jack (Z, Figure 57) and handle. Depending on your particular model, it may be necessary to remove covers and/or open the rear door of the machine.
2. Position the brake release receiver (Y) and insert the jack handle.
3. Push down and hold the plunger (Z) against the brake release.
4. Jack the brake release to build pressure. As pressure builds, plunger (X) stays down and no longer needs to be held.
5. Continue to jack the brake release until jacking resistance no longer increases.




Figure 57 – Parking Brake Release Option

***Note:** The brake release has a pressure relief which prevents damage to the travel motors.*

6. Tow the machine for short distances only, such as towing it onto a trailer. Depending on the internal leakage rate of the travel motors, the machine may roll easily with the brake release activated, or the tires may skid until the oil is forced from the motors.
7. Reset the parking brake by pulling up on plunger (X) or starting the machine.

Jump-starting

If the battery is discharged or does not have enough power to start the engine, jump-start the engine as follows:

 **WARNING** Two people are required for safe jump-starting. An additional person is required to remove the jumper cables with the operator remaining in the operator's seat once the engine is running. Start the engine from the operator's seat with all controls in "neutral."

NEVER make jumper cable connections directly to the starter solenoid of either engine.

To reduce the risk of a short circuit, keep metal parts on your clothing and metal jewelry away from the battery.

Do not jump-start a frozen battery, or it may explode. A discharged battery can freeze at 14°F (10°C).

Wear safety glasses and avoid leaning over the batteries while jump-starting.

To avoid personal injury, closely follow the procedure, step-by-step.

***Important:** The external power source must deliver 12 volts, DC. Supply voltages higher than 12V can damage the electrical systems of both machines. Only use jumper cables that are in good condition.*

***Important:** The booster battery must have a voltage of 12-volts.*

1. Turn the ignition keyswitches of both machines to the OFF position. Be sure the controls in both machines are in the neutral position and the machines are NOT touching each other. If the machine with the booster battery has a drive transmission, place the transmission into neutral and apply the parking brake.
2. Open the engine compartment to provide access to the discharged battery (Figure 58). If the machine is equipped with a battery disconnect switch (see “Battery Disconnect Switch” on page 76), be sure the switch is in the ON position.
3. Route the jumper cables so that they cannot catch on any moving objects or components and connect the positive (+) terminal (A, Figure 59) on the discharged battery.

Important: Prevent the other positive jumper cable clamp from touching any metal other than the positive (+) remote battery terminal.

4. Connect the other end of the positive jumper cable to the positive (+) terminal (B) on the booster battery.
5. Connect the negative jumper cable to the negative (-) terminal (C) on the booster battery.
6. Connect the other end of the negative (-) jumper cable to an unpainted frame surface (D) inside the engine compartment of the machine with the discharge battery. Connect the cable as far as possible away from the battery.

Important: Prevent the other negative jumper cable clamp from touching any metal other than the frame of the machine with the discharged battery.



Figure 58 – Battery Locations




Figure 59 – Booster Battery Connection



WARNING

Do not connect the other end of the negative jumper cable clamp to the negative terminal (-) on the discharged battery. Gas emerging from the battery may ignite if sparks are formed.

7. Start the machine with the discharged battery. See “Starting the Engine” on page 87. If the engine does not start immediately, stop cranking after 10 seconds and repeat starting procedure after approximately 30 seconds.

Note: Alternately, a third person can start the machine with the booster battery, to avoid excessive drain on the booster battery.

8. Once the machine with the discharged battery is running, disconnect the jumper cables in reverse order of connection. Be careful not to short the jumper cables together when disconnecting.
9. Run the machine for at least 30 minutes to re-charge the battery.

Travel Drive Operation

Refer to travel drive control information starting on page 61.



WARNING

Never allow anyone to enter the machine travel path and/or inside the turning radius of the machine. Signal your intention to move by sounding the horn.

Traveling should be performed with the attachment in transport position. See “Attachment Transport Position” on page 96.

Avoid sudden stops, starts or turns. Do not raise the arm rests/safety bars while traveling. Raising the arm rests/safety bars will apply the parking brake abruptly. Loss of control could result.

Do not turn the ignition keyswitch to the OFF position while traveling. Sudden braking will occur and loss of control could result.

Always check and look behind you before and while traveling in reverse. Traveling in reverse without checking and looking could result in collision with a person or obstacle.

Remove obstacles in the machine’s path before traveling with a load.

Two-Speed Drive (Option)

Machines equipped with the two-speed drive have two (high and low) travel speed ranges. See “Two-Speed Drive (Option)” on page 69 for two-speed drive control information.



WARNING

Reduce speed before shifting from two-speed to single-speed drive. Down-shifting from two- to single-speed drive while traveling at high speed may cause the machine to tip and can cause injury, loss of control and damage to the machine.

Driving on an Incline

When traveling on an incline, travel with the heavy end pointing uphill.

Driving over Rough Terrain

When traveling over rough terrain, activate the Hydraglide™ ride control system and drive slowly with the bucket lowered in the transport position (“Attachment Transport Position” on page 96). See “Hydraglide™ Ride Control System (Option)” on page 73 for details about activating Hydraglide™.

Transport on Public Roads

Refer to “Loading and Transporting the Machine on a Transport Vehicle” on page 115 if it is necessary to transport the machine a long distance. For short distance travel on public roads, attach an SMV (Slow-Moving Vehicle) emblem (purchased locally) to the back of the machine. For highway operation, install the optional flashing beacon.


Important: Follow the applicable legal regulations of the country and locality where the machine is used. Only the attachments listed in the operation license or vehicle papers are admissible for driving on public roads.

Transport Hydraulics Lock-out (Option)

When driving the machine on public roads activate the transport hydraulics lock-out on machines equipped with this option.

Position the lift arm in the transport position and press the hydraulics lock-out button (A) to deactivate the attachment lift and tilt hydraulics and prevent inadvertent lift arm movement. Pressing the button again will toggle hydraulic function back on.

Note: Attachment tilt and lift hydraulics are deactivated when LED (B) is lit.



Lift Arm Operation

Refer to lift and tilt control information starting on page 61.



WARNING

Do not lift loads exceeding rated operating capacity. See “Payloads/Capacities” on page 190.



WARNING

The float mode can be used where the engine has stopped, is unable to be started, and lowering the lift arm is necessary to allow the operator to exit the machine. See “Lift Arm Float” on page 71.


Attachment Transport Position



WARNING

Always carry loads in transport position to minimize the possibility of tipping or rollover accidents and unstable balance conditions that can cause loss of control.

Carry materials 200-300 mm (8-12”) above the ground (A, Figure 61), and adjust as necessary to clear obstacles. Generally, carry the load as low as safely possible. Tilt buckets back, as shown in Figure 61, to prevent spilling material.



Lift Arm Float



WARNING

Make sure the bucket is lowered to the ground before activating the lift arm float. Activating float with an attachment raised will cause the lift arm to fall to the ground, which can cause severe injury or death.

Do not drive forward with the lift arm float activated. Damage to the machine and/or loss of control can result.

Float allows the lowered lift arm to follow the ground contour while traveling over changing ground conditions. It is useful when grading surfaces while driving the machine in reverse.

Note: *Lift arm float is not effective if the lift arm is lowered against the chassis frame.*

See “Lift Arm Float” on page 71 for details about the lift arm float control.

Hydraglide™ Ride Control System

Hydraglide™ cushions lift arm loads during transport. It provides a smoother ride over uneven surfaces.

 **WARNING** When ride control is activated, the lift arm may drop slightly without a load, or several inches with a heavy load.

 **WARNING** Do not use Hydraglide™ when using pallet forks.

Important: *Do not use Hydraglide™ when digging. Precise control of the digging operation is difficult with the Hydraglide™ option activated.*

Note: *Hydraglide™ is not effective if the lift arm is lowered against the chassis frame.*

See “Hydraglide™ Ride Control System (Option)” on page 73 for details about Hydraglide™ control.

Changing Attachments

⚠ WARNING To prevent unexpected release of the attachment from the hitch, make sure the attachment is fully locked onto the hitch before using the attachment. On manual All-Tach® hitches, rotate the latch levers fully. On Power-A-Tach® hitches, verify that the pin flags are all the way to the outside of the hitch.


Always verify that the locking pins on the hitch are fully engaged down through the holes in the attachment frame before using the attachment. The attachment could fall off if it is not locked on the hitch and could cause serious injury or death.

Connecting Attachments

1. In an open, level area, place the attachment lock into the unlocked position (Figure 62):

- **All-Tach® system manual hitch:** Move hitch lock lever (G) all the way to the right.
- **Power-A-Tach® system quick attach hitch:** Press the Power-A-Tach® system unlock button (I) on the control keypad until safety flags (H) have moved all the way in.

2. Tilt the attachment plate forward and drive the machine straight forward toward the back of the attachment
3. Lower the lift arm so tabs (J) on the top of the attachment plate are aligned just under the hooks on the back of the attachment.
4. Tilt the attachment plate back until tabs (J) on the top of the attachment plate are engaged against the hooks on the back of the attachment.
5. Raise the lift arm slightly until the attachment is hanging from the hooks on the back of the attachment and tabs (J) are firmly inserted into the hooks. Tilt the attachment plate back, if necessary, so the back of the attachment is resting flat against the attachment plate.



6. Place the attachment lock into the locked position (Figure 63):
 - **All-Tach® system manual hitch:** Perform the “Mandatory Safety Shutdown Procedure” on page 14 and move hitch lock lever all the way to the left (G).
 - **Power-A-Tach® system quick attach hitch:** Press the Power-A-Tach® system lock button (N) on the control keypad. The safety flags (H) will move to the outside of the hitch. On 1650R models - SN 191901 and Up, the warming circuit will also be activated. If the temperature is below 0° F (-18° C) it is recommended to leave the warming circuit on.

Note: It is safe to operate the loader with the warming circuit on or off, it won't affect the performance of the loader.

7. Make sure the locking pins (F, Figure 64) are fully engaged down through the holes in the attachment.




Figure 63 – Attachment Hitch Locked

WARNING To prevent unexpected release of the attachment from the hitch, be sure the locking lever is rotated all the way to the right (as viewed while facing back at the machine from the front) and the locking pins (F, Figure 64) extend down through the attachment frame.

Locking pins (F) must be fully extended down through the holes in the attachment frame before using the attachment. The attachment could fall off if it is not locked on the hitch and cause serious injury or death.

Important: To check that the attachment is properly installed, tilt the attachment forward slightly, and apply downward pressure to the attachment before using it.





Figure 64 – Hitch Locking Pins

Disconnecting Attachments

⚠ WARNING Position the attachment so that after disconnecting, the attachment will stand safely and not tip over. Serious injury can occur if an attachment tips over onto a person.

1. Empty the attachment and drive to an open, level area to disconnect the attachment.
2. Lower the attachment to the ground.
3. Place the attachment lock into the unlocked position (Figure 65):
 - **All-Tach® system manual hitch:** Move hitch lock lever (G) all the way to the right.
 - **Power-A-Tach® system quick attach hitch:** Press the Power-A-Tach® system unlock button (I) on the control keypad until safety flags (H) have moved all the way in.
4. Lower the lift arm until tabs (J) on top of the attachment plate disengage out of hooks (K) on the back of the attachment.
5. Look behind you for bystanders and obstacles. Drive straight back in reverse away from the attachment.




Connecting Auxiliary Hydraulic Couplings

Important: Connect hydraulically-powered attachment hoses to the auxiliary circuits after the attachment is secured to the hitch.

Disconnect hydraulically-powered attachment hoses from the auxiliary circuits before removing the attachment from the hitch.

1. Empty the attachment and lower it to the ground.
2. Shut off the engine. With the ignition on, but the engine off, move the auxiliary hydraulics control rocker switch (F, Figure 66) on the right T-bar, joystick or hand control back and forth to relieve pressure in the auxiliary hydraulics circuit.
3. Turn off the ignition. Remove the ignition key and take it with you.
4. Raise the safety bars/arm rests and exit the machine using the hand holds.



5. Clean the hydraulic connections on the hoses and the connections.

6. Relieve any residual pressure remaining in the auxiliary hydraulics circuit by pushing the attachment coupler firmly into the auxiliary coupler (Figure 67).

CAUTION Route the hydraulic hoses so they do not get pinched when the attachment is tilted forward and back. Damaged or burst hydraulic hoses could result.

7. Continue to push the hose connections firmly onto the auxiliary hydraulic connections until they snap into place.

Note: Pressure build-up caused by heat in hydraulic attachments left in direct sunlight can make it difficult to connect the quick-couplers to the fittings on the attachment.



Note: The auxiliary hydraulic couplers are located on the left lift arm. When the auxiliary control switch is activated in either direction, the inside and outside couplers can be “pressure” or “return”, depending on which direction the switch is activated. The smaller center coupler is for the case drain.

Important: Always check hydraulic function of the attachment before use, to make sure the hydraulic hoses have not been installed in reverse.

Disconnecting Auxiliary Hydraulic Couplings

1. Empty the attachment and lower it to the ground.
2. Shut off the engine, but do not turn off the ignition. Move the auxiliary hydraulics control rocker switch (F, Figure 68) on the right T-bar, joystick or hand control back and forth to relieve pressure in the auxiliary hydraulics circuit.
3. Turn off the ignition. Remove the ignition key and take it with you.
4. Raise the safety bars/arm rests and exit the machine using the hand holds.
5. Push on the hose connection locking rings until the hose connections release.




Self-Leveling (Option)

Self-leveling automatically keeps the tilt angle of the attachment constant, relative to the ground plane, when the lift arm is raised (A, Figure 69). This feature is especially useful when using pallet forks.

Important: Self-leveling operates only when the lift arm is raised: when the lift arm is lowered (B), self-leveling is not activated.

Note: Self-leveling is activated by default. To deactivate self-leveling, see “Self-Leveling Cancel” on page 104.



Self-Leveling Cancel

The self-leveling cancel option allows deactivation of the self-leveling feature when equipped with this option.

To deactivate self-leveling, press the self-level cancel button (E, Figure 70) on the control pad. To restore self-leveling, press button (E) again.

***Note:** If equipped with this option, self-leveling is activated by default. If the engine is shut off, self-leveling defaults to the activated condition.*




Figure 70 – Self-Leveling Cancel Button

***Note:** Indicator (F) above button (E) is lit when the self-leveling cancel option is on and the self-leveling cancel option is on and the self-leveling feature is deactivated. This indicator will light if the unit does not have this installed option.*

Using Buckets

⚠ WARNING Read the “Safety” section in this manual, starting on page 13, before working with a bucket. Pay special attention to the “During Operation” information, starting on page 16. Always follow the information included in the “Safety” section. Serious injury or death can occur if the safety information is not followed.

Always maintain a safe distance from electric power lines and avoid contact with any electrically charged conductor or gas line. Accidental contact or rupture can result in electrocution or an explosion. Contact the “Call Before You Dig” referral system at 8-1-1 in the U.S., or 888-258-0808 in the U.S. and Canada or proper local authorities for utility line locations before starting to dig.

Make sure the bucket is securely attached to the hitch before starting work. See “Connecting Attachments” on page 98.

Avoid tilting a bucket back when the lift arm is fully raised. Material may fall over the rear of the bucket and onto the operator. If necessary, fit the rear of the bucket with a guard to prevent material from falling out of the back of the bucket.

Always carry the loaded bucket with the lift arm in the transport position. See “Attachment Transport Position” on page 96. For additional stability when operating on inclines, always travel with the heavier end of the machine toward the top of the incline.

Make sure you have a good view of the material you are digging, and of the area you will be working in.


Use extreme care when digging around foundations or walls. Never remove material that might compromise a wall or foundation.

Never push the “float” button with the bucket or attachment raised, because this will cause the lift arm to fall.

⚠ CAUTION Follow the recommendations in “Fields of Application” on page 6.

Digging with a Bucket

1. (Figure 71) Approach the digging site with the lift arm slightly raised. Tilt the bucket forward until the cutting edge contacts the ground.
2. Tilt the cutting edge of the bucket down at an angle appropriate for ground hardness.
3. Drive forward slowly, digging into the ground with the cutting edge of the bucket and gradually lower the lift arm.
4. When the bucket is full, raise the bucket and tilt it back and back away from the material.



⚠ WARNING Always carry the loaded bucket with the lift arm in the transport position. See “Attachment Transport Position” on page 96. For additional stability when operating on inclines, always travel with the heavier end of the machine toward the top of the incline.

Loading a Bucket

1. (Figure 72) Lower the bucket to the ground.
2. Tilt the bucket slightly forward so the bucket cutting edge is pointing slightly down into the ground.
3. Drive forward until the bucket is filled with material. Adjust the bucket tilt as needed to remove an even layer of ground and to reduce tire slip.
4. Tilt the bucket back and raise it to scoop up material.
5. Reduce engine speed and back out of the material.
6. Set the bucket to transport position. See “Attachment Transport Position” on page 96.




Figure 72 – Loading a Bucket

Dumping a Load onto a Pile

1. (Figure 73) Approach the pile with the bucket as low as possible.
2. Gradually stop forward motion and raise the lift arm high enough so that the bucket clears the top of the pile.
3. Slowly move forward, position the bucket over the pile and dump the material.
4. Back away from the pile while tilting the bucket back and lowering the lift arm.




Figure 73 – Dumping




WARNING

Never push the “float” button with the bucket or attachment raised, because this will cause the lift arm to fall to the ground, which can cause severe injury or death.

Loading Trucks (or Hoppers)


Important: When the self-leveling feature is on, the tilt angle of the attachment is kept constant, relative to the ground plane, when the lift arm is raised: when the lift arm is lowered however, self-leveling is not activated. See “Self-Leveling (Option)” on page 103 for more information about the self-leveling feature.

1. (Figure 74) Approach the truck and stop, allowing for clearance to raise the lift arm and loaded bucket, and raise the bucket until the lower edge of the bucket clears the truck bed.
2. Drive slowly forward and stop with the bucket over the inside of the truck.
3. Tilt the bucket forward and dump the material into the truck bed.
4. When the truck is half-loaded, use the bucket to spread the load evenly.
5. Back away from the truck while tilting the bucket back and lowering the lift arm.



Tips When Loading Trucks

- (Figure 75) The truck and machine working direction should form an angle of 45°.
- Only raise a full bucket to the height needed for dumping when you are driving in a straight line toward the truck.
- Dump with the wind behind you to keep dust away from your face, air filters and fans.



Backfilling Holes and Embankments



WARNING

Do not drive too close to an excavation or ditch. Be sure the surrounding ground has adequate strength to support the weight of the machine and the load.

1. (Figure 76) Lower the bucket a few inches from the ground. Slowly drive forward until the front edge of the bucket extends halfway over the edge of the hole or embankment.
2. Tilt the bucket forward to dump the material.
3. Tilt back and raise the bucket. Inspect the hole/embankment for proper filling.
4. Continue to dump material as necessary for proper fill.
5. Back away from the embankment while tilting the bucket back and lowering the lift arm.





Figure 76 – Backfilling

Scraping with a Bucket

Important: Always scrape in the forward direction.


1. (Figure 77) Lower the lift arm down against the chassis frame.
2. Tilt the bucket forward until the cutting edge is at a slight angle to the surface being scraped.
3. Travel slowly forward. Material can flow over the cutting edge and collect inside the bucket.
4. Tilt the bucket back and raise it to scoop up material.



Grading

Grading Without Float

1. (Figure 78) Raise the bucket slightly and tilt it forward.
2. Release material from the bucket while traveling forward.
3. Tilt the bucket forward and adjust the lift arm height until the cutting edge is slightly above the ground.
4. Drive in reverse, smoothing the material released in step 2 with the front edge of the bucket.



WARNING


Check that the work area is clear of people and obstacles. Always look in the direction of travel.

Grading Using Float

⚠ WARNING Make sure the bucket is lowered to the ground before activating the lift arm float. Activating float with an attachment raised will cause it to fall to the ground, which can cause severe injury or death.

Do not drive the machine forward with the lift arm float activated. Damage to the machine and/or loss of control can result.

1. (Figure 79) Lower the bucket to the ground.
2. Activate the lift arm float. See “Lift Arm Float” on page 96 for information about the float feature.
3. Tilt the bucket forward so it stands on the cutting edge at a 30°-45° degree angle to the surface being leveled.
4. Drive in reverse, dragging the floating bucket. Adjust the tilt angle of the bucket while driving in reverse to control the spread of the material.



⚠ WARNING Check that the work area is clear of people and obstacles. Always look in the direction of travel.

Using Pallet Forks

Safety Instructions When Working with Pallet Forks

 WARNING Read the “Safety” section in this manual, starting on page 13, before working with pallet forks. Pay special attention to the “During Operation” information, starting on page 16.

Follow all instructions in the Operator's Manual provided with the pallet forks.

Always follow the information included in the “Safety” sections. Serious injury or death can occur if the safety information is not followed.

Always approach the load from a straight-ahead position. Position the fork arms underneath the pallet, as far as they will go, so the load is distributed as closely as possible to the fork frame. Position the fork arms as far apart as possible. Load both fork arms evenly.

Lift, transport and unload loads only on firm and level ground with sufficient load-bearing capacity.

Always transport the load close to the ground as is safely possible. Observe minimum ground clearance.

Use pallet forks for material handling and/or material transport only.

Never lift a load using only one fork arm.

Make sure the fork arms are safely locked onto the fork frame before use.

Do not lift unstable material, or material that is not properly secured on the fork arms.

Never leave a machine with the forks raised or a load unattended. Make sure all persons stay clear of suspended loads.

DO NOT exceed pallet fork load center and/or lifting capacity. See “Payloads/Capacities” on page 190.

Do not use high travel speed range when using pallet forks.

DO NOT use standard fork arms as reverse (inverted) forks.

Never allow a load to get closer than 6 m (20 ft.) to overhead electrical lines.

DO NOT push, pull or shove the fork arms, or move them in at a slanting angle; the resulting lateral forces can damage the fork arms.

DO NOT pull loads off the fork arms, or allow loads to fall onto the forks arms.

DO NOT tilt the pallet forks to raise loads.

DO NOT lift or transport molten material with pallet forks.

Repair work on fork arms must be performed only by authorized personnel.

Always keep pallet fork arms clean.

Secure loads as directed in the pallet fork Operator's Manual to prevent the loads from falling.

Never modify pallet fork arms.

Do not lift or transport persons on the pallet forks.

Do not drive on public roads with pallet forks installed on the machine.

Do not stack loads which are not properly packaged or have damaged pallets/stacking containers. Do not stack loads on top of loads, which may have shifted.

Always tilt pallet forks back slightly during transport to help retain the load.

Do not use bent, cracked, or otherwise damaged fork arms/pallet forks.

Always inspect pallet forks each time before using. Refer to the pallet fork manufacturer's documentation and/or contact the pallet fork manufacturer for information regarding safe pallet fork condition criteria:

- Check the fork arm locks for proper function and/or damage. Do not use pallet forks with damaged locks or locks that do not function properly.**
- Visually check the fork arm hooks and/or bends for cracks and/or deformations. Do not use fork arms that are cracked and/or have deformations that make the fork arms unsafe.**
- Do not use fork arms that have bends or blades that have more than 10% of the original material worn away.**
- Check the fork arms blades and tips for deformations or holes.**

Transporting Loads Using Pallet Forks

Important: When the self-leveling feature is on, the tilt angle of the attachment is kept constant, relative to the ground plane, when the lift arm is raised. When the lift arm is lowered however, self-leveling is not activated. Refer to “Self-Leveling (Option)” on page 103 for more information about the self-leveling feature.

Loading Pallet Forks

1. Stop the machine immediately in front of the material.
2. Position the fork arms parallel to the ground.
3. Make sure the fork arms are adjusted as far apart as possible, as allowed by the load, and are both the same distance away from the center-line of the load.
4. Adjust the height of the fork arms to fit the lifting area at the bottom of the pallet.
5. Drive slowly and carefully forward until the fork frame contacts the material.
6. Make sure the pallet is evenly and safely positioned on the pallet fork arms.

Lifting Loads Using Pallet Forks

7. Apply the parking brake.
8. Slowly raise the pallet forks. Do not raise the pallet forks any higher than required. Make sure to not exceed pallet fork load center and/or lifting capacity.
9. Lower the load immediately if you are unsure of the load, the equipment, or in case of any unsafe circumstances.
10. Tilt the pallet fork frame back slightly, to help retain the load.

Transporting Load Using Pallet Forks

11. Make sure the area around and behind the machine is clear of bystanders and obstacles.
12. Slowly and carefully drive in reverse and lower the pallet forks to transport position (“Attachment Transport Position” on page 96), when it is safe to do so.
13. Carry the load as low as safely possible during transport. Observe minimum ground clearance. Refer to “Attachment Transport Position” on page 96.
14. Drive slowly and carefully forward straight toward the place where the load will be set down.

Setting Down Loads Using Pallet Forks

Note: If the load will be placed on top of stacked material, make sure to align the load in the center of the stack.



WARNING

Do not stack loads which are not properly packaged or have damaged pallets/stacking containers. Do not stack loads, or on top of loads, which have shifted.

15. Raise the pallet forks slightly above where the load will be placed.
16. Tilt the pallet forks as needed to level the fork arms.
17. Carefully drive slowly forward until the load is positioned precisely above where the load will be placed. Use care when aligning the load with a stack.
18. Slowly and carefully lower the lift arm until the load is placed.
19. Make sure the fork arms are no longer bearing weight and are free to be retracted.
20. Make sure the area around and behind the machine is clear of bystanders and obstacles.
21. Slowly and carefully drive in reverse away from the placed load until the lift arm can be lowered to transport position. See “Attachment Transport Position” on page 96.
22. Slightly tilt the pallet fork frame backwards.

Loading and Transporting the Machine on a Transport Vehicle

 **WARNING** Park the transport vehicle on a level surface. Be sure the vehicle and its ramps have the weight and size capacity to support the machine. Make sure the driver of the transport vehicle knows the overall height, width and weight of the vehicle, including the loaded machine, before starting transport. See “Weights” on page 189.

Make sure the load does not fall short of the minimum axle load of the steering axle, otherwise the transport vehicle’s steering could be seriously affected.

Make sure the transport surface and the loading ramps are clear of debris and slippery material that may reduce traction.

Secure the loading ramps to the transport vehicle before loading. Position the loading ramps at the shallowest possible angle. Do not exceed an angle of 15°. Only use ramps with anti-skid surfaces. Move the machine on and off the vehicle ramp slowly and carefully.

Position the machine at the lowest possible position on the transport platform, with the center of gravity of the load over the centerline of the transport vehicle. Distribute partial loads to ensure an even load across the axles of the transport vehicle.

Secure the machine properly so it cannot move during transport. Consider all possible transport conditions such as: heavy braking, evasive maneuvers, and uneven or rough roadways. Always use the proper tie-down points when using straps and chains. See “Machine Orientation” on page 3.

Failure to follow these instructions could result in an overturn accident.


***Important:** Observe all local regulations governing the loading and transporting of equipment (Reference: U.S. Federal Motor Carrier Safety Regulations, Section 392). Ensure that the hauling vehicle meets all safety requirements before loading the machine.*

1. Park the transport vehicle on a level surface. Block the front and rear tires on the transport vehicle.
2. Before starting, check the engine oil level. The oil level must be at the “Full” mark on the dipstick. Add oil if needed. See “Checking Engine Oil Level” on page 137.

***Important:** When loading and driving on ramps, the engine can be damaged if the engine oil level is too low.*

3. Start the engine and raise the hitch plate/attachment enough so that it will not touch the loading ramps.

4. Slowly and carefully drive in reverse up the ramp onto the transport vehicle.
Important: Do not adjust travel direction while traveling on the ramps. Instead, drive down off of the ramps, and re-align the machine with the ramps.
5. Position the machine at the lowest possible position on the transport platform, with the center of gravity of the load over centerline of the transport vehicle.
6. Lower the hitch plate/attachment to the transport platform, turn off the engine and remove the key.
7. Raise the operator restraint bar to lock out the hydraulic functions. If applicable, close the cab door and lock it. Do not allow anyone to stay in the cab.
8. Fasten the machine to the hauling vehicle at the points indicated by the tie-down decals (Figure 80).
9. Place blocks in front and behind wheels to prevent movement.
10. Measure the clearance height of the machine and transport vehicle. Post the clearance height in the cab of the transport vehicle.



Note: Before transporting the machine through heavy rain, close off the exhaust pipe with a cap or suitable adhesive tape.

Towing

WARNING Towing the machine is not recommended as a means of transportation.

Note: The machine may be equipped with an optional brake release. Refer to “Brake Release Operation (Option)” on page 91 for more information.

Use the tie-down/retrieval point in situations where lifting the machine is not possible and the overall distance the machine must be moved is less than 100 feet (30.5 m). Retrieve/tow the machine at 6 mph (10 kph) or less.

Connect the towline to both tie-down/retrieval points at the front or the rear of the machine. Use of only a single retrieval point or connecting the towline to any point on the machine other than a designated tie-down/retrieval location could damage the machine.

Important: Towline capacity must be at least 1.5 times the gross weight of the machine. Towline length cannot allow the maximum towing angle to exceed 20°.

Note: Tow the machine for short distances only, such as towing it onto a trailer.

Lifting the Machine Using a Crane or Hoist

***Note:** Single-point and four-point lift kits are available for lifting the machine. Contact your dealer for more information.*



Contact your dealer for available lift kits for the machine. Do not lift the machine without an approved lift kit installed.

Before lifting, check the lift kit for proper installation. Securely fasten the lifting gear to the machine at the designated lift points.

When using any lift kit, follow the directions included with the lift kit.

Never allow riders in the operator's compartment while the machine is lifted.

Keep clear of suspended loads. Keep everyone a safe distance away from the machine while it is lifted.

The machine may only be crane-lifted with an empty bucket, empty pallet forks, or with no attachment. Never lift the machine with any other attachment installed. Never lift the machine with a load in the bucket or on the pallet forks.

Lift equipment used and its installation is the responsibility of the party conducting the lift. All rigging **MUST** comply with applicable regulations and guidelines.

1. If a bucket is attached, make sure it is emptied. If pallet forks are attached, remove any load from the pallet forks.
2. Raise the arm rests/safety bars to apply the parking brake and lock out the hydraulic functions.
3. Turn off the engine and remove the ignition key. Close the doors and the engine cover. Do not allow anyone to stay in the cab.
4. Using suitable lift equipment, hook into the lift kit lifting points. Adjust the length of the slings or chains so the machine is level when lifted.

***Note:** The machine may be slightly off level (10 degrees max.) when lifted.*

5. Center the hoist over the ROPS/FOPS. To prevent shock loading of the equipment and excessive swinging, slowly lift the machine off the ground. Perform all movements slowly and gradually. As needed, use a tag line to help position the machine and keep it from swinging.

Diesel Particulate Filter (DPF) Regeneration Procedures

The Diesel Particulate Filter (DPF) treats exhaust emissions in compliance with Tier 4 emission standards. The DPF filter relies on high exhaust temperatures. Periodic DPF maintenance (regeneration) is required, dependent upon machine operation load / temperature.

***Note:** Machines operated primarily at high loads and operating temperatures require less frequent DPF maintenance. Extended periods of engine idling rapidly increases DPF soot levels, requiring more frequent regeneration operations.*

There are 3 modes of DPF regeneration:

- **Passive / Assist Regeneration:** Occurs automatically without operator input. Passive/assist regeneration does not affect machine operation.
- **Reset Regeneration:** Occurs automatically, but can be inhibited by the operator. Increases exhaust gas temperatures. Reset regeneration occurs approximately every 100 hours of operation. See “Reset Regeneration” on page 119.

***Note:** Reset regeneration effectiveness is improved if the machine is operated at mid- to high-throttle settings when reset regeneration mode is in progress.*

- **Stationary Regeneration:** Requires operator action to initiate and takes approximately 25-30 minutes to complete. See “Stationary Regeneration” on page 120.

***Important:** The machine cannot be operated and must be parked in a well-ventilated area away from flammable materials when stationary regeneration is in progress.*

 **WARNING** There is a possibility of carbon monoxide poisoning if stationary regeneration occurs in an enclosed space. Always perform stationary regeneration in a well-ventilated area.

 **WARNING** During regeneration, there will be high exhaust gas temperatures, even at low load. Stay clear of the DPF during regeneration.

Reset Regeneration

Important: Reset regeneration can be prevented from occurring. See “Reset Regeneration Inhibit” on page 119.

Reset regeneration occurs automatically (unless inhibited) approximately every 100 hours of operation.

Note: Reset regeneration effectiveness is improved if the machine is operated at mid- to high-throttle settings while regeneration is in progress.

When reset regeneration occurs, the DPF in-progress (elevated temperature) symbol <3> (K, Figure 81) displays on the screen.




Figure 81 – Reset Regeneration In-Progress

Reset Regeneration Inhibit

DPF regeneration inhibit prevents reset regeneration from occurring.

CAUTION Permanently inhibiting regeneration is not recommended, as this will eventually cause significant reduction in engine power and will force premature DPF soot filter replacement.

To temporarily inhibit reset regeneration, hold down button (U, Figure 82) until the strikethrough in the Reset Regeneration symbol (W) turns to red.

Note: DPF in-progress (elevated temperature) symbol <3> (K, Figure 81) will not be displayed when reset regeneration is inhibited.




Figure 82 – Reset Regeneration Inhibit Button

Stationary Regeneration

Stationary regeneration may be periodically required to reduce DPF soot build-up. The frequency of stationary regeneration is dependent upon machine operation and engine load.

The machine cannot be used during stationary regeneration and cannot be moved without interrupting the stationary regeneration process.

When stationary regeneration needs to be performed, the regeneration request screen (Figure 83) displays on the information center electronic display.




Figure 83 – Stationary Regeneration Request Screen

Note: The stationary regeneration request screen can be temporarily dismissed by pressing the reset regeneration inhibit button (U, Figure 82) for 3 seconds. Until the previous screen displays. The stationary regeneration request screen will return 1 minute after being dismissed, for as long as the request remains active.

Important: Perform stationary regeneration as soon as possible when the stationary regeneration request screen displays. Postponing stationary regeneration for extended periods will cause significant reduction in engine power and will force premature DPF filter core replacement.

To proceed with stationary regeneration (Figure 84):

1. Park the machine in a safe, well-ventilated location away from flammable materials.
2. The following conditions need to be met before stationary regeneration continues:
 - A. Press the (P) button on the control keypad (page 48) or lift the operator restraint bar to apply the parking brake. A checkmark is displayed next to the parking brake symbol (A).
 - B. When engine coolant has reached operating temperature (above 140° F / 60° C, a checkmark is displayed next to the coolant temperature symbol (B).
 - C. Place throttle controls to the lowest speed setting. A checkmark is displayed next to the engine RPM symbol when the engine is running at low idle.





Figure 84 – Stationary Regeneration

- When all three checkmarks (A, B & C) are displayed on the Stationary Regeneration screen, press and hold the button (Z) until the Stationary Regeneration In-Progress screen displays (Figure 85)

Note: Stationary regeneration can be interrupted at any time by releasing the parking brake, advancing the throttle, or stopping the engine. Stationary regeneration must start again from the beginning if it is interrupted.



Stationary regeneration completion percentage is displayed as during the stationary regeneration progresses. Progress percentage disappears when stationary regeneration completes.

Note: Stationary regeneration takes approximately 25-30 minutes.


CAUTION It is not necessary to stay in the machine during stationary regeneration. Keep the machine under observation while regeneration is in progress in case of malfunction. Keep bystanders away from the machine while regeneration is in progress.

Forcing Stationary Regeneration

Stationary regeneration can be performed at any time after 50 operating hours following the previous stationary regeneration.

To perform stationary regeneration on-demand:

Press button (Y, Figure 86) associated with the DPF regeneration symbol (X), until the regeneration screen displays. Refer to “Stationary Regeneration” on page 120 to proceed with stationary regeneration.



DPF Maintenance

DPF soot filter replacement is required when the DPF (Diesel Particulate Filter) Service Screen (Figure 87) displays.

Note: Contact your dealer when the DPF Service screen displays.




Figure 87 – Stationary Regeneration In-Progress Screen

Camera Observation System

A camera observation system is optionally available on all models. The camera observation system utilizes a rear-facing camera mounted within the rear door of the machine to provide full visibility to the region behind the machine of which portions of that region may otherwise be masked by the machine's structure.

The camera system is configured to turn on automatically when the machine's ignition switch is moved to the "ON" position. The camera image is displayed on the monitor which is centered above the front door opening of the operator's compartment.

The vertical viewing angle of the monitor is adjustable by loosening the knobs positioned on either side of the monitor. Prior to operating the machine the operator should check the monitor to verify that the monitor is positioned at the optimum viewing angle for them.

As an integral safety feature of the machine it is important for the operator to verify that the camera system is operating properly prior to moving the machine. A camera system that is operating properly will display a sharp image that is free of any obstructions when the key is switched on. The displayed image should be centered on the area directly behind the machine. If the displayed image does not meet this criteria the following system checks can be made:

- While the system is configured to power up automatically upon key on, depress the system power button at the display to see if the system powers up.
- Verify that the electrical connections to the monitor and camera are intact. This includes checking the A/V cable connection into the rear of the monitor and the camera connection to the camera extension cable located in the engine compartment in close proximity to the rear door hinges.
- Roll back the ROPS/FOPS and check the camera system harness connections forward of the engine flywheel housing. The connection of the camera system power harness to

the accessory power connections in the chassis harness are located in this region. Verify that these connections are intact.

- Remove the right A-pillar cover within the ROPS/FOPS and locate the fuse holder in the camera system power harness located therein. Verify that the two Amp fuse within is intact and fully inserted into the fuse holder terminals.
- If the monitor displays a picture but that picture is not bright and clear, verify that the camera lens is clean and that the camera is properly aligned with the aperture in the rear door. The mounting brackets allow for left/right, up/down, and fore/aft adjustment. When making adjustments, ensure that the resulting pictures displayed on the monitor squarely shows the area behind the loader.

Additional troubleshooting measures are detailed in the camera observation system manual for instructions on how to correct any issues.

If the camera system is not able to be made functional after these initial checks, contact your dealer for service. A camera system that is unable to provide a clear image of the rear of the machine should be considered disabled and the machine should not be operated until the camera is made to function properly again.

Back-Up Alarm

A back-up alarm system is optionally available which serves to warn people working in the area around the machine of the machine's rearward movement. The back-up alarm is installed within the engine compartment on the inside surface of the rear door. The alarm emits a tone whenever the machine begins to move in the rearward direction.

CHAPTER 6

MAINTENANCE



WARNING

Read and understand the “Safety” Chapter in this manual, starting on page 15, before servicing the machine. Follow all applicable warnings and instructions. Check for correct function after performing maintenance. Failure to follow instructions can result in injury or death.

BEFORE performing any maintenance, perform the “Mandatory Safety Shutdown Procedure” on page 14.

Fluid leaks from hydraulic hoses or pressurized components can be difficult to see, but pressurized oil can have enough force to pierce the skin and cause serious injury. Always use a piece of wood or cardboard to check for suspected hydraulic leaks. Never use your hands. Obtain immediate medical attention if pressurized oil pierces the skin. Failure to obtain prompt medical assistance could result in gangrene or other serious damage to tissue.

Do not smoke or allow any open flames in the area while checking or servicing the hydraulic, battery and fuel systems because all contain highly flammable liquids or explosive gases, which can cause an explosion or fire if ignited.

Wear a face shield when disassembling spring-loaded components or working with battery acid. Always wear eye protection to protect eyes from electric arcs from shorts, fluids under pressure, and flying debris or loose material. Wear a helmet or goggles with special lenses when welding or cutting with a torch.

When working beneath a raised machine, always use blocks, jack-stands or other rigid and stable supports. Wear appropriate protective clothing, gloves and shoes. Keep feet, clothing, hands and hair away from moving parts.

Always apply the lift arm support when maintenance work requires the lift arm in the raised position. See “Lift Arm Support” on page 44.



WARNING

NEVER weld on the machine without consulting the manufacturer. Special metals may be used, which require special welding techniques or parts may be designed so that they should not be welded. **NEVER** cut or weld on fuel lines or tanks.

If repair welding is ever required, remove the positive (+) battery terminal connection before starting to weld. Be sure to attach the negative ground (-) cable from the welder as close as possible to the area to be repaired.

Allow only trained and authorized personnel, with full knowledge of safe procedures, to perform maintenance on the machine.

If any guards, shields and covers were removed during maintenance, **BE SURE** to replace them in their original positions **BEFORE** starting the machine.



CAUTION

Do not use the machine when maintenance is due. Postponed maintenance can result in a serious reduction of the service life of the machine, costly equipment failures, and contribute to unsafe operating conditions.

Do not perform maintenance or service not included in this manual. Maintenance and service not included in this manual should be performed only by an authorized repair shop.

Proper care and maintenance improves machine operational readiness and service life.

Perform maintenance as indicated in “Maintenance Schedules” on page 127, or earlier if required by conditions.

The “Maintenance Schedules” on page 127 were developed to match maintenance information in this manual. Detailed information about each maintenance procedure is located later in this chapter.

***Note:** Refer to the hour meter in the information center electronic display to determine maintenance interval timing. See “Information Center Electronic Display Screens” on page 56.*

Log all maintenance when it is performed in the “Maintenance Log” on page 129. Recording 10-hour or daily service intervals is impractical and is not recommended.

***Important:** Under severe operating conditions, more frequent service than the recommended intervals may be required.*

Maintenance Schedules

Table 14: Inspection, Checks and Cleaning

Service Procedure	Maximum Interval		
	10 Hours (or Daily)	250 Hours	500 Hours (or Annually)
Remove foreign material (page 133).	X		
Check engine air cleaner restriction indicator (page 143).	X		
Check for loose or missing parts; repair/replace if necessary.	X		
Check engine oil level and condition (page 137).	X		
Check fuel level and fill if necessary (page 139).	X		
Check hydraulic oil level and condition (page 137).	X		
Check coolant level and condition (page 137).	X		
Check cooling system for dirt and debris (page 145).	X		
Check water separator; drain water, if present (page 140).	X		
Check windshield washer system and wiper blade, if applicable (page 158).	X		
Check tire pressures (page 153).	X		
Check bucket cutting edge (page 152).	X		
Test safety interlock system (page 42).	X		
Check hydraulic cylinder piston rods for damage/wear; clean if necessary.	X		
Check ROPS/FOPS structure – all fasteners must be installed and tightly secured.	X		
Check hydraulic hoses and tubes for cracks and/or debris (page 146).	X		
Grease hitch, hitch-related cylinder pivots and latch pins (page 132).	X		
Grease lift arm pins (page 132).	X		
Check wheel fastener torque (page 153).	X ^a	X	
Check oil level in chaincases (page 151).		X	
Check drive chain tension (page 152).		X	
Check alternator/fan belt tension and condition (page 144).		X	
Check battery (page 157).			X
Check engine mounting hardware (page 137).			X

- a. Check wheel fastener torque before initial operation and every two hours until the wheel mounting hardware torque stabilizes. Check wheel nut torque every 250 hours thereafter. "Wheel Nuts" on page 153.

Table 15: Leakage Check

Service Procedure	Maximum Interval		
	10 Hours (or Daily)	250 Hours	500 Hours (or Annually)
Check engine for oil/coolant leaks.	X		
Check cooling system for leaks.	X		
Check hydraulic system for leaks.	X		

Table 16: Lubrication and Filter Changes

Service Procedure	Maximum Interval			
	10 Hours (or Daily)	250 Hours (or every 6 months)	500 Hours	1000 Hours (or Annually)
Lubricate grease fittings according to lubrication diagram (page 132).	X			
Change hydraulic oil filter (page 149).			X	
Change engine oil and filter (page 137).			X ^b	
Change cab air filter, if applicable (page 148).		X ^a		X
Lubricate all levers, cables and hinges.		X		
Change outer air cleaner filter element. Check and change inner air cleaner element if necessary (page 143).		X ^a		
Change chaincase oil (page 151).				X
Change hydraulic oil (page 149).				X
Change main fuel filter (page 142)			X ^c	
Change water separator filter (page 140)			X	
Change coolant (page 145).				X

a. Replace if needed.

b. 1650R Non-DPF machines require a 250 hour engine oil change interval.

c. Non-DPF machines require a 250 hour main fuel filter change interval.

Table 17: Functional Check

Service Procedure	Maximum Interval		
	10 Hours (or Daily)	250 Hours	500 Hours (or Annually)
Check seat belt (page 133).	X		
Check service and parking brake function.	X		
Check joystick operation.	X		
Check windshield wipers, if applicable.	X		

Table 17: Functional Check

Service Procedure	Maximum Interval		
	10 Hours (or Daily)	250 Hours	500 Hours (or Annually)
Check control switches/buttons, indicators and audible warning devices.	X		
Check lighting systems.	X		

Maintenance Log

Log maintenance when it is performed in the following table.

Table 18: Maintenance Log

[illegible]

Table 18: Maintenance Log


[illegible]

General Lubrication

Important: Use of lubricants not corresponding to manufacturer recommendations may invalidate warranty claims. Always dispose of waste lubrication oils and hydraulic fluids according to environmental laws or take to a recycling center for proper disposal. DO NOT pour fluids onto the ground or down a drain.

See “Fluid Capacities/Lubricants” on page 187 for proper grease specifications. Wipe dirt from the fittings before and after applying grease to prevent contamination. Replace any missing or damaged fittings. Avoid excessive greasing to minimize dirt build-up.

Lubricate Daily or After Every 10 Hours of Operation



- A. Front lift cylinder grease fittings (2).
- B. Top lift arm grease fittings (2).
- C. Back lift cylinder grease fittings (2).
- D. Attachment hitch pivot points (2) – NOTE: Lubricate (D) from inside of pin.
- E. Bottom tilt cylinder grease fittings (2).

Removing Foreign Material

Remove dirt and other foreign matter from the following areas daily before operating the machine:

- Around the lift cylinders.
- At the front of the machine.
- On the attachment hitch, especially around the tilt cylinder.
- Around hydraulic oil reservoir breather.
- In the engine compartment.
- In the operator's compartment.

Important: Build-up of foreign materials in these areas can interfere with machine operation, cause component damage or become a fire hazard.

Tilting the ROPS/FOPS


⚠ WARNING Never operate the machine with the ROPS/FOPS in the raised position or removed. Be sure to reinstall the anchor bolts, washers and locknuts before using the machine. Torque to 43 Nm (32 lb-ft).

Always close the cab door before tilting the ROPS/FOPS. Stay clear from underneath the ROPS/FOPS as it is tilted.

Be sure the lock is securely engaged when the ROPS/FOPS is raised. Properly support the ROPS/FOPS when unlatching the lock mechanism and lowering the ROPS/FOPS.

Raising the ROPS/FOPS

1. Perform the “Mandatory Safety Shutdown Procedure” on page 14.
2. Remove hardware (A, Figure 88) at the front of the ROPS/FOPS.



**Figure 88 – ROPS/FOPS
Anchor Hardware**

3. Tilt the ROPS/FOPS up and back, moving the control handles out of the way. Tilt the ROPS/FOPS back slowly, until locking mechanism (B, Figure 89) locks the ROPS/FOPS in the raised position.

***Note:** A gas-charged spring helps balance the ROPS/FOPS as it tilts. A self-actuating lock mechanism engages to lock the ROPS/FOPS in the tilted position.*




Figure 89 – ROPS/FOPS Lock Mechanism

Lowering the ROPS/FOPS

1. Lift the ROPS/FOPS slightly while pulling lock mechanism release (C, Figure 90) toward the front.
2. Lower the ROPS/FOPS slowly onto the chassis, moving the control handles out of the way.
3. Secure the ROPS/FOPS in the lowered position with anchor hardware (A, Figure 88). Torque to 43 Nm (32 lb.-ft.).




Figure 90 – ROPS/FOPS Lock Mechanism Release

Lifting the Machine

Use the following procedure to raise the machine so all four tires are off the ground for service:

⚠ WARNING Do not rely on a jack or hoist to hold the machine in the lifted position without additional blocking and supports. Serious personal injury could result from improperly lifting or blocking the machine.

1. Use suitable blocks (solid wood, hard plastic or metal) or jackstands to properly block the machine so all four tires are raised off the ground.
2. Using a jack or hoist with a capacity greater than the fully-equipped weight of the machine (with all attached options), lift the rear of the machine until the rear tires are off the ground.

Important: Be sure the lifting apparatus is of sufficient capacity for the weight of the machine. Refer to “Weights” on page 93. If lifting the machine, refer to “Lifting the Machine Using a Crane or Hoist” on page 117.

3. Stack blocks or place jackstands under the flat part of the chassis. Blocks should run parallel with, but not touch, the rear tires.
4. Slowly lower the machine until it rests on the blocks/jackstands. If the tires still touch the ground, raise the machine, add more blocks or raise the jackstands and lower the machine onto the blocks.
5. Repeat this procedure for the front tires. When complete, all four tires will be off the ground so they can be removed.

Lowering the Machine

1. Using a jack or hoist, raise the front of the machine until it no longer rests on the front blocks or jackstands.
2. Carefully remove the blocking under the front of the machine.
3. Slowly lower the machine until the front tires are resting on the ground.
4. Repeat this procedure for the rear tires. When complete, all four tires will be on the ground with the blocks removed from under the machine.



Figure 91 – Lifting Machine

Engine Access

1. Lift the engine cover and pull the rear door latch (Z, Figure 92) up.
2. Carefully swing open the rear door.

Note: Rear door prop (Y) near the top hinge pin of the door is used to secure the door open.




Figure 92 – Engine Compartment Access

3. Additionally, the radiator swings out, providing greater access to the engine:
 - a. Pull down on spring pin lock (C, Figure 93) to release pin (D). Lift pin (D) out of the bracket.
 - b. Swing the radiator outward.
 - c. When engine maintenance is complete, return the radiator back to the closed position and secure it in place with pin (D). Lock pin (D) in the bracket with spring pin lock (C).




Figure 93 – Radiator Latch

Engine Mounting Hardware Inspection

⚠ WARNING Perform the Mandatory Safety Shutdown Procedure. Allow hot engine and hydraulic system components to cool before servicing.

All bolts that secure the engine mounting brackets to the engine and the chassis should be checked and re-tightened as necessary.

Checking Engine Oil Level

Check the engine oil level daily before starting the machine, or after every 10 hours of use.

1. Park the machine on a level surface.
2. Perform “Mandatory Safety Shutdown Procedure” on page 14.
3. Wait until the engine has cooled.
4. Open the engine access cover and rear door.
5. Twist engine oil dipstick (E, Figure 94) counterclockwise to unlatch it. Remove the dipstick from the engine.
6. Wipe the dipstick with a clean cloth and replace it in the engine. Push it in until it is fully inserted.
7. Remove the dipstick again. The oil level should be within the “Add” (G) and “Full” (H) markings.
8. If the oil level is below the “Add” marking:
 - a. Clean the area around the oil fill cap (F) with a clean cloth.
 - b. Remove fill cap (F).
 - c. Add oil through the fill cap opening until the level reaches the “Full” mark.
 - d. Replace and tighten fill cap (F).




Figure 94 – Engine Oil Dipstick and Fill Cap

Important: Do not over-fill the engine with oil; engine damage could result.

Changing Engine Oil and Filter

Refer to the “Maintenance Schedules” on page 127 for the service interval for replacing the engine oil and filter.

1. Park the machine on a level surface.
2. Perform “Mandatory Safety Shutdown Procedure” on page 14.

3. Wait until the engine has cooled, but is not completely cold.

Note: Oil drains faster and more completely when warm.

4. All machines except model 1650R:

Remove the rear belly pan to access engine oil drain plug (X, Figure 95).

5. Position a waste oil collection container under the engine oil drain plug to catch draining oil.

Note: On model 1650R machines, engine oil drain plug (A, Figure 96) is located inside the left rear wheel well, on the outside of the chassis behind the rear wheel.



Figure 95 – Engine Oil Drain Plug

Important: Dispose waste engine oil according to environmental laws, or take to a recycling center for proper disposal. DO NOT pour waste engine oil onto the ground or down a drain.



Figure 96 – Model 1650R Remote Engine Oil Drain Plug Location

6. Remove drain plug (X) or (A) and allow engine oil to drain into the waste oil collection container.
7. Remove oil filter (W, Figure 97), using a filter wrench if necessary. Carefully clean the filter head mounting surface with a clean cloth.



Figure 97 – Engine Oil Filter

8. Put clean oil on the new oil filter gasket. Install the filter and tighten 3/4 of a turn past the point where the gasket contacts the filter head.
9. Reinstall and tighten the drain plug.

10. Clean the area around oil fill cap (E, Figure 94). Remove oil fill cap (E) and add the recommended type and amount of oil. See “Fluid Capacities/Lubricants” on page 187. Replace and tighten oil fill cap (E) after the oil is added.

***Note:** Oil capacity listed is approximate. Always verify proper oil level with the engine oil dipstick.*

Important: Do not over-fill the engine with oil; engine damage could result.

11. Start the engine and let it run for several minutes at low idle. Watch for leaks at the oil filter and drain plug. Stop the engine and wait for it to cool.
12. Check the oil level. Add oil if necessary until the oil level is at the “Full” mark (H, Figure 94) on the dipstick.

Fuel System Maintenance

 **WARNING** Diesel fuel is flammable. Keep the machine away from open flames. Do not smoke when refueling or when working on the engine. Stop the engine before fueling.

Wear eye protection. The fuel system is under pressure and fuel could spray out when removing any fuel system component.

Wipe up spills immediately. NEVER use a shop rag to catch draining/leaking fuel. Vapors from the rag are flammable and explosive.

Failure to follow these instructions can cause fire and result in injury or death.

 **CAUTION** Use only proper types and grades of diesel fuel (See “Fluid Capacities/Lubricants” on page 187).

***Note:** The fuel tank is filled at the factory with United States off-road grade diesel fuel, which is dyed red for identification. It may take several fillings of the fuel tank before the red dye is purged from the fuel system.*

Adding Fuel

 **WARNING** Keep open flames and sparks away from fuel. Static electricity can produce dangerous sparks at the fuel-filling nozzle. Do not wear polyester, or polyester-blend clothing while fueling. Before fueling, touch the metal surface of the machine away from the fuel fill to dissipate any built-up static electricity. Do not re-enter the machine but stay near the fuel filling point during refueling to minimize the build-up of static electricity. Do not use cell phones while fueling. Make sure the static line is connected from the machine to the fuel truck before fueling begins.

Ultra-Low Sulfur Diesel (ULSD) poses a greater static ignition hazard than earlier diesel formulations. Avoid death or serious injury from fire or explosion; consult with your fuel or fuel system supplier to ensure the entire fuel delivery system is in compliance with fueling standards for proper grounding and bonding practices.

1. Perform the “Mandatory Safety Shutdown Procedure” on page 14.
2. Lift the engine cover.
3. Using the ignition key to unlock fuel cap (F, Figure 98) and remove the fuel cap from the fuel filler neck.

Note: On Model 1350R, fuel cap (F) is located under the engine cover.

4. Fill the fuel tank by adding fuel through the fuel filler neck opening.

Important: See “Fluid Capacities/ Lubricants” on page 187 and the engine operation manual for proper fuels. Use of improper fuels can cause engine damage.

5. When the fuel tank is full, replace and lock fuel cap (F) in the fuel filler neck opening.

Important: To provide for proper fuel system venting, do not top off the fuel tank.



Water Separator Maintenance



WARNING

NEVER service the fuel system while smoking, while near an open flame, or if the engine is hot.

Important: Water in the fuel system can cause severe engine damage. Drain water from the fuel filter/water separator whenever water is present.

Inspect the water separator daily, or every day before using the machine.

1. Perform the “Mandatory Safety Shutdown Procedure” on page 14.
2. Wait until the engine has cooled.

3. Inspect the water separator (Figure 99) for the presence of water:
 - If the indicator ring (M) is at the bottom of the cup, no action is required.
 - If the indicator ring (M) is floating off the bottom of the cup, water is present and needs to be drained.
4. If water needs to be drained, position a suitable collection container underneath the water separator drain.
5. Turn the fuel valve lever (V) on the water separator to the OFF position.
6. Loosen drain plug (N) at the bottom of the water separator. Allow water to drain until indicator ring falls to the bottom of the cup.




Figure 99 – Water Separator

7. Tighten drain plug (N) and discard fuel/water according to environmental laws.

Important: *Dispose waste fuel according to environmental laws. DO NOT pour fuel onto the ground or down a drain.*

8. Turn the fuel valve lever (V) on the water separator to the ON position.
9. Prime the fuel system by turning the ignition key to the ON position without starting the engine for 30 seconds. Repeat this step 3 times to ensure the fuel system is completely primed.

⚠ CAUTION Do not use the starter motor to crank the engine to prime the fuel system. Damage to the engine starter motor, coils, pinion/ring gear could result.

10. Start the engine and check for leaks.

Changing Water Separator Filter

⚠ WARNING NEVER service the fuel system while smoking, while near an open flame, or if the engine is hot.

1. Perform the “Mandatory Safety Shutdown Procedure” on page 14.
2. Wait until the engine has cooled.
3. Turn the fuel valve lever (V, Figure 99) on the water separator to the OFF position.
4. Unscrew the separator bowl from the housing and pull down on the existing filter to release it from the housing.
5. Install a new filter and reinstall the bowl.
6. Turn the fuel valve lever (V) on the water separator to the ON position.

7. Prime the fuel system by turning the ignition key to the ON position without starting the engine for 30 seconds. Repeat this step 3 times to ensure the fuel system is completely primed.

⚠ CAUTION Do not use the starter motor to crank the engine to prime the fuel system. Damage to the engine starter motor, coils, pinion/ring gear could result.

8. Start the engine and check for leaks.

Changing Fuel Filter

⚠ WARNING NEVER service the fuel system while smoking, while near an open flame, or if the engine is hot.

Refer to the “Maintenance Schedules” on page 127 for the service interval for replacing the fuel filter.

1. Perform the “Mandatory Safety Shutdown Procedure” on page 14.
2. Wait until the engine has cooled.
3. Turn fuel valve lever (V, Figure 100) on the water separator to the OFF position.




Figure 100 – Water Separator

4. Remove the fuel filter (W, Figure 101), using a filter wrench if necessary. Carefully clean the filter head mounting surface with a clean cloth.
5. Apply a coating of clean diesel fuel on the new fuel filter gasket. Install the filter and tighten 3/4 rotation past the point where the gasket contacts the filter head.
6. Turn fuel valve (V, Figure 100) on the water separator to the ON position.




Figure 101 – Fuel Filter

7. Prime the fuel system by turning the ignition key to the ON position without starting the engine for 30 seconds. Repeat this step 3 times to ensure the fuel system is completely primed.



CAUTION

Do not use the starter motor to crank the engine to prime the fuel system. Damage to the engine starter motor, coils, pinion/ring gear could result.

8. Start the engine and check for leaks.

Engine Air Cleaner

Important: Failure to follow proper air filter servicing instructions could result in catastrophic engine damage.

Do not operate the engine without the air cleaner components installed or damage to the engine could occur.

Check the air cleaner intake hose and clamps, and the mounting bracket hardware daily to be sure they are properly tightened.

Check, and if necessary replace, the engine air filter after every 250 hours of use, or every 6 months, or if the filter is damaged, oil- or soot-laden.

Be sure the air cleaner intake hose, clamps and mounting bracket hardware are properly tightened.

Changing Air Filter Elements

1. Perform the “Mandatory Safety Shutdown Procedure” on page 14.
2. Wait until the engine has cooled.
3. Unlatch clamps (J, Figure 102) on the air cleaner housing and remove the air filter cover (L).
4. Clean debris from inside the air cleaner housing and air filter cover.
5. Carefully remove the outer filter element (G).
6. Clean dirt from inside the air filter housing (M).
7. Remove inner filter element (H) only if it needs replacement.




Figure 102 – Engine Air Cleaner

Important: To prevent debris from entering the engine intake manifold, do not remove inner filter element (H) while cleaning the inside of the housing.


7. Remove inner filter element (H) only if it needs replacement.

8. Check the inside of the housing for damage.
9. If applicable, install a new inner filter element (H). Make sure the sealing surfaces are clean and the new element is properly seated.
10. Install a new outer filter element (G). Make sure the sealing surfaces are clean and the new element is properly seated.
11. Replace air filter cover (L). Latch clamps (J). Make sure the cover is tightly secured and is seated properly in the housing.
12. Check the air cleaner intake hose, clamps and mounting bracket hardware are properly secured and tightened.

DPF Service


DPF soot filter replacement is required when the DPF (Diesel Particulate Filter) Service Screen (Figure 103) displays.

***Note:** Contact your dealer when the DPF Service screen displays.*



V-Belt Maintenance

1. Perform the “Mandatory Safety Shutdown Procedure” on page 14.
2. Wait until the engine has cooled.
3. Inspect V-belt (F, Figure 104) for damage. If damaged, have belts replaced by an authorized repair shop.
4. Press on V-belt (F) mid-way between pulleys to check deflection. The belt should not deflect more than 8 mm (5/16 in.).
5. If deflection is more than 8 mm (5/16 in.):
Loosen adjustment bolt (G) and rotate alternator (E) outward until V-belt tension is correct. Tighten bolt (G) and re-check V-belt tension.



Cooling System

Important: Check the cooling system every day to prevent overheating, loss of performance or engine damage.

Checking Coolant Level

1. Park the machine on a level surface.
2. Perform the “Mandatory Safety Shutdown Procedure” on page 14.
3. Wait until the engine has cooled.



WARNING

Do not remove radiator cap when the coolant is hot. Serious burns could result.

4. Check the coolant level in the expansion reservoir (R, Figure 105). Coolant level must be between the full (T) and low (S) marks on the expansion reservoir. Add coolant to the expansion reservoir as required.

Important: The coolant system is specifically designed for coolant level top-off only through the expansion reservoir. Do not add coolant directly to the radiator.

Note: Use a low-silicate ethylene glycol-based coolant, mixed with quality water and supplemental coolant additives (SCAs) suitable for heavy-duty diesel engines. See “Fluid Capacities/Lubricants” on page 187, “Coolant Compound Mixtures” on page 193 and the engine operation manual for additional information.




Figure 105 – Coolant Expansion Reservoir

Cleaning Radiator Fins

The radiator fins can become blocked during use which will lead to reduced cooling function and engine overheating. Clean the radiator cooling fins after every 250 hours or 6 months of operation, whichever occurs first.

1. Perform the “Mandatory Safety Shutdown Procedure” on page 14.
2. Wait until the engine has cooled.
3. Open the rear door. Lift the engine cover.
4. Clean the radiator fins by blowing air/water through the fins from the rear of the radiator, toward the engine.

Important: Use caution! High pressure air/water can damage radiator fins.

Draining/Flushing Cooling System

1. Perform the “Mandatory Safety Shutdown Procedure” on page 14.
2. Wait until the engine has cooled.

WARNING Do not remove radiator cap when the coolant is hot. Serious burns could result.

3. Slowly loosen radiator cap (P, Figure 106) and allow pressure to escape. Remove cap.
4. Position a suitable collection container, with a minimum capacity of 19 L (4 gals.) underneath the radiator.



Figure 106 – Radiator Cap

5. Remove radiator drain plug (X, Figure 107) underneath the radiator and allow the coolant to drain into the container.

Important: Dispose waste coolant according to environmental laws. DO NOT pour coolant onto the ground or down a drain.

6. Replace the drain plug (X) and tighten securely.
7. Fill the radiator with coolant.




Figure 107 – Radiator Drain

Note: Use a low-silicate ethylene glycol-based coolant, mixed with clean water and supplemental coolant additives (SCAs) suitable for heavy-duty diesel engines. See “Fluid Capacities/Lubricants” on page 187, “Coolant Compound Mixtures” on page 193 and the engine operation manual for additional information.

8. Reinstall radiator cap and tighten securely.
9. Start and run the engine until it reaches operating temperature.
10. Check the coolant level according to “Checking Coolant Level” on page 145.

Hydraulic System

WARNING Never use your hands to search for hydraulic fluid leaks; use a piece of paper or cardboard to find leaks. Escaping fluid under pressure can be invisible and can penetrate the skin, causing serious injury. If any fluid is injected into your skin, see a doctor at once. Injected fluid MUST be surgically removed, or gangrene may result.

Checking Hydraulic Oil Level


Check the hydraulic oil level daily before starting the machine, or after every ten hours of use.

1. Perform the “Mandatory Safety Shutdown Procedure” on page 14.
2. Wait until the engine has cooled.
3. Open the engine compartment according to “Engine Access” on page 136.
4. Check the level of the hydraulic oil:
 - **Models 1500R/1650R:** Locate sight gauge (Y, Figure 108) in the left engine compartment wall. The oil level should be in the middle (A) of the sight gauge.
 - **Model 1350R:** Remove the hydraulic tank filler/dipstick cap (H).

Important: Slowly remove the hydraulic oil fill cap (H). Allow the pressure to escape before completely removing the cap.

Wipe dipstick (X) with a clean cloth and replace it in the filler neck. Push it in until cap (H) is fully seated.

Remove the dipstick again. The oil level should be at the (F) mark.



5. If the hydraulic oil level is low, remove the hydraulic tank filler cap (H, Figure 109), located in the left engine compartment wall.

Important: *Slowly remove the hydraulic oil fill cap (H). Allow the pressure to escape before completely removing the cap.*

6. Add hydraulic fluid if required. See “Fluid Capacities/Lubricants” on page 187 for proper hydraulic oil grade and type.

Important: *Do not mix different types/grades of hydraulic fluids.*

7. Reinstall hydraulic tank filler cap (H) and tighten securely.




Figure 109 – Hydraulic Oil Fill

Changing Hydraulic Oil Filter

1. Perform the “Mandatory Safety Shutdown Procedure” on page 14.
2. Wait until the engine has cooled.
3. Open the engine compartment according to “Engine Access” on page 136.
4. Place oil pan under the machine to catch the oil.
5. Unscrew and remove hydraulic oil filter (L, Figure 110).

6. Clean the surface of the filter housing where the element seal contacts the housing. Put clean oil on the rubber gasket of the new filter (L).

7. Install and tighten the filter (L) 3/4 of a rotation past the point where the gasket contacts the filter head.



Figure 110 – Hydraulic Oil Filter

Changing Hydraulic Oil

The hydraulic oil must be replaced if it becomes contaminated or after major repairs. Refer to the “Maintenance Schedules” on page 127 for the service interval for replacing the hydraulic oil.

1. Perform the “Mandatory Safety Shutdown Procedure” on page 14.
2. Wait until the engine has cooled.
3. Open the engine compartment according to “Engine Access” on page 136.
4. Slowly loosen hydraulic oil filler cap (H, Figure 109).
5. Position a waste oil collection container with a capacity of at least 60 L (16 gals.) underneath the hydraulic oil reservoir.

Note: *The hydraulic reservoir drain plug is accessed from underneath the machine at the left rear corner.*


6. Remove the hydraulic reservoir drain plug (O, Figure 111) and allow the oil to drain completely.

Important: *Always dispose of hydraulic oil according to environmental laws or take to a recycling center for proper disposal. DO NOT pour onto the ground or down a drain.*

7. Unscrew and remove the hydraulic oil filter (L, Figure 110).
8. Clean the surface of the filter housing where the element seal contacts the housing. Put clean oil on the rubber gasket of the new filter (L, Figure 110).
9. Install and tighten the filter (L, Figure 110) 3/4 of a rotation past the point where the gasket contacts the filter head.
10. Reinstall and tighten drain plug (O, Figure 111).
11. Remove hydraulic oil filler cap (H, Figure 109) and fill the hydraulic oil reservoir until the oil level is correct (Y, Figure 108).

Important: *See “Fluid Capacities/Lubricants” on page 187 for proper hydraulic oil grade and type. Hydraulic oil capacity listed is approximate. Always verify proper oil level. See to “Checking Engine Oil Level” on page 137.*

12. Start the engine and operate the drive, lift and tilt controls.
13. Stop the engine and check for leaks at the filter and reservoir drain plug.
14. Check the fluid level and add fluid if needed.



Hydraulic Hose Maintenance

⚠ WARNING Hydraulic hoses and connections must be inspected by a trained technician before the first use of the machine, and at least annually thereafter, for leaks and/or damage.

Leakages and damaged pressure hose/lines must be immediately repaired or replaced by an authorized service center.

Never use your hands to check for suspected hydraulic leaks. Always use a piece of wood or cardboard.

Leaks from hydraulic hoses or pressurized components can be difficult to see, but pressurized oil can have enough force to pierce the skin and cause serious injury.

Obtain immediate medical attention if pressurized oil pierces the skin. Failure to obtain prompt medical assistance could result in gangrene or other serious damage to tissue.

Always relieve hydraulic system pressure before performing any maintenance on the machine. Do not tighten leaking connections when the hydraulic system is under pressure.

Never weld or solder damaged or leaking pressure lines and/or screw connections. Always replace damaged hydraulic components.

Hydraulic hoses must be replaced every six years from the date of manufacture, even if they do not appear damaged. The date of manufacture (month or quarter and year) is indicated on hydraulic hoses. See Figure 112.




Figure 112 – Hydraulic Hose Manufacture Date

Chaincases

The chaincase contains the drive sprockets and drive chains. There are two plugs in each chaincase. One is to drain the oil and the other is to check the oil level. Refer to the “Maintenance Schedules” on page 127 for change intervals. See “Fluid Capacities/Lubricants” on page 187 for information on recommended type and amount of oil.

Drive Motors

The travel drive motors do not require periodic lubrication oil changes because they are lubricated by the oil in the hydraulic system.

Checking and Adding Chaincase Oil

1. Park the machine on a level surface.
2. Perform the “Mandatory Safety Shutdown Procedure” on page 14.
3. Older Models: Remove check/fill plug (S, Figure 113) from each chaincase housing. If the oil can be reached with the tip of your finger, the oil level is adequate.
4. If the level is low, add oil through the check plug until the oil level reaches the edge of the hole. Reinstall the check/fill (S) plug.
5. Newer Models: Remove the combination check/fill/drain check plug on one side at the front of the loader (). The oil level should be at the plug level or no more than 1/4 in. (6 mm) below the plug. Check the other side accordingly.



Figure 113 – Chaincase Fill/Check Plugs - Older Models

Changing Chaincase Oil

1. Raise the rear of the machine to aid in draining the chaincases.
2. Remove drain or combination check/drain plugs (T, Figure 114) on both chaincases and drain the oil into a suitable container(s).

Note: Drain plugs (T) are located inside the tie-down brackets at the bottom front of the machine.

3. Reinstall and tighten plugs (T).
4. Refill the chaincases according to “Checking and Adding Chaincase Oil” on page 151.




Figure 114 – Chaincase Drain Plug

Drive Chain Tension

Drive chains are located in the chaincase on each side of the machine. See “Maintenance Schedules” on page 127 for chain tension check interval.

Checking Chain Tension

1. Raise the machine according to the “Lifting the Machine” on page 134.
2. Rotate each tire by hand. The proper amount of chain deflection should be 3-25 mm (1/8-1 in.) forward and rearward tire movement. If the chain deflection is more than 25 mm (1 in.) or less than 3 mm (1/8 in.) in either direction, the chains should be adjusted.

Adjusting Chain Tension

1. Raise the machine according to the “Lifting the Machine” on page 134.
2. Remove the wheel from the axle to be adjusted.
3. Loosen (but DO NOT remove) the bolts holding the axle to the chaincase.
4. **Front Chain Tension** – To tighten the front chain, move the front axle assembly toward the front of the machine. To loosen the chain, move the front axle assembly toward the rear of the machine.

Rear Chain Tension – To tighten the rear chain, move the rear axle assembly rearward. To loosen the chain, move the rear axle assembly toward the front of the machine.

5. After proper tension is achieved, tighten the bolts.

Important: *Be careful not to over-tighten the drive chains. Over-tightening will cause premature drive chain and axle sprocket wear.*

6. Reinstall the wheel.
7. Repeat this procedure for any other axle requiring adjustment.
8. Lower the machine according to the “Lowering the Machine” on page 135.

Seat and Restraint Bar Switches

Electrical switches in the seat and restraint bar must be closed (operator sitting in the seat and restraint bar lowered) and the auxiliary hydraulics must be in neutral to complete the circuit and start the engine.

Bucket Cutting Edge

The bucket cutting edge should be replaced when it is worn to within 25 mm (1 in.) of the bucket body.

Wheel Nuts

Wheel nut torque must be checked before initial operation and every two hours until the wheel mounting hardware torque stabilizes at the following recommended settings:

- **Model 1350R:** 161-175 Nm (120-130 lb.-ft)
- **Models 1500R/1650R:** 244 Nm (180 lb.-ft)

Check wheel nut torque every 250 hours thereafter.

When tires are removed and replaced, this procedure must be repeated.

Tires

Rear tires usually wear faster than the front ones. To keep tire wear even, rotate the tires from front to rear and rear to front.

It is important to keep the same size tire on both sides of the machine to prevent excessive wear on tires or other damage. If different sizes are used, each tire will be turning at different speeds, causing excessive wear.

The tread bar of all tires must face the same direction.

Mounting Tires

 **WARNING** Servicing tires can be dangerous. When possible, trained personnel should service and mount tires. To avoid possible death or serious injury, follow the safety precautions below.

***Important:** The tread bars of all tires should point the same direction.*

- Be sure the rim is clean and free of rust.
- Lubricate the tire beads and rim flanges with a soap solution. Do not use oil or grease.
- Use a clip-on tire chuck with remote hose and gauge, allowing you to stand clear while inflating the tire. Do not place your fingers on the tire bead or rim during inflation.
- Never inflate beyond 240 kPa (35 psi) to seat the beads. If the beads have not seated by the time the pressure reaches 240 kPa (35 psi), deflate the assembly, reposition the tire on the rim, lubricate both parts and re-inflate. Inflation pressure beyond 240 kPa (35 psi) with unseated beads may break the bead or rim with explosive force sufficient to cause death or serious injury.
- After seating the beads, adjust the inflation pressure to the recommended operating pressure.
- Do not weld, braze or otherwise attempt to repair and use a damaged rim.

Checking Tire Pressure

Table 19: Tire Inflation Pressures

Tire Size	Inflation Pressure	
	Max psi	Max kPa
10.00 x 16.5 10-Ply Severe Duty	75	517
10.00 x 16.5 10-Ply Flotation	75	517
12.00 x 16.5 12-Ply Flotation	80	552
27 x 10.50 x 15 8-Ply	59	407

Correct tire pressure should be maintained for all tires to enhance operating stability and extend tire life. Refer to the above chart for the proper inflation pressure.

When installing tires, be sure they are the same size and style on both sides of the machine. Always replace tires with the same size as the original equipment.

Electrical System

 **WARNING**

Inspect and check the machine’s electrical equipment at regular intervals. Defects, such as loose connections or scorched cables must be repaired before using the machine.



Only use proper, original equipment fuses with the specified current rating. Turn off the machine immediately if there are any problems with the electrical system.

Work on the machine’s electrical system must be performed only by a trained technician.

Fuses, Relays and Diodes

Important: Blown fuses indicate electrical system malfunctions. Determine what caused the fuse to blow and repair the problem before replacing the fuse.

The fuse, relay and diode boxes are located in the engine compartment, just behind the cab, on the right side of the machine.

**Table 20: Relay Locations (Figure 116)**

Relay	Circuit	Relay	Circuit
A	High-speed cab blower fan relay	B	Horn relay
C	Medium-speed cab blower fan relay	D	Exhaust Gas Recirculation (EGR) relay
E	Low-speed cab blower fan relay		

Table 21: Fuse Locations (Figure 116)

Fuse	Rated Current (A))	Circuit	Fuse	Rated Current (A)	Circuit
F	20A	Control Keypad	G	20A	Windshield wiper, Door
H	20A	Cab blower fan	I	20A	Electronic Control Unit (ECU) Note: if required
J	5A	Dome light, Radio	K	10A	Horn, Alarm
L	20A	Exhaust Gas Recirculation (EGR)	M	20A	Operator's seat switch/ optional air suspension
N	3A	Electronic display LCD	O	5A	Hand control buttons

Table 22: Diode Locations (Figure 116)

Diode	Circuit	Diode	Circuit
P	Ignition	Q	EGR Valve (Tier 4)




Table 23: Maxi Fuse Locations (Figure 117)

Fuse	Rated Current (A)	Circuit	Fuse	Rated Current (A)	Circuit
R	50A	Cab heat, Wiper	S	80A	Glow Plugs
T	60A	Starter	U	20A	Ignition, Accessories
V	50A	Micro Controller Unit (MCU)	W	30A	Road lights

Battery

⚠ WARNING Before servicing the battery or electrical system, be sure the battery disconnect switch (if equipped) is in the OFF position. If not equipped with a disconnect switch, disconnect the ground (-) terminal from battery.

The battery is a 12-volt, wet-cell battery. To access the battery, remove front floor panel.

The battery top must be kept clean. Clean it with an alkaline solution (ammonia or baking soda and water). After foaming has stopped, flush the battery top with clean water. If the terminals and cable connection clamps are corroded or have a build-up, disconnect the cables and clean the terminals and clamps with the same alkaline solution.

⚠ WARNING Explosive gas is produced while a battery is in use or being charged. Keep flames or sparks away from the battery area. ALWAYS charge the battery in a well-ventilated area.

Never lay a metal object on top of a battery, because a short circuit can result.

Whenever the battery is removed, be sure to disconnect the negative (-) battery terminal connection first.

Battery acid is harmful on contact with skin or fabrics. If acid spills, follow these first-aid tips:

1. Immediately remove any clothing on which acid spills.
2. If acid contacts the skin, rinse the affected area with running water for 10 to 15 minutes.
3. If acid contacts the eyes, flood the eyes with running water for 10 to 15 minutes. See a doctor at once. Never use any medication or eye drops unless prescribed by the doctor.
4. To neutralize acid spilled on the floor, use one of the following mixtures:
 - a. 0.5 kg (1 lb.) of baking soda in 4 L (1 gal.) of water.
 - b. 0.5 L (1 pt.) of household ammonia in 4 L (1 gal.) of water.

Windshield Washer Reservoir

The windshield washer reservoir (E, Figure 118) is located inside the engine compartment. Check the windshield washer reservoir level daily before starting the machine and fill if necessary.

Important: Fill the windshield washer fluid reservoir with clean tap water or windshield washer fluid only. If using tap water, add a cleaning agent if required and/or antifreeze in cold weather.



Figure 118 – Windshield Washer Reservoir Fill

Long-Term Storage

If storing the machine for a long period (longer than 2 months), perform the procedures in this section.

Before Storage

1. Wash the entire machine. Treat vinyl surfaces in the operator's compartment with a vinyl protectant.
2. Perform all steps for long-term engine storage according to the engine operation manual.
3. Check tire pressure; adjust to correct pressure, if necessary. See "Tires" on page 153.
4. Lubricate all grease fittings. See "General Lubrication" on page 132.
5. Check all fluid levels and top-off as necessary.
6. Add a fuel stabilizer to the fuel system according to the fuel supplier's recommendations.
7. If the machine is so equipped, turn the battery disconnect switch to the off position. See "Battery Disconnect Switch" on page 76.
8. Remove and fully charge the battery. Store the battery in a cool, dry location.
9. If the machine will not be operated for a month or longer, apply grease to all exposed hydraulic cylinder rod areas or retract all cylinders so rod exposure is minimized. Apply grease to any remaining rod areas.
10. Protect against extreme weather conditions such as moisture, sunlight and temperature. Fill the engine coolant system with the proper mix of antifreeze and water as required for expected temperatures according to "Coolant Compound Mixtures" on page 193.

Important: Contact your dealer for additional storage preparation information if the machine will be stored in an environment where temperatures could range below -42°C (-44°F), and/or above 49°C (120°F).

After Storage

1. Replace and re-connect the battery.
2. If the machine is so equipped, turn the battery disconnect switch to the on position. See “Battery Disconnect Switch” on page 76.
3. Check tire pressure; adjust to correct pressure, if necessary. See “Tires” on page 153.
4. Perform all steps for returning the engine to service according to long-term engine storage section in the engine operation manual.
5. Check V-belt tension. See “V-Belt Maintenance” on page 144.
6. Check all fluid levels and top-off as necessary.
7. Start the engine. Observe all indicators. If all indicators are functioning properly and reading normally, move the machine outside.
8. When outside, park the machine and let the engine idle for at least 5 minutes.
9. Shut off the engine and walk around machine. Make a visual inspection looking for evidence of leaks.

Final Shutdown / Decommissioning

Important: *Dispose of all materials properly. Used oils/fluids are environmental contaminants and may only be disposed of at approved collection facilities. Never drain any oils/fluids onto the ground, dispose of in municipal waste collection containers, or in metropolitan sewer systems or landfills. Check state and local regulations for other material disposal requirements.*

If the machine will no longer be used as intended, shutdown, decommission and dispose of it according to the valid regulations.

Before Disposal

1. Shut down the machine according to valid regulations regarding proper shutdown.
2. Park the machine on level, dry ground. Ensure the surface can support the weight of the machine. Ensure the location is protected against access by unauthorized persons.
3. Move the throttle to the low-idle position and allow the engine to cool for approximately 2 minutes.
4. Shut off the engine.
5. Move the lift/tilt and if equipped, the Power-A-Tach® quick attach control(s) to verify that the controls do not cause movement of the lift arm or hitch.
6. Raise the arm rests/safety bars to apply the parking brake and lock out the hydraulic controls.
7. Switch off all electrical switches.
8. Unfasten the seat belt, remove the ignition key and take it with you.
9. Ensure the machine poses no dangers in the place where it is standing.
10. Ensure the machine cannot be operated after shutdown until further disposal.
11. Ensure no environmentally hazardous materials, fluids and/or fuel can escape the machine.
12. Specifically check for leaks from the engine, the hydraulic system and the coolant system.
13. Remove any dirt and/or debris from the engine compartment, the chassis and the cylinder rod surfaces.
14. Remove the battery.
15. Lock the cab door, the storage compartment, the battery and hydraulic filler compartments and the engine compartment. Remove the key(s) and take it/them with you.

Machine Disposal

Make sure all materials are disposed of in an ecologically sound manner.

Recycle the machine in accordance with the current state of the art at the time of recycling.
Observe all accident prevention regulations.

Dispose of all parts at the at the recycling sites specific to the material of the part. Take care to separate different materials for recycling.

Dealer Services

Service of the following components require special tools, skill and knowledge are not part of normal maintenance and are not included in this manual. Service of these components should only be performed by an authorized dealer:

- Engine service not included in this manual:
- Hydrostatic components.
- Hydraulic system pumps.
- Valves.
- Cylinders.
- Electrical components (other than the battery, relays and fuses).

NOTES

CHAPTER 7

TROUBLESHOOTING

Engine Troubleshooting

Table 24: Engine Troubleshooting

Problem	Possible Cause	Corrective Action
Engine does not turn over	Blown fuse.	Check circuit and replace fuse. See “Fuses, Relays and Diodes” on page 155.
	Dead battery.	Charge or replace battery—see “Jump-starting” on page 92.
	Battery disconnect switch in open position or malfunctioning.	Place battery disconnect switch into closed position— Repair or replace if necessary.
	Starter malfunction.	Contact dealer.
	Operator not in operator’s seat.	Operator’s seat must be occupied. for the engine to start.
	Malfunctioning seat/restraint bar/door switch.	Replace seat/restraint bar/door switch.
	Cab door open (if equipped).	Close cab door.
	Engine electronics logic error.	Contact dealer.
	Engine fault code(s) displayed.	Identify problem and correct.

Table 24: Engine Troubleshooting

Problem	Possible Cause	Corrective Action
Engine turns over but will not start	Engine cranking speed too slow.	Check battery and charge/replace as necessary—tighten battery terminals. In cold temperatures, pre-warm the engine.
	Fuel tank empty.	Fill tank and vent fuel system if necessary.
	Fuel filter plugged or restricted.	Change fuel filter.
	Fuel paraffin separation in winter.	Use winter grade diesel fuel.
	Fuel line leak.	Tighten all threaded connections and clamps; replace fuel line as necessary.
	Fuel shut-off solenoid not energizing. (interim Tier 4 engines only)	Check electrical connections/voltage to shut-off solenoid.
	Fuel filter restricted/fuel hose restriction.	Replace filter/check for pinched fuel hose.
	Fuel pump malfunction.	Contact dealer.
	Water in fuel filter.	Purge water from filter.
	Fuel valve on water separator in the OFF position.	Turn the valve to the ON position.
	Engine fault code(s) displayed.	Identify problem and correct.
	Engine too cold/ambient temperature too low.	Pre-heating module malfunction; check connection and voltage and charge/replace as necessary. Install block heater.
Engine overheating	Crankcase oil level incorrect.	Adjust oil level—see “Fluid Capacities/ Lubricants” on page 187 for proper oil grade.
	Cooling air circulation restricted.	With engine off, remove restriction.
	Fan shroud improperly positioned.	With engine off, reposition shroud/contact dealer.
	Improper oil grade or oil excessively dirty.	Change engine oil—see “Fluid Capacities/ Lubricants” on page 187 for proper oil grade.
	Exhaust restricted.	Allow exhaust to cool; remove restriction.
	Air filter restricted.	Replace filter(s).
	Low coolant level.	Top off coolant. See “Fluid Capacities/ Lubricants” on page 187 for proper coolant mixture.
	Loose fan belt.	Tighten fan belt.
	Dirty/restricted radiator.	Clean radiator.
	Thermostat malfunction.	Replace thermostat.

Table 24: Engine Troubleshooting

Problem	Possible Cause	Corrective Action
Exhaust excessively smoky	Black smoke	Black smoke indicates poor and incomplete diesel fuel combustion, which could be caused by: • Incorrect timing. • Dirty or worn injectors. • Incorrect valve clearance. • Incorrect air/fuel ratio. • Low cylinder compression. • Dirty air cleaner. • Restricted induction system. • Faulty engine tuning. • Poor quality fuel. • Carbon build-up in combustion and exhaust spaces. • Cool operating temperatures.
	Blue smoke	Blue smoke indicates engine oil combustion, which could be caused by: • Worn valve guides or seals. • Wear in cylinders, piston rings, ring grooves, etc. • Cylinder glaze. • Sticking piston ring. • Incorrect engine oil grade. • Fuel dilution in engine oil.
	White smoke	White smoke indicates incomplete diesel combustion, or coolant in the combustion chamber, which could be caused by: • Faulty or damaged injectors. • Incorrect injection timing. • Low cylinder compression. • Faulty head gaskets. • Cracked cylinder heads/blocks.

Indicator Lamp Troubleshooting

Table 25: Indicator Lamp Troubleshooting

Indicator Icon	Indicator Activated	Possible Cause	Corrective Action
	Engine oil pressure	Engine oil pressure too low.	Stop engine immediately; check oil level and top off oil if necessary; check oil pump.
		Engine oil level too low.	Top off oil. See "Fluid Capacities/Lubricants" on page 187 for proper oil grade.
		Oil pump malfunction.	Contact dealer.
	Hydraulic oil temperature		Check cooling system for debris in radiator.
		Oil temperature is too hot.	Check hydraulic oil level. See "Checking Hydraulic Oil Level" on page 147.
		Drive system continuously overloaded.	Improve operation procedure.
		Lift/tilt or auxiliary system continuously overloaded.	Improve operation procedure.
		Drive motor(s) or hydrostatic pump(s) internal damage/leakage.	Contact dealer.
		Hydraulic oil filter restricted.	Replace filter.
		Radiator/cooler restricted.	Clean radiator/cooler.
	Hydraulic oil filter	Hydraulic oil filter service required.	Replace hydraulic oil and filter. See "Hydraulic System" on page 146 NOTE: During cold start in cold temperatures, this indicator may be activated until hydraulic oil warms to operating temperature.
	Coolant temperature	Coolant level too low.	Top off coolant. See "Coolant Compound Mixtures" on page 193 for proper coolant mixture.
		Air filter plugged.	Replace air filter(s). See "Changing Air Filter Elements" on page 143.
		Coolant leak.	Repair cooling system and top-off coolant.

Table 25: Indicator Lamp Troubleshooting

Indicator Icon	Indicator Activated	Possible Cause	Corrective Action
	Battery voltage	Alternator not charging properly.	Adjust V-belt tension.
			Repair/replace alternator.
	Engine air filter restriction	Air filter dirty/restricted.	Replace air filter(s). See "Changing Air Filter Elements" on page 143.
		Blockage in air filter housing.	Remove blockage.

Seal and Hose Troubleshooting

Table 26: Seal and Hose Troubleshooting

Problem	Possible Cause	Corrective Action
Oil, coolant or fuel leakage	Loose hose connection(s).	Tighten hose connections.
	Damaged seals or hoses.	Change seals/hoses as necessary.
Hydraulic fluid leakage	Loose fittings.	Tighten hydraulic connections.
	Seals, hoses or lines damaged.	Repair/replace seals, hoses or lines as necessary.

Hydraulic System Troubleshooting

Table 27: Hydraulic System Troubleshooting

Problem	Possible Cause	Corrective Action
Lift/tilt and drive controls fail to respond	Restraint bar raised.	Lower restraint bar.
	Solenoid valve malfunctioning.	Check electrical connections to pilot solenoid. Repair/replace as necessary.
	Hydraulic oil viscosity too heavy.	Replace existing oil with proper viscosity oil. See "Fluid Capacities/Lubricants" on page 187.
		Allow longer warm-up.
	Hydraulic oil level low.	Check oil level; Top off if necessary. See "Fluid Capacities/Lubricants" on page 187 for proper oil grade.
		Check for external leaks; repair/replace as necessary.
	Hydraulic oil viscosity too heavy.	Replace existing oil with proper viscosity oil. See "Fluid Capacities/Lubricants" on page 187.
		Allow longer warm-up.
	Drive coupling failure.	Repair/replace coupling.

Table 27: Hydraulic System Troubleshooting

Problem	Possible Cause	Corrective Action
Sluggish hydraulic system performance	Low hydraulic fluid level.	Top off hydraulic fluid.
	Hydraulic oil viscosity too heavy.	Replace existing oil with proper viscosity oil. See "Fluid Capacities/Lubricants" on page 187.
		Allow longer warm-up.
	Engine to pump coupling or hydraulic pump damaged.	Contact dealer.
	Pressure limiting valves set too low or damaged.	
	Hydraulic cylinder damaged.	
	Control valves damaged.	
	Oil leaking past cylinder/motor seals (internal or external).	
	Oil leaking past spools in control valve.	
	Low engine speed.	Increase engine speed.
	Engine running rough.	Poor fuel quality or incorrect grade. See "Fluid Capacities/Lubricants" on page 187 for proper fuel grade.
		Restricted fuel filter/fuel system. Replace fuel filter; remove restriction. See "Changing Fuel Filter" on page 142.
	Dirty/restricted air filter(s).	Replace filter(s).
	Air in hydraulic system.	Cycle lift and tilt cylinders to maximum stroke and maintain pressure for short time to clear air from the hydraulic system. Also check for low oil level in reservoir; top off as necessary.
	Worn hydraulic pump.	Contact dealer.
Hydraulic system overheating	Control linkage malfunction.	Adjust/repair linkage for full spool travel.
	Solenoid valve malfunction.	Check solenoid electrical connections; repair as necessary.
	Hydraulic oil cooler restricted.	Clean hydraulic oil cooler. See "Cleaning Radiator Fins" on page 145.
	Low hydraulic oil level.	Top off hydraulic oil. See "Checking Hydraulic Oil Level" on page 147. See "Fluid Capacities/Lubricants" on page 187 for proper oil grade.
	Hydraulic system overloaded.	Reduce load.

Table 27: Hydraulic System Troubleshooting

Problem	Possible Cause	Corrective Action
Attachment tilts down with tilt control in neutral	Oil leaking past tilt cylinder seals (internal or external).	Contact dealer.
	Oil leaking past lift spool in control valve.	
	Self-leveling valve malfunction.	
	Leaking hydraulic hoses, tubes or fittings between control valve and cylinders.	Repair as required.
Attachment does not self-level when lift arm is raised	Self-leveling valve malfunction.	Contact dealer.
	Self-leveling is deactivated.	Activate self-leveling. See "Self-Leveling Cancel" on page 104.
Lift arms move down with lift control in neutral	Oil leaking past lift cylinders seals (internal or external).	Contact dealer.
	Oil leaking past lift spool in control valve.	
	Self-leveling valve malfunctioning.	
	Leaking hydraulic hoses, tubes or fittings between control valve and cylinders.	Repair as required.
Lift arm does not raise/lower	Lift spool in control valve not actuated or leaking.	Contact dealer.
	Hydraulic oil leaking past cylinder piston seals.	
	Lift arm support engaged.	Release lift arm support.
	Lift solenoid valve malfunction.	Check solenoid electrical connections; repair as necessary.
	Restraint bar not lowered.	Lower restraint bar.
	Seat or restraint bar switch malfunction.	Check switch electrical connections; repair as necessary.
Lift and/or tilt functions inconsistent/jerky	Air in hydraulic system.	Cycle lift and tilt cylinders to maximum stroke and maintain pressure for short time to clear air from the hydraulic system. Also check for low oil level in reservoir; see "Checking Hydraulic Oil Level" on page 147. Top off as necessary.
	Low hydraulic oil level.	Top off hydraulic oil. See "Checking Hydraulic Oil Level" on page 147. See "Fluid Capacities/ Lubricants" on page 187 for proper oil grade.
	Cylinder(s) malfunction.	Contact dealer.
	Seat or restraint bar switch malfunction.	Check electrical connections to switches. Repair as required.

Table 27: Hydraulic System Troubleshooting

Problem	Possible Cause	Corrective Action
Auxiliary hydraulics do not function	Restraint bar raised.	Lower restraint bar.
	Restraint bar switch malfunctioning.	Check electrical connections.
		Contact dealer.
	Solenoid malfunctioning.	Check electrical connections.
		Contact dealer.
	Spool in control valve not actuated or leaking.	Contact dealer.
	Hydraulic oil leaking past seals.	
Auxiliary hydraulics connections difficult to connect/disconnect	Auxiliary hydraulic connections improperly connected.	Correct hydraulic connections.
	Auxiliary hydraulic control module malfunction.	Contact dealer.
Lift arm operates, but attachment tilt does not	Auxiliary hydraulics circuit under pressure.	With the engine off, but the ignition on, move the auxiliary hydraulics control rocker switch on the right T-bar, joystick or hand control back and forth to relieve pressure in the auxiliary hydraulics circuit.
	Tilt solenoid valve malfunction.	Check electrical connections to solenoid; repair as necessary.
		Contact dealer.
	Tilt spool in control valve not actuated or leaking.	Contact dealer.
	Control valve in float position.	Move control out of float position.
	Tilt cylinder malfunction.	Contact dealer.
Attachment tilt operates, but lift arm does not	Control valve relief valve malfunction (Squealing noise during operation).	
	Restraint bar not lowered.	Lower restraint bar.
	Seat or restraint bar switch malfunction.	Check switch electrical connections; repair as necessary.
	Lift arm support engaged.	Release lift arm support.
	Restraint bar not lowered.	Lower restraint bar.
	Seat or restraint bar switch malfunction.	Check switch electrical connections; repair as necessary.
	Hydraulic oil leaking past cylinder piston seals.	Contact dealer.
	Lift solenoid valve malfunction.	Check electrical connections to solenoid; repair as necessary.
		Contact dealer.
	Lift spool in control valve not actuated or leaking.	Contact dealer.

Hydrostatic Drive System Troubleshooting

Table 28: Hydrostatic Drive System Troubleshooting

Problem	Possible Cause	Corrective Action
Travel drive does not operate in either direction	Parking brake is applied.	Release parking brake.
	Low hydraulic oil level.	Top off hydraulic oil. See "Checking Hydraulic Oil Level" on page 147. See "Fluid Capacities/Lubricants" on page 187 for proper oil grade.
	Low or no charge pressure.	Contact dealer.
	Hydrostatic pump(s) relief valve malfunction.	
	Restraint bar not lowered.	Lower restraint bar.
	Seat or restraint bar switch malfunction.	Check switch electrical connections; repair as necessary.
Right side drive doesn't operate in either direction; left side operates normally	Rear hydrostatic pump relief valve malfunction.	Contact dealer.
	Rear hydrostatic pump control rod linkage malfunction.	Check linkage connection at control levers and neutral centering mechanisms. Adjust/repair as necessary. Contact dealer.
Right side drive doesn't operate in one direction	Rear hydrostatic pump relief valve malfunction.	Contact dealer.
	Rear hydrostatic pump malfunction.	
Left side drive doesn't operate in either direction; right side operates normally	Front hydrostatic pump relief valve malfunction.	Contact dealer.
	Linkage front hydrostatic pump control rod linkage malfunction.	Check linkage connection at control levers and neutral centering mechanisms. Adjust/repair as necessary. Contact dealer.
Left side drive doesn't operate in one direction	Front hydrostatic pump relief valve malfunction.	Contact dealer.
	Front hydrostatic pump malfunction.	
Travel drive system noisy	Hydraulic oil viscosity too heavy.	Replace existing oil with proper viscosity oil. See "Fluid Capacities/Lubricants" on page 187.
		Allow longer warm-up.
	Low hydraulic oil level.	Top off hydraulic oil. See "Checking Hydraulic Oil Level" on page 147. See "Fluid Capacities/Lubricants" on page 187 for proper oil grade.
	Air in hydraulic system.	Cycle lift and tilt cylinders to maximum stroke and maintain pressure for short time to clear air from system. Also check for low oil level in reservoir; top off as necessary.
	Drive motor(s) or hydrostatic pump(s) internal damage/leakage.	Contact dealer.

Table 28: Hydrostatic Drive System Troubleshooting

Problem	Possible Cause	Corrective Action
Sluggish travel drive acceleration	Low hydraulic oil level.	Top off hydraulic oil. See "Checking Hydraulic Oil Level" on page 147. See "Fluid Capacities/Lubricants" on page 187 for proper oil grade.
	Low hydrostatic system charge pressure.	Contact dealer.
	Drive motor or hydrostatic pump internal damage/leakage.	
	Air in hydraulic system.	Cycle lift and tilt cylinders to maximum stroke and maintain pressure for short time to clear air from system. Also check for low oil level in reservoir; top off as necessary.
Travel drive overheating	Drive system continuously overloaded.	Improve operation procedure.
	Lift/tilt or auxiliary system continuously overloaded.	
	Drive motor(s) or hydrostatic pump(s) internal damage/leakage.	Contact dealer.
	Low hydraulic oil level.	Top off hydraulic oil. See "Checking Hydraulic Oil Level" on page 147. See "Fluid Capacities/Lubricants" on page 187 for proper oil grade.
	Oil cooler fins restricted.	Clean oil cooler fins.
	Hydraulic oil filter restricted.	Clean hydraulic oil cooler. See "Cleaning Radiator Fins" on page 145.
Right side drive doesn't operate in either direction. Left side operates normally.	Rear hydrostatic pump relief valve malfunction.	Contact dealer.
	Rear hydrostatic pump control rod linkage malfunction.	
Right side drive doesn't operate in one direction.	Rear hydrostatic pump relief valve malfunction.	Contact dealer.
	Rear hydrostatic pump malfunction.	
Left side drive doesn't operate in either direction. Right side operates normally.	Front hydrostatic pump relief valve malfunction.	Contact dealer.
	Linkage front hydrostatic pump control rod linkage malfunction.	
Left side drive doesn't operate in one direction.	Front hydrostatic pump relief valve malfunction.	Contact dealer.
	Front hydrostatic pump malfunction.	

Electrical Troubleshooting

Table 29: Electrical Troubleshooting

Problem	Possible Cause	Corrective Action
Electrical system does not function	Battery disconnect switch is in OFF position.	Turn battery disconnect switch to the ON position. See "Battery Disconnect Switch" on page 76.
	Battery terminals or cables loose or corroded.	Clean battery terminals and cables and retighten.
	Battery malfunction.	Test battery. Recharge/replace as necessary.
	Blown main fuse.	Correct over-current problem and replace main fuse. See "Fuses, Relays and Diodes" on page 155.
	Main wiring harness connectors at rear of ROPS/FOPS not properly plugged in.	Check main harness connectors. Reconnect/repair as needed.
Control pad and information center display do not activate with ignition keyswitch in the ON/RUN position	Blown fuse.	Check circuit and replace fuse. See "Fuses, Relays and Diodes" on page 155.
	Battery terminals/cables loose/corroded.	Clean battery terminals and cables and tighten.
	Main wiring harness connectors at rear of ROPS/FOPS not properly plugged in.	Check main harness connectors. Reconnect/repair as needed.
Starter does not engage when ignition keyswitch turned to the START position	Poor electrical connections in start circuit.	Check connections repair as necessary.
	Battery terminals/cables loose/corroded.	Clean battery terminals and cables and tighten.
	Starter relay malfunction.	Test relay; replace if necessary. Contact dealer.
	Battery discharged/malfunctioning.	Test battery. Recharge/replace if necessary.
	Starter solenoid malfunction.	Contact dealer.
	Starter or pinion malfunctioning.	Repair/replace as needed.
	Ignition wiring, seat switch, restraint bar switch, etc. loose or disconnected.	Check wiring for poor connections, broken leads; repair wiring or connection.
	Restraint bar raised.	Lower restraint bar.
	Engine fault code(s).	Contact dealer.
Fuel gauge inoperative	Fuel level sender malfunction.	Replace fuel level sender.
	Loose wiring/terminal connections.	Check wiring connections.
	Blown fuse.	Check circuit and replace fuse. See "Fuses, Relays and Diodes" on page 155.
	Fuel gage malfunction.	Replace gauge.

Table 29: Electrical Troubleshooting

Problem	Possible Cause	Corrective Action
Coolant temperature gauge inoperative	Temperature sender malfunction.	Replace temperature sender.
	Loose wiring/terminal connections.	Check wiring connections.
	Blown fuse.	Check circuit and replace fuse. See "Fuses, Relays and Diodes" on page 155.
	Coolant temperature gage malfunction.	Replace gauge.
Hour meter inoperative	Loose wiring/terminal connections.	Check wiring/connections.
	Alternator malfunction.	Repair/replace alternator.
	Hour meter malfunction.	Replace information center electronic display.
Work/road lights inoperative	Single light not working— light bulb burned out, faulty wiring.	Check and replace light bulb as needed, check wiring connections.
	No lights—blown fuse.	Check circuit and replace fuse. See "Fuses, Relays and Diodes" on page 155.
	Light switch malfunction, poor ground or other wiring connection.	Check ground/wire connections, replace light switch.
Lift/tilt and/or drive lock solenoid malfunction	Solenoid wiring disconnected or faulty.	Check circuit; repair as necessary.
	Seat or restraint bar switch malfunction.	Contact dealer.
	Solenoid valve coil malfunction.	
	Instrument panel hydraulic solenoid relay malfunction.	

Error Codes

The tables in this section describe error codes which may be reported on the information center electronic display screen. More than one error can be reported at one time and may be display on more than one screen. See page 58.

Engine Diagnostic Trouble Codes (DTC)

Table 30: Yanmar Engine Diagnostic Trouble Codes (DTC)

DTC			Error Item	
SPN	FMI	P-Code	Part	State
28	0	P1126	Acceleration Sensor 3	Sensor failure (foot pedal in open position)
	1	P1125	Acceleration Sensor 3	Sensor failure (foot pedal in closed position)
	2	P0224	Acceleration Sensor 3	Intermittent fault
	3	P0223	Acceleration Sensor 2	Acceleration sensor 2 fault (high voltage)
	4	P0222	Acceleration Sensor 2	Acceleration sensor 2 fault (low voltage)
29	0	P1226	Accelerator Pedal Position Sensor "B"	Above normal operation range
	1	P1225	Accelerator Pedal Position Sensor "B"	Below normal operation range
	3	P0227	Acceleration Sensor 3	Acceleration sensor 3 fault (high voltage)
		P0228	Acceleration Sensor 3	Acceleration sensor 3 fault (high voltage)
	8	P1127	Acceleration Sensor 3	Sensor failure (pulse communication)
		P1227	Accelerator Pedal Position Sensor "B"	Communication fault
	15	P1228	Accelerator Pedal Position Sensor "B"	Not available
51	3	P02E9	Intake Throttle Opening Sensor	Intake throttle opening sensor fault (high voltage)
	4	P02E8	Intake Throttle Opening Sensor	Intake throttle opening sensor fault (low voltage)
91	2	P0124	Acceleration Sensor 1	Intermittent Fault
	3	P0123	Acceleration Sensor 1	Acceleration sensor 1 fault (high voltage)
	4	P0122	Acceleration Sensor 1	Acceleration sensor 1 fault (low voltage)
100	1	P1198	Oil Pressure Switch	Low oil pressure fault alarm
	4	P1192	Oil Pressure Switch	Oil pressure switch open circuit
102	3	P0238	EGR Low Pressure Side Sensor	EGR low pressure side sensor fault (high voltage)
	4	P0237	EGR Low Pressure Side Sensor	EGR low pressure side sensor fault (low voltage)
	13	P0236	EGR Low Pressure Side Sensor	Abnormal learning value

Table 30: Yanmar Engine Diagnostic Trouble Codes (DTC)

DTC			Error Item	
SPN	FMI	P-Code	Part	State
105	3	P040D	Intake Air Temperature Sensor	Intake air temperature sensor fault (high voltage)
	4	P040C	Intake Air Temperature Sensor	Intake air temperature sensor fault (low voltage)
108	2	P2230	Barometric Pressure Sensor	Intermittent fault
	3	P2229	Atmospheric Pressure Sensor	Atmospheric pressure sensor fault (high voltage)
	4	P2228	Atmospheric Pressure Sensor	Atmospheric pressure sensor fault (low voltage)
	10	P1231	Atmospheric Pressure Sensor	Atmospheric pressure sensor characteristic fault
110	0	P0217	Cooling Water Temperature Sensor	Cooling water temperature sensor temperature abnormally high (overheat)
	2	P0119	Cooling Water Temperature Sensor	Intermittent fault
	3	P0118	Cooling Water Temperature Sensor	Cooling water temperature sensor fault (high voltage)
	4	P0117	Cooling Water Temperature Sensor	Cooling water temperature sensor fault (low voltage)
157	0	P0088	Abnormal Rail Pressure	Actual rail pressure rise error
	3	P0193	Rail Pressure Sensor	Rail pressure sensor (high voltage)
	4	P0192	Rail Pressure Sensor	Rail pressure sensor (low voltage)
	15	P0093	Abnormal Rail Pressure	Rail pressure deviation error during the actual rail pressure rise
	16	P000F	PLV (Common Rail Pressure Limit Value)	PLV open valve
	18	P0094	Abnormal Rail Pressure	Rail pressure deviation error during the actual rail pressure drop
158	0	P0563	System Voltage	Too high
	1	P0562	System Voltage	Too low
167	1	P1568	Charge Switch	Charge alarm
	5	P1562	Charge Switch	Charge switch open circuit
172	3	P0113	New Air Temperature Sensor	New air temperature sensor fault (high voltage)
	4	P0112	New Air Temperature Sensor	New air temperature sensor fault (low voltage)
173	3	P0546	Exhaust Air Temperature Sensor	Exhaust air temperature sensor fault (high voltage)
	4	P0545	Exhaust Air Temperature Sensor	Exhaust air temperature sensor fault (high voltage)

Table 30: Yanmar Engine Diagnostic Trouble Codes (DTC)

DTC			Error Item	
SPN	FMI	P-Code	Part	State
174	0	P0168	Fuel Temperature Sensor	Fuel temperature sensor temperature abnormally high
	3	P0183	Fuel Temperature Sensor	Fuel temperature sensor fault (high voltage)
	4	P0182	Fuel Temperature Sensor	Fuel temperature sensor fault (low voltage)
190	16	P0219	Overspeed	Overspeed
237	13	U3002	CAN 2	VI (CAN message) reception data fault
	31	U0168	CAN 2	VI (CAN message) reception time-out error
412	3	P041D	EGR Gas Temperature Sensor	EGR gas temperature sensor fault (high voltage)
	4	P041C	EGR Gas Temperature Sensor	EGR gas temperature sensor fault (low voltage)
628	2	P1605	ECU Internal Fault	FlashROM checksum error (data sheet 1)
		P1606	ECU Internal Fault	FlashROM checksum error (data sheet 2)
	12	P0605	ECU Internal Malfunction	FlashROM checksum error (main software)
630	2	P1601	ECU Internal Fault	EEPROM error
	12	P0601	EEPROM	EEPROM memory deletion error
633	3	P0629	SCV (MPROP)	SCV (MPROP) high side VB short-circuit
	5	P0627	SCV (MPROP)	SCV (MPROP) open circuit
	6	P1642	SCV (MPROP)	SCV (MPROP) high side GND short-circuit
638	2	P1214	Engine	Malfunction
	3	P1213	Engine Fuel Rack Position Actuator	Shorted to high source
	4	P1212	Engine Fuel Rack Position Actuator	Shorted to low source
	7	P1211	Engine Fuel Rack Position Actuator	Mechanical malfunction
639	12	U0001	High Speed CAN	Communication fault
651	3	P1271	Injector 1 (Cylinder Number 4)	Injector 1 short-circuit
	5	P0204	Injector 1 (Cylinder Number 4)	Injector 1 open circuit (inherent location of the injector)
	6	P0271	Injector 1 (Cylinder Number 4)	Injector 1 coil short-circuit
	11	P0272	Injector 1 (Cylinder Number 4)	Injector 1 unclassified

Table 30: Yanmar Engine Diagnostic Trouble Codes (DTC)

DTC			Error Item	
SPN	FMI	P-Code	Part	State
652	3	P1262	Injector 1 (Cylinder Number 3)	Injector 1 short circuit
		P1268	Injector 4 (Cylinder Number 3)	Injector 4 short-circuit
	5	P0203	Injector 1 (Cylinder Number 3))	Injector 1 open circuit (inherent location of the Injector)
		P0203	Injector 4 (Cylinder Number 3)	Injector 4 open circuit (inherent location of the injector)
	6	P0268	Injector 1 (Cylinder Number 3)	Injector 1 coil short circuit
		P0268	Injector 4 (Cylinder Number 3)	Injector 4 coil short-circuit
	11	P1263	Injector 1 (Cylinder Number 3)	Injector 1 unclassified
		P1269	Injector 4 (Cylinder Number 3)	Injector 4 unclassified
653	3	P1265	Injector 2 (Cylinder Number 2)	Injector 2 short-circuit
	5	P0202	Injector 2 (Cylinder Number 2)	Injector 2 open circuit (inherent location of the injector)
	6	P0265	Injector 2 (Cylinder Number 2)	Injector 2 coil short-circuit
	11	P1266	Injector 2 (Cylinder Number 2)	Injector 2 unclassified
654	3	P1262	Injector 3 (Cylinder Number 1)	Injector 3 short-circuit
	5	P0201	Injector 3 (Cylinder Number 1)	Injector 3 open circuit (inherent location of the injector)
	6	P0262	Injector 3 (Cylinder Number 1)	Injector 3 coil short-circuit
	11	P1263	Injector 3 (Cylinder Number 1)	Injector 3 unclassified
1078	4	P0340	Fuel Injection Pump Speed Sensor	Shorted to low source
1079	2	P1644	Sensor 5V	Intermittent fault
	3	P0643	Sensor 5V	Shorted to high source
	4	P0642	Sensor 5V	Shorted to low source

Table 30: Yanmar Engine Diagnostic Trouble Codes (DTC)

DTC			Error Item	
SPN	FMI	P-Code	Part	State
1136	0	P0634	ECU Internal Temperature	Too high
	2	P1664	ECU Internal Temperature Sensor	Intermittent fault
	3	P0669	ECU Internal Temperature Sensor	Shorted to high source
	4	P0668	ECU Internal Temperature Sensor	Shorted to low source
1202	2	U423	Immobilizer	System fault
1209	3	P0473	EGR High Pressure Side Sensor	EGR low pressure side sensor fault (high voltage)
	4	P0472	EGR High Pressure Side Sensor	EGR low pressure side sensor fault (low voltage)
	13	P0471	EGR High Pressure Side Sensor	Abnormal learning value
1210	3	P1203	Engine Fuel Rack Position Sensor	Shorted to high source
	4	P1202	Engine Fuel Rack Position Sensor	Shorted to low source
1485	2	P068A	Main Relay	Power off without main relay self-holding / Main relay early opening
	4	P0686	ECU Main Relay	Shorted to low source
	7	P068B	Main Relay	Main relay contact stuck
2791	0	P0404	EGR Valve	EGR over-voltage malfunction
	1	P1404	EGR Valve	EGR low voltage malfunction
	7	P1409	EGR Valve	EGR feedback malfunction
	9	U0401	EGR Valve	EGR ECM data fault
	12	P0403	EGR Valve	Open circuit between the EGR motor coils
2797	6	P1146	Injector (Common)	Injector drive circuit (bank 1) short-circuit (common circuit for number 1, number 4)
2798	6	P1149	Injector (Common)	Injector drive circuit (bank 2) short-circuit (common circuit for number 2, number 3)
2950	3	P1658	Intake Throttle Drive Circuit	Power short-circuit of throttle valve drive H bridge output 1
	4	P1659	Intake Throttle Drive Circuit	GND short-circuit of throttle valve drive H bridge output 1
	5	P0660	Intake Throttle Drive Circuit	No-load of throttle valve drive H bridge circuit
	6	P1660	Intake Throttle Drive Circuit	Overload on the drive H bridge circuit of the throttle valve

Table 30: Yanmar Engine Diagnostic Trouble Codes (DTC)

DTC			Error Item	
SPN	FMI	P-Code	Part	State
2951	3	P1661	Intake Throttle Drive Circuit	VB power short-circuit of throttle valve drive H bridge output 2
	4	P1662	Intake Throttle Drive Circuit	GND short-circuit of throttle valve drive H bridge output 2
3242	0	P1436	DPF Inlet Temperature Sensor	DPF inlet temperature sensor temperature abnormally high
	3	P1428	DPF Inlet Temperature Sensor	DPF inlet temperature sensor fault (high voltage)
	4	P1427	DPF Inlet Temperature Sensor	DPF inlet temperature sensor fault (low voltage)
3250	0	P1426	DPF Intermediate Temperature Sensor	DPF intermediate temperature sensor temperature abnormally high (post-injection failure)
	1	P0420	DPF Intermediate Temperature Sensor	DPF intermediate temperature sensor temperature abnormally low
	3	P1434	DPF Intermediate Temperature Sensor	DPF intermediate temperature sensor fault (high voltage)
	4	P1435	DPF Intermediate Temperature Sensor	DPF intermediate temperature sensor fault (low voltage)
3251	0	P2452	DPF Differential Pressure Sensor	DPF differential pressure sensor differential pressure abnormally high
	3	P2455	DPF Differential Pressure Sensor	DPF differential pressure sensor fault (high voltage)
	4	P2454	DPF Differential Pressure Sensor	DPF differential pressure sensor fault (low voltage)
	13	P2453	DPF Differential Pressure Sensor	Abnormal learning value
3609	3	P1455	DPF High Pressure Sensor	DPF high pressure side sensor fault (high voltage)
	4	P1454	DPF High Pressure Sensor	DPF high pressure side sensor fault (low voltage)
3719	0	P1424	DPF OP Interface	Backup mode
	7	P1446	DPF OP Interface	Recovery regeneration prohibition
	9	P1445	DPF OP Interface	Recovery regeneration failure
	16	P1421	DPF OP Interface	Stationary regeneration standby
3720	0	P1420	DPF OP Interface	Ash cleaning request 2
	16	P242F	DPF OP Interface	Ash cleaning request 1
4257	12	P0611	Injector (Common)	Injector drive IC error
37251	16	P1437	DPF	Maintenance (maintenance not performed for a given period of time)

Table 30: Yanmar Engine Diagnostic Trouble Codes (DTC)

DTC			Error Item	
SPN	FMI	P-Code	Part	State
522241	2	P1224	Engine Fuel Rack Actuator Relay	Intermittent fault
	3	P1223	Engine Fuel Rack Actuator Relay	Circuit fault B
	4	P1222	Engine Fuel Rack Actuator Relay	Circuit fault A
	7	P1221	Reserved	N/A
522242	2	P1244	Cold Start Device	Intermittent fault
	3	P1243	Cold Start Device	Circuit fault B
	4	P1242	Cold Start Device	Circuit fault A
522243	2	P1234	Air Heater Relay	Intermittent fault
	3	P1233	Air Heater Relay	Circuit fault B
	4	P1232	Air Heater Relay	Circuit fault A
	5	P0543	Start Auxiliary Relay	Start auxiliary relay interrupted
	6	P0541	Start Auxiliary Relay	Start auxiliary relay GDN interrupted
522251	3	P1403	EGR Stepping Motor "A"	Circuit fault B
	4	P1402	EGR Stepping Motor "A"	Circuit fault A
522252	3	P1413	EGR Stepping Motor "B"	Circuit fault B
	4	P1412	EGR Stepping Motor "B"	Circuit fault A
522253	3	P1423	EGR Stepping Motor "C"	Circuit fault B
	4	P1422	EGR Stepping Motor "C"	Circuit fault A
522254	3	P1433	EGR Stepping Motor "D"	Circuit fault B
	4	P1432	EGR Stepping Motor "D"	Circuit fault A
522314	0	P1217	Engine Coolant Temperature	Abnormal temperature
522323	0	P1101	Air Cleaner Switch	Air cleaner clogged alarm
522329	0	P1151	Oil/Water Separator switch	Oil/water separator alarm
522400	2	P0336	Crank Sensor	Crank signal malfunction
	5	P0037	Crank Sensor	No crank signal
522401	2	P0341	Cam Sensor	Cam signal malfunction
	5	P0342	Cam Sensor	No cam signal
	7	P1341	Cam Sensor	Angle offset failure
522402	4	P1340	Aux Speed Sensor	Shorted to low source
522567	12	U1401	EGR	EGR target value out of range
522571	3	P1641	SCV (MPROP)	SCV (MPROP) low side VB short-circuit
	6	P1643	SCV (MPROP)	SCV (MPROP) low side GND short-circuit

Table 30: Yanmar Engine Diagnostic Trouble Codes (DTC)

DTC			Error Item	
SPN	FMI	P-Code	Part	State
522572	6	P062A	SCV (MPROP)	High-pressure pump drive circuit (drive current [high level])
	11	P1645	SCV (MPROP)	High-pressure pump drive circuit (pump overload error)
522573	0	P2463	DPF	Over-accumulation (method C)
522574	0	P1463	DPF	Over-accumulation (method P)
522575	7	P2458	DPF	Regeneration defect (stationary regeneration failure)
522576	12	P160E	EEPROM	EEPROM memory read error
522577	11	P2459	DPF	Regeneration defect (stationary regeneration not performed)
522578	12	P160F	EEPROM	EEPROM memory write error
522579	12	P1405	EGR	Short-circuit between the EGR motor coils
522580	12	P0488	EGR	EGR position sensor malfunction
522581	7	P148A	EGR	EGR stuck open valve malfunction
522582	7	P049D	EGR	EGR initialization malfunction
522583	1	P1410	EGR	EGR high temperature thermistor malfunction
522584	1	P1411	EGR	EGR low temperature thermistor malfunction
522585	12	P1613	ECU Internal Malfunction	CY146 SPE/SPI communication error
522588	12	P1608	ECU Internal Malfunction	Excessive supply 1 voltage error
522589	12	P1617	ECU Internal Malfunction	Dropped/Insufficient supply 1 voltage error
522590	12	P1609	ECU Internal Malfunction	Sensor supply voltage error 1
522591	12	P1618	ECU Internal Malfunction	Sensor supply voltage error 2
522592	12	P1619	ECU Internal Malfunction	Sensor supply voltage error 3
522593	12	P1624	ECU Internal Malfunction	Power for sensor SRC low error
522594	3	P160A	ECU Internal Malfunction	Actuator drive circuit 1 VB short-circuit
522595	3	P1625	ECU Internal Malfunction	Actuator drive circuit 2 VB short-circuit
522596	9	U0292	CAN 2	TSC1 (CAN message) reception time out (SA1)
522597	9	U1301	CAN 2	TSC1 (CAN message) reception time out (SA2)
522598	11	P160B	ECU Internal Malfunction	SW reset (recovery) execution 1
522599	9	U1292	CAN 2	Y_ECR1 (CAN message) reception time out error
	11	P1636	ECU Internal Malfunction	SW reset (recovery) execution 2

Table 30: Yanmar Engine Diagnostic Trouble Codes (DTC)

DTC			Error Item	
SPN	FMI	P-Code	Part	State
522600	9	U1293	CAN 2	Y_EC (CAN message) reception time out error
	11	P1637	ECU Internal Malfunction	SW reset (recovery) execution 3
522601	9	U1294	CAN 2	Y_RSS (CAN message) reception time out error
	12	P160D	ECU Internal Malfunction	WDA/ABE shut off due to dropped voltage
522602	12	P1639	ECU Internal Malfunction	WDA/ABE shut off due to excessive voltage
522603	9	U1296	CAN 2	VH (CAN message) reception time out
	12	P1640	ECU Internal Malfunction	WDA/ABE shut off due to unknown cause
522605	9	U1298	CAN 2	Y_ECM3 (CAN message) reception time out
522609	9	U1300	CAN 2	Y_ETCP1 (CAN message) reception time out
522610	9	U101B	CAN 1	CAN1 (for EGR): Reception time out error
	19	U040C	EGR	CAN1 (for EGR): Reception data length error
522611	9	U1107	CAN1 / Exhaust Throttle	Exhaust throttle (CAN message from the exhaust throttle time out)
522617	12	U1401	EGR Valve	EGR target value out of range
522618	9	U1302	CAN 2	EBC1 (CAN message) Reception time out error
522619	9	U1303	CAN 2	Y_DPFIF (CAN message) reception time out
522623	7	P1647	Acceleration Sensor 1/2	Dual accelerator sensor (open position)
522624	7	P1646	Acceleration Sensor 1/2	Dual accelerator sensor (closed position)
522727	12	P1610	ECU Internal Fault	Sub-CPU error A
	12	P1611	ECU Internal Fault	Sub-CPU error B
	12	P1612	ECU Internal Fault	Sub-CPU error C
522728	12	P1620	ECU Internal Fault	Engine map data version error
522730	8	U1167	Immobilizer	Pulse communication fault
	12	U0167	Immobilizer	Communication fault
522744	4	P1626	ECU Internal Malfunction	Actuator drive circuit 1 GND short-circuit
522746	12	P1438	Exhaust Throttle	Voltage fault
522747	12	P1439	Exhaust Throttle	Motor fault
522748	12	P1440	Exhaust Throttle	Sensor system fault
522749	12	P1441	Exhaust Throttle	MPU fault
522750	12	P1442	Exhaust Throttle	PCB fault

Table 30: Yanmar Engine Diagnostic Trouble Codes (DTC)

DTC			Error Item	
SPN	FMI	P-Code	Part	State
522751	19	P1443	Exhaust Throttle	CAN fault
522994	4	P1633	ECU Internal Malfunction	Actuator drive circuit 2 GND short-circuit
	12	P1607	ECU Internal Malfunction	WDA/ABE communication error
	12	P1615	ECU Internal Malfunction	CY320 SPI communication error
	12	P1616	ECU Internal Malfunction	MSC communication error of R2S2
523249	5	P0008	Cam Sensor	No signal from both sensors
523460	7	P1670	Rail Pressure Control/ Sensor	Rail pressure fault (operation time error during RPS limp mode)
523462	13	P1648	Injector (Correction Value)	IQA corrected injection amount for injector 1
523463	13	P1649	Injector (Correction Value)	IQA corrected injection amount for injector 2
523464	13	P1650	Injector (Correction Value)	IQA corrected injection amount for injector 3
523465	13	P1651	Injector (Correction Value)	IQA corrected injection amount for injector 4
523468	9	P1665	PLV (Common Rail Pressure Limit Value); Rail Pressure Sensor	Rail pressure fault (controlled rail pressure error after PLV valve opening)
523469	0	P1666	Rail Pressure Sensor	Rail pressure fault (PLV opening timing error)
523470	0	P1667	Rail Pressure Sensor	Rail pressure fault (PLV opening timing error)
523471	6	P1467	ECU Internal Malfunction	Actuator drive circuit 3 GND short-circuit
523473	12	P1469	ECU Internal Malfunction	AD converter fault 1
523474	12	P1470	ECU Internal Malfunction	AD converter fault 2
523475	12	P1471	ECU Internal Malfunction	External monitoring IC and CPU fault 1
523476	12	P1472	ECU Internal Malfunction	External monitoring IC and CPU fault 2
523477	12	P1473	ECU Internal Malfunction	ROM fault
523478	12	P1474	ECU Internal Malfunction	Shutoff path fault 1
523479	12	P1475	ECU Internal Malfunction	Shutoff path fault 2
523480	12	P1476	ECU Internal Malfunction	Shutoff path fault 3
523481	12	P1477	ECU Internal Malfunction	Shutoff path fault 4
523482	12	P1478	ECU Internal Malfunction	Shutoff path fault 5
523483	12	P1479	ECU Internal Malfunction	Shutoff path fault 6
523484	12	P1480	ECU Internal Malfunction	Shutoff path fault 7
523485	12	P1481	ECU Internal Malfunction	Shutoff path fault 8
523486	12	P1482	ECU Internal Malfunction	Shutoff path fault 9
523487	12	P1483	ECU Internal Malfunction	Shutoff path fault 10
523488	0	P1484	ECU Internal Malfunction	Recognition error of engine speed

Table 30: Yanmar Engine Diagnostic Trouble Codes (DTC)

DTC			Error Item	
SPN	FMI	P-Code	Part	State
523489	0	P1668	PLV (Common Rail Pressure Limit Value); Rail Pressure Sensor	Rail pressure fault (the actual rail pressure is too high during PRV limp mode)
543491	0	P1669	Rail Pressure Control/ Sensor	Rail pressure fault (injector B/F temp error during PLV4 limp home)
102	10	P1673	EGR Low Pres. Sensor Malfunction	Aftertreatment Error
105	10	P1676	Intake Air Temp. Sensor Malfunction	Aftertreatment Error
110	10	P1674	Coolant Temp. Sensor Malfunction	Aftertreatment Error
173	10	P1677	Exhaust Temp. Sensor Malfunction	Aftertreatment Error
412	10	P1675	EGR Gas Temp Sensor Malfunction	Aftertreatment Error
1209	10	P1679	EGR High Pres. Sensor Malfunction	Aftertreatment Error
3242	10	P167E	DPF Inlet Temp. Sensor Malfunction	Aftertreatment Error
3250	10	P167A	DPF Intermediate Temp Sensor Malfunction	Aftertreatment Error
3609	10	P167C	DPF High Pres. Sensor Malfunction	Aftertreatment Error
4795	31	P226D	DPF Substrate Removed	Aftertreatment Error

NOTES

CHAPTER 8

SPECIFICATIONS

Fluid Capacities/Lubricants

Table 31: Fluid Capacities/Lubricants


Component/ Application	Type	1350R	1500R	1650R
Engine Oil (with filter)	Refer to the Engine Operator's Manual for specific engine oil recommendations. Service Classification: API-CK-4 preferred, API-CJ-4 SM acceptable. Conventional oils - select the oil viscosity based on the ambient temperature where the engine is being operated. See SAE viscosity chart. Full Synthetic Oil 0W-40 is approved. Do not mix oil types.	6.7 L (7.1 qts.) (w/out filter)		9.5 L (10 qts.)
				
Hydraulic Oil Tank	Petro Canada HVI60, Mobil DTE 15M or equivalent, which contain anti-rust, anti-foam and anti-oxidation additives, and conforms to ISO VG46.	37.9 L (10 gal.)	41.6 L (11 gal.)	
Hydraulic System – Total	HVLPD 46 (HYD0530) Biodegradable oil: AVILUB Syntofluid 46; PANOLIN HLP Synth 46	53.0 L (14 gal.)	56.8 L (15 gal.)	

Table 31: Fluid Capacities/Lubricants

Component/ Application	Type	1350R	1500R	1650R
Grease Fittings, Lift Arm	Lithium-saponified, brand- name multi-purpose grease MPG-A	As Required		
Battery Terminals	SP-B acid-proof grease	As Required		
Diesel Fuel Tank	DPF Models: ULSD ^a ultra-low sulfur only, below 15 PPM. ASTM D975 with biodiesel content limited to 5% of DIN EN14214 type (no additives allowed!)	62.5 L (16.5 gal.)		
	Non-DPF Models: ASTM D975-94 (no additives allowed!) DIN EN14214 Biodiesel (no additives allowed!) LSD or ULSD ^a low sulfur or ultra-low sulfur, below 500 PPM. Up to 5% (B5) mixture of BioDiesel allowed			
Engine Coolant	Long life coolant ASTM D4985, D6210 (United States) SAE J814C, J1941, J1034 or J2036 (international) (See "Coolant Compound Mixtures" on page 193)	9.5 L (2.5 gal.)		14.4 L (3.8 gal.)
Radiator Cap Pressure	N/A	1.10 bar (16 psi)		
Chaincase (each)	SAE grade 10W-30 motor oil	5.7 L (6.0 qts.)	8.5 L (9 qts.)	
Motor Gearbox	Drive motor mechanism lubricated by hydraulic system oil.			

- a. Ultra-Low Sulfur Diesel (ULSD) fuel lubricity must have a maximum scar diameter of 0.45 mm, as measured by ASTM D6079 or ISO 12156-1, or a minimum of 3100 grams as measured by ASTM D6078. Contact your fuel supplier for details. Specification 1-D S15 or 2-D S15, ASTM D975.

Weights

Table 32: Weights

	1350R	1500R	1650R
Operating Weight (without counterweight)	2327 kg (5130 lbs.)	2690 kg (5930 lbs.)	2796 kg (6165 lbs.)
Operating Weight (with counterweight)	2424 kg (5345 lbs.)	2783 kg (6135 lbs.)	2887 kg (6365 lbs.)
Shipping Weight (without counterweight) ^a	2073 kg (4570 lbs.)	2422 kg (5340 lbs.)	2529 kg (5575 lbs.)
Shipping Weight (with counterweight)	2170 kg (4785 lbs.)	2515 kg (5545 lbs.)	2619 kg (5775 lbs.)

a. Without operator and bucket; with 10% fuel.

Payloads/Capacities

Note: Refer to “Common Materials and Densities” on page 199 for selecting the appropriate bucket.

Table 33: Payloads/Capacities (General)

	1350R	1500R	1650R
Rated Operating Load (w/o Counterweight)	612 kg (1350 lbs.)	680 kg (1500 lbs.)	748 kg (1650 lbs.)
Rated Operating Load (with Counterweight)	680 kg (1500 lbs.)	748 kg (1650 lbs.)	816.5 kg (1800 lbs.)
SAE Tipping Load (w/o Counterweight)	1225 kg (2700 lbs.)	1373 kg (3027 lbs.)	1486 kg (3275 lbs.)
SAE Tipping Load (with Counterweight)	1358 kg (2994 lbs.)	1506 kg (3320 lbs.)	1629 kg (3591 lbs.)
SAE Breakout Force – Tilt (w/o Counterweight)	1320 kg (2910 lbs.)	2059 kg (4540 lbs.)	2082 kg (4591 lbs.)
SAE Breakout Force – Lift (w/o Counterweight)	1346 kg (2967 lbs.)	1538kg (3391 lbs.)	1636 kg (3607 lbs.)

Table 34: Payloads/Capacities (Dirt/Construction Buckets) w/out Counterweight

	Weight	1350R Rating	1500R Rating	1650R Rating
1372 mm/0.28 m ³ (54 in./9.8 ft. ³)	131 kg (288 lbs.)	612 kg (1350 lbs.)	N/A	N/A
1524 mm/0.31 m ³ (60 in./11.0 ft. ³)	139 kg (306 lbs.)	600 kg (1323 lbs.)	695 kg (1533 lbs.)	738 kg (1627 lbs.)
1562 mm/0.32 m ³ (61.5 in./11.3 ft. ³)	140 kg (309 lbs.)	604 kg (1331 lbs.)	687 kg (1514 lbs.)	743 kg (1638 lbs.)
1778 mm/0.46 m ³ (70 in./16.1 ft. ³)	214 kg (471 lbs.)	N/A	N/A	688 kg (1517 lbs.)

Table 35: Payloads/Capacities (Construction Bucket with Spill Guard) w/out Counterweight

	Weight	1350R Rating	1500R Rating	1650R Rating
1562 mm/0.40 m ³ (61.5 in./14.1 ft. ³)	182 kg (415 lbs.)	671 kg (1479 lbs.)	757 kg (1670 lbs.)	812 kg (1790 lbs.)
1778 mm/0.59 m ³ (70 in./20.9 ft. ³)	152 kg (334 lbs.)	N/A	N/A	759 kg (1674 lbs.)

Table 36: Low Profile/Grading Buckets w/out Counterweight

	Weight	1350R Rating	1500R Rating	1650R Rating
1778 mm/0.55 m ³ (70 in./19.4 ft. ³)	228 kg (527 lbs.)	N/A	N/A	609 kg (1343 lbs.)

Table 37: Utility (Light Material) Buckets

	Weight	1350R Rating	1500R Rating	1650R Rating
1372 mm/0.43 m ³ (54 in./15.1 ft. ³)	177 kg (390 lbs.)	559 kg (1233 lbs.) ^a	N/A	N/A
1524 mm/0.48 m ³ (60 in./16.9 ft. ³)	187 kg (412 lbs.)	554 kg (1222 lbs.)	631 kg (1392 lbs.)	N/A
1676 mm/0.54 m ³ (66 in./19.0 ft. ³)	203 kg (476 lbs.)	538 kg (1186 lbs.)	606 kg (1336 lbs.)	656 kg (1446 lbs.)
1778 mm/0.57 m ³ (70 in./20.3 ft. ³)	228 kg (502 lbs.)	N/A	N/A	651 kg (1436 lbs.)

a. Can be used on 1350R with 8.50 or 10.50 tires, but will provide zero (0) heel clearance

Table 38: Pallet Forks

	1350R	1500R	1650R
SAE Tipping Load (w/o Counterweight) 406 mm (16 in) (en 474-3)	418 kg (922 lbs.)	490 kg (1080 lbs.)	526 kg (1159 lbs.)
SAE Tipping Load (w/o Counterweight) 508 mm (20 in) (en 474-3)	384 kg (847 lbs.)	457 kg (1008 lbs.)	492 kg (1084 lbs.)
SAE Tipping Load (w/o Counterweight) 610 mm (24 in) (en 474-3)	362 kg (797 lbs.)	428 kg (944 lbs.)	458 kg (1010 lbs.)

Table 39: Engine

	1350R	1500R	1650R
Engine Make/Model	Yanmar 4TNV88C-KMSV (DPF Models)		Yanmar 4TNV98C-NMS2V (DPF Models)
	Yanmar 4TNV88-BKMSR2 (Non-DPF Models)		4TNV98-ZNMS3R (Non-DPF Models)
Low/High Idle	1100 / 2830 RPM		2530/1000 RPM
Design	In-line 4 cylinder, 4-stroke diesel, naturally aspirated		
Displacement	2.19 L (133.6 in ³)		3.3 L (201.4 in ³)
Bore and Stroke	88 × 90 mm		98 × 110 mm
Gross Power	34.5 kW (46.3 HP) @ 2800 rpm		52 kW (69.9 HP) @ 2800 rpm
Net Power	33 kW (44.5 HP) @ 2800 rpm		51 kW (68.4 HP) @ 2800 rpm
Peak Torque	146 Nm (107.8 ft-lbs) @ 1820 rpm		241 Nm (178 ft-lbs) @ 1625 rpm
Low/High Idle	1100 / 2830 rpm		1100 / 2530 rpm
Fuel Injection System	Direct injection with common rail injection system		
Fuel Delivery	High-pressure common rail		
Fuel Shut-off	On individual injectors		
Fuel Filtering	In-line filter cartridge with water trap and replaceable element		
Firing Order	1-3-4-2-1 (from flywheel end)		
Normal Starting Aid	Glow plugs		
Cold Starting Aid (Optional)	Engine block / Oil pan heater		
Lubrication	Forced lubrication with trochoid pump		
Crankcase Ventilation	Closed		
Max. Inclined Angle (engine still supplied with oil)	30° in all directions		
Cooling System	Water/ethylene glycol		
Permissible Coolant Temperature	110°C (230°F)		
Thermostat Rating	82° C (180°F) cracking / 95° C (203°F) full open		
Fan Type / Ratio	Pusher / 1:1		Pusher / 0.867:1
Exhaust Emission Compliance	EPA Tier 4 / EU Stage 5		
Electric Starter Motor Power	12 VDC - 2.3 kW (3.1 HP)		12 VDC - 3.0 kW (4.0 HP)
Alternator Voltage / Amperage	12-14VDC / 100 A		
Operating Range- Ambient Temperature ^a	-15°C (+5°F) – +45°C (+113°F)		

a. Operation above temperature range may result in overheating; operation below temperature range may result in hard-starting. Contact your dealer before operating the machine outside temperature range.

Coolant Compound Mixtures

Table 40: Coolant Compound Mixtures

Outside Temperature	Water	Anti-corrosion agent		Antifreeze
Up to °F (°C)	% by volume	in ³ /gal (cm ³ /L)	% by Volume	% by Volume
39 (4)	99	2.6 (10)	1	–
14 (-10)	79			20
-4 (-20)	65			34
-13 (-25)	59			40
-22 (-30)	55			45
-44 (-42)	50			50

Hydraulics

Table 41: Hydraulics

	1350R	1500R	1650R T-Bar, Hand/ Foot	1650R Joysticks
Main Hydraulic System Pressure / Auxiliary System Standard-Flow - Relief Valve Opening Pressure	207 bar (3000 psi)			
Standard-Flow Auxiliary System @ Speed (theoretical)	60.5 L/min (16.0 gpm) @ 2830 rpm	62 L/min (16.4 gpm) @ 2830 rpm	77.2 L/min (20.4 gpm) @ 2530 rpm	70.8 L/min (18.7 gpm) @ 2530 rpm
High-Flow Auxiliary System Pressure			2600 psi (179 bar)	
High-Flow Auxiliary System Rating@ Speed (theoretical)			113.9 L/min (30.1 gpm) @ 2530 rpm	121.5 L/min (32.1 gpm) @ 2530 rpm
Cylinder Type	Double-acting			
Lift – SAE Raising Time	3.71 secs.	4.42 secs.	3.82 secs.	
Lift – SAE Lowering Time	2.32 secs.	2.88 secs.	2.61 secs.	
Tilt – SAE Dumping Time	0.88 secs.	2.70 secs.	1.30 secs.	
Dumping Time Stop-to-Stop	1.91 secs.	2.83 secs.	2.40 secs.	
Tilt – SAE Rollback Time	1.03 secs.	1.60 secs.	1.30 secs.	
Tilt – Rollback Time Stop-to-Stop	1.40 secs.	2.03 secs.	1.80 secs.	

Travel Speeds

Table 42: Travel Speeds

	1350R	1500R	1650R
Low Speed Range (One-Speed)	0 - 12.9 km/h (8.0 mph)	0 - 11.9 km/h (7.4 mph)	0 - 12.2 km/h (7.6 mph)
Low Speed Range (Two-Speed Option)	N/A	N/A	0 - 12.6 km/h (7.8 mph)
High Speed Range (Two-Speed Option)	N/A	N/A	0 - 19.5 km/h (12.1 mph)

Electrical System

Table 43: Electrical System

	1350R	1500R	1650R
Glow Plug (Engine Pre-heat)	Auto with glow lamp		
Electrical System Voltage	12.6 V		
Alternator	100 Amp		
Battery			
Type	Maintenance-free		
Volts	12		
Group Size	34	31	
Cold Cranking Amps @ Temperature	950 CCA @ -18°C (0°F)	950 CCA @ -18°C (0°F)	
Minimum Reserve Capacity	115 minutes minimum	170 minutes minimum	

Sound Levels

Table 44: Sound Power/Pressure Levels^a

Sound Power Level (Environmetal)	101 dB(A)
Sound Pressure Level (Operator Ear)	85 dB(A)

a. With sound attenuation package. R165 with Tier 4 engine; R135/R150 with interim Tier 4 engine.

Vibration Levels

Table 45: Whole-Body and Hand-Arm Vibration Levels^a

Model 1650R		
Whole Body Vibration Values		
Seat Option	Vibration m/s ²	Uncertainty m/s ²
Standard Non-Suspension	1.05	0.5
Mechanical Suspension	0.96	0.5
Air Ride Suspension	0.97	0.5
Hand-Arm Vibration Values		
Control Option	Vibration m/s ²	Uncertainty m/s ²
Hand/Foot	1.13	0.6
T-Bar	1.53	0.8
Pilot	1.27	0.6
Model 1500R		
Whole Body Vibration Values		
Seat Option	Vibration m/s ²	Uncertainty m/s ²
Standard Non-Suspension	0.80	0.4
Mechanical Suspension	0.68	0.3
Air Ride Suspension	0.73	0.4
Hand-Arm Vibration Values		
Control Option	Vibration m/s ²	Uncertainty m/s ²
Hand/Foot	1.60	0.8
T-Bar	1.30	0.7
Model 1350R		
Whole Body Vibration Values		
Seat Option	Vibration m/s ²	Uncertainty m/s ²
Standard Non-Suspension	0.90	0.5
Mechanical Suspension	0.81	0.4
Air Ride Suspension	0.75	0.4
Hand-Arm Vibration Values		
Control Option	Vibration m/s ²	Uncertainty m/s ²
Hand/Foot	1.90	1
T-Bar	1.77	0.9

a. Whole-Body Vibration levels in accordance with ISO 2631-1. Hand-Arm Vibration levels in accordance with ISO 5349-1.

Dimensions




Table 46: Dimensions

		1350R	1500R	1650R
A	Overall Operation Height – Fully Raised	3655 mm (143.9 in.)	3876 mm (152.6 in.)	
B	Height to Hinge Pin – Fully Raised	2784 mm (109.6 in.)	3023 mm (119 in.)	
C	Overall Height – Top of ROPS	1908 mm (75.1 in.)	1948 mm (76.7 in.)	
D	Overall Length – Bucket Down (w/o Counterweight)	3056 mm (120.3 in.)	3101 mm (122.1 in.)	
	Overall Length – Bucket Down (with Counterweight)	3091 mm (121.7 in.)	3139 mm (123.6 in.)	
E	Dump Angle at Full Height	40°	38°	
F	Dump Height (42° Bucket Angle)	2090 mm (82.6 in.)	2379 mm (93.7 in.)	
G	Dump Reach – Bucket Full Height (42° Bucket Angle)	577 mm (22.7 in.)	579 mm (22.8 in.)	
J	Rollback at Ground	29°	28°	
M	Rollback Angle at Full Height	82°	99°	
O	Seat to Ground Height	846 mm (33.3 in.)	904 mm (35.6 in.)	
P	Wheelbase – Normal	955 mm (37.6 in.)	988 mm (38.9 in.)	
Q	Overall Width (w/o Bucket) ^a	1364 mm (53.7 in.)	1580 mm (62.2 in.)	
R	Bucket Width – Overall	1372 mm (54.0 in.)	1562 mm (61.5 in.)	
S	Ground Clearance – to Chassis (Between Wheels)	201 mm (7.9 in.)	160 mm (6.3 in.)	
V	Overall Length – (w/o Bucket & with Counterweight)	2342 mm (92.2 in.)	2385 mm (93.9 in.)	
	Overall Length – (w/o Bucket & with Counterweight)	2380 mm (93.7 in.)	2426 mm (95.5 in.)	

Table 46: Dimensions

		1350R	1500R	1650R
W	Departure Angle (w/o Counterweight)	25°	21°	
	Departure Angle (with Counterweight)	21°	19°	
X	Clearance Circle – Front (with Bucket)	1842 mm (72.5 in.)	1869 mm (73.6 in.)	
Y	Clearance Circle – Front (w/o Bucket)	1120 mm (44.1 in.)	1130 mm (45.4 in.)	
Z	Clearance Circle – Rear (w/o Counterweight)	1372 mm (54.0 in.)	1466 mm (57.7 in.)	
	Clearance Circle – Rear (w/o Counterweight)	1417 mm (55.8 in.)	1519 mm (59.8 in.)	

a. Overall width (Q) is dependent upon amount of wheel offset.

Features

Table 47: Standard Features

Indicator and Warning Lamp Display	Pre-Heat Starting Assist
Hydraulic Oil Temperature Indicator Lamp	Lift Arm Support Device
Battery Charge Indicator Lamp	Dual Front and Rear Halogen Work Lights and Dual Tail Lights
Seat Belt Indicator	Bi-directional Auxiliary Hydraulics with Flat-Faced Couplers
Choice of three control types: • Pilot-Controlled Hydrostatic Drive (Hand/Foot) • Pilot-Controlled Hydrostatic Drive (Dual Joystick^a) • Servo-Controlled Hydrostatic Drive (T-Bar)	All-Tach® Attachment Mounting System: Single-Lever (manual)
Hand Throttle	Engine Auto-Shutdown System
Foot Throttle (Dual Joystick and T-Bar) ^b	Emergency Exit Rear Window
Operator Restraint Bar	Hydrostatic Drive – Servo
ROPS/FOPS (ISO 3471, ISO 3449 Level II)	Acoustical Cab Material and Headliner
Skid Plate for Clean Out	Electric (Battery) Disconnect Switch ^c
Hydraloc™ System – Brakes and Interlock for Starter, Lift Cylinders, Tilt Cylinders, Auxiliary Hydraulics, Wheel Drives	Horn
Anti-Vandalism Rear Grille	Float Control
Self-Leveling Lift Action with cancel button	Interior Dome Light
Dual-Element Air Cleaner with Indicator	3-Spool Open Center Control Valve
12 VDC Power Socket	Swing-out Radiator
Hydrostatic Dynamic Braking	Parking / Emergency Brake
Auto / Manual Brake Control	DPF (Diesel Particulate Filter) Technology
Remote Engine Oil Filter	Proportionate Auxiliary Hydraulic Control

Table 47: Standard Features

Connect Under Pressure Auxiliary Couplers	Dual Lift / Tilt Cylinders with Induction Hardened Chrome Plated Cylinder Rods
Independent Hydraulic Reservoir with Cooler	Cup Holder / Storage Tray
Deluxe High-Back, Cushion Seat	Zero Maintenance Axles

- a. Available only on Model 1650R
- b. Not available with hand/foot controls.
- c. EU machines only

Table 48: Optional Features

Self-Leveling Lift Action with cancel button	Engine Block Heater
3-inch Wide Seat Belt (Where Required by State Law)	Four- and Single-Point Lift System Kits
Upper-torso Restraint (Required with Two-Speed Drive)	Two-Speed Drive ^a
Sliding Side Windows	Lift Kit - Single Point Lift System
Rear-View Mirror	Hydraglide™ Ride Control System (T-Bar) ^b
Front Door with Wiper	Operator's Compartment Heater/Defroster with Filters
Impact-Resistant Front Door Window	Power-A-Tach® System Hydraulic-Powered Quick-Attach
Audible Back-Up Alarm	Adjustable Air or Mechanical Suspension Seats
Strobe Light	Bucket Bolt-On Cutting Edge Kits
Electric (Battery) Disconnect Switch ^c	Counterweight
Radio System	Cab Enclosure
Mechanical / Air Suspension Seat	

- a. Model 1650R only.
- b. Not available on Model 1350R.
- c. Standard on EU Machines

Common Materials and Densities

Table 49: Common Materials and Densities

Material	Density	
	lbs./ft. ³	kg/m ³
Ashes	35-50	560-800
Brick-common	112	1792
Cement	110	1760
Charcoal	23	368
Clay, wet-dry	80-100	1280-1600
Coal	53-63	848-1008
Concrete	115	1840
Cinders	50	800
Coal-anthracite	94	1504
Coke	30	480
Earth-dry loam	70-90	1121-1442
Earth-wet loam	80-100	1281-1602
Granite	93-111	1488-1776
Gravel-dry	100	1602
Gravel-wet	120	1922
Gypsum-crushed	115	1840
Iron ore	145	2320
Lime	60	960
Lime stone	90	1440
Manure-liquid	65	1040
Manure-solid	45	720
Peat-solid	47	752
Phosphate-granular	90	1440
Potash	68	1088
Quartz-granular	110	1760
Salt-dry	100	1602
Salt-rock-solid	135	2160
Sand-dry	108	1728
Sand-wet	125	2000
Sand-foundry	95	1520
Shale-crushed	90	1440
Slag-crushed	70	1120
Snow	15-50	240-800
Taconite	107	1712

Note: The densities listed are average values and intended only as a guide for bucket selection. For a material that is not in the table, obtain its density value before selecting the appropriate bucket.

Direct and/or Indirect Visibility

Tested in accordance with ISO 5006: 2017.

The machine has been subjected to a static visibility assessment with the lift structure in a carry position or 200 mm (7-7/8 in.) above the ground.

The test simulates operator visibility from the operator’s position:

- The line of sight between the operator’s eye position and a point on the ground at a 12 m (472 in.) radius.
- On a rectangular boundary 1 m (39 in.) from the machine, 12 m (47 in.) above the ground.
- Masking was recorded as shown (Fig. 6), and is within the allowable limits in accordance with ISO 5006: 2017.
- The standard/test does not account for head movement or rotation, which can improve visibility and mitigate masking.
- During machine operation, the operator must continually survey all areas around the machine in all directions.

This diagram indicates the blind spot zone on the visibility test circle (radius = 12 m [47 ft.]) and the 1 m (39in.) rectangular zone around the machine.




Fig. 6 – Visibility Performance

INDEX

A

Accessory Keypad	51
Accessory Plug	76
Activating The Warning Circuit	79
Attachment Hitch	77, 78
Attachment Mounting	77
Attachment Transport Position	96
Attachments	
Changing	97, 98
Using Buckets	104
Auxiliary Hydraulic System	80
Auxiliary Hydraulic Couplers	80
Connecting Couplings	101
Disconnecting Couplings	102
Auxiliary Hydraulics System	
Auxiliary Hydraulics Control	81

B

Back-Up Alarm	124
Battery Disconnect Switch	46, 76
Beacon	74
Brake Release Option	91
Bucket	
Cutting Edge	152
Buckets	104
Backfilling	108
Cutting Edge	152
Digging with a Bucket	105
Dumping a Load onto a Pile	106
Grading	109
Loading a Bucket	106
Scraping	109

C

Cab Door Electrical Connection	86
Cab Entry and Exit	85
Cab Heat/Cool	74
Camera Observation System	122
Chaincase	
Drive Chain Tension	152

Maintenance	151
Oil Maintenance	151
Changing Attachments	98
Connection Attachments	98
Control Keypad	48
Controls	47, 59
Hand and Foot Controls	67
Joystick Controls	64
T-Bar Controls	61
Throttle Controls	60

D

Dealer Services	161
Dome Light	75
DPF Regeneration Procedures	118
DPF Maintenance	122, 144
Forcing Stationary Regeneration	121
Reset Regeneration	119
Reset Regeneration Inhibit	119
Stationary Regeneration	120
Drive Motor Maintenance	151

E

Electrical System	154
Battery	157
Fuses, Relays and Diodes	155
Electronic Display	53
Emergency Exit/Rear Window	43
Engine	
Changing Oil	137
Changing Oil Filter	137
Cooling System	145
Maintenance	136
Oil Level Check	137
Engine Stalling	90

F

Fields of Application	6
Final Shutdown / Decommissioning	160
Fire Extinguisher Location	11

Float/Lift Arm	71
Fuel System	
Adding Fuel	139
Maintenance	139
Water Separator	140
Fuses	155

G

General Information	83, 125
Grading	109

H

HVAC	74
Hydraulic Hose Maintenance ...	150
Hydraulic System	
Checking Oil Level	147
Hose Maintenance	150
Maintenance	146
Oil Changing	149
Oil Filter	148

I

Ignition Keyswitch	59
Indicator/Operation Symbol	12
Indicators	47
Information Center Electronic Display	
53	
Introduction	1

J

Jump-starting	92
---------------------	----

L

Lift Arm	96
Lift Arm Support	44
Lift Arm Float	71, 96
Lifting the Machine	117, 134
Lights	
Beacon	74
Position	74
Work	74
Lights/Lockout Keypad	52
Lubrication	132

M

Machine Disposal	161
------------------------	-----

Machine Orientation	3
Maintenance	125
Chaincase	151
Chaincases	151
Cooling System	145
Draining/Flushing ...	146
Engine	136
Fuel System	139
Hydraulic System	146
V-Belt	144

Maintenance Log	129
Maintenance Schedules	127
Manual Contents and Use	1
Manufacturer Information	11
Model Identification	3
Model Numbers	5

O

Operation	83
Before Starting	83
Checks During Operation ...	84
Driving on an Incline/slope ..	95
Driving over Rough Terrain ..	95
Engine Starting	87
After Starting	89
Cold-Starting	88
Jump-starting	92
Pre-Start Checks ...	83
Grading	109
Lift Arm	96
Lift Arm Float	71, 96
Operational Checks	83
Pallet Forks	111
Ride Control System	97
Run-In Period	90
Self-Leveling	103
Stalling	90
Stopping the Machine	90
Transport on Public Roads ..	95
Travel Drive	94
Using Buckets	104
Using Pallet Forks	111
Warm Up	90

Operator Restraint Bar	41
Operator's Manual Overview	1
Operator's Position	39
Operator's Seat	39
Seat Suspension	40

P

Pallet Forks	111
Transporting Loads	113
Parking Brake	43
Parking the Machine	91
Position Lights	74
Product and Component Plate Locations	38

R

Registration, Machine	4
Relays	155
Ride Control System	73, 97
Road Lights	174
ROPS/FOPS	43
ROPS/FOPS, Tilting	133
Run-In Period	90

S

Safety	13
Additional Safety Equipment ..	16
Applications with Load-Handling Devices	19
Battery Hazards	23
Before Starting	14
Crystalline Silica Exposure ...	24
During Operation	16
Electrical Energy	20
Fire Hazards	23
Guards and Shields	39
Lift Arm Support	44
Lifting the Machine with a Crane	24
Loading and Transporting the Machine	25
Maintenance	21
Mandatory Safety Shutdown Procedure	14
Pallet Forks	111

Proper Machine Use	4
Rear Window Emergency Exit ..	43
Safety Alert Symbol	1, 13
Safety Decals	25
ANSI-Style Safety Decals ..	26
ISO-Style Safety Decals ..	32
Safety Equipment	39
Safety Interlock System	42
Safety Signal Words	1, 13
Transporting the Machine ...	24
Safety Seat and Restraint Bar Switches	152
Seat	39
Seat Belt	40
Upper Torso Restraint	41
Self-Leveling	103
Self-Leveling Cancel	104
Serial Numbers	5
Specifications	187
Coolant Compound Mixtures ..	193
Electrical System	194
Engine	192
Fluid Capacities/Lubricants ..	187
Hydraulics	193
Payloads/Capacities	190
Sound Levels	194
Travel Speeds	194
Vibration Levels	195
Weights	189
Stalling	90
Starting the Engine	87
Storage, Long-Term	158

T

Tire Maintenance	153
Towing	116
Transport Hydraulics Lock-out ...	95
Transporting the Machine	115
Troubleshooting	163
Drive System	171
Electrical	173
Engine Diagnostic Trouble Codes (DTC)	175

Error Codes 175

Hydraulic System 167

Seal and Hose 167

Two-Speed Drive 69, 94

U

Upper Torso Restraint 41

V

V-Belt Maintenance 144

Vibration Information 9, 195

W

Wheel Nuts 153

Windshield Washer 158

Windshield Wiper/Washer 75

Work Lights 74

Torque Specifications

Note: Use these torque values when tightening hardware (excluding: locknuts and self-tapping, thread forming and sheet metal screws) unless specified otherwise.

UNIFIED NATIONAL THREAD	GRADE 2		GRADE 5		GRADE 8	
	DRY	LUBED	DRY	LUBED	DRY	LUBED
8-32	19*	14*	30*	22*	41*	31*
8-36	20*	15*	31*	23*	43*	32*
10-24	27*	21*	43*	32*	60*	45*
10-32	31*	23*	49*	36*	68*	51*
1/4-20	66*	50*	9	75*	12	9
1/4-28	76*	56*	10	86*	14	10
5/16-18	11	9	17	13	25	18
5/16-24	12	9	19	14	25	20
3/8-16	20	15	30	23	45	35
3/8-24	23	17	35	25	50	35
7/16-14	32	24	50	35	70	55
7/16-20	36	27	55	40	80	60
1/2-13	50	35	75	55	110	80
1/2-20	55	40	90	65	120	90
9/16-12	70	55	110	80	150	110
9/16-18	80	60	120	90	170	130
5/8-11	100	75	150	110	220	170
5/8-18	110	85	180	130	240	180
3/4-10	175	130	260	200	380	280
3/4-16	200	150	300	220	420	320
7/8-9	170	125	430	320	600	460
7/8-14	180	140	470	360	660	500
1-8	250	190	640	480	900	680
1-12	270	210	710	530	1000	740
METRIC COARSE THREAD	GRADE 8.8		GRADE 10.9		GRADE 12.9	
	DRY	LUBED	DRY	LUBED	DRY	LUBED
M6-1	8	6	11	8	13.5	10
M8-1.25	19	14	27	20	32.5	24
M10-1.5	37.5	28	53	39	64	47
M12-1.75	65	48	91.5	67.5	111.5	82
M14-2	103.5	76.5	145.5	108	176.5	131
M16-2	158.5	117.5	223.5	165.5	271	200

*All Torque Values are in ft-lbs. except those marked with an *, which are in-lbs.

For metric torque value (N·m), multiply ft-lbs. value by 1.355 or the in-lbs. value by 0.113.



For Support and Service, Contact Your Dealer



Manitou Group
One Gehl Way, West Bend, WI 53095-0179 U.S.A.
www.us.manitou.com / www.mustangmfg.com

© 2022 All rights reserved