

KUKJE Branson 2100 Branson Tractor

Parts Catalogue



BRANSON TRACTOR

CONTENTS

GROUP NO	GROUP NAME	PAGE
000	00 TRACTOR PARTS(2014~)	6
T001A	1. AIR CLEANER	8
T002A	2. COMP MUFFLER	10
T003	3. ACCELERATOR LEVER	12
T005	5. FUEL TANK	14
T006	6. FUEL FILTER & PIPE	16
T007	7. WATER PIPE	18
T008	8. RADIATOR	20
T009	9. RESERVE TANK	22
T010A	10. BATTERY	24
T011-1A	11. SWITCH	26
T011-2A	SWITCH(2017.11)	28
T012-2A	SWITCH PANEL BOARD(2017.11)	30
T012A	12. SWITCH PANEL BOARD	32
T013.1	13. HEAD LIGHT	34
T013.2	13. HEAD LIGHT	36
T014A	14. TAIL LIGHT	38
T015	15. WINKER LAMP	40
T016A	16. ELECTRICAL WIRING	42
T017	17. CLUTCH	44
T018	18. CLUTCH ROD & RELEASE	46
T019	19. CLUTCH PEDAL	48
T020-1	20. CLUTCH HOUSING	50
T020-2	20. CLUTCH HOUSING	52
T021-1	21. CENTER FRAME	54
T021-2	21. CENTER FRAME	56
T022	22. TRANSMISSION CASE	58
T024	24. DIFFERENTIAL GEAR CASE	60
T025	25. REAR CASE	62
T026	26. CLUTCH SHAFT	64
T027	27. PROPELLER SHAFT	66
T030	30. FRONT SHAFT	68
T032-1	32. PTO SHAFT	70
T032-2	32. PTO SHAFT	72
T034	34. MID PTO	74

GROUP NO	GROUP NAME	PAGE
T036	36. MID PTO COVER	76
T037	37. REAR DIFFERENTIAL	78
T038	38. FRONT WHEEL PROPELLER SHAFT	80
T040	40. 2ND SHAFT	82
T042	42. 3RD.SHAFT	84
T044	44. 4TH. SHAFT	86
T046	46. MAIN GEAR SHIFT FORK	88
T047	47. RANGE GEAR SHIFT FORK	90
T048	48. PTO GEAR SHIFT FORK	92
T050	50. DIFFERENTIAL LOCK SHIFT FORK	94
T051	51. REAR AXLE	96
T052	52. BRAKE	98
T053	53. BRAKE ROD	100
T054	54. BRAKE PEDAL	102
T055	55. BRAKE SWITCH	104
T056	56. SIDE BRAKE	106
T057	57. MAIN GEAR SHIFT LEVER	108
T061	61. RANGE GEAR SHIFT LEVER	110
T062	62. FRONT WHEEL DRIVE LEVER	112
T063	63. PTO GEAR SHIFT LEVER	114
T065	65. POSITION CONTROL LEVER	116
T066	66. DIFFERENTIAL LOCK PEDAL	118
T068-1	68. FRONT AXLE FRAME	120
T068-2	68. FRONT AXLE FRAME	122
T069	69. FRONT AXLE CASE	124
T070-1	70. FRONT DIFFERENTIAL	126
T070-2	FRONT DIFFERENTIAL	128
T071	71. DIFFERENTIAL GEAR SHAFT	130
T072-1	72. BEVEL GEAR CASE	132
T072-2	BEVEL GEAR CASE(2017.05)	134
T073	73. FRONT AXLE CASE	136
T074	74. FRONT SPINDLE	138
T075	75. FORNT DRIVE SHAFT	140
T077	77. PST CYLINDER COVER	142
T078	78. TIE ROD	144

GROUP NO	GROUP NAME	PAGE
T079	79. STEERING WHEEL	146
T080	80. STEERING POST	148
T081	81. PST UNIT	150
T082	82. HYDRAULIC PUMP	152
T083	83. HYDRAULIC OIL LINE (SUCTION)	154
T084A	84. HYDRAULIC OIL LINE (DELIVERY)	156
T085A	85. HYDRAULIC STEERING LINE	158
T086-2H	86. HYDRAULIC OIL LINE - HST	160
T088	88. HYDRAULIC OIL LINE (F/M)	162
T090	90. HYDRAULIC CYLINDER	164
T091	91. HYDRAULIC CYLINDER (POSITION TYPE)	166
T092	92. HYDRAULIC PISTON / LIFT ARM	168
T093	93. FEED BACK LEVER	170
T094	94. FEED BACK LEVER (POSITION TYPE)	172
T095	95. CONTROL VALVE	174
T096	96. 3PT LIFT VALVE (POSITION TYPE)	176
T097	97. LIFT LINK	178
T098	98. LIFT ARM	180
T099	99. TOP LINK	182
T100	100. CHECK CHAIN	184
T101	101. DRAW BAR	186
T102	102. PTO SHEILD	188
T103-1	103. HOOD	190
T103-2	103. HOOD	192
T104	104. PANEL COVER	194
T105	105. SHUTTER PLATE	196
T106	106. LEVER GUIDE	198
T108	108. FENDER	200
T109	109. FENDER STAY	202
T110	110. FLOOR SEAT	204
T111	111. SEAT	206
T112	112. SEAT - EU	208
T114	114. STEP	210
T115	115. ROPS	212
T116	116. MID ROPS - PO	214

[illegible]

FIG 000 Branson 2100	00 TRACTOR PARTS(2014~)	Year/Month 2020/02
------------------------------------	--------------------------------	----------------------------------



00 TRACTOR PARTS



ENGINE

FIG T001A

Branson 2100

1. AIR CLEANER

Year/Month

2020/02




FIG T002A

2. COMP MUFFLER

Year/Month

2020/02

Branson 2100




FIG T003

Branson 2100

3. ACCELERATOR LEVER

Year/Month

2020/02




FIG T005

Branson 2100

5. FUEL TANK

Year/Month

2020/02





FIG T006

Branson 2100

6. FUEL FILTER & PIPE

Year/Month

2020/02



[illegible]


FIG T007

Branson 2100

7. WATER PIPE

Year/Month

2020/02



[illegible]

FIG T008

Branson 2100

8. RADIATOR

Year/Month

2020/02




FIG T009

Branson 2100

9. RESERVE TANK

Year/Month

2020/02




FIG T010A

Branson 2100

10. BATTERY

Year/Month

2020/02





FIG T011-1A

Branson 2100

11. SWITCH

Year/Month

2020/02



[illegible]

FIG T011-2A

SWITCH(2017.11)

Year/Month

2020/02

Branson 2100





FIG T012-2A

Branson 2100

SWITCH PANEL BOARD(2017.11)

Year/Month

2020/02



[illegible]

FIG T012A

Branson 2100

12. SWITCH PANEL BOARD

Year/Month

2020/02




FIG T013.1

Branson 2100

13. HEAD LIGHT

Year/Month

2020/02




FIG T013.2

Branson 2100

13. HEAD LIGHT

Year/Month

2020/02




FIG T014A

Branson 2100

14. TAIL LIGHT

Year/Month

2020/02




FIG T015

Branson 2100

15. WINKER LAMP

Year/Month

2020/02




FIG T016A

Branson 2100

16. ELECTRICAL WIRING

Year/Month

2020/02




FIG T017

Branson 2100

17. CLUTCH

Year/Month

2020/02





FIG T018

Branson 2100

18. CLUTCH ROD & RELEASE

Year/Month

2020/02



[illegible]


FIG T019

Branson 2100

19. CLUTCH PEDAL

Year/Month

2020/02



[illegible]


FIG T020-1

Branson 2100

20. CLUTCH HOUSING

Year/Month

2020/02



[illegible]


FIG T020-2

Branson 2100

20. CLUTCH HOUSING

Year/Month

2020/02



[illegible]

FIG T021-1

Branson 2100

21. CENTER FRAME

Year/Month

2020/02




FIG T021-2

Branson 2100

21. CENTER FRAME

Year/Month

2020/02





FIG T022

Branson 2100

22. TRANSMISSION CASE

Year/Month

2020/02



[illegible]

FIG T024

Branson 2100

24. DIFFERENTIAL GEAR CASE

Year/Month

2020/02




FIG T025

Branson 2100

25. REAR CASE

Year/Month

2020/02





FIG T026

Branson 2100

26. CLUTCH SHAFT

Year/Month

2020/02



[illegible]


FIG T027

Branson 2100

27. PROPELLER SHAFT

Year/Month

2020/02



[illegible]

FIG T030

Branson 2100

30. FRONT SHAFT

Year/Month

2020/02





FIG T032-1

Branson 2100

32. PTO SHAFT

Year/Month

2020/02



[illegible]


FIG T032-2

Branson 2100

32. PTO SHAFT

Year/Month

2020/02



[illegible]


FIG T034

Branson 2100

34. MID PTO

Year/Month

2020/02



[illegible]

FIG T036

Branson 2100

36. MID PTO COVER

Year/Month

2020/02





FIG T037

Branson 2100

37. REAR DIFFERENTIAL

Year/Month

2020/02



[illegible]


FIG T038

Branson 2100

38. FRONT WHEEL PROPELLER SHAFT

Year/Month

2020/02



[illegible]


FIG T040

Branson 2100

40. 2ND SHAFT

Year/Month

2020/02



[illegible]

[illegible]

FIG T044

Branson 2100

44. 4TH. SHAFT

Year/Month

2020/02





FIG T046

Branson 2100

46. MAIN GEAR SHIFT FORK

Year/Month

2020/02



[illegible]


FIG T047

Branson 2100

47. RANGE GEAR SHIFT FORK

Year/Month

2020/02



[illegible]


FIG T048

Branson 2100

48. PTO GEAR SHIFT FORK

Year/Month

2020/02



[illegible]

FIG T050

Branson 2100

50. DIFFERENTIAL LOCK SHIFT FORK

Year/Month

2020/02




FIG T052

Branson 2100

52. BRAKE

Year/Month

2020/02




FIG T053

Branson 2100

53. BRAKE ROD

Year/Month

2020/02




FIG T054

Branson 2100

54. BRAKE PEDAL

Year/Month

2020/02




FIG T055

Branson 2100

55. BRAKE SWITCH

Year/Month

2020/02





FIG T056

Branson 2100

56. SIDE BRAKE

Year/Month

2020/02



[illegible]


FIG T057

Branson 2100

57. MAIN GEAR SHIFT LEVER

Year/Month

2020/02



[illegible]

[illegible]

FIG T062

Branson 2100

62. FRONT WHEEL DRIVE LEVER

Year/Month

2020/02





FIG T063

Branson 2100

63. PTO GEAR SHIFT LEVER

Year/Month

2020/02



[illegible]

FIG T065

Branson 2100

65. POSITION CONTROL LEVER

Year/Month

2020/02




FIG T066

Branson 2100

66. DIFFERENTIAL LOCK PEDAL

Year/Month

2020/02




FIG T068-1

Branson 2100

68. FRONT AXLE FRAME

Year/Month

2020/02




FIG T068-2

Branson 2100

68. FRONT AXLE FRAME

Year/Month

2020/02




FIG T069

Branson 2100

69. FRONT AXLE CASE

Year/Month

2020/02





FIG T070-1

Branson 2100

70. FRONT DIFFERENTIAL

Year/Month

2020/02



[illegible]

FIG T070-2	FRONT DIFFERENTIAL	Year/Month
Branson 2100		2020/02

This technical drawing is an exploded view of a front differential assembly. The central component is a large housing labeled P69-01. To its left, a shaft assembly is shown in an exploded state, including a shaft (23), a pinion (24), and various gears and bearings (19, 20, 21, 22, 25, 26). To the right of the housing, a series of components are shown in an exploded state, including a pinion (27), a series of gears (01, 02, 03, 04, 05, 06, 07, 08, 09, 10, 11, 12, 13, 14, 15), and a pinion (16). The diagram uses dashed lines to indicate the assembly path and alignment of the components.

[illegible]

FIG T071

Branson 2100

71. DIFFERENTIAL GEAR SHAFT

Year/Month

2020/02





FIG T072-1

Branson 2100

72. BEVEL GEAR CASE

Year/Month

2020/02



[illegible]

FIG T072-2

Branson 2100

BEVEL GEAR CASE(2017.05)

Year/Month

2020/02




FIG T073

Branson 2100

73. FRONT AXLE CASE

Year/Month

2020/02





FIG T074

Branson 2100

74. FRONT SPINDLE

Year/Month

2020/02





FIG T075

Branson 2100

75. FORNT DRIVE SHAFT

Year/Month

2020/02



[illegible]

FIG T077

Branson 2100

77. PST CYLINDER COVER

Year/Month

2020/02




FIG T078

Branson 2100

78. TIE ROD

Year/Month

2020/02




FIG T079

Branson 2100

79. STEERING WHEEL

Year/Month

2020/02




FIG T080

Branson 2100

80. STEERING POST

Year/Month

2020/02




FIG T081

Branson 2100

81. PST UNIT

Year/Month

2020/02




FIG T082

Branson 2100

82. HYDRAULIC PUMP

Year/Month

2020/02





FIG T083

Branson 2100

83. HYDRAULIC OIL LINE (SUCTION)

Year/Month

2020/02



[illegible]

FIG T084A

Branson 2100

84. HYDRAULIC OIL LINE (DELIVERY)

Year/Month

2020/02




FIG T085A

Branson 2100

85. HYDRAULIC STEERING LINE

Year/Month

2020/02





FIG T086-2H

Branson 2100

86. HYDRAULIC OIL LINE - HST

Year/Month

2020/02



[illegible]

FIG T088

Branson 2100

88. HYDRAULIC OIL LINE (F/M)

Year/Month

2020/02





FIG T090

Branson 2100

90. HYDRAULIC CYLINDER

Year/Month

2020/02



[illegible]


FIG T091

Branson 2100

91. HYDRAULIC CYLINDER (POSITION TYPE)

Year/Month

2020/02



[illegible]


FIG T092

Branson 2100

92. HYDRAULIC PISTON / LIFT ARM

Year/Month

2020/02



[illegible]


FIG T093

Branson 2100

93. FEED BACK LEVER

Year/Month

2020/02



[illegible]


FIG T094

Branson 2100

94. FEED BACK LEVER (POSITION TYPE)

Year/Month

2020/02



[illegible]


FIG T095

Branson 2100

95. CONTROL VALVE

Year/Month

2020/02



[illegible]

FIG T096

Branson 2100

96. 3PT LIFT VALVE (POSITION TYPE)

Year/Month

2020/02




FIG T097

Branson 2100

97. LIFT LINK

Year/Month

2020/02




FIG T098

Branson 2100

98. LIFT ARM

Year/Month

2020/02




FIG T099

Branson 2100

99. TOP LINK

Year/Month

2020/02




FIG T100

Branson 2100

100. CHECK CHAIN

Year/Month

2020/02




FIG T101

Branson 2100

101. DRAW BAR

Year/Month

2020/02




FIG T102

Branson 2100

102. PTO SHEILD

Year/Month

2020/02





FIG T103-1

Branson 2100

103. HOOD

Year/Month

2020/02



[illegible]


FIG T103-2

Branson 2100

103. HOOD

Year/Month

2020/02



[illegible]


FIG T104

Branson 2100

104. PANEL COVER

Year/Month

2020/02



[illegible]

FIG T105

Branson 2100

105. SHUTTER PLATE

Year/Month

2020/02




FIG T106

Branson 2100

106. LEVER GUIDE

Year/Month

2020/02




FIG T108

Branson 2100

108. FENDER

Year/Month

2020/02




FIG T109

Branson 2100

109. FENDER STAY

Year/Month

2020/02




FIG T110

Branson 2100

110. FLOOR SEAT

Year/Month

2020/02




FIG T111

Branson 2100

111. SEAT

Year/Month

2020/02





FIG T112

Branson 2100

112. SEAT - EU

Year/Month

2020/02



[illegible]

FIG T114

Branson 2100

114. STEP

Year/Month

2020/02




FIG T115

Branson 2100

115. ROPS

Year/Month

2020/02




FIG T116

Branson 2100

116. MID ROPS - PO

Year/Month

2020/02




FIG T117

Branson 2100

117. SMV BRACKET

Year/Month

2020/02




FIG T118

Branson 2100

118. NAME PLATE LAMP ASSY - EU

Year/Month

2020/02




FIG T119

Branson 2100

119. 작업등 조합

Year/Month

2020/02




FIG T120A

120. FRONT WHEEL

Year/Month

2020/02

Branson 2100




FIG T121A

Branson 2100

121. REAR WHEEL

Year/Month

2020/02




FIG T122.1-1A

Branson 2100

122. DECAL

Year/Month

2020/02





FIG T122.1-2A

Branson 2100

122. DECAL

Year/Month

2020/02



[illegible]


FIG T122.2-1A

Branson 2100

122. DECAL

Year/Month

2020/02



[illegible]

FIG T122.2-2A

Branson 2100

122. DECAL

Year/Month

2020/02




FIG T124

Branson 2100

124. BALLAST WEIGHT

Year/Month

2020/02




FIG T125

Branson 2100

125. MIRROR

Year/Month

2020/02





FIG T126

Branson 2100

126. SINGLE REMOTE

Year/Month

2020/02



[illegible]


FIG T127

Branson 2100

127. LEVER LOADER

Year/Month

2020/02



[illegible]

128. CANOPY - OPTION

Year/Month

2020/02

