

KUKJE 5220R Branson Tractor

Parts Catalogue

CONTENTS

GROUP NO	GROUP NAME	PAGE
000	5220R	5
E001	CYLINDER BLOCK	7
E002	GEAR CASE	9
E003	MOUNTING FLANGE & OIL PAN	11
E004	CYLINDER HEAD & HEAD COVER	13
E005	INTAKE MANIFOLD	16
E006	EXHAUST MANIFOLD & SILENCER	18
E007	CAM SHAFT & DRIVING GEAR	20
E008	CRANK SHAFT & PISTON	22
E010	BALANCER	24
E011	LUB. OIL SYSTEM	26
E012	COOLING SYSTEM	28
E013	FUEL INJECTION PUMP	30
E015	FUEL INJECTION SYSTEM & VALVE	32
E017	STARTING MOTOR	34
E018	GENERATOR & ELECTRIC DEVICE	36
S001	LEVER ACCELERATOR	38
S002	STEERING COLUMN	40
S003	SHUTTLE ASSY	42
S004	FRONT AXLE BRACKET	44
S009	CENTER PIN SUPPORTER	46
S010	TIE ROD	48
S012	RING GEAR, DIFFERENTIAL GEAR	50
S019	GEAR CASE, FRONT AXLE	52
S020	SPACER	55
S023	COVER SHAFT	57
S032	POWER STEERING CYLINDER	59
S034	POWER STEERING HYD LINE	61
S036	CLUTCH HOUSING (2)	63
S038	CLUTCH ASSY	65
S040	CLUTCH RELEASE	67
S041	TRANSMISSION CASE SHIFT	69
S042	MAIN REVERSER GEAR	72
S043	FRONT DRIVE & RANGE SHIFT	75
S044	FRONT DRIVE & RANGE SHIFT LEVER	77

GROUP NO	GROUP NAME	PAGE
S045	PTO SPEED SHIFT	80
S046	REAR AXLE CASE, PTO SHIFT	83
S047	LEVER ASS'Y, PTO SPEED CHANGE	85
S048	HOUSING, REAR AXLE	87
S049	DRIVING PART, REAR AXLE	89
S050	BRAKE	92
S053	BRAKE, CLUTCH PEDAL	94
S067	LEVER, MAIN SHIFT	97
S099-1	HYD PUMP	99
S099-2	HYD PUMP	101
S101	CASE, HYD CYLINDER	103
S102	IND PTO VALVE SUPPORT	105
S103	S.C.V. SUPPORT	107
S104	PISTON ASS'Y	109
S106	CONTROL VALVE	111
S108	RELIEF VALVE	113
S109	STOP VALVE	115
S110	SAFETY VALVE	117
S111	HYD CONTROL	119
S115.	HYD PIPING (2)	121
S118	HYD FILTER	123
S119	ELE'C WIRING	125
S124	BATTERY	127
S125	SWITCHES	129
S131	HORN	131
S132	LAMP	133
S134	METER ASS'Y	135
S135	HOOD	137
S136.	HOOD SUPPORT	139
S137	DASH BOARD	141
S138	FENDER	143
S139	FOOT REST ASSY	145
S140	SEAT	147
S141	FUEL TANK	149
S144.	NAME PLATE	151

[illegible]

FIG 000 5220R	5220R	Year/Month 2020/01
----------------------	-------	---------------------------



B CHASSIS



A ENGINE

FIG E001

CYLINDER BLOCK

Year/Month

5220R

2020/01




FIG E002

5220R

GEAR CASE

Year/Month

2020/01





FIG E003

5220R

MOUNTING FLANGE & OIL PAN

Year/Month

2020/01



[illegible]

FIG E004

5220R

CYLINDER HEAD & HEAD COVER

Year/Month

2020/01




FIG E004		CYLINDER HEAD & HEAD COVER			Year/Month
5220R					2020/01
KeyNo.	Part Number	Part Name	Quantity	Other	
1	EA00000636A	HEAD, CYLINDER (A2300T)	1		
2	EA00000624A	HEAD, CYLINDER	1		
3	HRA0400102B4	GUIDE, VALVESTEM	4		
4	HRA0400103B4	GUIDE, VALVESTEM	4		
5	HRA0400104B4	SEAT, ENGINE INTAKE VALVE	4		
6	HRA0400105B4	SEAT, ENGINE EXHAUST VALVE	4		
7	27241-400000	PLUG (D40)	2		
8	27241-220000	PLUG, EXPANSION	4		
9	27241-220000	PLUG, EXPANSION	4		
10	HRA0400200A4	VALVE, INTAKE	4		
11	HRA0400300A4	VALVE, EXHAUST	4		
12	22312-040100	PIN, DOWEL (4-10)	2		
13	HA03070000A4	SEAL, VALVESTEM	8		
15	HRA0400700A4	SPRING, VALVE	8		
16	HRA0400800A4	RETAINER, VALVESPRING	8		
17	HRA0400900A4	COTTER, VALVE	16		
18	HK03680000B4	CAP, VALVE	8		
19	HRA0401100B2	LEVER, ROCKER	1		
20	HRA0401200A4	SUPPORT, ROCKERLEVER	1		
21	HRA0401300A4	SUPPORT, ROCKERLEVER	3		
22	HRA0401400A4	SPRING, COMPRESSION	3		
23	HRA0401500A2	SHAFT, ROCKERLEVER	1		
24	HRA0401600A4	LEVER, ROCKER	8		
25	AF02110000E4	SCREW, RKRLEVERADJUSTING	8		
26	HH05280000A4	NUT, VALVEADJUSTING	8		
27	26921-080102	SCREW, SLOTTEDSET	1		
28	22242-000190	SNAP RING, SHAFT (Φ 19)	2		
29	HRA0401800A4	STUD	4		
30	22117-120000	WASHER, PLAIN (Φ 12)	4		
31	HRA0402300B0	COVER, VALVE	1		
32	HRA0402400B3	GASKET, VALVECOVER	1		
33	HA03520000B4	NUT, HEXAGONCAP	4		
34	24311-000140	O-RING, DYNAMIC (Φ14)	4		
35	26587-040102	SCREW, FILLISTERHEADCAP	4		
36	HRA0403600A4	COVER, BREATHER	1		
37	HRA0403700A4	Valve, Pressure Relief	1		
38	HRA0403800A4	GASKET, BREATHER	1		
39	HRA0403900A4	PLATE, BREATHERADJUSTING	1		
40	HRA0404000A4	TUBE, BREATHER	1		
41	HLT0501000A4	HOSE, PLAIN	1		
42	23080-021000	CLAMP, VBAND	1		
43	HC03470000B4	CAP, FILTER	1		
44	24311-000320	O-RING, DYNAMIC (Φ32)	1		
45	HK03530000A4	BRACKET, LIFTING	1		
46	26106-080162	SCREW, HEXFLANGEHEADCAP	2		


FIG E005

5220R

INTAKE MANIFOLD

Year/Month

2020/01



[illegible]


FIG E006

5220R

EXHAUST MANIFOLD & SILENCER

Year/Month

2020/01



[illegible]


FIG E007

5220R

CAM SHAFT & DRIVING GEAR

Year/Month

2020/01



[illegible]


FIG E008

5220R

CRANK SHAFT & PISTON

Year/Month

2020/01



[illegible]

FIG E010

5220R

BALANCER

Year/Month

2020/01




FIG E011

5220R

LUB. OIL SYSTEM

Year/Month

2020/01






FIG E011		LUB. OIL SYSTEM			Year/Month
5220R					2020/01
KeyNo.	Part Number	Part Name	Quantity	Other	
1	HRA1100109A9	PUMP, LUBRICATING OIL	1		
13	HRA1100112A3	GEAR,LUBRICATINGOILPUMP	1		
14	HRA1100600A4	GASKET,LUBOILPUMP	1		
15	26450-060252	SCREW,SOCKETHEADCAP	4		
16	HRC1101600B2	COOLER,OIL	1		
17	HRC1101700A4	SCREW,HEXAGONHEADCAP	1		
18	24311-000210	O-RING, DYNAMIC (Φ21)	1		
19	24311-000200	O-RING, DYNAMIC (Φ20)	1		
20	24321-000070	ORING497-7	1		
21	HRA1100700A4	GASKET,OILPAN	1		
22	HRA1100800A2	PIPEASSY,OILINTAKE	1		
23	26106-080352	SCREW,HEXFLANGEHEADCAP	2		
24	HRC1100900B1	HEAD,LUBOILFILTER	1		
25	HRC1100901B1	HEAD,LUBOILFILTER	1		
26	24311-000210	O-RING, DYNAMIC (Φ21)	1		
27	HH10090000A4	SHIM	5		
28	HH10140000B4	SPRING,COMPRESSION	1		
29	HH10080000B4	VALVE,PRESSUREREGULATOR	1		
30	HH10130000B4	RETAINER,SPRING	1		
31	23871-020000	Plug, Pipe	1		
32	HH11030000B4	RETAINER,PRXLMGVALVE	1		
33	HRC1101000B4	GASKET,FILTERHEAD	1		
34	HRA1102000A3	FILTER, ENGINE OIL	1		
35	26106-080652	SCREW,HEXFLANGEHEADCAP	3		
36	HRC1102000A4	CHECK VALVE ASS'Y	4		
37	HRC1101900A3	NOZZLE,PISTON COOLING	4		
38	22351-030010	PIN, SPRING (3-01)	4		
39	23414-080000	WASHER, PLAIN (Φ8)	4		
40	22312-060080	PIN, DOWEL (6-08)	2		
41	EA00002292A	TUBE, OIL GAUGE	1		
42	EA00002293A	OIL GAUGE	1		
43	HA09220000A4	SCREW,BANJOCONNECTOR	2		
44	HA09250000A3	SWITCH,OILPRESSURE	1		
45	HRU043010DA3	TUBE, TURBO OIL SUPPLY	1		
46	23414-100000	PLAIN WASHER (D10)	4		
47	HRF1105000A4	ELBOW,PLAIN UNION	1		
48	HRU043080DB3	TUBE,TURBO OIL DRAIN	1		
49	HRU0430900C3	HOSE, PLAIN	1		
50	23080-020000	CLAMP, V BAND	2		
51	HP09350000A4	GASKET,OILDRAIN	1		
52	26106-060182	Bolt, Hexa (6-18)	2		
53	26106-080162	SCREW,HEXFLANGEHEADCAP	1		
54	26106-080122	Bolt, Hexa (8-12)	1		

FIG E012 5220R	COOLING SYSTEM	Year/Month
		2020/01



[illegible]


FIG E013

5220R

FUEL INJECTION PUMP

Year/Month

2020/01



[illegible]

FIG E017

5220R

STARTING MOTOR

Year/Month

2020/01





FIG E018

5220R

GENERATOR & ELECTRIC DEVICE

Year/Month

2020/01



[illegible]


FIG S001

5220R

LEVER ACCELERATOR

Year/Month

2020/01



[illegible]


FIG S003

5220R

SHUTTLE ASSY

Year/Month

2020/01



[illegible]

FIG S004

5220R

FRONT AXLE BRACKET

Year/Month

2020/01





FIG S009

5220R

CENTER PIN SUPPORTER

Year/Month

2020/01



[illegible]

FIG S010

5220R

TIE ROD

Year/Month

2020/01





FIG S012

5220R

RING GEAR, DIFFERENTIAL GEAR

Year/Month

2020/01



[illegible]

FIG S019

5220R

GEAR CASE, FRONT AXLE

Year/Month

2020/01




FIG S019		GEAR CASE, FRONT AXLE			Year/Month
5220R					2020/01
KeyNo.	Part Number	Part Name	Quantity	Other	
1	TA00015844A	OIL GAUGE	1		
2	24311-000180	O-RING, DYNAMIC (Φ18)	1		
3	26013-012352	HEX BOLT W/WASHER	14		
4	TB26060000A4	PLUGRUBBER	1		
5	TC60130000A4	SLEEVE,SI	2		
6	TC60150000A3	OILSEAL	2		
7	24101-062094	BALL BEARING (#6209)	2		
8	TC60330000A3	GEAR, 2ND SHAFT	2		
9	24101-062074	BALL BEARING (#6207)	2		
10	22252-000720	RING, CIRCLIP (Φ 72)	2		
11	TC59050000A4	SAPCER	2		
12	TC59030000A4	SIM A	2		
13	TC59040000A4	SIM B	4		
14	TC59120000A4	SHIM C	4		
15	TC59070000A4	PIPE	2		
16	TC59020000A3	FRONT 1ST AXLE PINION	2		
17	24321-001150	O-RING(G115)	2		
18	TA60060000A	SUB TO-> TC60060000A1	1		
19	TA60070000A	SUB TO-> TC60070000A1 CASE R, FRONT GEAR	1		
20	23887-180002	PULG	1		
21	23414-180000	WASHER,SEALING	5		
22	TC60100000A1	GEAR HOUSING (LH), FRONT	1		
23	TC60140000A1	GEAR HOUSING (RH),FRONT	1		
24	22312-100200	PIN, DOWEL (10-20)	4		
25	26116-080122	SCREW,HEXAGONHEADCAP	2		
26	22190-080002	WASHER, PLAIN (Φ 08)	2		
27	24311-000160	O-RING, DYNAMIC (Φ16)	2		
28	TB28120000C4	DRAIN PLUG	2		
29	TC60110000A3	SEAL	2		
30	24101-060104	Bearing, Ball (#6010)	2		
31	TC60370000B3	FRONT SECOND SHAFT	2		
32	TC60360000B3	FRONT FINAL PINION	2		
33	TC60340000A4	BEARING(TM207C3)	2		
34	24321-002200	O-RING	2		
35	TT19070000A4	SHIMA	12		
36	TT19080000A4	SHIMB	12		
37	22252-000900	RING, CIRCLIP (Φ 90)	2		
38	26116-100202	HEX FLANGE BOLT(M10X1.5X20)	4		
39	TC61070000B4	WASHER(D47XT6)	2		
39B	TC61120000A4	BENDING WASHER	2		
40	24101-062104	BALL BEARING #6210 -> FGF4200000A4	2		
41	TC60430000A4	OIL SEAL	2		
42	TC61080000A3	SL SLEEVE	2		
43	TC61060000B2	FRONT FINAL GEAR	2		
44	TC60120000A1	BEARINGCASE,FRONT	2		


FIG S020

5220R

SPACER

Year/Month

2020/01



[illegible]


FIG S023

5220R

COVER SHAFT

Year/Month

2020/01



[illegible]


FIG S032

5220R

POWER STEERING CYLINDER

Year/Month

2020/01



[illegible]


FIG S034

5220R

POWER STEERING HYD LINE

Year/Month

2020/01



[illegible]


FIG S036

5220R

CLUTCH HOUSING (2)

Year/Month

2020/01



[illegible]

FIG S038

5220R

CLUTCH ASSY

Year/Month

2020/01




FIG S040

5220R

CLUTCH RELEASE

Year/Month

2020/01




FIG S041

5220R

TRANSMISSION CASE SHIFT

Year/Month

2020/01




FIG S041		TRANSMISSION CASE SHIFT			Year/Month
5220R					2020/01
KeyNo.	Part Number	Part Name	Quantity	Other	
1	NT41010000C3	UPPERCOVER,T/M	1		
2	26013-080252	Bolt, Hexa (8-25)	19		
3	NT41040000B3	GASKET	1		
4	TN41070000A4	PIN	1		
5	NT41080000A4	LEVER3-4	1		
6	NT41600000A4	LEVER[1ST-2ND],MAINSHIFT	1		
7	24311-000210	O-RING, DYNAMIC (Φ21)	3		
8	TN41100000A4	HOLDERMAINSHIFT	2		
9	24421-173007	Seal, Oil (#17-30-07)	3		
10	22351-080028	PIN, SPRING (8-28)	2		
11	22351-050028	PIN, SPRING (5-02)	2		
12	TT65120000A4	COLLARB	3		
13	NT41130000B4	ARM(3-4), MAIN SHIFT	1		
14	NT41140000A4	ARM(1-2),MAINSHIFT	1		
15	NT41150000A3	FORKSHAFT[3-4],MAINSHIFT	1		
16	NT41160000A3	FORKSHAFT(1-2),MAINAHIFT	1		
17	TN41170000B3	FORK1ST~2ND,MAINSHIFT	1		
18	TN41180000B3	FORK3-4MAINSHAFT	1		
19	22351-060030	PIN, SPRING (6-30)	2		
20	TZ41200000A3	PACKING	1		
21	NT41580000A2	oil seal case	1		
22	22217-080000	WASHER, SPRING (Φ 08)	5		
23	26116-080222	BOLT7T(8X22)	5		
24	TN41250000A4	FIXINGBOLT	1		
25	23414-100000	PLAIN WASHER (D10)	1		
26	NT41270000A4	CAPBOLT	1		
27	23414-160000	WASHER,SEALING	2		
28	TT42020000A4	SPRING	3		
29	24190-100001	Ball, Steel (5/16)	3		
30	24311-000110	O-RING, DYNAMIC (Φ11)	1		
31	23871-010000	PLUG	1		
32	NT41350000A4	SHAFTSHUTTLECHANGE	1		
33	TN41360000A3	SHAFTSH.FORK	1		
34	NT41380000A4	LEVERSHUTTLESHAFT	1		
35	22351-060025	PIN, SPRING (6-25)	2		
36	22351-080028	PIN, SPRING (8-28)	1		
37	TZ41440000A4	PACKING	2		
38	23414-080000	WASHER, PLAIN (Φ8)	1		
39	NT41460000A4	BOLT	1		
40	TN41490000B3	FORK, SHUTTLE SHIFT	1		
41	NT41540000A4	HOLDER,SHUTTLESHIFT	1		
42	NT41550000A4	LINKC,SHUTTLE	1		
43	NT41430000A4	PARALLEL PIN	2		
44	NT36200000B3	SPACER,MISSIONCASE	1		
45	26216-120952	BOLT	1		

FIG S042

5220R

MAIN REVERSER GEAR

Year/Month

2020/01




FIG S042		MAIN REVERSER GEAR			Year/Month
5220R					2020/01
KeyNo.	Part Number	Part Name	Quantity	Other	
1	NT42010000A4	OILSEAL	1		
2	24101-062084	Bearing, Ball (#6208)	3		
3	TN42030000A3	GEARREVERSER26T	1		
4	22242-000450	SNAP RING, SHAFT (Φ 45)	2		
5	22252-000800	RING, CIRCLIP (Φ 80)	2		
6	TN42060000A3	GEAR,FORWARD	1		
7	22242-000350	SNAP RING, SHAFT (Φ 35)	1		
8	TN42090000B4	BUSH	1		
9	TN42100000B4	BUSHA,GUIDE	1		
10	TN42950000A3	4SHIFT_GEAR(32T)	1		
11	TN42960000A3	3RDGEAR37T	1		
12	TN42180000B4	HUSHB,GUIDE	1		
13	TN42970000A3	GEAR 41T	1		
14	TN42980000A3	GEAR 1ST.43T	1		
15	TN42210000B4	BUSHC	1		
16	22292-000350	RING, CIRCLIP (Φ 35)	1		
17	24101-063074	Bearing, Ball (#6307)	1		
18	TN42240000C2	GUIDE SHAFT,MAINSHIFT GEAR	1		
19	24311-000200	O-RING, DYNAMIC (Φ20)	1		
20	TN42260000B3	IDLE SHAFT, REVERSE	1		
21	24101-060044	Bearing, Ball (#6004)	2		
22	22252-000420	RING, CIRCLIP (Φ 42)	1		
23	TN42300000A3	REVERSERGEARIDLE	1		
24	TN42310000B4	COLLAR	1		
25	22351-060030	PIN, SPRING (6-30)	1		
26	NT42350000A2	COUNTERSHAFTA'SSY	1		
27	24101-063064	Bearing, Ball (#6306)	2		
28	22252-000720	RING, CIRCLIP (Φ 72)	1		
29	22242-000300	SNAP RING, SHAFT (Φ 30)	1		
30	TN42480000A4	BUSH D, GUIDE	2		
31	24161-404527	NEEDLEBEARING	2		
32	TN42500000E3	REVERSE GEAR 30T	1		
33	TN42510000E3	GEAR, FORWARD 32T	1		
34	TT18050000A4	SHIMA	1		
35	TT18060000A4	SHIMB	1		
36	TN42690031A2	SYNCHRO.RING(OUTER)	6		
37	TN42650000A9	PIECE	9		
38	TN42660000A9	SPRING	6		
39	TN42670000A3	HUB	3		
40	TN42680000A9	SLEEVE	1		
41	TN42690000A9	SYNCHRO.RINGASS'Y	2		
43	NT42830000A3	main shaft(outer)	1		
44	24550-020120	DRYBUSH	1		
45	24413-203007	Seal, Oil (#20-30-07)	1		
46	NT42730000A3	MAIN SHAFT, INNER	1		


FIG S043

FRONT DRIVE & RANGE SHIFT

Year/Month

5220R

2020/01



[illegible]

FIG S044

5220R

FRONT DRIVE & RANGE SHIFT LEVER

Year/Month

2020/01




FIG S044		FRONT DRIVE & RANGE SHIFT LEVER			Year/Month
5220R					2020/01
KeyNo.	Part Number	Part Name	Quantity	Other	
1	TA00002757A	STAY ASS'Y,SEATRAIL	1		
2	TA00058723A	KNOB	1		
2-1	TA00016324B	KNOB, RANGE SHIFT	1	deleted/삭제	
3	TA00001060C	LEVER, SUB SHIFT	1		
4	22417-250250	PIN , COTTER (2-25)	6		
5	22137-100000	WASHER, PLAIN (Φ 10)	6		
6	22272-000150	RING, CIRCLIP (Φ 15)	2		
7	TN44080000B3		1		
8	TT70080000A4	BUSH	2		
9	NT44100000B3	Lever, Front Drive	1		
10	TT70090000A4	BUSH	1		
11	TN44590000A4	GREASENIPPLE	1		
12	NT44140000A4	ROD,FRONTDRIVE	1		
13	24190-100001	Ball, Steel (5/16)	3		
14	TT42020000A4	SPRING	3		
15	TN44220000A3	FORKFRONTDRIVE	1		
16	TN44230000A3	SHAFTFRONTDRIVEFORK	1		
17	23414-080000	WASHER, PLAIN (Φ8)	2		
18	23414-100000	PLAIN WASHER (D10)	2		
19	TN44280000A4	PLUG	2		
20	24321-000250	O-RING	3		
21	24421-173007	Seal, Oil (#17-30-07)	3		
22	26013-080252	Bolt, Hexa (8-25)	3		
23	TT65120000A4	COLLARB	5		
24	22351-080028	PIN, SPRING (8-28)	2		
25	NT44360000A4	LEVER,A'SSYB.FRONTDRIVE	1		
26	TN44370000A4	HOLDERSHIFTARM	2		
27	TN44380000A4	LEVERASS'YF.DRIVE	1		
28	TN44400000A4	BOLT	2		
29	TN44410000B3	SHAFT,RANGESHIFTFORK	1		
30	TN44420000A3	FORKRANGESHIFT	1		
31	TN44440000D4	LEVERASS'Y(B),RANGESHAFT	1		
32	TA00056015A	LEVER, FRONT DRIVE	1		
32-1	TA00015827A	KNOB, FRONT DRIVE LEVER	1	deleted/삭제	
33	TN46180000A4	O-RING	1		
34	22351-080030	PIN, SPRING (8-30)	2		
35	TN44520000B3	SHAFT,RANGESHIFTLEVER	1		
36	22351-050030	PIN, SPRING (5-03)	2		
37	TN44260000B4	LEVER ASS'Y CREEPER	1		
38	26023-040162	SCREW	3		
41	NT44350000B4		1		
42	NT44070000B3		1		
43	TN44300000A4	Holder, Shift Arm	1		
44	TN44180000A3	FORK SHAFT,CREEPER LEVER	1		
45	TN44170000A4	FORK	1		

[illegible]

FIG S045

5220R

PTO SPEED SHIFT

Year/Month

2020/01




FIG S045		PTO SPEED SHIFT			Year/Month
5220R					2020/01
KeyNo.	Part Number	Part Name	Quantity	Other	
7	24101-063074	Bearing, Ball (#6307)	2		
8	NT45430000A4	NEEDLEBUSH.D	1		
9	NT45930000A3	PTO GEAR 46T	1		
10	TZ45100000A3	HUB,P.T.O	1		
11	TZ45110000B4	SLEEVE,P.T.O	1		
12	TZ45120000A3	GEARLST,P.T.O	1		
13	NT45130000B3	shaft, PTO	1		
14	TZ45140000A4	COLLAR	1		
15	TZ45150000A4	BUSHB,NEEDLE	1		
16	TN45120000A4	WASHER	1		
17	24161-455328	NEEDLE BEARING (#45-53-28)	1		
18	24161-455320	NEEDLEBEARING	0		
20	TT62040000A3	PTO OIL SEAL QLF35X60X19	1		
22	TZ45220000C	SHAFT,P.T.O DRIVE	1		
23	22242-000350	SNAP RING, SHAFT (Φ 35)	0		
24	22252-000720	RING, CIRCLIP (Φ 72)	0		
25	24101-062074	BALL BEARING (#6207)	1		
28	TN45520000A4	COLLAR	1		
29	22242-000300	SNAP RING, SHAFT (Φ 30)	1		
30	26013-080202	Bolt, Hexa (8-20)	2		
31	26013-060162	Bolt, Hexa (6-16)	3		
33	26013-080302	HEX BOLT W/WASHER	2		
34	TT80030000A3	P.T.OCOVER	1		
45	NT45440000A4	COLLAR	1		
48	NT45480000A3	PTO COUPLING	1		
50	22312-100200	PIN, DOWEL (10-20)	2		
51	NT45510000A1	HOUSING, PTO SHAFT	1		
52	NT45520000B3	PTO CLUTCH PACK	1		
53	26013-100252	SCREW,CAPTIVEWASHERCAP	3		
54	26013-100352	Bolt, Hexa (10-35)	4		
62	NT45620000A3	Seal Case	1		
63	23871-010000	PLUG	1		
64	NT45640000A4	Bearing Cover	1		
65	26013-060162	Bolt, Hexa (6-16)	3		
66	24161-182417	Bearing, Neddle (#18-24-17)	1		
67	NT45670000A4	Thrust Washer	1		
68	NT45680000A4	Spacer	1		
69	NT45690000A4	SIGHT GLASS	1		
72	NT45720000A4	Plate	1		
73	26106-060162	HEXFLANGEBOLT	2		
74	NT45740000A3	PACKING, PTO SHAFT HOUSING	1		
75	24101-063064	Bearing, Ball (#6306)	1		
77	TN45200000A4	JOINT	1		
79	24161-253020	Bearing, Neddle (#25-30-20)	1		
80	TN45180000A4	BUSH,BEARING	1		

[illegible]

FIG S046

5220R

REAR AXLE CASE, PTO SHIFT

Year/Month

2020/01





FIG S047

5220R

LEVER ASS'Y, PTO SPEED CHANGE

Year/Month

2020/01



[illegible]


FIG S048

5220R

HOUSING, REAR AXLE

Year/Month

2020/01



[illegible]

FIG S049

5220R

DRIVING PART, REAR AXLE

Year/Month

2020/01




FIG S049		DRIVING PART, REAR AXLE			Year/Month
5220R					2020/01
KeyNo.	Part Number	Part Name	Quantity	Other	
1	TN49510000A2	COUNTERSAHFT	1		
2	TN49520000C2	RINGGEAR	1		
3	TN49030000D2	CASE,DIFFERENTIAL -> TA00022799A	1		
5	TT78020000A3	BEARINGNJ307R	1		
6	22312-060360	PIN, DOWEL (6-36)	1		
7	22351-060032	PIN, SPRING (6-32)	1		
8	TF64080000A4	PINIONSHAFT	1		
9	TF64090000A4	BOLT	6		
10	TF64100000A3	PINION	2		
11	TF64110000A4	PINIONLINER	2		
12	TF64120000A3	DIFF.SIDEGEAR(A)	1		
13	TF64130000A3	DIFF.SIDEGEAR(B)	1		
14	TF64140000B4	SIDEGEARLINER	2		
15	TB32150000A4	RETAINER	2		
16	TN49160000A3	PINIONL,FINAL	1		
17	TN4917000SA3	PINIONR,FINAL	1		
18	24101-062114	Bearing, Ball (#6211)	1		
19	TF64190000A4	BALL BEARING (#6308HL1) -> TF64190000A3	2		
20	22242-000500	SNAP RING, SHAFT (Φ50)	1		
21	26013-080202	Bolt, Hexa (8-20)	4		
25	TF64250000B3	THRUST, DIFF-LOCK ASSY	1		
26	26776-220002	NUT	2		
27	24101-060102	BALL BEARING (#6010)	1		
28	22217-220000	WASHER, SPRING (Φ 22)	2		
29	TN49550000B2	CARRIOR	1		
30	TN49590000A4	RETAINER	1		
31	TZ49560000A4	SHIMA	3		
32	TZ49570000A4	SHIMB	3		
33	TZ49580000A4	SHIMC	2		
34	22351-080032	PIN, SPRING (8-32)	2		
35	24311-000160	O-RING, DYNAMIC (Φ16)	1		
36	TB32360000A4	RETAINER	2		
37	TN49370000A4	WASHER	2		
38	TN49380000A4	WASHER	1		
39	26013-080202	Bolt, Hexa (8-20)	10 10		
40	TN49400000A2	FORK DIFFERENTIAL LOCK	1		
41	TN49410000B3		1		
43	TN49430000A4	SPRING	1		
44	22351-080040	PIN, SPRING (8-40)	1		
45	22351-050040	PIN, SPRING (5-04)	1		
46	TA00001510B	PEDAL, DIFF.LOCK	1		
50	22121-140000	WASHER, PLAIN (Φ 14)	1		
51	24421-152507	Seal, Oil (#15-25-07)	1		
52	22252-000800	RING, CIRCLIP (Φ 80)	1		
54	TTB1300000A4	SPRING,RETURN	1		

[illegible]

FIG S050

5220R

BRAKE

Year/Month

2020/01




FIG S053

5220R

BRAKE, CLUTCH PEDAL

Year/Month

2020/01




FIG S053		BRAKE, CLUTCH PEDAL			Year/Month
5220R					2020/01
KeyNo.	Part Number	Part Name	Quantity	Other	
1	TA00017501A	COVER	1		
2	26106-060122	HEX BOLT (6-12)	2		
3	26716-080002	NUT,HEX (D8)	1		
4	26116-080252	BOLT7T(8X25)	1		
5	TCB6100000A4	BOOTS, PEDAL	3		
6	22487-100200	PIN, HEAD (10-20)	4		
7	TW43030000A4	SUTTLE CLEVIS A	4		
8	RR51230000A4	SNAP PIN	5		
9	TA00002285A	BRAKE CABLE	2		
10	TT83010000A4	TURN BUCKLE, 10X70	2		
11	22137-100000	WASHER, PLAIN (Φ 10)	6		
12	RR64050000A4	Pin, Come-Off Snap (Φ8)	2		
13	TA00017497A	CLUTCH ROD UPPER	1		
14	TA00017498B	CLUTCH ROD LOWER	1		
15	26716-120002	BOLT,CYLINDER HEAD(B)	3		
16	TT67010000A4	TURN BUCKLE	3		
17	TT67040000A4	NUT.LH	3		
18	22272-000190	RING, CIRCLIP (Φ 19)	2		
19	TC73010200A4	BUSH25*28*20	6		
20	TC73090000A4	RETURN SPRING	3		
21	TA00002795B	CLUTCH PEDAL ASS'Y	1		
22	TCB6300000A3	PIPE	2		
23	TC73050000A3	PEDALHEADCOVER	3		
24	TC73030000A4	RIVET(PEDALHEAD)	3		
25	TC73040000A4	WASHER(REVET)	3		
26	TA00002785B	BRAKE PEDAL L ASS'Y	1		
27	TA00002784C	BRAKE PEDAL R ASS'Y	1		
28	TA00017369A	SHAFT, BRAKE	1		
29	22272-000240	RING, CIRCLIP (Φ 24)	2		
30	TB35120000B4	WASHER B	2		
31	TB35110000B4	WASHER A	1		
32	TA00017352B	BRAKE LINE(L)REAR	1		
33	TA00017353B	BRAKE LINE(R)REAR	1		
34	22351-080050	PIN, SPRING (8-50)	1		
35	22351-050050	PIN, SPRING (5-05)	1		
36	TB26240000A4	BUSH	2		
37	22487-100260	PIN, HEAD (10-26)	1		
38	TA00017354A	CABLE, PARKING BRAKE -> TA00017354C	1		
39	TT41090000A4	PIN10X23	4		
40	22417-200300	PIN , COTTER (2-30)	4		
41	TA00001403A	PARKING BRAKE	1		
42	26106-080202	SQR FLANGE BOLT	2		
43	22417-250300	PIN , COTTER (2-30)	1		
44	22137-080000	WASHER, PLAIN (Φ 08)	1		
45	TA00018293A	ROCK(CLUTCH PEDAL)	1		

FIG S067

5220R

LEVER, MAIN SHIFT

Year/Month

2020/01





FIG S099-1

5220R

HYD PUMP

Year/Month

2020/01



[illegible]


FIG S101

5220R

CASE, HYD CYLINDER

Year/Month

2020/01



[illegible]


FIG S102

5220R

IND PTO VALVE SUPPORT

Year/Month

2020/01



[illegible]


FIG S103

5220R

S.C.V. SUPPORT

Year/Month

2020/01



[illegible]

FIG S106

5220R

CONTROL VALVE

Year/Month

2020/01

-





FIG S108

5220R

RELIEF VALVE

Year/Month

2020/01





FIG S109

5220R

STOP VALVE

Year/Month

2020/01



[illegible]

FIG S110

5220R

SAFETY VALVE

Year/Month

2020/01





FIG S111

5220R

HYD CONTROL

Year/Month

2020/01



[illegible]


FIG S115.

5220R

HYD PIPING (2)

Year/Month

2020/01



[illegible]

FIG S118

5220R

HYD FILTER

Year/Month

2020/01





FIG S119

5220R

ELE'C WIRING

Year/Month

2020/01



[illegible]

FIG S124

5220R

BATTERY

Year/Month

2020/01





FIG S125

5220R

SWITCHES

Year/Month

2020/01



[illegible]

FIG S131

5220R

HORN

Year/Month

2020/01




FIG S132

5220R

LAMP

Year/Month

2020/01




FIG S134

5220R

METER ASS'Y

Year/Month

2020/01





FIG S135

5220R

HOOD

Year/Month

2020/01



[illegible]


FIG S136.

5220R

HOOD SUPPORT

Year/Month

2020/01



[illegible]

FIG S137

5220R

DASH BOARD

Year/Month

2020/01





FIG S138

5220R

FENDER

Year/Month

2020/01



[illegible]


FIG S139

5220R

FOOT REST ASSY

Year/Month

2020/01



[illegible]


FIG S140

5220R

SEAT

Year/Month

2020/01



[illegible]


FIG S141

5220R

FUEL TANK

Year/Month

2020/01



[illegible]


FIG S144.

5220R

NAME PLATE

Year/Month

2020/01



[illegible]


FIG S146

5220R

TOP LINK LIFT LINK

Year/Month

2020/01



[illegible]


FIG S150

5220R

LOWER LINK

Year/Month

2020/01



[illegible]

FIG S152

5220R

DRAWBAR HITCH

Year/Month

2020/01





FIG S158

5220R

SAFETY FRAME ASSY

Year/Month

2020/01



[illegible]

FIG S160

5220R

FRONT WEIGHT

Year/Month

2020/01





FIG S161.

5220R

ENGINE SUB

Year/Month

2020/01



[illegible]


FIG S190

5220R

MID REMOTE VALVE JOYSTICK

Year/Month

2020/01



[illegible]

FIG S191

5220R

FILTERS

Year/Month

2020/01

